

FANUC Robot M-710*i*C/20L/12L/20M

**MECHANICAL UNIT
OPERATOR'S MANUAL**

B-82514EN/10

- **Original Instructions**

Thank you very much for purchasing FANUC Robot.

Before using the Robot, be sure to read the "FANUC Robot series SAFETY HANDBOOK (B-80687EN)" and understand the content.

This manual can be used with controllers labeled R-30*i*A or R-J3*i*C. If you have a controller labeled R-J3*i*C, you should read R-30*i*A as R-J3*i*C throughout this manual.

- No part of this manual may be reproduced in any form.
- All specifications and designs are subject to change without notice.

The products in this manual are controlled based on Japan's "Foreign Exchange and Foreign Trade Law". The export from Japan may be subject to an export license by the government of Japan.

Further, re-export to another country may be subject to the license of the government of the country from where the product is re-exported. Furthermore, the product may also be controlled by re-export regulations of the United States government.

Should you wish to export or re-export these products, please contact FANUC for advice.

In this manual, we endeavor to include all pertinent matters. There are, however, a very large number of operations that must not or cannot be performed, and if the manual contained them all, it would be enormous in volume. It is, therefore, requested to assume that any operations that are not explicitly described as being possible are "not possible".

SAFETY PRECAUTIONS

This chapter describes the precautions which must be followed to enable the safe use of the robot. Before using the robot, be sure to read this chapter thoroughly.

For detailed functions of the robot operation, read the relevant operator's manual to understand fully its specification.

For the safety of the operator and the system, follow all safety precautions when operating a robot and its peripheral equipment installed in a work cell.

For safe use of FANUC robots, you must read and follow the instructions in the “FANUC Robot series SAFETY HANDBOOK (B-80687EN)”.

1 PERSONNEL

Personnel can be classified as follows.

Operator:

- Turns the robot controller power ON/OFF
- Starts the robot program from operator panel

Programmer or Teaching operator:

- Operates the robot
- Teaches the robot inside the safeguarded space

Maintenance technician:

- Operates the robot
 - Teaches the robot inside the safeguarded space
 - Performs maintenance (repair, adjustment, replacement)
-
- The operator is not allowed to work in the safeguarded space.
 - The programmer or teaching operator and maintenance technician are allowed to work in the safeguarded space. Work carried out in the safeguarded space include transportation, installation, teaching, adjustment, and maintenance.
 - To work inside the safeguarded space, the person must be trained on proper robot operation.

Table 1 (a) lists the work outside the safeguarded space. In this table, the symbol “○” means the work allowed to be carried out by the specified personnel.

Table 1 (a) List of work outside the Safeguarded Space



	Operator	Programmer or Teaching operator	Maintenance technician
Turn power ON/OFF to Robot controller	○	○	○
Select operating mode (AUTO/T1/T2)		○	○
Select remote/local mode		○	○
Select robot program with teach pendant		○	○
Select robot program with external device		○	○
Start robot program with operator's panel	○	○	○
Start robot program with teach pendant		○	○
Reset alarm with operator's panel		○	○
Reset alarm with teach pendant		○	○
Set data on teach pendant		○	○
Teaching with teach pendant		○	○
Emergency stop with operator's panel	○	○	○
Emergency stop with teach pendant	○	○	○
Operator's panel maintenance			○
Teach pendant maintenance			○

During robot operation, programming and maintenance, the operator, programmer, teaching operator and maintenance technician take care of their safety using at least the following safety protectors:

- Use clothes, uniform, overall adequate for the work
- Safety shoes
- Helmet

2 DEFINITION OF SAFETY NOTATIONS

To ensure the safety of users and prevent damage to the machine, this manual indicates each precaution on safety with "**WARNING**" or "**CAUTION**" according to its severity. Supplementary information is indicated by "**NOTE**". Read the contents of each "**WARNING**", "**CAUTION**" and "**NOTE**" before using the robot.

Symbol	Definitions
 WARNING	Used if hazard resulting in the death or serious injury of the user will be expected to occur if he or she fails to follow the approved procedure.
 CAUTION	Used if a hazard resulting in the minor or moderate injury of the user, or equipment damage may be expected to occur if he or she fails to follow the approved procedure.
NOTE	Used if a supplementary explanation not related to any of WARNING and CAUTION is to be indicated.

3

PROCEDURE TO MOVE ARM WITHOUT DRIVE POWER IN EMERGENCY OR ABNORMAL SITUATIONS

- (1) For emergency or abnormal situations (e.g. persons trapped in or pinched by the robot), brake release unit can be used to move the robot axes without drive power. Please order following unit and cable.

Name	Specification
Brake release unit	A05B-2450-J350 (Input Voltage AC100-115V single-phase)
	A05B-2450-J351 (Input Voltage AC200-240V single-phase)
Robot connection cable	A05B-2450-J360 (5m)
	A05B-2450-J361(10m)
Power cable	A05B-2525-J010 (5m) (AC100-115V Power plug) (*)
	A05B-2525-J011(10m) (AC100-115V Power plug) (*)
	A05B-2450-J364 (5m) (AC100-115V or AC200-240V No power plug)
	A05B-2450-J365(10m) (AC100-115V or AC200-240V No power plug)

(*) These do not support CE marking.

- (2) Please make sure that adequate numbers of brake release units are available and readily accessible for robot system before installation.
- (3) Regarding how to use brake release unit, please refer to Robot controller maintenance manual.



CAUTION

Robot systems installed without adequate number of brake release units or similar means are not in compliance with EN ISO 10218-1 and the Machinery Directive and therefore cannot bear the CE marking.



WARNING

Robot arm would fall down by releasing its brake because of gravity. Therefore it is strongly recommended to take adequate measures such as hanging Robot arm by a crane before releasing a brake.




Fig. 3 (a) Arm operation by the release of J2, J3-axis motor brake and measures

4 WARNING & CAUTION LABEL

(1) Greasing and degreasing label



Fig. 4 (a) Greasing and Degreasing Label

Description

When greasing and degreasing, observe the instructions indicated on this label.

- 1) When greasing, be sure to keep the grease outlet open.
- 2) Use a manual pump to grease.
- 3) Be sure to use specified grease.



CAUTION

See Section 7.3 and 8.3 for explanations about specified grease, the grease amount, and the locations of grease and degrease outlets for individual models.

(2) Step-on prohibitive label**Fig. 4 (b) Step-on Prohibitive Label****Description**

Do not step on or climb the robot or controller as it may adversely affect the robot or controller and you may get hurt if you lose your footing as well.

(3) High-temperature warning label**Fig. 4 (c) High-temperature warning label****Description**

Be cautious about a section where this label is affixed, as the section generates heat. If you have to inevitably touch such a section when it is hot, use a protective provision such as heat-resistant gloves.

(4) Transportation label




Fig. 4 (d) Transportation label

Description

When transporting the robot, observe the instructions indicated on this label. The above label indicates the following:

- 1) Using a forklift
 - Use a forklift having a load capacity of 1000 kg or greater.
 - Keep the total weight of the robot to be transported to within 1000 kg, because the allowable load of the forklift bracket (option) is 4900 N (500 kgf).
- 2) Using a crane
 - Use a crane with a load capacity of 1000 kg or greater.
 - Use four slings with each load capacity of 500 kg or greater.
 - Use four eyebolts with each allowable load of 4410 N (450 kgf) or greater.



CAUTION

Transportation labels are model-specific. Before transporting the robot, see the transportation label affixed to the J2 arm.

See Sub-section 1.1 TRANSPORTATION for explanations about the posture a specific model should take when it is transported.

(5) **Transportation caution label**
(When transport equipment option is specified.)




Fig. 4 (e) Transportation caution label

Description

Keep the following in mind when transporting the robot.

- 1) Do not pull eyebolts sideways.
- 2) Prevent the forks of the forklift from having impact on transport equipment.
- 3) Do not thread a chain or the like through transport equipment.

(6) **Operating space and payload (capacity) label**
(When CE specification is specified)

The following label is added:





Fig. 4 (f) Operating space and payload label (Example of M-710iC/20L)

PREFACE

This manual explains operation procedures for the following mechanical units:

Model name	Mechanical unit specification No.	Maximum load
FANUC Robot M-710iC/20L	A05B-1125-B205	20kg
	A05B-1125-B255	20kg
FANUC Robot M-710iC/12L	A05B-1125-B206	12kg
	A05B-1125-B256	12kg
FANUC Robot M-710iC/20M	A05B-1125-B209	20kg

The label stating the mechanical unit specification number is affixed in the following position. Before reading this manual, verify the specification number of the mechanical unit.



Position of label indicating mechanical unit specification number

TABLE 1)

	(1)	(2)	(3)	(4)	(5)
CONTENTS	MODEL NAME	TYPE	NO.	DATE	WEIGHT kg (Without controller)
LETTERS	FANUC Robot M-710iC/20L	A05B-1125-B205	SERIAL NO. IS PRINTED	PRODUCTION YEAR AND MONTH ARE PRINTED	540
	FANUC Robot M-710iC/20L	A05B-1125-B255			540
	FANUC Robot M-710iC/12L	A05B-1125-B206			540
	FANUC Robot M-710iC/12L	A05B-1125-B256			540
	FANUC Robot M-710iC/20M	A05B-1125-B209			530

RELATED MANUALS

For the FANUC Robot series, the following manuals are available:

SAFETY HANDBOOK B-80687EN All persons who use the FANUC Robot and system designer must read and understand thoroughly this handbook		Intended readers: Operator, system designer Topics: Safety items for robot system design, operation, maintenance
R-30iA controller	OPERATOR'S MANUAL SPOT TOOL+ B-83124EN-1 HANDLING TOOL B-83124EN-2 ARC TOOL B-83124EN-3 DISPENSE TOOL B-83124EN-4 ALARM CODE LIST B-83124EN-6 SERVO GUN FUNCTION B-82634EN	Intended readers: Operator, programmer, maintenance technician, system designer Topics: Robot functions, operations, programming, setup, interfaces, alarms Use: Robot operation, teaching, system design
	MAINTENANCE MANUAL B-82595EN B-82595EN-1 (For Europe) B-82595EN-2 (For RIA)	Intended readers: Maintenance technician, system designer Topics: Installation, start-up, connection, maintenance Use: Installation, start-up, connection, maintenance
R-30iB, R-30iB Mate, R-30iB Plus, R-30iB Mate Plus controller	OPERATOR'S MANUAL (Basic Operation) B-83284EN (Alarm Code List) B-83284EN-1 OPTIONAL FUNCTION B-83284EN-2 ARC WELDING FUNCTION B-83284EN-3 SPOT WELDING FUNCTION B-83284EN-4 DISPENSE TOOL B-83284EN-5 Servo Gun Function B-83264EN	Intended readers: Operator, programmer, maintenance technician, system designer Topics: Robot functions, operations, programming, setup, interfaces, alarms Use: Robot operation, teaching, system design
	MAINTENANCE MANUAL R-30iB, R-30iB Plus : B-83195EN R-30iB Mate, R-30iB Mate Plus : B-83525EN	Intended readers: Maintenance technician, system designer Topics: Installation, start-up, connection, maintenance Use: Installation, start-up, connection, maintenance

This manual uses following terms.

Name	Terms in this manual
Connection cable between robot and controller	Robot connection cable
Robot mechanical unit	Mechanical unit

TABLE OF CONTENTS

SAFETY PRECAUTIONS.....	s-1
PREFACE.....	p-1
1 TRANSPORTATION AND INSTALLATION	1
1.1 TRANSPORTATION.....	1
1.1.1 Transportation with an End Effector Attached.....	5
1.2 INSTALLATION	6
1.2.1 Installation Method.....	7
1.2.2 Angle of Mounting Surface Setting.....	9
1.3 MAINTENANCE AREA.....	11
1.4 INSTALLATION CONDITIONS.....	11
2 CONNECTION WITH THE CONTROLLER	12
3 BASIC SPECIFICATIONS	13
3.1 ROBOT CONFIGURATION	13
3.2 MECHANICAL UNIT OPERATING SPACE AND INTERFERENCE AREA.....	17
3.3 ZERO POINT POSITION AND MOTION LIMIT	20
3.4 WRIST LOAD CONDITIONS	25
3.5 LOAD CONDITIONS ON J3 CASING.....	27
3.6 ABOUT SWITCHING BETWEEN MOVEMENT TYPES.....	28
3.7 OPERATING SPACE FOR WALL/INCLINED SURFACE MOUNTED ROBOTS	30
4 EQUIPMENT INSTALLATION TO THE ROBOT.....	43
4.1 END EFFECTOR INSTALLATION TO WRIST	43
4.2 EQUIPMENT MOUNTING FACE	45
4.3 LOAD SETTING	47
5 PIPING AND WIRING TO THE END EFFECTOR	49
5.1 AIR SUPPLY (OPTION)	50
5.2 AIR PIPING (OPTION)	51
5.3 INTERFACE FOR OPTION CABLE (OPTION)	52
6 AXIS LIMITS SETUP.....	65
6.1 CHANGE AXIS LIMIT BY DCS (OPTION).....	66
6.2 ADJUSTABLE MECHANICAL STOPPER AND LIMIT SWITCH SETTING (OPTION)	69
6.2.1 Installing adjustable mechanical stopper option.....	70
6.2.2 Changing the parameter setting.....	73
6.2.3 The maximum stopping distance (position) of adjustable mechanical stopper.....	74
6.3 CHANGING THE MOTION RANGE BY THE LIMIT SWITCH (OPTION)	76
6.4 ADJUSTING LIMIT SWITCH (OPTION)	77

7	CHECKS AND MAINTENANCE (M-710iC/20L/20M).....	78
7.1	CHECKS AND MAINTENANCE	78
7.1.1	Daily Checks	78
7.1.2	Periodic Check and Maintenance	79
7.2	CHECK POINTS.....	81
7.2.1	Confirmation of Oil Seepage.....	81
7.2.2	Confirmation of the Air Control Set (option).....	82
7.2.3	Check the Mechanical Unit Cables and Connectors	83
7.2.4	Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper	85
7.3	MAINTENANCE.....	86
7.3.1	Replacing the Batteries (1.5 Year checks)	86
7.3.2	Greasing	87
7.3.3	Replacing the Grease of the Drive Mechanism (3-years (11520 Hours) Checks)	88
7.3.3.1	Grease replacement procedure of the J1, J2, J3-axis reducer.....	90
7.3.3.2	Grease replacement procedure for the J4-axis gearbox	92
7.3.3.3	Grease replacement procedure for the J5-axis gearbox	92
7.3.3.4	Procedure for releasing remaining pressure within the grease bath	93
7.4	STORAGE	94
8	CHECKS AND MAINTENANCE (M-710iC/12L).....	95
8.1	CHECKS AND MAINTENANCE	95
8.1.1	Daily Checks	95
8.1.2	Periodic Check and Maintenance	96
8.2	CHECK POINTS.....	99
8.2.1	Confirmation of Oil Seepage.....	99
8.2.2	Confirmation of the Air Control Set.....	100
8.2.3	Check the Oil Sight Glasses	101
8.2.4	Check the Failure of the Wrist Part Fluoric Resin Ring.....	101
8.2.5	Check the Mechanical Unit Cables and Connectors	102
8.2.6	Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper	103
8.3	MAINTENANCE.....	104
8.3.1	Replacing the Batteries (1.5 Year checks)	104
8.3.2	Replacing the Grease and Oil of the Drive Mechanism (3-years (11520 Hours) Checks)	105
8.3.2.1	Grease replacement procedure of the J1, J2, J3-axis reducer and J4-axis gearbox	105
8.3.2.2	Procedure for releasing remaining pressure from the grease bath (J1 to J4-axis).....	109
8.3.2.3	Oil replacement procedure for the J5/J6- axis gearbox.....	109
8.3.2.4	Procedure for releasing remaining pressure from the oil bath (J5/J6-axis).....	114
8.4	STORAGE	114
9	MASTERING	115
9.1	OVERVIEW	115
9.2	RESETTING ALARMS AND PREPARING FOR MASTERING	116
9.3	ZERO POSITION MASTERING	117
9.4	QUICK MASTERING	121
9.5	QUICK MASTERING FOR SINGLE AXIS	123
9.6	SINGLE AXIS MASTERING	126
9.7	MASTERING DATA ENTRY.....	130
9.8	VERIFYING MASTERING	132

10	TROUBLESHOOTING	133
10.1	TROUBLESHOOTING.....	133
11	SEVERE DUST/LIQUID PROTECTION PACKAGE (OPTION).....	141
11.1	OVERVIEW	141
11.2	CONFIGURATION OF THE SEVERE DUST/LIQUID PROTECTION PACKAGE	142

APPENDIX

A	PERIODIC MAINTENANCE TABLE	145
B	STRENGTH OF BOLT AND BOLT TORQUE LIST.....	150
C	INSULATION ABOUT ARC WELDING ROBOT	151
C.1	INSULATION AT THE WRIST	151
C.2	INSULATION AT THE ADDITIONAL AXIS	152

1 TRANSPORTATION AND INSTALLATION

1.1 TRANSPORTATION

Use a crane or a forklift to transport the robot. When transporting the robot, be sure to change the posture of the robot to that shown below and lift by using the eyebolts and the transport equipment at their points.

**WARNING**

- 1 When hoisting or lowering the robot with a crane or forklift, move it slowly with great care. When placing the robot on the floor, exercise care to prevent the installation surface of the robot from striking the floor.
- 2 It is recommended to transport robot detaching the end effector and the incidental equipment from the robot because there is the following possibilities when transported with the end effector and the incidental equipment installed.
 - It becomes unstable by the change in the position of the center of the gravity of the robot while transporting it.
 - The end effector acts by the vibration when transported and an excessive load acts on far movement and the robot.
- 3 Please firmly fix the end effector referring to Subsection 1.1.1 when it is difficult to detach the end effector and transport it.
- 4 Use the forklift pockets only to transport the robot with a forklift. Do not use the forklift pockets for any other transportation method. Do not use the forklift pockets to secure the robot.
- 5 Before moving the robot by using transport equipment, check the bolts on the transport equipment and tighten any loose bolts if any.

- (1) Transportation using a crane (Fig. 1.1 (b) to (d))

Fasten the M16 eyebolts to the four points of the robot base plate and lift the robot by the four slings.

**CAUTION**

When lifting the robot, take notice so that the motor, connectors, or cables of the robot are not damaged by slings.

- (2) Transportation using a forklift (Fig. 1.1 (e) to (g))

The specific transport equipment must be attached. Transport equipment is prepared as an option.




Fig. 1.1 (a) Position of the eyebolts and transportation equipment




Fig. 1.1 (b) Transportation using a crane (M-710iC/20L)

1. TRANSPORTATION AND INSTALLATION




Fig. 1.1 (c) Transportation using a crane (M-710iC/12L)




Fig. 1.1 (d) Transportation using a crane (M-710iC/20M)




Fig. 1.1 (e) Transportation using a forklift (M-710iC/20L)




Fig. 1.1 (f) Transportation using a forklift (M-710iC/12L)



CAUTION

Be careful not to strike the transport equipment with the forklift forks.




Fig. 1.1 (g) Transportation using a forklift (M-710iC/20M)

**CAUTION**

Be careful not to strike the transport equipment with the forklift forks.

1.1.1 Transportation with an End Effector Attached

When transporting a robot with an end effector such as a welding gun or hand attached, secure the arm with wood. If the arm is not secured, the end effector may oscillate for a cause such as vibration during transportation, as a result, a large impact load, imposes on the reducer of the robot, cause premature failure of the reducer.




Fig. 1.1.1 (a) Example of securing the arm during transportation when an end effector is attached

1.2 INSTALLATION

Fig. 1.2 (a) shows the robot base dimensions. Avoid placing any object in front of the robot on the locating surface to facilitate the installation of the mastering fixture.




Fig. 1.2 (a) Dimensions of the robot base

1.2.1 Installation Method

Fig. 1.2.1 (a) shows the actual example of the robot installation.

The floor plate is imbedded in concrete and fastened with four M20 (Tensile strength 400N/mm^2 or more) chemical anchors. Also, fasten the base plate to the robot base using four M20 x 50 bolts (Tensile strength 1200N/mm^2 or more). Next, position the robot, and weld the base plate to the floor plate. (Floor length is 10 to 15mm.)




Fig. 1.2.1 (a) Actual installation example


CAUTION

Flatness of robot installation surface must be less than or equal to 0.5mm.
Inclination of robot installation surface must be less than or equal to 0.5°.
If robot base is placed on uneven ground, it may result in the base breakage or low performance of the robot.

Fig. 1.2.1 (b) and Table 1.2.1 (a) indicate the force and moment applied to the base plate at the time of Power-Off stop of the robot. Table 1.2.1 (b) and Table 1.2.1 (c) indicate the stopping distance and time of the J1 through J3 axes until the robot stopping by Power-Off stop or by Controlled Stop after input of the stop signal. Refer to the data when considering the strength of the installation face.

NOTE

Stopping times and distances in Table 1.2.1 (b) and (c) are reference values measured in accordance with ISO 10218-1. Please measure and check the actual values, since it varies depending on robot individual, load condition and operation program. Stopping times and distances in Table 1.2.1 (b) are affected by the robot's operating status and the number of Servo-off stops. Please measure and check the actual values periodically.

Table 1.2.1 (a) Force and moment during Power-Off stop

Model	Vertical moment M_V [kNm(kgfm)]	Force in vertical direction F_V [kN(kgf)]	Horizontal moment M_H [kNm(kgfm)]	Force in horizontal direction F_H [kN(kgf)]
M-710iC/20L	16.8 (1714)	9.8 (1003)	6.5 (659)	7.1 (720)
M-710iC/12L	12.9 (1320)	9.1 (930)	5.4 (550)	6.8 (690)
M-710iC/20M	13.1 (1335)	9.2 (942)	4.8 (488)	5.9 (599)

Table 1.2.1 (b) Stopping time and distance until the robot stopping by Power-Off stop after input of stop signal

Model		J1-axis	J2-axis	J3-axis
M-710iC/20L	Stopping time [ms]	276	247	217
	Stopping distance [deg] (rad)	24.0 (0.42)	21.6 (0.38)	19.5 (0.34)
M-710iC/12L	Stopping time [ms]	284	284	172
	Stopping distance [deg] (rad)	27.5 (0.48)	25.8 (0.45)	14.5 (0.25)
M-710iC/20M	Stopping time [ms]	252	228	188
	Stopping distance [deg] (rad)	24.3 (0.42)	22.6 (0.39)	19.2 (0.33)

Table 1.2.1 (c) Stopping time and distance until the robot stopping by Controlled stop after input of stop signal

Model		J1-axis	J2-axis	J3-axis
M-710iC/20L	Stopping time [ms]	718	734	710
	Stopping distance [deg] (rad)	65.2 (1.14)	62.4 (1.09)	68.7 (1.20)
M-710iC/12L	Stopping time [ms]	772	908	756
	Stopping distance [deg] (rad)	75.1 (1.31)	74.6 (1.30)	71.8 (1.25)
M-710iC/20M	Stopping time [ms]	741	708	668
	Stopping distance [deg] (rad)	66.2 (1.15)	66.0 (1.15)	65.4 (1.14)




Fig. 1.2.1 (b) Force and moment during Power-Off Stop

1.2.2 Angle of Mounting Surface Setting

For all robot mounts except floor mount, be sure to set the mounting angle referring to the procedure below. Refer to Section 3.1 for installation specifications.

- 1 Turn on the controller with [PREV] and [NEXT] key pressed. Then select “3. Controlled start”.
- 2 Press the [MENU] key and select “9 MAINTENANCE” .
- 3 Select the robot for which you want to set the mount angle, and press the [ENTER] key.

ROBOT MAINTENANCE		CTRL START MANU	
Setup Robot System Variables			
Group	Robot Library/Option	Ext	Axes
1	M-710iC/20L		0
[TYPE]ORD NO AUTO MANUAL			

- 4 Press the [F4] key.

- 5 Press the [ENTER] key until screen below is displayed.

```
*****Group 1 Initialization*****  
*****M-710iC/20L*****  
  
--- MOUNT ANGLE SETTING ---  
  
0 [deg] : floor mount type  
90 [deg] : wall mount type  
180 [deg] : upside-down mount type  
  
Set mount_angle (0-180[deg])->  
Default value = 0
```

- 6 Input the angle of mounting surface referring to Fig. 1.2.2 (a).




Fig. 1.2.2 (a) Mounting angle

- 7 Press the [ENTER] key until screen below is displayed again.

```
ROBOT MAINTENANCE      CTRL START MANU  
-----  
Setup Robot System Variables  
  
Group  Robot Library/Option Ext Axes  
1       M-710iC/20L              0  
  
[TYPE]ORD NO      AUTO      MANUAL
```

- 8 Press the [FCTN] key and select "1 START (COLD)".

1.3 MAINTENANCE AREA

Fig. 1.3 (a) shows the maintenance area of the mechanical unit. Be sure to leave enough room for the robot to be mastered. See Chapter 8 for mastering.




Fig. 1.3 (a) Maintenance area

1.4 INSTALLATION CONDITIONS

Refer to the caution below concerning installation conditions.
Refer to also to the specifications found in Section 3.1.



CAUTION

Damage to the cable jacket can cause water intrusion. Take care not to damage the cable jacket when installing the robot. Replace the cable if it is damaged.

2 CONNECTION WITH THE CONTROLLER

The robot is connected with the controller via the power and signal cable and earth cable. Connect these cables to the connectors on the back of the robot base.

For details on air and option cables, see Chapter 5.



WARNING

Before turning on controller power, be sure to connect the robot and controller with the earth line (ground). Otherwise, there is the risk of electrical shock.



CAUTION

- 1 Before connecting the cables, be sure to turn off the controller power.
- 2 Do not use 10m or longer coiled cable without first untying it. The long coiled cable will heat up and become damaged.




Fig. 2 (a) Cable connection

3 BASIC SPECIFICATIONS

3.1 ROBOT CONFIGURATION




Fig. 3.1 (a) Mechanical unit configuration (M-710iC/20L/20M)




Fig. 3.1 (b) Mechanical unit configuration (M-710iC/12L)




Fig. 3.1 (c) Each axis coordinates and mechanical interface coordinates

NOTE

The end effector mounting face center is 0, 0, 0 of the mechanical interface coordinates.

Specifications (NOTE 1)

Item			Specification		
Model			M-710iC/20L	M-710iC/12L	M-710iC/20M
Type			Articulated Type		
Controlled axes			6-axis (J1, J2, J3, J4, J5, J6)		
Reach			3110mm	3123mm	2582mm
Installation (NOTE 2)			Floor, upside-down mount (angle)		
Motion range	J1-axis	Upper limit	180° (3.14rad)	180° (3.14rad)	180° (3.14rad)
		Lower limit	-180° (-3.14rad)	-180° (-3.14rad)	-180° (-3.14rad)
	J2-axis	Upper limit	135° (2.36rad)	135° (2.36rad)	135° (2.36rad)
		Lower limit	-90° (-1.57rad)	-90° (-1.57rad)	-90° (-1.57rad)
	J3-axis	Upper limit	270° (4.71rad)	270° (4.71rad)	275° (4.80rad)
		Lower limit	-162° (-2.83rad)	-164° (-2.86rad)	-160° (-2.79rad)
	J4-axis	Upper limit	200° (3.49rad)	200° (3.49rad)	200° (3.49rad)
		Lower limit	-200° (-3.49rad)	-200° (-3.49rad)	-200° (-3.49rad)
	J5-axis	Upper limit	140° (2.44rad)	190° (3.31rad)	140° (2.44rad)
		Lower limit	-140° (-2.44rad)	-190° (-3.31rad)	-140° (-2.44rad)
	J6-axis	Upper limit	450° (7.85rad)	360° (6.28rad)	450° (7.85rad)
		Lower limit	-450° (-7.85rad)	-360° (-6.28rad)	-450° (-7.85rad)
Max motion speed (NOTE 3)	J1-axis		175°/s (3.05rad/s)	180°/s (3.14rad/s)	175°/s (3.05rad/s)
	J2-axis		175°/s (3.05rad/s) (A05B-1125-B205)	180°/s (3.14rad/s)	175°/s (3.05rad/s)
			165°/s (2.88rad/s) (A05B-1125-B255)		
	J3-axis		180°/s (3.14rad/s)	180°/s (3.14rad/s)	180°/s (3.14rad/s)
	J4-axis		350°/s (6.11rad/s)	400°/s (6.98rad/s)	350°/s (6.11rad/s)
	J5-axis		360°/s (6.28rad/s)	430°/s (7.50rad/s)	360°/s (6.28rad/s)
	J6-axis		600°/s (10.47rad/s)	630°/s (11.0rad/s)	600°/s (10.47rad/s)
Max. load capacity	At wrist		20kg	12kg	20kg
	At J3 casing (NOTE 4)		24kg		
Allowable load moment at wrist	J4-axis		39.2N·m (4.0kgf·m)	22.0N·m (2.24kgf·m)	39.2N·m (4.0kgf·m)
	J5-axis		39.2N·m (4.0kgf·m)	22.0N·m (2.24kgf·m)	39.2N·m (4.0kgf·m)
	J6-axis		19.6N·m (2.0kgf·m)	9.8N·m (1.0kgf·m)	19.6N·m (2.0kgf·m)
Allowable load inertia at wrist	J4-axis		0.88kg·m ² (9.0kgf·cm·s ²)	0.65kg·m ² (6.6kgf·cm·s ²)	0.88kg·m ² (9.0kgf·cm·s ²)
	J5-axis		0.88kg·m ² (9.0kgf·cm·s ²)	0.65kg·m ² (6.6kgf·cm·s ²)	0.88kg·m ² (9.0kgf·cm·s ²)
	J6-axis		0.25kg·m ² (2.5kgf·cm·s ²)	0.17kg·m ² (1.7kgf·cm·s ²)	0.25kg·m ² (2.5kgf·cm·s ²)
Drive method			Electric servo drive by AC servo motor		
Repeatability(NOTE 5)			±0.11mm	±0.09mm	±0.06mm
Mass (NOTE 6)			540kg		530kg
Acoustic noise level			71.3dB (NOTE 7)		
Installation environment			Ambient temperature: 0 - 45°C (NOTE 8) Ambient humidity: Normally 75%RH or less (No dew nor frost allowed.) Short time (within one month) Max 95%RH (No dew nor frost allowed.) Height: Up to 1000 meters above the sea level required, no particular provision for posture. Vibration acceleration : 4.9m/s ² (0.5G) or less Free of corrosive gases (NOTE 9)		

NOTE

- Even if the robot is used according to the defined specifications, motion programs might shorten reducer life or cause the robot to overheat. Use ROBOGUIDE (system design support tool by FANUC) for further evaluation before running production.
- There are restrictions on the J1- and J2-axis motion ranges under the installation condition indicated in parentheses. However, there is no restriction for M-710iC/20M. Refer to Section 3.7 for details.
- During short distance motions, the axis speed may not reach the maximum value stated.
- The Max. load capacity at J3 casing is restricted by the load weight at wrist. For details, see Section 3.5.
- Compliant with ISO 9283.
- The weight of the controller is not included.
- This value is the equivalent continuous A-weighted sound pressure level that applied with ISO11201 (EN31201). This value is measured with the following conditions.
 - Maximum load and speed
 - Operating mode is AUTO
- When the robot is used in a low temperature environment that is near to 0°C, or the robot is not operated for a long time in the an environment that is less than 0°C, for example in during a holiday or the overnight, because viscous resistance of the drive train is so big that may cause occurrence of collision detect alarm (SRVO-050) etc. In this case, we recommend performing the a warm up operation for several minutes.
- Contact the service representative, if the robot is to be used in an environment or a place subjected to hot/cold temperatures, severe vibrations, heavy dust, water, water vapor, cutting oil, cleaning fluid splash and or other contaminations.

The following table lists the IEC60529-based severe dust/liquid protection characteristics of the M-710iC.

	Standard	Severe dust/liquid protection package
J3 arm and wrist unit	IP67	IP67
Drive unit of the main body	IP66	IP67
Main body	IP54 (*)	IP67

(*) Except some connectors




Fig. 3.1 (d) Severe dust/liquid protection characteristics of the M-710iC

NOTE

Definition of IP code

Definition of IP 67

6=Dust-tight: Complete protection against contact

7=Protection from water immersion: Ingress of water in harmful quantity shall not be possible when the enclosure is immersed in water under defined conditions of pressure and time.

Definition of IP 66

6=Dust-tight: Complete protection against contact

6=Protection from powerful water jets: Water projected in powerful jets against the enclosure from any direction shall have no harmful effects.

Definition of IP 54

5=Dust-tight: Ingress of dust is not entirely prevented, but it must not enter in sufficient quantity to interfere with the satisfactory of the equipment.

4=Protection from water immersion: Water splashing against the enclosure from any direction shall have no harmful effect.

Performance of resistant chemicals and resistant solvents

- (1) The robot (including severe dust/liquid protection model) cannot be used with the following liquids. Potentially these liquids will cause irreversible damage to the rubber parts (such as: gaskets, oil seals, O-rings etc.). (As exception to this only liquids tested and approved by FANUC can be used with the robot.)
 - (a) Organic solvents
 - (b) Cutting fluid or detergent including chlorine / gasoline
 - (c) Amine type cutting fluid or detergent
 - (d) Acid, alkali and liquid causing rust
 - (e) Other liquids or solutions, that will harm NBR
- (2) When the robots work in the environment, using water or liquid, complete draining of J1 base must be done. Incomplete draining of J1 base will make the robot break down.

- (3) Don not use unconfirmed liquid.
- (4) Do not use the robot immersed in water, neither temporary nor permanent. Robot must not be wet permanently.

*Example : in case motor surface is exposed to water for a long time, liquid may invade inside the motor and cause failure.

3.2 MECHANICAL UNIT OPERATING SPACE AND INTERFERENCE AREA

Fig. 3.2 (a) to (c) show the robot operating space. When installing peripheral equipment, be careful not to interfere with the robot and its operating space.




Fig. 3.2 (a) Operating space (M-710iC/20L)




Fig. 3.2 (b) Operating space (M-710iC/12L)




Fig. 3.2 (c) Operating space (M-710iC/20M)

3.3 ZERO POINT POSITION AND MOTION LIMIT

Zero point and motion range are provided for each controlled axis. Exceeding the software motion limit of a controlled axis is called overtravel (OT). Overtravel is detected at both ends of the motion limit for each axis. The robot cannot exceed the motion range unless there is a loss of zero point position due to abnormalities in servo system or system error. In addition, the motion range limit by a mechanical stopper or limit switch is also prepared to improve safety.

Fig. 3.3 (a) shows the position of mechanical stopper. Only in case of J1 axis, robot stops by transforming mechanical stopper. Be sure to exchange transformed stopper to new one. Tight the bolts according to Appendix B. Replace mechanical stopper of J1- axis referring to Fig. 3.3 (a).



WARNING

Do not reconstruct the fixed mechanical stopper. There is a possibility that the robot doesn't stop normally.




Fig. 3.3 (a) Position of mechanical stopper

Fig. 3.3 (b) to (i) show the zero point and motion limit, LS detection position, and maximum stopping distance (stopping distance in condition of max.speed and max.load) of each axis.

- * The motion range can be changed. For information on how to change the motion range, see Chapter 6, "AXIS LIMIT SETUP".




Fig. 3.3 (b) J1-axis motion limit




Fig. 3.3 (c) J2-axis motion limit




Fig. 3.3 (d) J3-axis motion limit




Fig. 3.3 (e) J4-axis motion limit




Fig. 3.3 (f) J5-axis motion limit (M-710iC/20L/20M)




Fig. 3.3 (g) J5-axis motion limit (M-710iC/12L)




Fig. 3.3 (h) J6-axis motion limit (M-710iC/20L/20M)




Fig. 3.3 (i) J6-axis motion limit (M-710iC/12L)

3.4 WRIST LOAD CONDITIONS

Fig. 3.4 (a) and (b) are diagrams showing the allowable load that can be applied to the wrist section. Apply a load within the region indicated in the graph. Apply the conditions of the allowable load moment and the allowable load inertia. See Section 4.1 about allowable load moment and the allowable load inertia.




Fig. 3.4 (a) Wrist load diagram (M-710iC/20L/20M)




Fig. 3.4 (b) Wrist load diagram (M-710iC/12L)

3.5 LOAD CONDITIONS ON J3 CASING

Table 3.5 (a) and Fig. 3.5 (a), (b) show J3 casing load condition.
(The J3 casing load weight is limited according to the wrist load weight.)




Fig. 3.5 (a) J3 casing load condition (M-710iC/20L/20M)

Table 3.5 (a) J3 casing load condition (M-710iC/20L/20M)

Wrist load weight W_1	J3 casing load weight W_2
15kg or less	24 kg or less
More than 15kg and less than 20kg	$W_2 \leq \frac{14}{5} \times (20 - W_1[kg]) + 10$




Fig. 3.5 (b) J3 casing load condition (M-710iC/12L)

⚠ CAUTION

- Do not put load on J3 arm. (There is no problem for putting load on J3 casing.)
- If equipment is installed to J3 arm, it is dangerous because it rotates with J3 arm.
- If you put load on J3 arm, unavoidably, treat it as wrist load.

3.6 ABOUT SWITCHING BETWEEN MOVEMENT TYPES

The M-710iC/20L (A05B-1125-B205)/12L/20M have two movement types: general setting (Turbomove enabled) and sealing setting (Turbomove disabled).

Switching between the settings is automatically performed when you run a dedicated switching program as described below.

Switching program name

CHNGMOVE.PC (Common to M-710iC/20L (A05B-1125-B205)/12L/20M)

When you run this program, you are asked whether you really want to switch to the other movement type of the Robot.

If the current setting is “General Setting (Minimum Time Control Enabled)”

Move type setting for M-710iC/20L
(Group: 1)

The present movetype is General type.
Do you change to Sealing type?

[Yes: 1, No: Else] ->

If the current setting is “Sealing Setting (Minimum Time Control Disabled)”

Move type setting for M-710iC/20L
(Group: 1)

The present movetype is Sealing type.
Do you change to General type?

[Yes: 1, No: Else] ->

When you select “Yes” in response to the prompt, switching to the other movement type (parameter change) is performed. A message then appears on the screen, notifying you of the switching.

If switching from “General Setting” to “Sealing Setting” has been performed

[Yes: 1, No: Else] -> 1
Sealing type setting has been set.
(Group: 1)

If switching from “Sealing Setting” to “General Setting” has been performed

[Yes: 1, No: Else] -> 1
General type setting has been set.
(Group: 1)

When you select “No” in response to the prompt, the current movement type is maintained. A message then appears on the screen, indicating that switching has been canceled.

If switching has been canceled

[Yes: 1, No: Else] -> 0
Move type setting has been canceled.
(Group: 1)

If there is more than one M-710iC/20L(A05B-1125-B205)/12L/20M unit in a multi-group system, you are further asked whether you really want to switch to the other movement type of the second M-710iC/20L(A05B-1125-B205)/12L/20M unit.

[Yes: 1, No: Else] -> 1
Sealing type setting has been set.
(Group: 1)

Move type setting for M-710iC/20L
(Group: 2)

The present movetype is General type.
Do you change to Sealing type?

[Yes: 1, No: Else] ->

If switching to the other movement type has been performed (if movement type switching has been performed for one or more groups in a multi-group system), you are prompted to turn the power off and then back on when you exit the program. In addition, alarm “SRVO-333 POWER OFF AND ON” is then issued.

The switching completes when the power is turned off and then back on.

If switching to the other movement type has been performed

[Yes: 1, No: Else] -> 1
Sealing type setting has been set.
(Group: 1)

Please power off



CAUTION

This program can only be used to switch between movement types of the M-710iC/20L(A05B-1125-B205)/12L/20M. Even if a multi-group system includes other robots, a switching prompt does not appear for a group with a robot other than the M-710iC/20L(A05B-1125-B205)/12L/20M.

3.7 OPERATING SPACE FOR WALL/INCLINED SURFACE MOUNTED ROBOTS

In case of M-710iC/20L/12L, when robots are mounted on wall or inclined surface, the operating space has restricted range depending on its mounted angle.

Wall mount and inclination installation is enable against only the front direction and the back direction. Against side direction is impossible.




Fig.3.7 (a) Direction of robot wall mount and inclination installation

Fig.3.7 (b) to (m) show operating space for robots mounted on wall or inclined surface depending on its mounted angle. However, there is no restriction for M-710iC/20M.




Fig. 3.7 (b) Operating space for mounted angle range (1)
 $(-180^\circ \leq \phi \leq -130^\circ \quad -50^\circ \leq \phi \leq 50^\circ, \quad 130^\circ \leq \phi \leq 180^\circ)$ (M-710iC/20L (A05B-1125-B205))




Fig. 3.7 (c) Operating space for mounted angle range (2)
 $(-130^\circ < \phi \leq -120^\circ, -60^\circ \leq \phi < -50^\circ, 50^\circ < \phi \leq 60^\circ, 120^\circ \leq \phi < 130^\circ)$ (M-710iC/20L(A05B-1125-B205))




Fig. 3.7 (d) Operating space for mounted angle range (3)
 $(-120^\circ < \phi \leq -110^\circ, -70^\circ \leq \phi < -60^\circ, 60^\circ < \phi \leq 70^\circ, 110^\circ \leq \phi < 120^\circ)$ (M-710iC/20L(A05B-1125-B205))




Fig. 3.7 (e) Operating space for mounted angle range (4)
 $(-110^\circ < \phi < -70^\circ, 70^\circ < \phi < 110^\circ)$ (M-710iC/20L(A05B-1125-B205))




Fig. 3.7 (f) Operating space for mounted angle range (1)
 $(-180^\circ \leq \phi \leq -140^\circ \quad -40^\circ \leq \phi \leq 40^\circ, 140^\circ \leq \phi \leq 180^\circ)$ (M-710iC/20L (A05B-1125-B255))




Fig. 3.7 (g) Operating space for mounted angle range (2)
 $(-140^\circ < \phi \leq -130^\circ, -50^\circ \leq \phi < -40^\circ, 40^\circ < \phi \leq 50^\circ, 130^\circ \leq \phi < 140^\circ)$ (M-710iC/20L(A05B-1125-B255))




Fig. 3.7 (h) Operating space for mounted angle range (3)
 $(-130^\circ < \phi \leq -120^\circ, -60^\circ \leq \phi < -50^\circ, 50^\circ < \phi \leq 60^\circ, 120^\circ \leq \phi < 130^\circ)$ (M-710iC/20L(A05B-1125-B255))




Fig. 3.7 (i) Operating space for mounted angle range (4)
 $(-120^\circ < \phi < -60^\circ, 60^\circ < \phi < 120^\circ)$ (M-710iC/20L(A05B-1125-B255))




Fig. 3.7 (j) Operating space for mounted angle range (1)
 $(-180^\circ \leq \phi \leq -125^\circ, -55^\circ \leq \phi \leq 55^\circ, 125^\circ \leq \phi \leq 180^\circ)$ (M-710iC/12L)




Fig. 3.7 (k) Operating space for mounted angle range (2)
 $(-125^\circ < \phi \leq -120^\circ, -60^\circ \leq \phi < -55^\circ, 55^\circ < \phi \leq 60^\circ, 120^\circ \leq \phi < 125^\circ)(M-710iC/12L)$




Fig. 3.7 (I) Operating space for mounted angle range (3)
 $(-120^\circ < \phi \leq -110^\circ, -70^\circ \leq \phi < -60^\circ, 60^\circ < \phi \leq 70^\circ, 110^\circ \leq \phi < 120^\circ)(M-710iC/12L)$




Fig. 3.7 (m) Operating space for mounted angle range (4)
 $(-110^\circ < \phi < -70^\circ, 70^\circ < \phi < 110^\circ)$ (M-710iC/12L)

4 EQUIPMENT INSTALLATION TO THE ROBOT

4.1 END EFFECTOR INSTALLATION TO WRIST

Fig. 4.1 (a) shows the figures for installing end effectors on the wrist of M-710iC/20L/20M. The end effector is engaged using a $\phi 50\text{h}7$ spigot or $\phi 25\text{H}7$ socket, positioned using a 1- $\phi 6\text{H}7$ reamed hole, and fastened using four M6 self-tapping screws. As for the M6 self-tapping screws, select those not longer than the tapping depth (10 mm).

Fig. 4.1 (b) show the figures for installing end effectors on the wrist of M-710iC/12L. Select screws and positioning pins of a length that matches the depth of the tapped and pinholes.

See Appendix B “Bolt tightening torque” for tightening torque specifications.



CAUTION

Notice the tooling coupling depth to wrist flange should be shorter than the flange coupling length.




Fig. 4.1 (a) Mounting surface for the end effector (M-710iC/20L/20M)




Fig. 4.1 (b) Mounting surface for the end effector (M-710iC/12L)



CAUTION

Do not remove the M3 bolts of shaped area. If they are removed, the robot does not return to the original state.

4.2 EQUIPMENT MOUNTING FACE

As shown in Fig. 4.2 (a) to (c), tapped holes are provided to install equipment to the robot.



CAUTION

- 1 Never perform additional machining operations such as drilling or tapping on the robot body. This can seriously affect the safety and functions of the robot.
- 2 Note that the use of a tapped hole not shown in the following figure is not assured.
Please do not tighten both with the tightening bolts used for mechanical unit.
- 3 Equipment should be installed so that mechanical unit cable is not pinched or damaged. If equipment installation restricts or damages the mechanical unit cable, it might become disconnected, and unexpected conditions might occur.
- 4 Do not put load on J3 arm. (There is no problem for putting load on J3 casing.)
- 5 If equipment is installed to J3 arm, it is dangerous because it rotate with J3 arm.
- 6 If you put load on J3 arm, unavoidably, treat it as wrist load.




Fig. 4.2 (a) Equipment mounting surfaces (M-710iC/20L)




Fig. 4.2 (b) Equipment mounting surfaces (M-710iC/12L)




Fig. 4.2 (c) Equipment mounting surfaces (M-710iC/20M)

4.3 LOAD SETTING

⚠ CAUTION

- 1 Set the correct load condition parameter before the robot runs. Do not operate the robot in over when its payload is exceeded or incorrect. Do not exceed the allowable payload including connection cables. Operation in with the robot over payload may result in troubles such as reducer life reduction.

- 2 WHEN PERFORMING LOAD ESTIMATION AFTER PARTS REPLACEMENT (for M-710iC/12L)

If wrist axis motors (J5/J6-axis) or reducers are replaced, payload estimation accuracy may decrease. Perform calibration of load estimation without the load such as hand before performing load estimation.

Section 9.15 "LOAD ESTIMATION" in R-30iA Controller

Spot tool+ OPERATOR'S MANUAL (B-83124EN-1).

Section 9.15 "LOAD ESTIMATION" in R-30iA Controller

Handling tool OPERATOR'S MANUAL (B-83124EN-2).

Section 9.15 "LOAD ESTIMATION" in R-30iA Controller

Dispense tool OPERATOR'S MANUAL (B-83124EN-3).

Chapter 9 "LOAD ESTIMATION" in R-30iB/R-30iB Mate/R-30iB Plus

/R-30iB Mate Plus/R-30iB Compact Plus/R-30iB Mini Plus Controller

Optional Function OPERATOR'S MANUAL (B-83284EN-2).

The motion performance screens include the MOTION PERFORMANCE screen, MOTION PAYLOAD SET screen, and MOTION ARMLOAD SET screen. These screens are used to specify payload information and equipment information on the robot.

- 1 Press the [MENU] key to display the screen menu.
- 2 Select "6 SYSTEM" from the next page.
- 3 Press the F1 ([TYPE]) key.
- 4 Select "MOTION." The MOTION PERFORMANCE screen will be displayed.

MOTION PERFORMANCE			JOINT 10%	
Group1				
No.	PAYLOAD[kg]		Comment	
1	20.00	[]	
2	0.00	[]	
3	0.00	[]	
4	0.00	[]	
5	0.00	[]	
6	0.00	[]	
7	0.00	[]	
8	0.00	[]	
9	0.00	[]	
10	0.00	[]	
Active PAYLOAD number =0				
[TYPE]	GROUP	DETAIL	ARMLOAD	SETIND >
	IDENT			>

4. EQUIPMENT INSTALLATION TO THE ROBOT

B-82514EN/10

- 5 Ten different pieces of payload information can be set using condition No. 1 to 10 on this screen. Place the cursor on one of the numbers, and press F3 [DETAIL]. The MOTION PAYLOAD SET screen will be displayed.

MOTION PAYLOAD SET			JOINT	100%
Group 1				
Schedule No[1]: [Comment]				
1	PAYLOAD	[kg]		20.00
2	PAYLOAD CENTER X	[cm]		-10.00
3	PAYLOAD CENTER Y	[cm]		0.00
4	PAYLOAD CENTER Z	[cm]		7.50
5	PAYLOAD INERTIA X	[kgf·cm·s ²]		0.663
6	PAYLOAD INERTIA Y	[kgf·cm·s ²]		0.727
7	PAYLOAD INERTIA Z	[kgf·cm·s ²]		0.644
[TYPE] GROUP NUMBER DEFAULT HELP				




Fig. 4.3 (a) Standard tool coordinate

- 6 Set the payload, gravity center position, and inertia around the gravity center on the MOTION PAYLOAD SET screen. The X, Y, and Z directions displayed on this screen correspond to the respective standard tool coordinates (with no tool coordinate system set up). When values are entered, the following message will be displayed: “Path and Cycletime will change. Set it?” Respond to the message with F4 ([YES]) or F5 ([NO]).
- 7 Pressing F3 ([NUMBER]) will bring you to the MOTION PAYLOAD SET screen for another condition
- 8 Press the [PREV] key to return to the list screen. Press F5 SETIND, and enter a desired load setting condition number.
- 9 On the list screen, pressing F4 [ARMLOAD] brings you to the device-setting screen.

MOTION ARMLoad SET			JOINT	100 %
Group1				
1	ARM LOAD AXIS #1 [kg]			0.00
2	ARM LOAD AXIS #3 [kg]			12.00
[TYPE] GROUP DEFAULT HELP				

- 10 Specify the mass of the loads on the J2 base and J3 casing. When you enter ARM LOAD AXIS #1[kg] (Mass of the load on the J2 base) and ARM LOAD AXIS #3[kg] (Mass of the load on the J3 arm), the confirmation message “Path and Cycletime will change. Set it?” will be displayed. Select F4 YES or F5 NO. Once the mass of a device is entered, it is put in effect by cycling power.

5 PIPING AND WIRING TO THE END EFFECTOR



WARNING

- Only use appropriately-specified mechanical unit cables.
- Do not add user cables or hoses inside of the mechanical unit.
- Please do not obstruct the movement of the mechanical unit when cables are added to the outside of the mechanical unit.
- Please do not perform remodeling (adding a protective cover, or secure an additional outside cable) that obstructs the behavior of the cable.
- When external equipment is installed on the robot, make sure that it does not interfere with other parts of the robot.
- Cut and discard any unnecessary length of wire strand of the end effector (hand) cable. Insulate the cable with seal tape. (See Fig. 5 (a))
- If you have end effector wiring and a process that develops static electricity, keep the end effector wiring as far away from the process as possible. If the end effector and process must remain close, be sure to insulate the cable.
- Be sure to seal the connectors of the user cable and terminal parts of all cables to prevent water from entering the mechanical unit. Also, attach the cover to the unused connector.
- Frequently check that connectors are tight and cable jackets are not damaged.
- When precautions are not followed, damage to cables might occur. Cable failure may result in incorrect function of the end effector, robot faults, or damage to robot electrical hardware. In addition, electric shock could occur when touching the power cables.




Fig. 5 (a) Treatment method of end effector (hand) cable

5.1 AIR SUPPLY (OPTION)

Robot has air inlet and air outlet on the side of the J1 base and the front of the J3 casing used to supply air pressure to the end effector. The connector is an Rc1/2 female (ISO).

Because couplings are not supplied, it will be necessary to prepare couplings, which suit to the tube size.




Fig. 5.1 (a) Air supply (option)

5.2 AIR PIPING (OPTION)

Fig. 5.2 (a) shows how to connect air tube to the robot. If the air control set is specified as an option, the air tube between the mechanical unit and the air control set is provided. A tap holes shown in Fig. 5.2 (b) are necessary for the installation of the air control set. Please prepare by customer.




Fig. 5.2 (a) Air piping (option)

Air control set

For the lubricator of air control set, fill in turbine oil #90 to #140 to the specified level. The machine tool builder is required to prepare mounting bolts.




Fig. 5.2 (b) Air control set (option)

NOTE

The capacity of the air control set is as follows.
These values must not be exceeded.

Air pressure	Supply air pressure	0.49~0.69MPa(5~7kgf/cm ²) Setting: 0.49MPa(5kgf/cm ²)
	Amount of consumption	Maximum instantaneous amount 150Nl/min (0.15Nm ³ /min)

5.3 INTERFACE FOR OPTION CABLE (OPTION)

Fig. 5.3 (a) to (d) show the position of the option cable interface.

End effector interface (RI/RO), user cable (signal line, signal line usable to force sensor and 3D Laser Vision sensor), user cable (power line), Additional axis motor cable (Pulsecoder/power brake), camera cable, 3D Laser Vision sensor cable, wire feeder cable (for LINCOLN welding power supply), Ethernet cable (signal) : are prepared as options.

NOTE

Each option cable is written as shown below on the connector panel.

EE interface : EE

User cable (signal) : AS

User cable (signal line usable to force sensor and 3D Laser Vision sensor) : ASi

User cable (power) : AP

Additional axis motor cable (Pulsecoder) : ARP

Additional axis motor cable (power, brake) : ARM

Camera cable : CAM

3D Laser Vision sensor cable : SEN/3DV

Wire feeder cable : W/F

Ethernet cable (signal) : ES




Fig. 5.3 (a) Position of the option cable interface (option)




Fig. 5.3 (b) Interface for option cable (1/3)




Fig. 5.3 (c) Interface for option cable (2/3)

5. PIPING AND WIRING TO THE END EFFECTOR




Fig. 5.3 (d) Interface for option cable 2/2 (When severe dust/liquid protection is specified) (3/3)

5. PIPING AND WIRING TO THE END EFFECTOR

B-82514EN/10

(1) EE interface (RI/RO) (option)

Fig. 5.3 (e) and (f) show the pin layout for the EE interface (RI/RO). When severe dust/liquid protection package is specified, the connector has guide pins and bushes for preventing improper insertion. For cables prepared by the user, use these guide pins and bushes.




Fig. 5.3 (e) Pin layout for EE interface(RI/RO) (option)




Fig. 5.3 (f) Pin layout for EE interface (RI/RO) (Severe dust/liquid protection package)



CAUTION

For wiring of the peripheral device to the end effector interface, refer to the CONNECTION Chapter 4 of CONTROLLER MAINTENANCE MANUAL.

(2) User cable (signal line) (AS) Interface (option)

Fig. 5.3 (g) shows pin layout for user cable (signal line) interface.




Fig. 5.3 (g) Pin layout for user cable (signal line) (AS) interface (option)

(3) User cable (signal line usable to force sensor and 3D Laser Vision sensor) (ASi) Interface (option)

Fig. 5.3 (h) shows the pin layout for the user cable (signal line usable to force sensor and 3D Laser Vision sensor) interface.




Fig. 5.3 (h) Pin layout for user cable (signal line usable to force sensor and 3D Laser Vision sensor) (ASi) interface (option)

5. PIPING AND WIRING TO THE END EFFECTOR

B-82514EN/10

(3) User cable (power line) (AP) Interface (option)

Fig. 5.3 (i) shows the pin layout for the user cable (power line) interface.




Fig. 5.3 (i) Pin layout for user cable (power line) (AP) interface (option)

(4) Additional axis motor cable (Pulsecoder line) (ARP) Interface (option)

Fig. 5.3 (j) shows pin layout for Additional axis motor cable (Pulsecoder line) interface.




Fig. 5.3 (j) Pin layout and code pin position of the additional axis (2-axes) motor cable (Pulsecoder cable) (ARP) interface and layout position of the code pin (option)

Table 5.3 (a) Comparative table of signal name according to the motor

ARP	α motor, β motor	αi , αi -B motor, βi , βi -B motor
SPD	SD	-
XSPD	*SD	-
PRQ	REQ	RD
XPRQ	*REQ	*RD

- (5) Additional axis motor cable (power and brake cables) (ARM) Interface (option)
 Fig. 5.3 (k) shows pin layout for Additional axis motor cable (power and brake cables) interface.
 The connector has a code pin for preventing improper insertion.




Fig. 5.3 (k) Pin layout and code pin position of the additional axis (2-axis) motor cable (power and brake cables) (ARM) interface and layout position of the code pin (option)

5. PIPING AND WIRING TO THE END EFFECTOR

B-82514EN/10

(6) Wire feeder power supply Interface (W/F)(option)

Fig. 5.3 (l) show the pin layout for the wire feeder power supply interface.




Fig. 5.3 (l) Pin layout for LINCOLN wire feeder power supply (W/F) interface (option)

(7) Ethernet cable (signal line) (ES) interface (option)

Fig. 5.3 (m) shows the pin layout of the Ethernet cable (signal line) (ES) interface.




Fig. 5.3 (m) Pin layout for Ethernet cable (signal line) (ES) interface (option)

Connector specifications

Table 5.3 (b) Connector specifications (Mechanical unit side)

Cable	Input side (J1 base)		Output side (J3 casing)		Maker /Dealer
EE(RI/RO)	—————		JMWR2524F		Fujikura . Ltd
AS	Housing Insert Contact	09 30 006 0301 09 16 024 3001 09 15 000 6103	Housing Insert Contact	09 30 006 0301 09 16 024 3101 09 15 000 6203	HARTING K.K.
AP	Housing Insert Contact	09 20 010 0301 09 21 015 3001 09 15 000 6103	Housing Insert Contact	09 20 010 0301 09 21 015 3101 09 15 000 6203	
RI/RO (Cable correspon ds to the severe dust/liquid protection)	Housing Insert Contact Guide pin	—————	Housing Insert Contact Guide pin	09 30 006 0301 09 16 024 3101 09 15 000 6204 09 30 000 9908	
ARP	Housing Insert Contact Code pin	09 30 006 0301 09 16 024 3001 09 15 000 6103 09 30 000 9901	Housing Insert Contact Code pin	09 30 006 0301 09 16 024 3101 09 15 000 6203 09 30 000 9901	
ARM	Housing Insert Contact Code pin	09 20 010 0301 09 21 015 3001 09 15 000 6101 09 30 000 9901	Housing Insert Contact Code pin	09 20 010 0301 09 21 015 3101 09 15 000 6201 09 30 000 9901	
LMP1	JMWR1303M		—————		Fujikura . Ltd
W/F	MS3102A20-27PY		MS3102A20-27SY		Fujikura. Ltd Japan Aviation Electronics Industry, Ltd.
ES	Connector Contact	21 03 881 2425 09 67 000 7476	Connector Contact	21 03 881 2425 09 67 000 7476	HARTING K.K.

5. PIPING AND WIRING TO THE END EFFECTOR

B-82514EN/10

Table 5.3 (c) Connector specifications (User side) (1/2)

Cable	Input side (J1 base)			Output side (J3 casing)			Maker /Dealer
EE (RI/RO)	————			JMSP2524M (*1) Straight JMLP2524M Angle			Fujikura . Ltd
AS	Hood (NOTE 2)	09 30 006 1540 1541 0542 0543 1440 1441 0442 0443	Side entry ↓ Top entry ↓	Hood	←The same		HARTING K.K.
	Insert	09 16 024 3101		Insert	09 16 024 3001		
	Contact (NOTE 2)	09 15 000 6204 6203 6205 6202 6201 6206	AWG 26-22 AWG 20 AWG 18 AWG 18 AWG 16 AWG 14	Contact (NOTE 2)	09 15 000 6104 6103 6105 6102 6101 6106	AWG 26-22 AWG 20 AWG 18 AWG 18 AWG 16 AWG 14	
	Clamp (NOTE 2)	09 00 000 5083 5086 5090 5094 etc.		Clamp	←The same		
AP	Hood (NOTE 2)	09 30 006 1540 0541 0541 1440 0440 0441	Side entry ↓ Top entry ↓	Hood	←The same		HARTING K.K.
	Insert	09 21 015 3101		Insert	09 21 015 3001		
	Contact (NOTE 2)	09 15 000 6204 6203 6205 6202 6201 6206	AWG 26-22 AWG 20 AWG 18 AWG 18 AWG 16 AWG 14	Contact (NOTE 2)	09 15 000 6104 6103 6105 6102 6101 6106	AWG 26-22 AWG 20 AWG 18 AWG 18 AWG 16 AWG 14	
	Clamp (NOTE 2)	09 00 000 5083 5086 5090 5094 etc.		Clamp	←The same		

5. PIPING AND WIRING TO THE END EFFECTOR

Table 5.3 (d) Connector specifications (User side) (2/2)

Table 3.3 (b) Connector specifications (User side) (2/2)						
Cable	Input side (J1 base)		Output side (J3 casing)			Maker /Dealer
EE (RI/RO) (These are attached to the cables which are corresponded to the sever dust/liquid protection.)			Hood (NOTE 2)	09 30 006 1540	Side entry	HARTING K.K
				1541	↓	
				0542		
				0543		
				1440(*2)	Top entry	
				1441	↓	
				0442		
			0443			
Insert	09 16 024 3001 (*3)					
Contact (24 pcs)	09 15 000 6104 (*4)			AWG 26-22		
	6103			AWG 20		
	6105			AWG 18		
	6102			AWG 18		
	6101			AWG 16		
Clamp (NOTE 2)	09 00 000 5085 (*5)					
	5086					
	5090					
	5094					
Many other types are available						
Guide pin (2 pcs)	09 33 000 9908 (*6)					
Bush (2 pcs)	09 33 000 9909 (*7)					
LMP1	JMSP1303F Straight plug (FANUC spec. A63L-0001-0234#S1303F)					Fujikura . Ltd
	JMLP1303F Angle plug					
W/F	Straight plug : MS3106B20-27SY (*1) Elbow plug : MS3108B20-27SY or a compatible product Clamp : MS3057-12A (*1) (FANUC spec. : A05B-1221-K843 Straight plug (*1) and clamp (*1) are included)		Straight plug : MS3106B20-27PY (*2) Elbow plug : MS3108B20-27PY or a compatible produce Clamp : MS3057-12A (*2) (FANUC spec. :A05B-1221-K841 Straight plug (*1) and clamp (*1) are included)			Fujikura. Ltd Japan Aviation Electronics Industry, Ltd.
ES	Connector	21 03 881 1405	←The same			HARTING K.K.
	Contact (Note 2)	09 67 000 7576	AWG 28-24			
5576		AWG 26-22				
8576		AWG 24-20				
3576		AWG 22-18				

NOTE 1

Underlined parts are attached. Below shows spec. to order in our company.

- (*1) A63L-0001-0234#S2524M
- (*2) A63L-0001-0453#06B1440
- (*3) A63L-0001-0453#24DDM
- (*4) A63L-0001-0453#CA6104
- (*5) A63L-0001-0453#A-152D
- (*6) A63L-0001-0453#A-9908
- (*7) A63L-0001-0453#A-9909

NOTE 2

For details, such as the dimensions, refer to the related catalogs offered by the respective manufacturers, or contact your local FANUC representative.

6

AXIS LIMITS SETUP

By setting the motion range of each axis, you can change the robot's motion range from the standard values. Changing the motion range of the robot is effective under the following circumstances:

- Used motion range of the robot is limited.
- There is an area where tool and peripheral devices interfere with the robot.
- The length of cables and hoses attached for application is limited.

There are three methods used to prevent the robot from going beyond the necessary motion range.

- Limit axis motion range by DCS (All axes (option))
- Limit axis motion range adjustable mechanical stopper (J1/J2/J3-axes (option))
- Limit axis motion range by adjustable mechanical stopper and switches (J1/J2/J3-axis (option))



WARNING

- 1 Changing the motion range of any axis affects the operating range of the robot. To avoid trouble, carefully consider any possible effect of the change to the movable range of each axis in advance. Otherwise, it is likely that an unexpected condition will occur; for example, an alarm may occur in a previously taught position.
- 2 When limiting the motion range, for J1-axis, use adjustable mechanical stoppers, for J2/J3-axis, use the adjustable mechanical stoppers or DCS function so that damage to peripheral equipment and injuries to human bodies can be avoided.
- 3 Mechanical stoppers are physical obstacles. For J1 to J3-axis, it is possible to re-position the adjustable mechanical stoppers. But the robot cannot move beyond them. For J5-axis, the mechanical stoppers are fixed. For the J4 and J6-axes, only DCS-specified limits are available.
- 4 Adjustable mechanical stoppers (J1, J2, and J3-axes) are deformed in a collision to stop the robot. Once a stopper is subject to a collision, it can no longer assure its original strength and, therefore, may not stop the robot. When this happens, replace it with a new one.

6.1 CHANGE AXIS LIMIT BY DCS (OPTION)

The robot motion can be restricted with DCS (Dual check safety) function by using the following software. For J2/J3-axis, the same effect as adjustable mechanical stopper described in Section 6.2 can be obtained. The robot motion can be restricted at any angle and position if it is in robot motion area. DCS functions are certified to meet the requirements of International Standard ISO13849-1 and IEC61508 approved by notified body. If only the operating space is set using Joint Position Check, the robot stops after it goes beyond the workspace. When the motor power is shut down, the robot's momentum causes it to move some distance before it completely stops. The actual "Robot Stop Position" will be beyond the workspace. To stop the robot within the robot workspace, use the DCS Stop Position Prediction function. The stop position prediction is disabled by default.

- DCS position/speed check function (J567)

As an example, we show the procedure to set $\pm 30^\circ$ for J2-axis in here. Refer to R-30iB/R-30iB Mate /R-30iB Plus Controller Dual check safety function Operator's Manual (B-83184EN) or R-30iA/R-30iA Mate Controller Dual check safety function Operator's Manual (B-83104EN) for details of other setting, function and DCS stop position prediction.

Setting procedure

- 1 Press the [MENU] key to display the screen menu.
- 2 Press [0 NEXT] and press [6 SYSTEM].
- 3 Press the F1 ([TYPE]).
- 4 Select [DCS]. The following screen will be displayed.

DCS		AUTO
		JOINT 1%
1	Joint position check	
2	Joint speed check:	
3	Cart. position check	OK
4	Cart. speed check	
5	T1 mode speed check	
6	User model	
7	Tool frame	
8	User frame	
9	Stop position prediction	
[TYPE] APPLY DETAIL		UNDO

- 5 Move the cursor to [1 Joint position check], then press the [DETAIL].

DCS		AUTO
		JOINT 1%
Join Position check		
No.	G	A Status Comment
1	DISABLE	1 1 ---- []
2	DISABLE	1 1 ---- []
3	DISABLE	1 1 ---- []
4	DISABLE	1 1 ---- []
5	DISABLE	1 1 ---- []
6	DISABLE	1 1 ---- []
7	DISABLE	1 1 ---- []
8	DISABLE	1 1 ---- []
9	DISABLE	1 1 ---- []
10	DISABLE	1 1 ---- []
[TYPE]		DETAIL

- 6 Move the cursor to [1], then press the [DETAIL].

DCS		AUTO
		JOINT 1%
No. 1	Status:	
1 Comment	[*****]	
2 Enable/Disable		DISABLE
3 Group		1
4 Axis		1
5 Safe side:		
Position (deg):		
Current:		0.000
6 Upper limit :		0.000
7 Lower limit :		0.000
8 Stop type:		Power-off stop
[TYPE]	PREV NEXT	UNDO

- 7 Move the cursor to [DISABLE], then press [CHOICE], set the status to [ENABLE].
 8 Move the cursor to [Group], then input the robot group number, then press the [ENTER] key.
 9 Move the cursor to [Axis], then input "2", then press the [ENTER] key.
 10 Move the cursor to [Upper limit] right side, then input "30", then press the [ENTER] key.
 11 Move the cursor to [Lower limit] right side, then input "-30", then press the [ENTER] key.



WARNING

If only the operating space is set using Joint Position Check, the robot stops after it goes beyond the workspace. When the motor power is shut down, the robot's momentum causes it to move some distance before it completely stops. The actual "Robot Stop Position" will be beyond the workspace. To stop the robot within the robot workspace, use the DCS Stop Position Prediction function. The stop position prediction is disabled by default.

DCS		AUTO
		JOINT 1%
No. 1	Status:	
1 Comment	[*****]	
2 Enable/Disable		ENABLE
3 Group		1
4 Axis		2
5 Safe side:		
Position (deg):		
Current:		0.000
6 Upper limit :		+30.000
7 Lower limit :		-30.000
8 Stop type:		Power-off stop
[TYPE]	PREV NEXT	UNDO

- 12 Press the [PREV] key two times, back to the first screen.

DCS		AUTO
		JOINT 1%
1	Joint position check	UNSF CHGD
2	Joint speed check:	
3	Cart. position check	OK
4	Cart. speed check	
5	T1 mode speed check	
6	User model	
7	Tool frame	
8	User frame	
9	Stop position prediction	
[TYPE]	APPLY DETAIL	UNDO

- 13 Press the [APPLY].
- 14 Input 4-digit password, then press the [ENTER] key. (Password default setting is “1111”.)
- 15 The following screen will be displayed, then press the [OK].

DCS		AUTO	
		JOINT 1%	
Verify (diff)			
F Number : F0000			
VERSION : HandlingTool			
\$VERSION : V7.7097 9/1/2015			
DATE: 17-7-28 19:44			
DCS Version: V2. 0. 11			
-----Joint Position Check-----			
No.	G	A	Status Comment
1	ENABLE	1 2	CHGD [
2	ENABLE	1 2	---- [
3	DISABLE	1 2	---- [
		ALL	OK QUIT

[CHGD] on the right side of [1 Joint position check] will change to [PEND].

DCS		AUTO	
		JOINT 1%	
1	Joint position check	UNSF	PEND
2	Joint speed check:		
3	Cart. position check	OK	
4	Cart. speed check		
5	T1 mode speed check		
6	User model		
7	Tool frame		
8	User frame		
9	Stop position prediction		
[TYPE] APPLY DETAIL		UNDO	

- 16 Cycle the power of the controller in the cold start mode so the new settings are enabled.



WARNING

You must cycle the power of the controller to enable the new setting. If you fail to do so, the robot does not work normally and it may injure personnel or damage the equipment.

6.2 ADJUSTABLE MECHANICAL STOPPER AND LIMIT SWITCH SETTING (OPTION)

For the J1, J2, and J3 axes, the adjustable mechanical stopper (option) can be installed. The position of the adjustable mechanical support can be changed. The limit switch-based movable range can be changed by changing the dog positions.

Change the position of the mechanical stoppers according to the desired movable range.

Table 6.2 (a) Motion range that can be set by the adjustable mechanical stopper and space between the upper and lower limits

Item		Movable range
J1 axis adjustable mechanical stopper, limit switch	Upper limit	Settable in steps of 15° degrees in a range of -105° to +180° degrees
	Lower limit	Settable in steps of 15° degrees in the range of -180° to +105° degrees
	Space between the upper and lower limits	A space of 75° degrees or more is required.
J2 axis adjustable mechanical stopper	Upper limit	Settable in steps of 10° in the range of -50° to +80°. A mechanical stopper is also provided at the upper limit +140° of the standard movable range.
	Lower limit	Settable in steps of 10° in the range of -60° to +80°. A mechanical stopper is also provided at the lower limit -95° of the standard movable range.
	Space between the upper and lower limits	A space of 50° degrees or more is required.
J3 axis adjustable mechanical stopper	Upper limit	Settable in steps of 20° in the range of -20° to +160° and -30° and +170°. A mechanical stopper is also provided at the upper limit +283.5° of the standard movable range.
	Lower limit	Settable in steps of 20° in the range of -40° to +140° and -50° and +150°. A mechanical stopper is also provided at the lower limit -163.5° of the standard movable range.
	Space between the upper and lower limits	A space of 60° degrees or more is required.

NOTE

- 1 If the newly set operation range does not include 0°, it is necessary to change it by zero position mastering so that 0° is included.
- 2 When adjustable mechanical stopper is ordered, mounting bolt is attached.
- 3 When motion range is changed by adjustable mechanical stopper, be sure to set the motion range of soft same refer to Section 6.2.2

6.2.1 Installing adjustable mechanical stopper option

Attach adjustable mechanical stoppers referring to Fig. 6.2.1 (a) to (e).

Notes on attaching the J1-axis mechanical stopper

The motion range limited by the J1-axis mechanical stopper can be changed in steps of 15 degrees by changing the installation hole. Select the appropriate installation hole corresponding to the desired limit angle with reference to the following figure.




Fig. 6.2.1 (a) Mechanical stopper and motion limit of J1-axis (Option)




Fig. 6.2.1 (b) J2-axis adjustable mechanical stopper




Fig. 6.2.1 (c) Attachment of J2-axis adjustable mechanical stopper




Fig. 6.2.1 (d) J3-axis adjustable mechanical stopper




Fig. 6.2.1 (e) Attachment of J3-axis adjustable mechanical stopper

6.2.2 Changing the parameter setting

Setting procedure

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE].
- 4 Select [Axis Limits]. The following screen will be displayed.

System Axis Limits				JOINT 100%
Group1				1/16
AXIS	GROUP	LOWER	UPPER	
1	1	-180.00	180.00	deg
2	1	-90.00	135.00	deg
3	1	-162.00	270.00	deg
4	1	-200.00	200.00	deg
5	1	-140.00	140.00	deg
6	1	-450.00	450.00	deg
7	1	0.00	0.00	mm
8	1	0.00	0.00	mm
9	1	0.00	0.00	mm

[TYPE]

NOTE

0.00 indicates the robot does not have these axes.

- 5 Move the cursor to the axis limit to be set. Type the new value using the numeric keys on the teach pendant. In this time, set the axial upper limit and the lower limit at the position same as adjustable mechanical stoppers are attached.

System Axis Limits				JOINT 100%
Group1				1/16
AXIS	GROUP	LOWER	UPPER	
2	1	-90.00	135.00	deg

[TYPE]

- 6 Turn off the controller and then turn it back on again in the cold start mode so the new information can be used.



WARNING

- 1 You must turn off the controller and then turn it back on to use the new information; otherwise, the old settings remain valid and could cause personnel injury or equipment damage.
- 2 After changing system variables, be sure to run the robot at a low speed and make sure that the robot stops at the ends of the stroke.
- 3 If a collision should occur, the adjustable mechanical stopper becomes deformed to absorb energy, so that the robot can stop safely. If the stopper is deformed by mistake, replace it.
- 4 Do not depend on parameter settings to control the motion range of your robot.

6.2.3 The maximum stopping distance (position) of adjustable mechanical stopper

The adjustable mechanical stopper is a mechanism that can be adjusted in its position. The robot can work safely inside the adjusted motion range, up to the maximum range as shown in Table 6.2.3 (a)

A robot attempting to travel beyond this set range of motion, will be stopped by these stoppers, by collision; and therefore the robot will remain contained within the setup range.

Stopping the robot will cause the mechanical stopper to be “transformed” (permanently damaged). Be sure to replace the deformed stopper before using the robot again.

Table 6.2.3 (a) The maximum stopping distance (position) of adjustable mechanical stopper

Item		Plus side	Minus side
M-710iC/20L	J1-axis	+17°	-17°
M-710iC/12L	J2-axis	+19°	-18°
M-710iC/20M	J3-axis	+11°	-10°




Fig. 6.2.3 (a) The maximum stopping distance of adjustable mechanical stopper (J1-axis)




Fig. 6.2.3 (b) The maximum stopping distance of adjustable mechanical stopper (J2-axis)





Fig. 6.2.3 (c) The maximum stopping distance of adjustable mechanical stopper (J3-axis)

6.3 CHANGING THE MOTION RANGE BY THE LIMIT SWITCH (OPTION)


The limit switch is an over travel switch, which interrupts power to the servo motor and stops the robot when turned on. The limit switch is optionally provided for the J1-axis.

To change the motion range by the limit switch, move the dog. The following figure shows the relationship between the dog position and the motion range.

The dog of the J1-axis is placed in the same position as with the mechanical stopper.



The dog of the J1-axis is attached to the mechanical stopper. At this time, use the screw hole of the mechanical stopper.



(Note) This figure is drawn with the J1-axis viewed from above. The dog of the J1-axis is placed in the same position as with the mechanical stopper.

Fig. 6.3 (a) J1-Axis Dog Position and Motion Range (Option)

6.4 ADJUSTING LIMIT SWITCH (OPTION)

After the motion range is changed by the limit switch, be sure to make adjustment.

ADJUSTING PROCEDURE

- 1 Set the \$MOR_GRP.\$CAL_DONE system parameter to FALSE. This disables the motion limit specified by the software. As a result, the operator can rotate the robot by a jog feed which goes beyond the motion limit.
- 2 Loosen the following bolts that hold the limit switch.
M8 x 12 2 pcs M4 x 25 2 pcs
- 3 Move the limit switch so that the robot activates it at about 1.0° degree before the stroke end. Step on the dog, and position the limit switch in such a place that only one of the step-on allowance indication lines at the tip of the switch is hidden.
- 4 When the limit switch operates and detects overtravel (OT), the robot stops, and an error message, "OVERTRAVEL", is displayed. To restart the robot, hold on the SHIFT key and press the RESET key. Then, while holding on the SHIFT key, move the adjusting axis off the OT limit switch by jogging in joint mode.
- 5 Check that the robot also activates the limit switch when the robot is approx. 1.0° degrees from the opposite stroke end in the same way as above. If the limit switch does not operate at the position, adjust the position of the switch again.
- 6 Set the \$MOR_GRP.\$CAL_DONE system parameter to TRUE.
- 7 Cycle power of the controller.




Fig. 6.4 (a) Adjusting J1-axis limit switch (option)

7 CHECKS AND MAINTENANCE (M-710iC/20L/20M)

Optimum performance of the robot can be maintained by performing the checks and maintenance procedures presented in this chapter. (See APPENDIX A PERIODIC MAINTENANCE TABLE.)

NOTE

The periodic maintenance procedures described in this chapter assume that the FANUC robot is used for up to 3840 hours a year. In cases where robot use exceeds 3840 hours/year, adjust the given maintenance frequencies accordingly. The ratio of actual operation time/year vs. the 3840 hours/year should be used to calculate the new (higher) frequencies. For example, when using the robot 7680 hours a year with a recommended maintenance interval of 3 years or 11520 hours, use the following calculation to determine the maintenance frequency: 3 years / 2 = perform maintenance every 1.5 years.

7.1 CHECKS AND MAINTENANCE

7.1.1 Daily Checks

Clean each part, and visually check component parts for damage before daily system operation. Check the following items when necessary.

Check items	Check points and management
Oil seepage	Check to see if there is oil on the sealed part of each joint. If there is an oil seepage, clean it. ⇒"7.2.1 Confirmation of Oil Seepage"
Air control set	(When air control set is used) ⇒"7.2.2 Confirmation of the Air Control Set"
Vibration, abnormal noises	Check whether vibration or abnormal noises occur. When vibration or abnormal noises occur, perform measures referring to the following section: ⇒"10.1 TROUBLESHOOTING" (symptom : Vibration, Noise)
Positioning accuracy	Check that the taught positions of the robot have not deviated from the previously taught positions. If displacement occurs, perform the measures as described in the following section: ⇒"10.1 TROUBLESHOOTING" (symptom : Displacement)
Peripheral equipment for proper operation	Check whether the peripheral equipment operate properly according to commands from the robot and the peripheral equipment.
Brakes for each axis	Check that the end effector drops 0.5 mm or less when servo power is turned off. If the end effector (hand) drops, perform the measures as described in the following section: ⇒"10.1 TROUBLESHOOTING" (symptom : Dropping axis)
Warnings	Check whether unexpected warnings occur in the alarm screen on the teach pendant. If unexpected warnings occur, perform the measures as described in the following manual: ⇒"R-30iB/R-30iB Mate/R-30iB Plus/R-30iB Mate Plus /R-30iB Compact Plus /R-30iB Mini Plus CONTROLLER OPERATOR'S MANUAL (Alarm Code List)(B-83284EN-1) or R-30iA/R-30iA Mate CONTROLLER OPERATOR'S MANUAL (Alarm Code List)(B-83124EN-6)"

7.1.2 Periodic Check and Maintenance

Check the following items at the intervals recommended below based on the period or the accumulated operating time, whichever comes first. (○ : Item needs to be performed.)

Check and maintenance intervals (Period, Accumulated operating time)						Check and maintenance item	Check points, management and maintenance method	Periodic maintenance table No.
1 month 320h	3 months 960h	1 year 3840h	1.5 years 5760h	3 years 11520h	4 years 15360h			
○ Only 1st check	○					Cleaning the controller ventilation system	Confirm that the controller ventilation system is not dusty. If dust has accumulated, remove it.	19
	○					Check for external damage or peeling paint	Check whether the robot has external damage or peeling paint due to contact with the peripheral equipment. If unintended contact has occurred, eliminate the cause. Also, if the external damage is serious, and causes a problem in which the robot will not operate, replace the damaged parts.	1
	○					Check for water	Check whether the robot is subjected to water or cutting oils. If water is found, remove the cause and wipe off the liquid.	2
	○ Only 1st check	○				Check for damages to the teach pendant cable, the operation box connection cable or the robot connection cable	Check whether the cable connected to the teach pendant, operation box and robot are unevenly twisted or damaged. If damage is found, replace the damaged cables.	18
		○				Check for damage to the mechanical unit cable (movable part)	Observe the movable part of the mechanical unit cable, and check for damage. Also, check whether the cables are excessively bent or unevenly twisted. ⇒"7.2.3 Check the Mechanical Unit Cables and Connectors"	3
	○ Only 1st check	○				Check for damage to the end effector (hand) cable	Check whether the end effector cables are unevenly twisted or damaged. If damage is found, replace the damaged cables.	4
		○				Check the connection of each axis motor and other exposed connectors	Check the connection of each axis motor and other exposed connectors. ⇒"7.2.3 Check the Mechanical Unit Cables and Connectors"	5
	○ Only 1st check	○				Retightening the end effector mounting bolts	Retighten the end effector mounting bolts. Refer to the following section for tightening torque information: ⇒"4.1 END EFFECTOR INSTALLATION TO WRIST"	6

7. CHECKS AND MAINTENANCE (M-710iC/20L/20M)

B-82514EN/10

Check and maintenance intervals (Period, Accumulated operating time)						Check and maintenance item	Check points, management and maintenance method	Periodic maintenance table No.
1 month 320h	3 months 960h	1 year 3840h	1.5 years 5760h	3 years 11520h	4 years 15360h			
	○ Only 1st check	○				Retightening the cover mounting bolts and external main bolts	Retighten the cover mounting bolts, the robot installation bolts, bolts that have been removed for inspection, and bolts exposed to the outside. Refer to the recommended bolt tightening torque guidelines at the end of the manual. An adhesive to prevent bolts from loosening is applied to some bolts. If the bolts are tightened with greater than the recommended torque, the adhesive might be removed. Therefore, follow the recommended bolt tightening torque guidelines when retightening the bolts.	7
	○ Only 1st check	○				Check the fixed mechanical stopper and the adjustable mechanical stopper	Check that there is no evidence of a collision on the fixed mechanical stopper, the adjustable mechanical stopper, and check that the stopper mounting bolts are not loose. Check that the J1-axis swing stopper rotates smoothly. ⇒ "7.2.4 Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper"	8
	○ Only 1st check	○				Clean spatters, sawdust and dust	Check that spatters, sawdust, or dust does not exist on the robot main body. If dust has accumulated, remove it. Especially, clean the robot movable parts well (each joint and the wrist flange). The insulation failure occurs when the spatter has collected around the wrist flange or welding torch, and there is a possibility of damaging the robot mechanism by the welding current. (See Appendix C)	9
			○			Replacing the mechanical unit batteries	Replace the mechanical unit batteries. Regardless of operating time, replace batteries at 1.5 years. ⇒ "7.3.1 Replacing the Batteries"	10
		○				Apply grease	Grease the J6-axis reducer ⇒ "7.3.2 Greasing"	16
				○		Replacing the grease of drive mechanism	Replace the grease of each axis reducer and gearbox ⇒ "7.3.3 Replacing the Grease of the Drive Mechanism"	11-15
					○	Replacing the mechanical unit cable	Replace the mechanical unit cable Contact your local FANUC representative for information regarding replacing the cable.	17
					○	Replacing the controller batteries	Replace the controller batteries. Regardless of operating time, replace batteries at 4 years. ⇒ Chapter 7 Replacing batteries of R-30iB/R-30iB Plus CONTROLLER MAINTENANCE MANUAL(B-83195EN) or R-30iB Mate CONTROLLER MAINTENANCE MANUAL (B-83525EN) or R-30iA CONTROLLER MAINTENANCE MANUAL (B-82595EN) or R-30iA CONTROLLER MAINTENANCE MANUAL(For Europe) (B-82595EN-1) or R-30iA CONTROLLER MAINTENANCE MANUAL(For RIA) (B-82595EN-2)	20

7.2 CHECK POINTS

7.2.1 Confirmation of Oil Seepage

Check items

Check to see whether there is an oil seepage on the rotating parts of each joint axis.




Fig. 7.2.1 (a) Check parts of oil seepage

Management

- Oil might accumulate on the outside of the seal lip depending on the movement condition or environment of the axis. If the oil changes to a state of liquid, the oil might fall depending on the axis movement. To prevent oil spots, be sure to wipe away any accumulated oil under the axis components before you operate the robot.
- In case of oil seepage, please consider replacing the grease. This replacement potentially can help improving the seepage situation.
- Also, motors might become hot and the internal pressure of the grease bath might rise by frequent repetitive movement and use in high temperature environments. In these cases, normal internal can be achieved by venting the grease outlet. (When opening the grease outlet, refer to Subsection 7.3.3 and ensure that grease is not expelled onto the machine or tooling.)



WARNING

Hot grease might eject suddenly when you open the grease outlet. Attach bags for collecting grease, and use appropriate protective equipment such as heat-resistant gloves, protective glasses, a face shield, or a body suit if necessary.

- If you must wipe oil frequently, and opening the grease outlet does not stop the seepage, perform the measures below.
 ⇒ "10.1 TROUBLESHOOTING" (symptom : Grease leakage)

7.2.2 Confirmation of the Air Control Set (option)

When an air control set is used, check the items below.

Item	Check items	Check points
1	Air pressure	Check the air pressure using the pressure gauge on the air control set as shown in Fig. 7.2.2 (a). If it does not meet the specified pressure of 0.49 to 0.69 MPa (5-7 kgf/cm ²), adjust it using the regulator pressure-setting handle.
2	Lubricator oil mist quantity	Check the number of oil drops during operation. If it does not meet the specified value (1 drop/10-20 sec), adjust it using the handle for lubricator adjustment. The lubricator becomes empty in about 10 to 20 days under normal operation.
3	Lubricator oil level	Check to see that the air control set oil level is within the specified level.
4	Leakage from hose	Check the joints, tubes, etc. for leaks. Retighten the joints or replace parts, as required.
5	Drain	Check the drain and empty it. When the quantity of liquid in the drain is excessive, examine the setting of the air dryer on the air supply side.




Fig. 7.2.2 (a) Air control set (option)

7.2.3 Check the Mechanical Unit Cables and Connectors

Inspection points of the mechanical unit cables

For the J1-axis, inspect the cables from above the J2 base and from the side by removing the metal plate on the side of the J1 base. When the J2 base cover is attached, inspect there after removing the cover. For the J2-axis, inspect there after removing the J2 base side cover. For the J3-axis, check cables after remove cover of J3 casing. When severe dust/liquid protection option is selected, gasket is attached to the cover. If you remove covers, be sure to exchange gasket for the new article.

Check items

Check the cables for a jacket break and wear. If wires of the cable appear, replace it.




Fig. 7.2.3 (a) Inspection points of the mechanical unit cables

Inspection points of the connectors

- Power/brake connectors of the motor exposed externally
- Robot connection cables, earth terminal and user cables

Check items

- Circular connector: Check the connector for tightness by turning it by hand.
- Square connector: Check the connector for engagement of its lever.
- Earth terminal: Check the terminal for tightness.




Fig. 7.2.3 (b) Connector Inspection points

7.2.4 Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper

- Check that there is no evidence of a collision on the mechanical stopper and the adjustable mechanical stopper. If there is evidence of a collision on the stopper, replace the parts.
- Check the tightness of the stopper mounting bolts. If they are loose, retighten them. Be sure to check the tightness of the mounting bolts of the J1-axis swing stopper.
- Check that the J1-axis swing stopper rotates smoothly.
- Refer to Section 6.2 of the operator's manual for details regarding the adjustable mechanical stopper.




Fig. 7.2.4 (a) Check of fixed mechanical stopper and adjustable mechanical stopper

7.3 MAINTENANCE

7.3.1 Replacing the Batteries (1.5 Year checks)

The position data of each axis is preserved by the backup batteries. The batteries need to be replaced every 1.5 year. Also perform the following procedure to replace them when the backup battery voltage drop alarm occurs.

Procedure of replacing the battery

- 1 Press the EMERGENCY STOP button to prohibit the robot motion.



CAUTION

Be sure to keep the power supply turned on. Replacing the batteries with the power supply turned off causes all current position data to be lost. If this occurs, mastering will be required again.

- 2 Remove the battery case cap (Fig. 7.3.1 (a)).
- 3 Take out the old batteries from the battery case.
- 4 Insert new batteries into the battery case. Pay attention to the direction of batteries.
- 5 Close the battery case cap.



CAUTION

When using a robot with the severe dust/liquid protection option, remove the cover from the battery case as shown in Fig.7.3.1 (b) to replace the battery. After replacing the battery, reinstall the cover. At this time, please be sure to replace gasket with new one for severe dust/liquid protection.




Fig. 7.3.1 (a) Replacing the battery




Fig.7.3.1 (b) Removing the battery cover plate (When severe dust/liquid protection is specified)

7.3.2 Greasing

The following shows greasing method for J6-axis reducer.
When greasing the robot, keep its power turned off.

- Replenish the robot with grease at cycle that is shorter between every 12 months and 3840 hours operating.
- See Fig. 7.3.2 (a) and Table 7.3.2 (a) for greasing points and the method.
- After applying grease, release the remaining pressure within the grease bath as described in the procedure in Subsection 7.3.3.4.

Table 7.3.2 (a) Greasing points

Greasing point	Specified grease	Amount of grease	Gun tip pressure	Greasing method
J6-axis reducer	Specification: A98L-0040-0110	40ml	0.1 MPa or less (NOTE)	Replace the extra low bolts and sealing washers of the J6-axis grease inlet and outlet, and attach the supplied grease nipple to the grease inlet of the J6-axis. After greasing, remove the grease nipple, and attach the flat-head bolts and sealing washers to the grease inlet and outlet.

NOTE

When using a hand pump, apply grease at a rate of approximately once per two seconds.



CAUTION

If you grease incorrectly, the pressure in the grease bath may increase steeply, leading to a broken seal, which will eventually cause grease leakage or malfunction.

When greasing, be sure to follow the cautions stated in Subsection 7.3.3.




Fig.7.3.2 Greasing the J6-axis reducer

Table 7.3.2 (b) Spec. of the seal washer

Parts name	Specification
Seal washer (M6)	A30L-0001-0048#6M

7.3.3 Replacing the Grease of the Drive Mechanism (3-years (11520 Hours) Checks)

According to this subsection, replace the grease of J1 to J3 axes reducer and J4, J5-axes gearbox at the intervals based on every 3 years or 11520 hours, whichever comes first. See Table 7.3.3 (a) for the grease name and the quantity.




Fig. 7.3.3 Installation method

7. CHECKS AND MAINTENANCE (M-710iC/20L/20M)

B-82514EN/10

Table 7.3.3 (a) Grease for 3-years (11520 hours) periodical replacement

Grease supplying position	Quantity	Gun tip pressure	Grease name
J1-axis reducer	2950g (3300ml)	0.1MPa or less (NOTE)	Spec.A98L-0040-0174
J2-axis reducer	1500g (1660ml)		
J3-axis reducer	950g (1060ml)		
J4-axis gearbox	880g (1000ml)		
J5-axis gearbox	400g (440ml)		

NOTE

When using a hand pump, apply grease at a rate of approximately once per two seconds.



WARNING

Hot grease might eject suddenly when you open the grease outlet. Attach bags for collecting grease, and use appropriate protective equipment such as heat-resistant gloves, protective glasses, a face shield, or a body suit if necessary.

For grease replacement or replenishment, use the postures indicated below.

Table 7.3.3 (b) Postures for greasing

Supply position		Posture					
		J1	J2	J3	J4	J5	J6
J1-axis reducer	Floor mount	0°	Arbitrary	Arbitrary	Arbitrary	Arbitrary	Arbitrary
	Upside-down mount						
	-90° wall mount						
	+90° wall mount						
J2-axis reducer	Floor mount	Arbitrary	0°	Arbitrary	Arbitrary	Arbitrary	Arbitrary
	Upside-down mount						
	-90° wall mount						
	+90° wall mount						
J3-axis reducer	Floor mount	Arbitrary	0°	0°	Arbitrary	Arbitrary	Arbitrary
	Upside-down mount						
	-90° wall mount						
	+90° wall mount						
J4-axis gearbox	Floor mount	Arbitrary	Arbitrary	0°	Arbitrary	Arbitrary	Arbitrary
	Upside-down mount			180°			
	-90° wall mount	0°		-90°			
	+90° wall mount			90°			
J5-axis gearbox	Floor mount	Arbitrary	Arbitrary	-90°	Arbitrary	Arbitrary	Arbitrary
	Upside-down mount			90°			
	-90° wall mount	0°		180°			
	+90° wall mount			0°			



CAUTION

Failure to follow proper greasing procedures may cause a sudden increase of the grease bath internal pressure and damage to the seal. This could lead to grease leakage and abnormal operation. When greasing, observe the following cautions.

- 1 Before starting to grease, remove the seal bolt or the taper plug to allow the grease to come out.
- 2 A grease inlet may optionally have a plug. Replace the plug with the attached grease nipple and then start greasing.
- 3 Supply grease slowly without applying excessive force, using a manual pump. (once per two seconds)
- 4 Whenever possible, avoid using a compressed-air pump, powered by the factory air supply. Even when it is unavoidable to use a compressed-air pump, the gun tip pressure needs to be set the value of the gun tip pressure on Table 7.3.3 (a).
- 5 Use specified grease. Use of non-approved grease may damage the reducer or lead to other problems.
- 6 After greasing, release the remaining pressure from the grease bath using the procedure given in Subsection 7.3.3.4, and then close the grease inlet, the grease outlet and the ventilator hole.
- 7 To prevent an accident such as a fall or fire, remove all the excess grease from the floor and robot.

7.3.3.1 Grease replacement procedure of the J1, J2, J3-axis reducer

- 1 Move the robot to the greasing posture described in Table 7.3.3 (b).
- 2 Turn off the controller power.
- 3 Remove the seal bolt from grease outlet. (Fig.7.3.3.1 (a) to (c))
- 4 Supply new grease through the wrist grease inlet until new grease is output from wrist grease outlet.
- 5 After greasing, release remaining pressure as the Subsection 7.3.3.4.




Fig. 7.3.3.1 (a) Replacing grease of the J1-axis reducer




Fig. 7.3.3.1 (b) Replacing grease of the J2-axis reducer




Fig. 7.3.3.1 (c) Replacing grease of the J3-axis reducer

Table 7.3.3.1 Specification of the seal bolt and grease nipple (J1 - J3-axis)

Parts name	Specifications
Seal bolt (M12)	A97L-0218-0417#121515
Grease nipple	A97L-0218-0013#A610

7.3.3.2 Grease replacement procedure for the J4-axis gearbox

- 1 Move the robot to the greasing posture described in Table 7.3.3 (b).
- 2 Turn off the controller power.
- 3 Remove the seal bolt from the grease outlet. (Fig. 7.3.3.2 (a))
- 4 Supply new grease until new grease is output from the grease outlet.
- 5 After greasing, release remaining pressure as the Subsection 7.3.3.4.




Fig. 7.3.3.2 (a) Replacing grease of the J4-axis gearbox (When the Seal Bolt is M8x10)

Table 7.3.3.2 Specification of the seal bolt and grease nipple (J4-axis)

Parts name	Specifications
Seal bolt (M8)	A97L-0218-0417#081010
Grease nipple	A97L-0218-0013#A610

7.3.3.3 Grease replacement procedure for the J5-axis gearbox

- 1 Move the robot to the greasing posture described in Table 7.3.3 (b).
- 2 Turn off the controller power.
- 3 Remove the extra low bolts and seal washers from the wrist grease inlet and outlet, and attach the grease nipple, which is supplied with the robot, to the grease inlet (Fig. 7.3.3.3 (a)).
- 4 Supply new grease through the wrist grease inlet until new grease is output from wrist grease outlet
- 5 After greasing, release remaining pressure as the Subsection 7.3.3.4.




Fig. 7.3.3.3 (a) Grease replacement procedure for the J5-axis gearbox

Table 7.3.3.3 Specification of the seal washer (J5-axis)

Parts name	Specifications
Seal washer (M6)	A30L-0001-0048#6M

7.3.3.4 Procedure for releasing remaining pressure within the grease bath

(For the J1-, J2-, J3-, or J4-axis)

After greasing, operate the robot as described in the table below for at least 20 minutes, with the grease nipple removed from the grease inlet and the seal bolt removed from the grease outlet, to release remaining pressure from the grease bath.

(For the J5-axis gearbox)

- After greasing, remove the bolts and seal washers from the grease inlet and outlet.
- Move the robot to J3=-90°, and perform $\pm 90^\circ$ repeating operation during 5 minutes for only J5-axis. Make wait time between 2 points 0, and perform the running with position pass fine.
- After 5 minutes, confirm that about 50ml grease is pulled out. (just as volume of 2 golf balls.)
- Attach the bolts and seal washers of grease inlet and outlet.

(For the J6-axis)

After greasing, operate the robot as described in the table below for at least 10 minutes, with the grease nipple removed from the grease inlet and the seal bolt removed from the grease outlet, to release remaining pressure from the grease bath.

Under the grease inlets and outlets, attach bags for collecting grease so that grease does not spatter when it comes out of the inlets or outlets.

Operating axis Grease replacement part	J1-axis	J2-axis	J3-axis	J4-axis	J5-axis	J6-axis
J1-axis reducer	Axis angle of 60° or more OVR 80%	Arbitrary				
J2-axis reducer	Arbitrary	Axis angle of 60° or more OVR 80%	Arbitrary			
J3-axis reducer	Arbitrary		Axis angle of 60° or more OVR 80%	Arbitrary		
J4-axis gearbox	Arbitrary			Axis angle of 60° or more OVR 80%	Arbitrary	
J5-axis gearbox	Arbitrary				Axis angle of 180° or more OVR 100%	Arbitrary
J6-axis reducer	Arbitrary					Axis angle of 60° or more OVR 100%

If the above operations cannot be performed because of workcell constraints, adjust the operating time according to the operating angle. (For example, the maximum allowable axis angle is 30°, perform twice the operation for 40 minutes or more.) If you grease multiple axes, you can exercise multiple axes at the same time.

After replacing grease, grease bath may rise if robot is operated again under frequent inversion movement or high temperature environment. In these cases, you can return internal pressure by releasing grease

outlet just after operation of robot. (When opening grease outlet or oil outlet, pay attention not to scatter grease or oil.)



CAUTION

When reusing seal bolt and taper plug, be sure to seal thread part with seal tape. As for the seal washer, In one side, rubber sticks to the entire. The other side, rubber sticks to only around hole and rubber sticks is incomplete state. Attach later face to bolt side. Confirm seal washer by viewing. If it is damaged obviously, replace it by new one.

See Table 7.3.2 (b), Table 7.3.3.1 (a), Table 7.3.3.2 (a) and Table 7.3.3.3 (a) about specification of seal bolts and seal washer.

7.4 STORAGE

When storing the robot, place it on a level surface with the same posture that was used for transportation. (See Section 1.1.)

8

CHECKS AND MAINTENANCE (M-710iC/12L)

Optimum performance of the robot can be maintained by performing the checks and maintenance procedures presented in this chapter. (See APPENDIX A PERIODIC MAINTENANCE TABLE.)

NOTE

The periodic maintenance procedures described in this chapter assume that the FANUC robot is used for up to 3840 hours a year. In cases where robot use exceeds 3840 hours/year, adjust the given maintenance frequencies accordingly. The ratio of actual operation time/year vs. the 3840 hours/year should be used to calculate the new (higher) frequencies. For example, when using the robot 7680 hours a year, the maintenance frequency should be doubled – i.e. the time interval should be divided by 2.

8.1 CHECKS AND MAINTENANCE

8.1.1 Daily Checks

Clean each part, and visually check component parts for damage before daily system operation. Check the following items when necessary.

Check items	Check points and management
Oil seepage	Check there is oil on the sealed part of each joint. If there is an oil seepage, clean them. ⇒"8.2.1 Confirmation of Oil Seepage"
Air control set	(When air control set is used) ⇒"8.2.2 Confirmation of the Air Control Set"
Vibration, abnormal noises	Check whether vibration or abnormal noises occur. When vibration or abnormal noises occur, perform measures referring to the following section: ⇒"10.1 TROUBLESHOOTING"(symptom : Vibration, Noise)
Positioning accuracy	Check that the taught positions of the robot have not deviated from the previously taught positions. If displacement occurs, perform the measures as described in the following section: ⇒"10.1 TROUBLESHOOTING"(symptom : Displacement)
Peripheral equipment for proper operation	Check whether the peripheral equipment operate properly according to commands from the robot and the peripheral equipment.
Brakes for each axis	Check that the end effector drops 5 mm or less when servo power is turned off. If the end effector (hand) drops, perform the measures as described in the following section: ⇒"10.1 TROUBLESHOOTING"(symptom : Dropping axis)
Warnings	Check whether unexpected warnings occur in the alarm screen on the teach pendant. If unexpected warnings occur, perform the measures as described in the following manual: ⇒"R-30iB/R-30iB Mate/R-30iB Plus/R-30iB Mate Plus /R-30iB Compact Plus /R-30iB Mini Plus CONTROLLER OPERATOR'S MANUAL (Alarm Code List)(B-83284EN-1) or R-30iA/R-30iA Mate CONTROLLER OPERATOR'S MANUAL (Alarm Code List)(B-83124EN-6)"

8.1.2 Periodic Check and Maintenance

Check the following items at the intervals recommended below based on the period or the accumulated operating time, whichever comes first. (○ : Item needs to be performed.)

Check and maintenance intervals (Period, Accumulated operating time)							Check and maintenance item	Check points, management and maintenance method	Periodic maintenance table No.
1 months 320h	3 months 960h	1 year 3840h	1.5 year 5760h	2 years 7680h	3 years 15360h	4 years 15360h			
○ Only 1st check	○						Check the oil sight glasses of J5/J6-axes gearboxes	Please confirm whether the amount of oil of the oil sight glass of J5/J6-axes gearboxes has come above the 1/4 of total height. ⇒"8.2.3 Check the Oil Sight Glasses"	10
○ Only 1st check	○						Check the failure of the wrist part fluoric resin ring	Check to see whether there is failure on the wrist part fluoric resin ring. If is broken, replace it by new one. ⇒"8.2.4 Check the Failure of the Wrist Part Fluoric Resin Ring"	19
○ Only 1st check	○						Cleaning the controller ventilation system	Confirm that the controller ventilation system is not dusty. If dust has accumulated, remove it.	21
	○						Check for external damage or peeling paint	Check whether the robot has external damage or peeling paint due to contact with the peripheral equipment. If unintended contact has occurred, eliminate the cause. Also, if the external damage is serious, and causes a problem in which the robot will not operate, replace the damaged parts.	1
	○						Check for water	Check whether the robot is subjected to water or cutting oils. If water is found, remove the cause and wipe off the liquid.	2
	○ Only 1st check	○					Check for damages to the teach pendant cable, the operation box connection cable or the robot connection cable	Check whether the cable connected to the teach pendant, operation box and robot are unevenly twisted or damaged. If damage is found, replace the damaged cables.	20
	○ Only 1st check	○					Check for damage to the mechanical unit cable (movable part)	Observe the movable part of the mechanical unit cable, and check for damage. Also, check whether the cables are excessively bent or unevenly twisted. ⇒"8.2.5 Check the Mechanical Unit Cables and Connectors"	3
	○ Only 1st check	○					Check for damage to the end effector (hand) cable	Check whether the end effector connection cables are unevenly twisted or damaged. If damage is found, replace the damaged cables.	4

8. CHECKS AND MAINTENANCE (M-710iC/12L)

B-82514EN/10

Check and maintenance intervals (Period, Accumulated operating time)							Check and maintenance item	Check points, management and maintenance method	Periodic maintenance table No.
1 months 320h	3 months 960h	1 year 3840h	1.5 year 5760h	2 years 7680h	3 years 15360h	4 years 15360h			
	○ Only 1st check	○					Check the connection of each axis motor and other exposed connectors	Check the connection of each axis motor and other exposed connectors. ⇒"8.2.5 Check the Mechanical Unit Cables and Connectors"	5
	○ Only 1st Check	○					Retightening the end effector mounting bolts	Retighten the end effector mounting bolts. Refer to the following section for tightening torque information: ⇒"4.1 END EFFECTOR INSTALLATION TO WRIST"	6
	○ Only 1st Check	○					Retightening the cover mounting bolts and external main bolts	Retighten the cover mounting bolts, the robot installation bolts, bolts that have been removed for inspection, and bolts exposed to the outside. Refer to the recommended bolt tightening torque guidelines at the end of the manual. An adhesive to prevent bolts from loosening is applied to some bolts. If the bolts are tightened with greater than the recommended torque, the adhesive might be removed. Therefore, follow the recommended bolt tightening torque guidelines when retightening the bolts.	7
	○ Only 1st Check	○					Check the fixed mechanical stopper and the adjustable mechanical stopper	Check that there is no evidence of a collision on the fixed mechanical stopper, the adjustable mechanical stopper, and check that the stopper mounting bolts are not loose. Check that the J1-axis swing stopper rotates smoothly. ⇒"8.2.6 Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper"	8
	○ Only 1st check	○					Clean spatters, sawdust and dust	Check that spatters, sawdust, or dust does not exist on the robot main body. If dust has accumulated, remove it. Especially, clean the robot movable parts well (each joint and the wrist flange). Insulation failure might occur when spatter has collected around the wrist flange or welding torch, and there is a possibility of damaging the robot mechanism by the welding current. (See Appendix C)	9
			○				Replacing the mechanical unit batteries	Replace the mechanical unit batteries. Regardless of operating time, replace batteries at 1.5 years. ⇒"8.3.1 Replacing the Batteries"	11

8. CHECKS AND MAINTENANCE (M-710iC/12L)

B-82514EN/10

Check and maintenance intervals (Period, Accumulated operating time)							Check and maintenance item	Check points, management and maintenance method	Periodic maintenance table No.
1 months 320h	3 months 960h	1 year 3840h	1.5 year 5760h	2 years 7680h	3 years 15360h	4 years 15360h			
				○			Replacing the wrist part fluoric resin ring	Replace the wrist part fluoric resin ring Contact your local FANUC representative for information regarding replacing the fluoric resin ring. ⇒"8.2.4 Check the Failure of the Wrist Part Fluoric Resin Ring"	19
				○			Replacing the Material handling (M/H) conduit	Replace the Material handling (M/H) conduit. Contact your local FANUC representative for information regarding replacing the Material handling (M/H) conduit	18
					○		Replacing the grease and oil of the J1-J3 axes reducer and J4-J6-axes gear box	Replace the grease and oil of each axis reducer and gearbox. ⇒"8.3.2 Replacing the Grease and Oil of the Drive Mechanism"	12-16
						○	Replacing the mechanical unit cable	Replace the mechanical unit cable Contact your local FANUC representative for information regarding replacing the cable.	17
						○	Replacing the controller batteries	Replace the controller batteries. Regardless of operating time, replace batteries at 4 years. ⇒Chapter 7 Replacing batteries of R-30iB/R-30iB Plus CONTROLLER MAINTENANCE MANUAL (B-83195EN) or R-30iB Mate CONTROLLER MAINTENANCE MANUAL (B-83525EN)"	22

8.2 CHECK POINTS

8.2.1 Confirmation of Oil Seepage

Check items

Check to see whether there is an oil seepage on the rotating parts of each joint axis.




Fig. 8.2.1 (a) Check parts of oil seepage

Management

- Oil might accumulate on the outside of the seal lip depending on the movement condition or environment of the axis. If the oil changes to a state of liquid, the oil might fall depending on the axis movement. To prevent oil spots, be sure to wipe away any accumulated oil under the axis components before you operate the robot.
- In case of oil seepage, please consider replacing the grease. This replacement potentially can help improving the seepage situation.
- Also, motors might become hot and the internal pressure of the grease bath or oil bath might rise by frequent repetitive movement and use in high temperature environments. In these cases, normal internal can be achieved by venting the grease outlet. (When opening the grease outlet of J1 to J4-axis, refer to Subsection 8.3.2 and ensure that grease is not expelled onto the machine or tooling. When opening the oil outlet of J4 to J5-axis, put a oil pan under the oil outlet or place the oil outlet at the upper side.)



WARNING

Hot grease might eject suddenly when you open the grease outlet. Attach bags for collecting grease, and use appropriate protective equipment such as heat-resistant gloves, protective glasses, a face shield, or a body suit if necessary.

- If you must wipe oil frequently, and opening the grease outlet does not stop the seepage, perform the measures below.
⇒ "10.1 TROUBLESHOOTING"(symptom : Grease leakage)

8.2.2 Confirmation of the Air Control Set

When an air control set is used, check the items below.

Item	Check items	Check points
1	Air pressure	Check the air pressure using the pressure gauge on the air control set as shown in Fig. 8.2.2 (a). If it does not meet the specified pressure of 0.49 to 0.69 MPa (5-7 kgf/cm ²), adjust it using the regulator pressure-setting handle.
2	Lubricator oil mist quantity	Check the number of oil drops during operation. If it does not meet the specified value (1 drop/10-20 sec), adjust it using the handle for lubricator adjustment. The lubricator becomes empty in about 10 to 20 days under normal operation.
3	Lubricator oil level	Check to see that the air control set oil level is within the specified level.
4	Leakage from hose	Check the joints, tubes, etc. for leaks. Retighten the joints or replace parts, as required.
5	Drain	Check the drain and empty it. When the quantity of liquid in the drain is excessive, examine the setting of the air dryer on the air supply side.




Fig. 8.2.2 (a) Air control set (option)

8.2.3 Check the Oil Sight Glasses

Please confirm whether the amount of oil of the oil sight glass of J4/J5/J6-axes gearboxes has come above the 1/4 of total height, and replenish it if there is a shortage. Though the oil sight glass might not show the air bubble, this does not necessarily mean that there is a problem. When there is not enough oil, the red index of the oil sight glass shows the reflected heat of the light, and the outline of the index is seen clearly. When there is enough oil, it does not show this reflected heat, and the outline of the index is not clear. If it is unknown, open the oil outlet, look in it with a flashlight, and confirm oil is sufficient. When the oil sight glass cannot be read at all because of the oil discoloration due to deterioration, as illustrated to the right in Fig. 8.2.3 (a), refer to Subsection 8.3.2 to exchange the oil.




Fig. 8.2.3 (a) The extent of oil deterioration



CAUTION

If you continue using oil that is dirty, it will reduce the seal performance of the oil seal, cause a sludge outbreak, and cause vibration of the robot. If the operation condition is severe, oil life is reduced; in that case, we recommend early oil replacing.

8.2.4 Check the Failure of the Wrist Part Fluoric Resin Ring

Check to see whether there is failure on the wrist part fluoric resin ring. If it is broken, replace it with a new one. This part should be changed every two years. If you operate the robot in a dusty environment, you might have to replace this part more often. (Spec. of fluoric resin ring: A290-7221-X571)




Fig. 8.2.4 (a) Fluoric resin ring

If the fluoroc resin ring is broken as shown in Fig. 8.2.4 (b), replace it.




Fig. 8.2.4 (b) Failure of the fluoroc resin ring

8.2.5 Check the Mechanical Unit Cables and Connectors

Inspection points of the mechanical unit cables

For the J1-axis and J2-axis, check cables after removing J2 motor cover.

For the J3-axis, check cables after removing cover of J3 casing.

When Severe dust/liquid protection option is selected, gasket is attached to the cover. If you remove covers, be sure to replace gaskets for the new articles.

Check items

Check the cables for a jacket breakage and wear. If wires of the cable appear, replace it.




Fig. 8.2.5 (a) Inspection points of the mechanical unit cables

Inspection points of the connectors

- Power/brake connectors of the motor exposed externally
- Robot connection cables, earth terminal and user cables

Check items

- Circular connector: Check the connector for tightness by turning it by hand.
- Square connector: Check the connector for engagement of its lever.
- Earth terminal: Check the terminal for tightness.




Fig. 8.2.5 (b) Connector Inspection points

8.2.6 Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper

- Check that there is no evidence of a collision on the mechanical stopper and the adjustable mechanical stopper. If there is evidence of a collision on the stopper, replace the parts.
- Check the tightness of the stopper mounting bolts. If they are loose, retighten them. Be sure to check the tightness of the mounting bolts of the J1-axis swing stopper.
- Check that the J1-axis swing stopper rotates smoothly.
- Refer to Section 6.2 of the operator's manual for details regarding the adjustable mechanical stopper.




Fig. 8.2.6 (a) Check of fixed mechanical stopper and adjustable mechanical stopper

8.3 MAINTENANCE

8.3.1 Replacing the Batteries (1.5 Year checks)

The position data of each axis is preserved by the backup batteries. The batteries need to be replaced every 1.5 year. Also perform the following procedure to replace them when the backup battery voltage drop alarm occurs.

Procedure of replacing the battery

- 1 Press the EMERGENCY STOP button to prohibit the robot motion.



CAUTION

Be sure to keep the power supply turned on. Replacing the batteries with the power supply turned off causes all current position data to be lost. If this occurs, mastering will be required again.

- 2 Remove the battery case cap (Fig. 8.3.1 (a)).
- 3 Take out the old batteries from the battery case.
- 4 Insert new batteries into the battery case. Pay attention to the direction of batteries.
- 5 Close the battery case cap.




Fig. 8.3.1 (a) Replacing the battery

8.3.2 Replacing the Grease and Oil of the Drive Mechanism (3-years (11520 Hours) Checks)

According to this subsection, replace the grease of J1 to J3 axes reducer and J4, J5, J6-axes gearbox at the intervals based on every 3 years or 11520 hours, whichever comes first.




Fig. 8.3.2 (a) Installation method

8.3.2.1 Grease replacement procedure of the J1, J2, J3-axis reducer and J4-axis gearbox



CAUTION

Failure to follow proper greasing procedures may cause the suddenly increase of the grease bath internal pressure and the damage to the seal, which could lead to grease leakage and abnormal operation. When greasing, observe the following cautions.

- 1 Before starting to grease, remove the seal bolt or the taper plug to allow the grease to come out.
- 2 Supply grease slowly, using a manual pump. (once per two seconds)
- 3 Whenever possible, avoid using an air pump, which is powered by the factory air supply.
If the use of an air pump is unavoidable, supply grease with the pump at a pressure lower than or equal to the gun tip pressure (Table 8.3.2.1 (a)).
- 4 Use specified grease. Use of non-approved grease may damage the reducer or lead to other problems.
- 5 After greasing, release the remaining pressure from the grease bath using the procedure given in Subsection 8.3.2.2, and then close the grease inlet, the grease outlet and the ventilator hole.
- 6 To prevent the accident like fall, fire, remove all the excess grease from the floor and robot.

8. CHECKS AND MAINTENANCE

(M-710iC/12L)

B-82514EN/10

According to below, replace the grease of J1 to J3 axes reducer and J4-axis gearbox at the intervals based on every 3 years or 11520 hours, whichever comes first. See Table 8.3.2.1 (a) for the grease name and the quantity.

Table 8.3.2.1 (a) Grease for 3-years (11520 hours) periodical replacement

Grease supplying position	Quantity	Gun tip pressure	Grease name
J1-axis reducer	2950g (3300ml)	0.1MPa or less (NOTE)	Spec.A98L-0040-0174
J2-axis reducer	1500g (1660ml)		
J3-axis reducer	950g (1060ml)		
J4-axis gearbox	1300g (1480ml)		

NOTE

When using a hand pump, apply grease at a rate of approximately once per two seconds.



WARNING

Hot grease might eject suddenly when you open the grease outlet. Attach bags for collecting grease, and use appropriate protective equipment such as heat-resistant gloves, protective glasses, a face shield, or a body suit if necessary.

For grease replacement or replenishment, use the postures indicated below.

Table 8.3.2.1 (b) Postures for greasing

Supply position		Posture					
		J1	J2	J3	J4	J5	J6
J1-axis reducer	Floor mount	0°	Arbitrary	Arbitrary	Arbitrary	Arbitrary	Arbitrary
	Upside-down mount						
	-90° wall mount						
	+90° wall mount						
J2-axis reducer	Floor mount	Arbitrary	0°	Arbitrary	Arbitrary	Arbitrary	Arbitrary
	Upside-down mount						
	-90° wall mount						
	+90° wall mount						
J3-axis reducer	Floor mount	Arbitrary	0°	0°	Arbitrary	Arbitrary	Arbitrary
	Upside-down mount						
	-90° wall mount						
	+90° wall mount						
J4-axis gearbox	Floor mount	Arbitrary	Arbitrary	0°	Arbitrary	Arbitrary	Arbitrary
	Upside-down mount			180°			
	-90° wall mount	0°		-90°			
	+90° wall mount			90°			

- 1 Move the robot to the greasing posture described in Table 8.3.2.1 (b).
- 2 Turn off the controller power.
- 3 Remove the seal bolt from grease outlet. (Fig. 8.3.2.1 (a) to (d))
- 4 Supply new grease through the wrist grease inlet until new grease is output from wrist grease outlet.
- 5 After greasing, release the remaining pressure as the Subsection 8.3.2.2.




Fig. 8.3.2.1 (a) Replacing grease of the J1-axis reducer




Fig. 8.3.2.1 (b) Replacing grease of the J2-axis reducer




Fig. 8.3.2.1 (c) Replacing grease of the J3-axis reducer

Table 8.3.2.1 (c) Specification of the seal bolt (J1 to J3-axis)

Parts name	Specifications
Seal bolt (M12)	A97L-0218-0417#121515
Grease nipple	A97L-0218-0013#A610




Fig. 8.3.2.1 (d) Replacing grease of the J4-axis gearbox

Table 8.3.2.1 (d) Specification of the seal bolt and grease nipple (J4-axis)

Parts name	Specifications
Seal bolt (M8)	A97L-0218-0417#081010
Grease nipple	A97L-0218-0013#A610

8.3.2.2 Procedure for releasing remaining pressure from the grease bath (J1 to J4-axis)

After applying grease, operate the robot more than 10 minutes as instructed below with the taper plug and seal bolt of the grease inlet and outlet uncapped to release the remaining pressure within the grease bath. In case of J2-axis, there are two seal bolts for grease outlet, so uncap both of them. Attach a recovery bag below the grease inlet and outlet to prevent output grease from splattering.

Operating axis Grease replacement part	J1-axis	J2-axis	J3-axis	J4-axis	J5-axis	J6-axis
J1-axis reducer	Axis angle of 60° or more OVR 80%	Arbitrary				
J2-axis reducer	Arbitrary	Axis angle of 60° or more OVR 80%	Arbitrary			
J3-axis reducer	Arbitrary		Axis angle of 60° or more OVR 80%	Arbitrary		
J4-axis gearbox	Arbitrary			Axis angle of 60° or more OVR 80%	Arbitrary	

If the above operation cannot be performed due to the environment of the robot, adjust the operating time according to the operating angle. (When the maximum allowable axis angle is 30 degrees, perform the operation for 40 minutes or more.) If you grease or supply oil multiple axes, you can exercise multiple axes at the same time. After completion of the operation, attach the taper plug and seal bolts to the grease inlets and outlets. When reusing the seal bolts, be sure to seal them with seal tape.

After replacing grease or oil, grease bath or oil bath may rise if robot is operated again under frequent inversion movement or high temperature environment. In these cases, you can return internal pressure by releasing grease outlet or oil outlet just after operation of robot. (When opening grease outlet or oil outlet, pay attention not to scatter grease or oil.)

8.3.2.3 Oil replacement procedure for the J5/J6- axis gearbox



CAUTION

There is severe risk of gear damage in case robot is operated with oil shortage. Please make sure the gearbox is always filled with correct amount of oil.

Table 8.3.2.3 (a) Oil name and amount of oiling of standard to be replaced at regular intervals of three years (11520 hours)

Oiling points	Amount of oil to be applied (total capacity of the oil bath) NOTE 1)	Gun tip pressure	Specified oil
J5/J6-axis gearbox	330g(390ml)	0.1MPa or less	Specification: A98L-0040-0233

NOTE 1) It is not a regulated amount injection. Please confirm height of oil sight glass oil surface is 1/4 or more of all heights. Refer to Fig. 8.3.2.3 (a).




Fig. 8.3.2.3 (a) Oil sight glass

For oil replacement or replenishment, use the postures indicated below.
Consider relative angle of from posture of floor mount when robot is angle mount.

Table 8.3.2.3 (b) Oiling posture (J5/J6-axis gearbox)

Oiling points		Posture					
		J1	J2	J3	J4	J5	J6
J5/J6-axis gearbox Oiling posture when using oil gun	Floor mount	Arbitrary	Arbitrary	18°	-40°	0°	Arbitrary
	Upside-down mount			-18°	140°		
	Wall mount -90°	0°		-72°	-40°		
	Wall mount +90°			108°	-40°		
J5/J6-axis gearbox Oiling posture when not using oil gun	Floor mount	Arbitrary		18°	90°		
	Upside-down mount			-18°	-90°		
	Wall mount -90°	0°		-72°	90°		
	Wall mount +90°			108°	90°		
J5/J6-axis gearbox oil replenishment	Floor mount	Arbitrary		90°	0°		
	Upside-down mount			-90°	0°		
	Wall mount -90°	0°		0°	0°		
	Wall mount +90°			180°	0°		
J5/J6-axisgearbolx oil discharge	Floor mount	Arbitrary		-30°	-70°		
	Upside-down mount			30°	110°		
	Wall mount -90°	0°		-210°	-70°		
	Wall mount +90°			150°	-70°		
J5/J6-axis gearbox confirm oiling	Floor mount	Arbitrary		0°	0°		
	Upside-down mount			180°	0°		
	Wall mount -90°	0°		-90°	0°		
	Wall mount +90°			90°	0°		
J5/J6-axis gearbox releasing remaining pressure	Floor mount	Arbitrary		20° - 90°	90°		
	Upside-down mount			-20° - -90°	-90°		
	Wall mount -90°	0°		0° - 70°	-90°		
	Wall mount +90°			110°-180°	90°		

(NOTE) Choose the one of the posture taken easily when there is two or more posture.

Exhausting oil method

- 1 Move the robot to the posture of J5/J6-axis (oil discharge) described in Table 8.3.2.3 (b).
 - 2 Turn off controller power.
 - 3 Put the oil pan under the oil outlet.
- Remove the taper plug, extra low bolt and seal washer of first oil inlet and oil outlet. See Fig. 8.3.2.3 (b) In this time, if you remove bolt of oil outlet firstly, you can prevent spilling oil on surroundings.




Fig. 8.3.2.3 (b) Oil inlet and outlet

Table 8.3.2.3 (c) Specification of extra low bolt, taper plug and seal washer

Parts name	Specification
Extra low bolt (M6)	A97L-0218-0502#M6X8
Extra low bolt (M8)	A97L-0218-0502#M8X8
Taper plug (R1/8)	A97L-0001-0436#1-1D
Seal washer (M5)	A30L-0001-0048#5M
Seal washer (M6)	A30L-0001-0048#6M
Seal washer (M8)	A30L-0001-0048#8M

- 4 Install the taper plugs or extra low bolts and seal washers to the first oil outlet and oil outlet after all oil is exhausted.
- 5 Turn on controller power.

Injecting oil method

- A When oil gun is used
- 1 Install oil injection nipple with valve to J5/J6-axis gearbox first oil inlet (A05B-1224-K006) (Fig. 8.3.2.3 (d)) referring to Fig.8.3.2.3 (c).
 - 2 Attach oil tray with valve (A05B-1221-K007) to J5/J6-axis gearbox oil outlet (J6-axis bearing part).
 - 3 Confirm valve of oil inlet and oil outlet are open referring to Fig.8.3.2.3 (c). Supply oil to J5/J6-axis gearbox by oil injection gun (A05B-1221-K005). If oil comes out in oil tray from oil outlet, Stop supplying oil, close the valve oil injection nipple, and remove oil gun
 - 4 Close the valve of oil tray, remove tray and close the oil outlet.
 - 5 Remove the oil injection nipple, then attach extra low bolt and seal washer to first oil inlet.
 - 6 Move robot to the posture for J5/J6-axis gearbox (replenishment) of Table 8.3.2.3 (b) and add oil from second oil inlet (M5) by a syringe fountain pen filler. If about 15ml of oil is added, oil comes out from oil inlet. Then close the oil inlet.
 - 7 Move robot to the posture for J5/J6-axis gearbox (confirm oiling) of Table 8.3.2.3 (b) and confirm the quantity of oil. (See Fig.8.3.2.3 (a).)
 - 8 Turn J4-axis 90 degree by each axis jog, back to the original posture, confirm oil amount height is 1/4 or more. If oil is insufficient, add oil by a syringe fountain pen filler.
 - 9 Release remaining pressure using the procedure given in Subsection 8.3.2.4 and confirm the oil sight glass again.



CAUTION

If supplying oil forcibly when valve is closed, internal pressure of oil bath rise abnormally and cause oil leak from seal part or oil seal falling out. Be careful.




Fig. 8.3.2.3 (c) Oil injection by oil gun




Fig. 8.3.2.3 (d) Oil injection nipple with valve (A05B-1224-K006)

B When oil gun is not used

- (1) Remove extra low bolt and seal washer of ventilator hole and second oil inlet of Fig.8.3.2.3 (b) and supply oil. When the adaptor for oiling (A290-7221-X591) is used, oiling is easy. (Fig. 8.3.2.3 (e)). In case of using adaptor for oiling, install it to second oil inlet. Remove J5/J6-axis gearbox ventilator hole and supply oil. The amount of oiling are about as many as two cups of adaptors. It takes about five minutes to oil as many as one cup.
- (2) When oil comes out from ventilator hole, in case of using adaptor for oiling, remove it, close the ventilator hole, move robot to the posture (confirm oiling) of Table 8.3.2.3 (b) and confirm amount of oil sight glass. (See Fig. 8.3.2.3 (a)) If oil is not sufficient, replenish it by a syringe fountain pen filler.
- (3) Move the robot to the posture (replenishment) and add oil from second oil inlet (M6). If about 15ml of oil is added, oil comes out from oil inlet. Then close the oil inlet.
- (4) Move robot to the posture for J5/J6-axis gearbox (confirm oiling) of Table 8.3.2.3 (b). In this time, rotate the J4-axis to +/- direction and confirm oil does not decrease. If it decreased, move the robot to the posture for J5/J6-axis gearbox (confirm oiling) of Table 8.3.2.3 (b). and add oil from second oil inlet (M6) by a syringe fountain pen filler.
- (5) Release the remaining pressure using the procedure given in Subsection 8.3.2.4.




Fig. 8.3.2.3 (e) Oil adapter (supplying oil J5/J6-axis gearbox)

8.3.2.4 Procedure for releasing remaining pressure from the oil bath (J5/J6-axis)

After replacing oil, please do the following operation to adjust the amount of oil properly.

In case of J5/J6-axis gearbox

Confirm that oil level seen in oil sight glass is as per Fig. 8.3.2.3 (a). If it was confirmed then please jog robot to the posture of J5/J6 (Release remaining pressure). Attach extra low bolt and seal washer of the second oil inlet (M6) but keep it loose. Operate robot J5 and J6 axis during 10 minutes, at 100% override, making 90 degrees motion (or more) on both axis. When completed, please jog to the posture of J5/J6 (Replenishment). Remaining pressure release at once if second oil inlet is opened.

Temporary close the second oil inlet, move the robot to posture of J5/J6 (confirm oiling), then confirm that oil level seen in oil sight glass is above 1/4 or more of total height. At this time, please rotate the J4 axis in the direction of +/-, and confirm that the amount of oil doesn't decrease. Move robot to the posture of J5/J6 (Replenishment) again and add oil from the second oil inlet with the syringe etc. when decreasing after operation, move the robot to posture of J5/J6 (confirm oiling), confirm the oil amount.

Then wipe off the oil that adhered to the surface of the robot off when confirming it and close the first oil inlet completely.

If the above operation cannot be performed due to the environment of the robot, adjust the operating time according to the operating angle. (When the maximum allowable axis angle is 45 degrees, perform the twice operation for 20 minutes or more.) After completion of the operation, attach the taper plug to the oil inlets. If you grease or supply oil multiple axes, you can exercise multiple axes at the same time.

After replacing grease or oil, grease bath or oil bath may rise if robot is operated again under frequent inversion movement or high temperature environment. In these cases, you can return internal pressure by releasing grease outlet or oil outlet just after operation of robot. (When opening grease outlet or oil outlet, pay attention not to scatter grease or oil.)



CAUTION

When reusing seal bolt and taper plug, be sure to seal thread part with seal tape. As for the seal washer, In one side, rubber sticks to the entire. The other side, rubber sticks to only around hole and rubber sticks is incomplete state. Attach later face to bolt side. Confirm seal washer by viewing. If it is damaged obviously, replace it by new one.

See Table 8.3.2.3 (c) about specification of seal bolts and seal washer.

8.4 STORAGE

When storing the robot, place it on a level surface with the same posture that was used for transportation. (See Section 1.1.)

9 MASTERING

Mastering is an operation performed to associate the angle of each robot axis with the pulse count value supplied from the absolute Pulsecoder connected to the corresponding axis motor. To be specific, mastering is an operation for obtaining the pulse count value corresponding to the zero position.



CAUTION

In case of performing mastering with gravity compensation is enabled, if load setting (See Section 4.3) is not correct, it will influence the precision of the mastering.

9.1 OVERVIEW

The current position of the robot is determined according to the pulse count value supplied from the Pulsecoder on each axis.

Mastering is factory-performed. It is unnecessary to perform mastering in daily operations. However, mastering becomes necessary after:

- Motor replacement.
- Pulsecoder replacement
- Reducer replacement
- Cable replacement
- Batteries for pulse count backup in the mechanical unit have gone dead



CAUTION

Robot data (including mastering data) and Pulsecoder data are backed up by their respective backup batteries. Data will be lost if the batteries go dead. Replace the batteries in the controller and mechanical units periodically. An alarm will be issued to warn the user of a low battery voltage.

Types of Mastering

Table 9.1 (a) describes the following mastering methods. Note that "Quick Mastering for Single Axis" is not supported in software version 7DC2 (V8.20P) or earlier.

Table 9.1 (a) Type of mastering

Fixture position mastering	Mastering performed with the mastering fixture before shipping.
Zero-position mastering (witness mark mastering)	Mastering which performed with all axes set at the 0-degree position. A zero-position mark (witness mark) is attached to each robot axis. This mastering is performed with all axes aligned to their respective witness marks.
Quick mastering	This is performed at a user-specified position. The corresponding count value is obtained from the rotation count of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost. (All axes at the same time)
Quick mastering for single axis	This is performed at a user-specified position for one axis. The corresponding count value is obtained from the rotation count of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost.
Single axis mastering	Mastering which performed for one axis at a time. The mastering position for each axis can be specified by the user. Useful in performing mastering on a specific axis.
Mastering data entry	Enter the Mastering data directly.

Once mastering is performed, you must carry out positioning (calibration). Positioning is an operation in which the controller reads the pulse count value to sense the current position of the robot.

This section describes zero-position mastering, quick mastering, quick mastering for single axis, single-axis mastering, and mastering data entry. For more detailed mastering (fixture position mastering), contact your local FANUC representative.

**WARNING**

- 1 If mastering is performed incorrectly, the robot may behave unexpectedly. This is very dangerous. For the reason, the Master/Cal screen is designed to appear only when the \$MASTER_ENB system variable is 1 or 2. After performing positioning, press the F5 ([DONE]) on the Master/Cal screen. The \$MASTER_ENB system variable is reset to 0 automatically. And the Master/Cal screen will disappear.
- 2 It is recommended that the current mastering data be backed up before mastering is performed.

9.2 RESETTING ALARMS AND PREPARING FOR MASTERING

Before performing mastering because a motor has been replaced, it is necessary to release the relevant alarm and display the positioning menu.

Alarm displayed

“SRVO-062 BZAL” or “SRVO-075 Pulse not established”

Procedure

- 1 Display the positioning menu by following the steps 1 to 6.
 - 1 Press the [MENU] key.
 - 2 Press [0 NEXT] and select [6 SYSTEM].
 - 3 Press F1 ([TYPE]), and select [Variable] from the menu.
 - 4 Place the cursor on \$MASTER_ENB, then key in “1” and press the [ENTER] key.
 - 5 Press F1 ([TYPE]), and select [Master/Cal] from the menu.
 - 6 Select the desired mastering type from the [Master/Cal] menu.
- 2 To reset the “SRVO-062 BZAL” alarm, follow steps 1 to 5.
 - 1 Press the [MENU] key.
 - 2 Press [0 NEXT] and select [6 SYSTEM].
 - 3 Press F1 ([TYPE]), and select [Master/Cal] from the menu.
 - 4 Press F3 ([RES_PCA]), then press F4 ([YES]).
 - 5 Cycle power of the controller.
- 3 To reset the “SRVO-075 Pulse not established” alarm, follow the steps 1 to 2.
 - 1 After cycling controller power, the message “SRVO-075 Pulse not established” appears again.
 - 2 Move the axis for which the message mentioned above has appeared in either direction till the alarm disappears when you press the [RESET] key.

9.3 ZERO POSITION MASTERING

Zero position mastering (witness mark mastering) is performed with all axes set at the 0-degree position. A zero-position mark (witness mark) is attached to each robot axis (Fig. 9.3 (a), (b)). This mastering is performed with all axes set at the 0-degree position using their respective witness marks.

Zero position mastering involves a visual check, and might not be highly accurate. It should be used only as a quick-fix method.

Zero-position Mastering Procedure

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE (for all axes)

After changing the system variables, cycle power of the controller.

- 5 Press the [MENU] key to display the screen menu.
- 6 Select [0 NEXT] and press [6 SYSTEM].
- 7 Press F1 [TYPE], display the screen change menu.
- 8 Select [Master/Cal]. The positioning screen will be displayed.

```

SYSTEM Master/Cal    AUTO  JOINT 10 %
                    TORQUE = [ON ]
1 FIXTURE POSITION MASTER
2 ZERO POSITION MASTER
3 QUICK MASTER
4 QUICK MASTER FOR SINGLE AXIS
5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE
  Press 'ENTER' or number key to select.

[ TYPE ]  LOAD  RES_PCA          DONE
  
```

- 9 Jog the robot into a posture for mastering.
- 10 Select [2 ZERO POSITION MASTER]. Press F4 [YES].

```

SYSTEM Master/Cal      AUTO  JOINT 10 %
                        TORQUE = [ON ]
1 FIXTURE POSITION MASTER
2 ZERO POSITION MASTER
3 QUICK MASTER
4 QUICK MASTER FOR SINGLE AXIS
5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE
Robot Mastered! Mastering Data:
<0> <11808249> <38767856>
<9873638> <12200039> <2000319>
[ TYPE ] LOAD RES_PCA      DONE

```


- 11 Select [7 CALIBRATE] and press F4 [YES]. Mastering will be performed automatically. Alternatively, turn off the controller power and on again.

```

SYSTEM Master/Cal      AUTO  JOINT 10 %
                        TORQUE = [ON ]
1 FIXTURE POSITION MASTER
2 ZERO POSITION MASTER
3 QUICK MASTER
4 QUICK MASTER FOR SINGLE AXIS
5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE
Robot Calibrated! Cur Jnt Ang(deg):
< 0.0000> < 0.0000> < 0.0000>
< 0.0000> < 0.0000> < 0.0000>

```

- 12 After positioning is completed, press F5 [DONE].



- 13 Return the setting of the gravity compensation.
 14 Return brake control to the original setting, and cycle power of the controller.

Table 9.3 (a) Posture with position marks (witness mark) aligned

Axis	Position
J1-axis	0 deg
J2-axis	0 deg
J3-axis	0 deg (NOTE) When J2-axis is 0 deg.
J4-axis	0 deg
J5-axis	0 deg
J6-axis	0 deg




Fig. 9.3 (a) Zero-position mark (witness mark) for each axis (J1 to J3 axes)




Fig. 9.3 (b) Zero-position mark (witness mark) for each axis (J4 to J6 axes)

9.4 QUICK MASTERING

Quick mastering is performed at a user-specified position for each axis. The pulse count value is obtained from the rotation times of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost.

Quick mastering is factory-performed at the position indicated in Table 9.3. Do not change the setting unless there is any problem.

If setting the robot at the position mentioned above is impossible, you must re-set the quick mastering reference position using the following method. (It would be convenient to set up a marker that can work in place of the witness mark.)

CAUTION

- 1 Quick mastering can be used, if the pulse count value is lost, for example, because a low voltage has been detected on the backup battery for the pulse counter.
- 2 Quick mastering cannot be used, after the motor is replaced or after the mastering data is lost from the robot controller.

Procedure for Recording the Quick Mastering Reference Position

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE (for all axes)

After changing the system variables, cycle power of the controller.

- 5 Select [6 SYSTEM].
- 6 Select [Master/Cal]. The positioning screen will be displayed.

```

SYSTEM Master/Cal    AUTO  JOINT 10 %
                    TORQUE = [ON ]

1 FIXTURE POSITION MASTER
2 ZERO POSITION MASTER
3 QUICK MASTER
4 QUICK MASTER FOR SINGLE AXIS
5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE
    Press 'ENTER' or number key to select.

[ TYPE ]  LOAD  RES_PCA          DONE
  
```

- 7 Jog the robot to the quick mastering reference position.
- 8 Select [6 SET QUICK MASTER REF] and press F4 [YES]. Quick mastering reference position is saved.

5 SINGLE AXIS MASTER 6 SET QUICK MASTER REF 7 CALIBRATE		
[TYPE]	YES	NO
<div style="border: 1px solid black; display: inline-block; padding: 5px 15px;">F4</div>		

- 9 Return the setting of the gravity compensation.
- 10 Return brake control to the original setting, and cycle power of the controller.

**CAUTION**

If the robot has lost mastering data due to mechanical disassembly or repair, you cannot perform this procedure. In this case, perform Fixture position mastering or Zero position mastering to restore mastering data.

Procedure of Quick Mastering

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE


\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE (for all axes)

After changing the system variables, cycle power of the controller.


- 5 Display the Master/Cal screen.

SYSTEM Master/Cal		AUTO	JOINT 10 %
TORQUE = [ON]			
1 FIXTURE POSITION MASTER			
2 ZERO POSITION MASTER			
3 QUICK MASTER			
4 QUICK MASTER FOR SINGLE AXIS			
5 SINGLE AXIS MASTER			
6 SET QUICK MASTER REF			
7 CALIBRATE			
Robot Not Mastered!			
Quick master? [NO]			

- 6 Jog the robot to the quick mastering reference position.
- 7 Move the cursor to [3 QUICK MASTER] and press [ENTER]. Press F4 [YES]. Quick mastering data is saved.



- 8 Select [7 CALIBRATE] and press [ENTER] key. Calibration is executed. Calibration is executed by cycling power.
- 9 After completing the calibration, press F5 Done.



- 10 Return the setting of the gravity compensation.
- 11 Return brake control to the original setting, and cycle power of the controller.

9.5 QUICK MASTERING FOR SINGLE AXIS

Quick mastering for a single axis is performed at a user-specified position for one axis. The pulse count value is obtained from the rotation times of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost.

Quick mastering is factory-performed at the position indicated in Table 9.3 (a). Do not change the setting unless there is any problem.

If setting the robot at the position mentioned above is impossible, you must re-set the quick mastering reference position using the following method. (It would be convenient to set up a marker that can work in place of the witness mark.)

CAUTION

- 1 Quick mastering can be used, if the pulse count value is lost, for example, because a low voltage has been detected on the backup battery for the pulse counter.
- 2 Quick mastering cannot be used, after the motor is replaced or after the mastering data is lost from the robot controller.

Procedure for Recording the Quick Mastering Reference Position

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE (for all axes)

After changing the system variables, cycle power of the controller.

- 5 Select [6 SYSTEM].
- 6 Select [Master/Cal]. The positioning screen will be displayed.

SYSTEM Master/Cal	AUTO	JOINT 10 %
TORQUE = [ON]		
1 FIXTURE POSITION MASTER		
2 ZERO POSITION MASTER		
3 QUICK MASTER		
4 QUICK MASTER FOR SINGLE AXIS		
5 SINGLE AXIS MASTER		
6 SET QUICK MASTER REF		
7 CALIBRATE		
Press 'ENTER' or number key to select.		
[TYPE]	LOAD	RES_PCA DONE

- 7 Jog the robot to the quick mastering reference position.
- 8 Select [6 SET QUICK MASTER REF] and press F4 [YES]. Quick mastering reference position is saved.

5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE

[TYPE]	YES	NO
----------	-----	----

F4

- 9 Return the setting of the gravity compensation.
- 10 Return brake control to the original setting, and cycle power of the controller.



CAUTION

If the robot has lost mastering data due to mechanical disassembly or repair, you cannot perform this procedure. In this case, perform Fixture position mastering or Zero position mastering to restore mastering data.

Procedure of Quick Mastering for single axis

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows :

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE (for all axes)

After changing the system variables, cycle power of the controller.

- 5 Display the Master/Cal screen.

```

SYSTEM Master/Cal      AUTO  JOINT 10 %
                        TORQUE = [ON ]
1 FIXTURE POSITION MASTER
2 ZERO POSITION MASTER
3 QUICK MASTER
4 QUICK MASTER FOR SINGLE AXIS
5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE
  Press 'ENTER' or number key to select.

[ TYPE ]  LOAD  RES_PCA          DONE
  
```


- 6 Select [4 QUICK MASTER FOR SINGLE AXIS]. You will see the quick master for single axis screen.

AUTO JOINT 1%					
QUICK MASTER FOR SINGLE AXIS					
	ACTUAL	POS	(MSTR POS)	(SEL)	1/9 [ST]
J1	0.000	(0.000)	(0)	[2]
J2	0.000	(0.000)	(0)	[2]
J3	0.000	(0.000)	(0)	[2]
J4	0.000	(0.000)	(0)	[2]
J5	0.000	(0.000)	(0)	[2]
J6	0.000	(0.000)	(0)	[0]
E1	0.000	(0.000)	(0)	[0]
E2	0.000	(0.000)	(0)	[0]
E3	0.000	(0.000)	(0)	[0]
EXEC					

- 7 Move the cursor to the (SEL) column for the unmastered axis and press the numeric key [1]. Setting of (SEL) is available for one or more axes.

AUTO JOIN 1%					
QUICK MASTER FOR SINGLE AXIS					
	ACTUAL	POS	(MSTR POS)	(SEL)	1/9 [ST]
J5	0.000	(0.000)	(1)	[2]
J6	0.000	(0.000)	(1)	[2]
EXEC					

- 8 Jog the robot to the quick mastering reference position.
 9 Press F5 [EXEC]. Mastering is performed. So, [SEL] is reset to 0, and [ST] is re-set to 2.
 10 Select [7 CALIBRATE] and press F4 [YES]. Calibration is executed. Calibration is executed by cycling power.
 11 After completing the calibration, press F5 [DONE].



- 12 Return the setting of the gravity compensation.
 13 Return brake control to the original setting, and cycle power of the controller.

9.6 SINGLE AXIS MASTERING

Single axis mastering is performed for one axis at a time. The mastering position for each axis can be specified by the user.

Single axis mastering can be used, if mastering data for a specific axis is lost, for example, because a low voltage has been detected on the pulse counter backup battery or because the Pulsecoder has been replaced.

SINGLE AXIS MASTER				AUTO	JOINT 10%
	ACTUAL	POS	(MSTR POS)	(SEL)	1/9 [ST]
J1	0.000	(0.000)	(0)	[2]
J2	0.000	(0.000)	(0)	[2]
J3	0.000	(0.000)	(0)	[2]
J4	0.000	(0.000)	(0)	[2]
J5	0.000	(0.000)	(0)	[2]
J6	0.000	(0.000)	(0)	[0]
E1	0.000	(0.000)	(0)	[0]
E2	0.000	(0.000)	(0)	[0]
E3	0.000	(0.000)	(0)	[0]
EXEC					

Table 9.6 (a) Items set in single axis mastering

Item	Description
Current position (ACTUAL AXIS)	The current position of the robot is displayed for each axis in degree units.
Mastering position (MSTR POS)	A mastering position is specified for an axis to be subjected to single axis mastering. It would be convenient to set to it to the 0_ position.
SEL	This item is set to 1 for an axis to be subjected to single axis mastering. Usually, it is 0.

Item	Description
ST	<p>This item indicates whether single axis mastering has been completed for the corresponding axis. It cannot be changed directly by the user.</p> <p>The value of the item is reflected in \$EACHMST_DON (1 to 9).</p> <p>0 : Mastering data has been lost. Single axis mastering is necessary.</p> <p>1 : Mastering data has been lost. (Mastering has been performed only for the other interactive axes.) Single axis mastering is necessary.</p> <p>2 : Mastering has been completed.</p>

Procedure of Single axis mastering

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE (for all axes)

After changing the system variables, cycle power of the controller.

- 5 Select [6 SYSTEM].
- 6 Select [Master/Cal]. The positioning screen will be displayed.

SYSTEM Master/Cal	AUTO	JOINT 10 %
TORQUE = [ON]		
1 FIXTURE POSITION MASTER		
2 ZERO POSITION MASTER		
3 QUICK MASTER		
4 QUICK MASTER FOR SINGLE AXIS		
5 SINGLE AXIS MASTER		
6 SET QUICK MASTER REF		
7 CALIBRATE		
Press 'ENTER' or number key to select.		
[TYPE]	LOAD	RES_PCA
		DONE

- 7 Select [5 SINGLE AXIS MASTER]. The following screen will be displayed.

SINGLE AXIS MASTER			AUTO	JOINT 10%	
					1/9
ACTUAL	POS	(MSTR POS)	(SEL)	[ST]	
J1	0.000	(0.000)	(0)	[2]	
J2	0.000	(0.000)	(0)	[2]	
J3	0.000	(0.000)	(0)	[2]	
J4	0.000	(0.000)	(0)	[2]	
J5	0.000	(0.000)	(0)	[2]	
J6	0.000	(0.000)	(0)	[0]	
E1	0.000	(0.000)	(0)	[0]	
E2	0.000	(0.000)	(0)	[0]	
E3	0.000	(0.000)	(0)	[0]	
EXEC					


- 8 Move the cursor to the [SEL] column for the unmastered axis and press the numeric key [1].
Setting of [SEL] is available for one or more axes.
- 9 Turn off brake control, then jog the robot to the mastering position.
- 10 Enter axis data for the mastering position.
- 11 Press F5 [EXEC]. Mastering is performed. So, [SEL] is reset to 0, and [ST] is re-set to 2 or 1.

SINGLE AXIS MASTER			AUTO	JOINT 10%	
					6/9
ACTUAL	POS	(MSTR POS)	(SEL)	[ST]	
J1	0.000	(0.000)	(0)	[2]	
J2	0.000	(0.000)	(0)	[2]	
J3	0.000	(0.000)	(0)	[2]	
J4	0.000	(0.000)	(0)	[2]	
J5	0.000	(0.000)	(0)	[2]	
J6	90.000	(0.000)	(1)	[0]	
E1	0.000	(0.000)	(0)	[0]	
E2	0.000	(0.000)	(0)	[0]	
E3	0.000	(0.000)	(0)	[0]	
EXEC					

- 12 When single axis mastering is completed, press the [PREV] key to resume the previous screen.

SYSTEM Master/Cal		AUTO	JOINT 10 %
TORQUE = [ON]			
1 FIXTURE POSITION MASTER			
2 ZERO POSITION MASTER			
3 QUICK MASTER			
4 QUICK MASTER FOR SINGLE AXIS			
5 SINGLE AXIS MASTER			
6 SET QUICK MASTER REF			
7 CALIBRATE			
Press 'ENTER' or number key to select.			
[TYPE]	LOAD	RES_PCA	DONE

- 13 Select [7 CALIBRATE], then press F4 [YES]. Positioning is performed. Alternatively, turn off the controller power and on again. Positioning is performed.
- 14 After positioning is completed, press F5 [DONE].



- 15 Return the setting of the gravity compensation.
- 16 Return brake control to the original setting, and cycle power of the controller.

9.7 MASTERING DATA ENTRY

This function enables mastering data values to be assigned directly to a system variable. It can be used if mastering data has been lost but the pulse count is preserved.

Mastering data entry method

- 1 Press the [MENU] key, then press [0 NEXT] and select [6 SYSTEM].
- 2 Press F1 [TYPE]. Select [Variables]. The system variable screen appears.

SYSTEM Variables		AUTO	JOINT 10%
			1/669
1	\$AAVM_GRP	AAVM_GRP_T	
2	\$AAVM_WRK	AAVM_WRK_T	
3	\$ABSPOS_GRP	ABSPOS_GRP_T	
4	\$ACC_MAXLMT	0	
5	\$ACC_MINLMT	0	
6	\$ACC_PRE_EXE	0	
[TYPE]		DETAIL	

- 3 Change the mastering data. The mastering data is saved to the \$DMR_GRP.\$MASTER_COUN system variable.

SYSTEM Variables		AUTO	JOINT 10%
			1/669
135	\$DMR_GRP	DMR_GRP_T	
136	\$DMSW_CFG	DMSW_CFG_T	
[TYPE]			

- 4 Select \$DMR_GRP.

SYSTEM Variables		AUTO	JOINT 10%
\$DMR_GRP			1/1
1	[1]	DMR_GRP_T	
[TYPE]		DETAIL	

SYSTEM Variables		AUTO	JOINT 10%
\$DMR_GRP			1/29
1	\$MASTER_DONE	FALSE	
2	\$OT_MINUS	[9] of BOOLEAN	
3	\$OT_PLUS	[9] of BOOLEAN	
4	\$MASTER_COUN	[9] of INTEGER	
5	\$REF_DONE	FALSE	
6	\$REF_POS	[9] of REAL	
[TYPE]		TRUE	FALSE


- 5 Select \$MASTER_COUN, and enter the mastering data you have recorded.

SYSTEM Variables		AUTO	JOINT 10%
\$DMR_GRP[1].\$MASTER_COUN			1/9
1	[1]	95678329	
2	[2]	10223045	
3	[3]	3020442	
4	[4]	30405503	
5	[5]	20497709	
6	[6]	2039490	
7	[7]	0	
8	[8]	0	
9	[9]	0	
[TYPE]			

- 6 Press the [PREV] key.
 7 Set \$MASTER_DONE to TRUE.

SYSTEM Variables		AUTO	JOINT 10%
\$DMR_GRP			1/29
1	\$MASTER_DONE	TRUE	
2	\$OT_MINUS	[9] of BOOLEAN	
[TYPE]		TRUE	FALSE

- 8 Display the positioning screen, and select [7 CALIBRATE], then press F4 [YES].
 9 After completing positioning, press F5 [DONE].



9.8 VERIFYING MASTERING

- 1 How to verify that the robot is mastered properly:
Usually, positioning is performed automatically when the power is turned on. To check whether mastering has been performed correctly, examine if the current displayed position meets the actual robot position by using the procedure described below:
 - (1) Reproduce a particular point in a program. Check whether the point agrees with the specified position.
 - (2) Set all axes of the robot to their 0-degree (0 rad) positions. Check that the zero-degree position marks indicated in Section 8.3 of OPERATOR'S MANUAL are aligned. There is no need to use a visual aid.
If the displayed and actual positions do not match, the counter value for a Pulsecoder may have been invalidated as a result of an alarm described in 2. Alternatively, the mastering data in system variable \$DMR_GRP.\$MASTER_COUN may have been overwritten as a result of an operation error or some other reason.
Compare the data with the values indicated on the supplied data sheet. This system variable is overwritten whenever mastering is performed. Whenever mastering is performed, record the value of the system variable on the data sheet.
- 2 Alarm type displayed during mastering and their solution method:
 - (1) BZAL alarm
This alarm is displayed if the Pulsecoder's backup battery voltage decreases to 0 V while the power to the controller is disconnected. Furthermore, if the Pulsecoder connector is removed for cable replacement, etc. this alarm is displayed as the voltage decreases to 0. Confirm if the alarm will disappear by performing a pulse reset (See Section 8.2.). Then, cycle power of the controller to check if the alarm disappears or not.
The battery may be drained if the alarm is still displayed. Perform a pulse reset, and turn off and on the controller power after replacing the battery. Note that, if this alarm is displayed, all the original data held by the Pulsecoder will be lost. Mastering is required.
 - (2) BLAL alarm
This alarm is displayed if the voltage of the Pulsecoder's backup battery has fallen to a level where backup is no longer possible. If this alarm is displayed, replace the battery with a new one immediately while keeping the power turned on. Check whether the current position data is valid, using the procedure described in 1.
 - (3) Alarm notification like CKAL, RCAL, PHAL, CSAL, DTERR, CRCERR, STBERR, and SPHAL may have trouble with Pulsecoder, contact your local FANUC representative.

10 TROUBLESHOOTING

The source of mechanical unit problems may be difficult to locate because of overlapping causes. Problems may become further complicated, if they are not corrected properly. Therefore, you must keep an accurate record of problems and take proper corrective actions.

10.1 TROUBLESHOOTING

Table 10.1 (a) shows the major troubleshooting symptom that may occur in the mechanical unit and their probable causes. If you cannot pinpoint a failure cause or which measures to take, contact your local FANUC representative. For the troubleshooting except the mechanical unit, refer to “CONTROLLER MAINTENANCE MANUAL (B-83195EN etc.)” and Alarm Code List (B-83284EN-1).

Table 10.1 (a) Troubleshooting

Symptom	Description	Cause	Measure
Vibration noise	<ul style="list-style-type: none"> - The J1 base lifts off the floor plate as the robot operates. - There is a gap between the J1 base and floor plate. - A J1 base retaining bolt is loose. 	[J1 base fastening] <ul style="list-style-type: none"> - It is likely that the robot J1 base is not securely fastened to the floor plate. - Probable cause is a loose bolt, an insufficient degree of surface flatness, or foreign material caught between the J1 base plate and floor plate. - If the robot is not securely fastened to the floor plate, the J1 base lifts the floor plate as the robot operates, allowing the base and floor plates to strike each other. That, in turn, leads to vibration. 	<ul style="list-style-type: none"> - If a bolt is loose, apply LOCTITE and tighten it with the appropriate torque. - Adjust the base plate surface flatness to within the specified tolerance. - If there is any foreign material between the J1 base and base plate, remove it. - As the robot operates, the rack or floor on which the robot is mounted vibrates.
	<ul style="list-style-type: none"> - The rack or floor plate vibrates during operation of the robot. 	[Rack or floor] <ul style="list-style-type: none"> - It is likely that the rack or floor is not rigid enough. - If they are not rigid enough, counterforce deforms the rack or floor, and responsible for the vibration. 	<ul style="list-style-type: none"> - Reinforce the rack or floor to make it more rigid. - If reinforcing the rack or floor is impossible, modify the robot control program; doing so will reduce the vibration.
	<ul style="list-style-type: none"> - Vibration becomes more serious when the robot adopts a specific posture. - If the operating speed of the robot is reduced, vibration stops. - Vibration is most noticeable when the robot is accelerating. - Vibration occurs when two or more axes operate at the same time. 	[Overload] <ul style="list-style-type: none"> - It is likely that the load on the robot is greater than the maximum rating. - It is likely that the robot control program is too demanding for the robot hardware. - It is likely that the ACCELERATION value is excessive. 	<ul style="list-style-type: none"> - Check the maximum load that the robot can handle once more. If the robot is found to be overloaded, reduce the load, or modify the robot control program. - Vibration in a specific portion can be reduced by modifying the robot control program while slowing the robot and reducing its acceleration (to minimize the influence on the entire cycle time).

Symptom	Description	Cause	Measure
Vibration Noise (Continued)	<ul style="list-style-type: none"> - Vibration or noise was first noticed after the robot collided with an object or the robot was overloaded for a long period. - The grease of the vibrating or noise occurring axis has not been replaced for a long period. - Periodic vibration and noise occur. 	<p>[Gear, bearing, or reducer]</p> <ul style="list-style-type: none"> - It is likely that the collision or overload applied an excessive force to the drive system, thus damaged the gear tooth surface or rolling surface of a bearing, or reducer. - It is likely that prolonged use of the robot while overloaded caused fretting of the gear tooth surface or rolling surface of a bearing, or reducer due to resulting metal fatigue. - It is likely that foreign material caught in a gear, bearing, or within a reducer caused damage on the gear tooth surface or rolling surface of the bearing, or reducer. - It is likely that foreign material caught in a gear, bearing, or within a reducer caused vibration. - It is likely that, because the grease has not been replaced for a long period, fretting occurred on the gear tooth surface or rolling surface of a bearing, or reducer due to metal fatigue. 	<ul style="list-style-type: none"> - Operate one axis at a time to determine which axis is vibrating. - Remove the motor, and replace the gear, the bearing, and the reducer. For the spec. of parts and the method of replacement, contact your local FANUC representative. - Using the robot within its maximum rating prevents problems with the drive mechanism. - Supplying the specified grease at the recommended interval will prevent problems.

Symptom	Description	Cause	Measure
Vibration Noise (Continued)	- The cause of problem cannot be identified from examination of the floor, rack, or mechanical unit.	<p>[Controller, cable, and motor]</p> <ul style="list-style-type: none"> - If a failure occurs in a controller circuit, preventing control commands from being supplied to the motor normally, or preventing motor information from being sent to the controller normally, vibration might occur. - Pulsecoder defect may be the cause of the vibration as the motor cannot propagate the accurate position to the controller. - If the motor becomes defective, vibration might occur because the motor cannot deliver its rated performance. - If a power line in a movable cable of the mechanical unit has an intermittent break, vibration might occur because the motor cannot accurately respond to commands. - If a Pulsecoder wire in a movable part of the mechanical unit has an intermittent break, vibration might occur because commands cannot be sent to the motor accurately. - If a robot connection cable has an intermittent break, vibration might occur. - If the power supply cable is about to be snapped, vibration might occur. - If the power source voltage drops below the rating, vibration might occur. - It may vibrate when an invalid value parameter was set. 	<ul style="list-style-type: none"> - Refer to the Controller Maintenance Manual for troubleshooting related to the controller and amplifier. - Replace the motor of the axis that is vibrating, and check whether vibration still occurs. For the method of replacement, contact your local FANUC representative. - If vibration occurs only when the robot assumes a specific posture, it is likely that there is a mechanical problem. - Check whether the cable jacket of the robot connection cable is damaged. If so, replace the connection cable, and check whether vibration still occurs. - Check whether the power cable jacket is damaged. If so, replace the power cable, and check whether vibration still occurs. - Check that the robot is supplied with the rated voltage. - Check that the robot control parameter is set to a valid value. If it is set to an invalid value, correct it. Contact FANUC for further information if necessary.

Symptom	Description	Cause	Measure
Vibration Noise (Continued)	<ul style="list-style-type: none"> - There is some relationship between the vibration of the robot and the operation of a machine near the robot. 	[Noise from a nearby machine] <ul style="list-style-type: none"> - If the robot is not grounded properly, electrical noise can be induced on the grounding wire, preventing commands from being transferred accurately, thus leading to vibration. - If the robot is grounded at an unsuitable point, its grounding potential becomes unstable, and noise is likely to be induced on the grounding line, thus leading to vibration. 	<ul style="list-style-type: none"> - Connect the grounding wire firmly to ensure a reliable ground potential thereby preventing extraneous electrical noise.
	<ul style="list-style-type: none"> - There is an unusual sound after replacement of grease. - There is an unusual sound after a long period. - There is an unusual sound during operation at low speed. 	<ul style="list-style-type: none"> - There may be an abnormal noise when using other than the specified grease. - Even for the specified grease, there may be an abnormal noise during operation at low speed immediately after replacement or after a long time. 	<ul style="list-style-type: none"> - Use the specified grease. - When there is an abnormal noise even when using the specified grease, operate for one or two days as an experiment. Generally, any abnormal noise will disappear.
Rattling	<ul style="list-style-type: none"> - While the robot is not supplied with power, pushing it with the hand causes part of the mechanical unit to wobble. - There is a gap on the mounting surface of the mechanical unit. 	[Mechanical section coupling bolt] <ul style="list-style-type: none"> - It is likely that overloading or a collision has loosened a mounting bolt in the robot mechanical section. 	<ul style="list-style-type: none"> - Check that the following bolts for each axis are tight. If any of these bolts is loose, apply LOCTITE and tighten it to the appropriate torque. <ul style="list-style-type: none"> - Motor retaining bolt - Reducer retaining bolt - Reducer shaft retaining bolt - Base retaining bolt - Arm retaining bolt - Casting retaining bolt - End effector retaining bolt

Symptom	Description	Cause	Measure
Motor overheating	<ul style="list-style-type: none"> - The motor overheated due to a rise in temperature in the installation area. - After a cover was attached to the motor, the motor overheated. - After changing the Robot control program or the load, the motor overheat. 	<p>[Ambient temperature]</p> <ul style="list-style-type: none"> - It is likely that the motor overheated when the ambient temperature rose, and could not dissipate the heat. <p>[Operating condition]</p> <ul style="list-style-type: none"> - It is likely that the overcurrent above the specified permissive average current. 	<ul style="list-style-type: none"> - Reducing the ambient temperature is the most effective means of preventing overheat. - If there is a source of heat near the motor, it is advisable to install shielding to protect the motor from heat radiation. - Relaxing the robot control program and load condition is an effective way to reduce the average current. Thus, prevent overheating. - The teach pendant can monitor the average current. Check the average current when the robot control program launched.
	<ul style="list-style-type: none"> - After a control parameter (load setting etc.) was changed, the motor overheated. 	<p>[Parameter]</p> <ul style="list-style-type: none"> - If data input for a workpiece is invalid, the robot cannot be accelerate or decelerate normally, so the average current increases, leading to the motor overheating. 	<ul style="list-style-type: none"> - As for load setting, Input an appropriate parameter referring to Section 4.3.
	<ul style="list-style-type: none"> - Symptom other than stated above 	<p>[Mechanical section problems]</p> <ul style="list-style-type: none"> - It is likely that problems occurred in the mechanical unit drive mechanism, thus placing an excessive load on the motor. <p>[Motor problems]</p> <ul style="list-style-type: none"> - It is likely that a failure of the motor brake resulted in the motor running with the brake applied, thus placing an excessive load on the motor. - It is likely that a failure of the motor prevented it from delivering its rated performance, thus causing an excessive current to flow through the motor. 	<ul style="list-style-type: none"> - Repair the mechanical unit while referring to the above descriptions of vibration, noise, and rattling. - Check that, when the servo system is energized, the brake is released. If the brake remains applied to the motor all the time, replace the motor. - If the average current falls after the motor is replaced, it indicates that the first motor was faulty.

Symptom	Description	Cause	Measure
Grease leakage	<ul style="list-style-type: none"> - Grease is leaking from the mechanical unit. 	<p>[Poor sealing]</p> <ul style="list-style-type: none"> - Probable causes are a crack in the casting, a broken O-ring, a damaged oil seal, or a loose seal bolt. - A crack in a casting can occur due to excessive force that might be caused in collision. - An O-ring can be damaged if it is trapped or cut during disassembling or re-assembling. - An oil seal might be damaged if extraneous dust scratches the lip of the oil seal. - A loose seal bolt might allow grease to leak along the threads. - Problems with the grease nipple or threads. 	<ul style="list-style-type: none"> - If a crack develops in the casting, sealant can be used as a quick-fix to prevent further grease leakage. However, the component should be replaced as soon as possible, because the crack might extend. - O-rings are used in the locations listed below. <ul style="list-style-type: none"> - Motor coupling section - Reducer (case and shaft) coupling section - Wrist coupling section - J3 arm coupling section - Inside the wrist - Oil seals are used in the locations stated below. <ul style="list-style-type: none"> - Inside the reducer - Inside the wrist - Seal bolts are used in the locations stated below. <ul style="list-style-type: none"> - Grease outlet - Replace the grease nipple.
Dropping axis	<ul style="list-style-type: none"> - An axis falls because the brake went out. - An axis falls while standing still. 	<p>[Brake drive relay and motor]</p> <ul style="list-style-type: none"> - It is likely that brake drive relay contacts are stuck to each other and keep the brake current flowing, thus preventing the brake from operating when the motor is reenergized. - It is likely that the brake shoe has worn out or the brake main body is damaged, preventing the brake from operating efficiently. - It is likely that oil or grease soak through the motor, causing the brake to slip. 	<ul style="list-style-type: none"> - Check whether the brake drive relays are stuck to each other or not. If they are found to be stuck, replace the relays. - Replace the motor after confirming whether the following symptoms have occurred. <ul style="list-style-type: none"> - Brake shoe is worn out - Brake main body is damaged - Oil soaked through the motor

Symptom	Description	Cause	Measure
Displacement	<ul style="list-style-type: none"> - The robot moves to a point other than the taught position. - The repeatability is not within the tolerance. 	[Mechanical section problems] <ul style="list-style-type: none"> - If the repeatability is unstable, probable causes are a failure in the drive mechanism or a loose bolt. - If the repeatability becomes stable, it is likely that a collision imposed an excessive load, leading to slipping on the base surface or the mating surface of an arm or reducer. - It is likely that the Pulsecoder is faulty. 	<ul style="list-style-type: none"> - If the repeatability is unstable, repair the mechanical section by referring to the above descriptions of vibration, noise, and rattling. - If the repeatability is stable, correct the taught program. The problem will not reoccur unless another collision occurs. - If the Pulsecoder is faulty, replace the motor.
	<ul style="list-style-type: none"> - Displacement occurs only in specific peripheral equipment. 	[Peripheral equipment displacement] <ul style="list-style-type: none"> - It is likely that an external force was applied to the peripheral equipment, thus shifting its position relative to the robot. 	<ul style="list-style-type: none"> - Correct the setting of the peripheral equipment position. - Correct the taught program.
	<ul style="list-style-type: none"> - Displacement occurred after a parameter was changed. 	[Parameter] <ul style="list-style-type: none"> - It is likely that the mastering data was rewritten in such a way that the robot origin was shifted. 	<ul style="list-style-type: none"> - Re-enter the previous mastering data, which is known to be correct. - If correct mastering data is unavailable, perform mastering again.

Symptom	Description	Cause	Measure
CLALM alarm occurred. Move error excess alarm occurred.	<ul style="list-style-type: none"> - CLALM alarm is displayed on the teach pendant screen, because ambient temperature of the robot installation location is low, - "Move error excess" alarm is displayed on the teach pendant screen, because ambient temperature of the robot installation position is low 	<p>[Peripheral temperature]</p> <ul style="list-style-type: none"> - When the robot is used in a low temperature environment that is near to 0°C, or the robot is not operated for a long time in an environment that is less than 0°C, there will be a large viscous resistance of the drive train immediately after starting which will cause the alarm. 	<ul style="list-style-type: none"> - Perform a warm up operation or a low speed operation for several minutes.
	<ul style="list-style-type: none"> - After changing the motion program or the load condition, the CLALM alarm is displayed. - After changing the motion program or the load condition, the "Move error excess" alarm is displayed. 	<ul style="list-style-type: none"> - It is likely that a robot collision occurred. 	<ul style="list-style-type: none"> - If a robot collision has occurred, press the [RESET] key while pressing the [SHIFT] key. Then, jog the robot in the opposite direction while pressing the [SHIFT] key. - Check the motion program.
		<p>[Overload]</p> <ul style="list-style-type: none"> - It is likely that load exceeded the permissible value. - It is likely that the motion program is too severe for the robot. <ul style="list-style-type: none"> • Excessive motion due to a large "ACC (value)". • Tight motion such as reverse motion using "CNT". • Linear motion occurs near singularity point where axes revolve in high speed. 	<ul style="list-style-type: none"> - Check the permissible value of the robot payload. If the load exceeds the permissible value, reduce the load or change the motion program. - Consider minimizing the cycle time by reducing the speed or acceleration, and changing the motion program. - Check that the load setting is performed correctly.
	<ul style="list-style-type: none"> - None of the symptoms stated above are the problem. 	<ul style="list-style-type: none"> - It is likely the vibration occurred. 	<ul style="list-style-type: none"> - Refer to the Symptoms: Vibration, Noise section of this troubleshooting for more information.
		<ul style="list-style-type: none"> - If the power source voltage drops below the rating, a vibration might occur. 	<ul style="list-style-type: none"> - Check that the robot is supplied with the proper rated voltage.
BZAL alarm occurred.	<ul style="list-style-type: none"> - BZAL is displayed on the teach pendant screen. 	<ul style="list-style-type: none"> - It is likely that the voltage of the memory backup battery is low. - It is likely that the Pulsecoder cable is defective. 	<ul style="list-style-type: none"> - Replace the battery. - Replace the cable.

11 SEVERE DUST/LIQUID PROTECTION PACKAGE (OPTION)

11.1 OVERVIEW

The package is intended to improve the Severe dust/liquid protection characteristics of the robot so that it can be used in a severe environment.

NOTE

Contact your FANUC representative for confirmation that the Severe dust/liquid protection package is suitable for your environment.

Model	Severe dust/liquid protection specification
M-710iC/20L	A05B-1125-J808 (*1)
	A05B-1125-J818 (*2)
	A05B-1125-J826 (*3)

(*1) When mechanical unit cable for camera is not selected.

(*2) When mechanical unit cable for camera (A05B-1125-H451) is selected.

(*3) When mechanical unit cable for camera (A05B-1125-H452) is selected.

11.2 CONFIGURATION OF THE SEVERE DUST/LIQUID PROTECTION PACKAGE

The following table lists the major differences between the M-710iC/20L standard specification and Severe dust/liquid protection package.

	Standard specification	Severe dust/liquid protection option
Bolts	Dyed black steel bolt	FR coating bolt Stainless bolt
Washer	Dyed black washer	Black chrome washer
Cover		J2 cover Battery box cover
EE connector	Non-waterproof connector	Waterproof connector
Others		Gaskets are added.




Fig. 11.2 (a) Configuration of the Severe dust/liquid protection package of M-710iC/20L

APPENDIX

A

PERIODIC MAINTENANCE TABLE

FANUC Robot M-710iC/20L/20M

Periodic Maintenance Table

Items		Accumulated operating time (H)	Check time	Grease amount	First check 320	3 months 960	6 months 1920	9 months 2880	1 year 3840	4800	5760	6720	2 years 7680	8640	9600	10560
Mechanical unit	1	Check for external damage or peeling paint	0.1H	—		○	○	○	○	○	○	○	○	○	○	○
	2	Check for water	0.1H	—		○	○	○	○	○	○	○	○	○	○	○
	3	Check the mechanical cable (damaged or twisted)	0.2H	—					○				○			
	4	Check the end effector (hand) cable	0.1H	—		○			○				○			
	5	Check the motor connector and exposed connector (loosening)	0.2H	—					○				○			
	6	Tighten the end effector bolt	0.1H	—		○			○				○			
	7	Tighten the cover and main bolt	1.0H	—		○			○				○			
	8	Check the mechanical stopper and adjustable mechanical stopper	0.1H	—		○			○				○			
	9	Clean spatters, sawdust and dust	1.0H	—		○			○				○			
	10	Replacing batteries *3	0.1H	—							●					
	11	Replacing grease of J1 axis reducer	0.5H	3300ml												
	12	Replacing grease of J2 axis reducer	0.5H	1660ml												
	13	Replacing grease of J3 axis reducer	0.5H	1060ml												
	14	Replacing grease of J4 axis gearbox	0.5H	1000ml												
	15	Replacing grease of J5 axis gearbox	0.5H	440ml												
	16	Greasing of J6 axis reducer	0.2H	40ml					●				●			
	17	Replacing cable of mechanical unit	4.0H	—												
Controller	18	Check the robot cable, teach pendant cable and robot connecting cable	0.2H	—		○			○				○			
	19	Cleaning the controller ventilation system	0.2H	—	○	○	○	○	○	○	○	○	○	○	○	○
	20	Replacing batteries *1 *3	0.1H	—												

*1 Refer to the “REPLACING UNITS Chapter of MAINTENANCE” in the following manuals.

R-30iA CONTROLLER MAINTENANCE MANUAL (Standard) (B-82595EN),
 R-30iA CONTROLLER MAINTENANCE MANUAL (For Europe) (B-82595EN-1),
 R-30iA CONTROLLER MAINTENANCE MANUAL (For RIA) (B-82595EN-2),
 R-30iB/R-30iB Plus CONTROLLER MAINTENANCE MANUAL (B-83195EN),
 R-30iB Mate/R-30iB Mate Plus CONTROLLER MAINTENANCE MANUAL (B-83525EN)

*2 ●: requires order of parts

○: does not require order of parts

*3 Regardless of the operating time, replace the mechanical unit batteries at 1.5 year, replace controller batteries at 4 years.

3 years 11520	12480	13440	14400	4 years 15360	16320	17280	18240	5 years 19200	20160	21120	22080	6 years 23040	24000	24960	25920	7 years 26880	27840	28800	29760	8 years 30720	Item
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	Overhaul	1
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		2
○				○				○				○				○					3
○				○				○				○				○					4
○				○				○				○				○					5
○				○				○				○				○					6
○				○				○				○				○					7
○				○				○				○				○					8
○				○				○				○				○					9
●						●						●						●			10
●												●									11
●												●									12
●												●									13
●												●									14
●												●									15
●				●				●				●				●					16
				●																	17
○				○				○				○				○					18
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		19
				●																	20

FANUC Robot M-710iC/12L

Periodic Maintenance Table

Items		Accumulated operating time (H)	Check time	Oil Grease amount	First check 320	3 months 960	6 months 1920	9 months 2880	1 year 3840	4800	5760	6720	2 years 7680	8640	9600	10560
Mechanical unit	1	Check for external damage or peeling paint	0.1H	-		○	○	○	○	○	○	○	○	○	○	○
	2	Check for water	0.1H	-		○	○	○	○	○	○	○	○	○	○	○
	3	Check the mechanical cable (Damaged or twisted)	0.2H	-		○			○				○			
	4	Check the end effector (hand) cable	0.1H	-		○			○				○			
	5	Check the motor connector and exposed connector (loosening)	0.2H	-		○			○				○			
	6	Tighten the end effector bolt	0.1H	-		○			○				○			
	7	Tighten the cover and main bolt	1.0H	-		○			○				○			
	8	Check the mechanical stopper and adjustable mechanical stopper	0.1H	-		○			○				○			
	9	Clean spatters, sawdust and dust	1.0H			○			○				○			
	10	Check the oil sight glass of J5/J6 axes	0.1H	-	○	○	○	○	○	○	○	○	○	○	○	○
	11	Replacing batteries *3	0.1H	-							●					
	12	Replacing grease of J1 axis reducer	0.5H	3300ml												
	13	Replacing grease of J2 axis reducer	0.5H	1660ml												
	14	Replacing grease of J3 axis reducer	0.5H	1060ml												
	15	Replacing oil of J4 axis gearbox	0.5H	1480ml												
	16	Replacing oil of J5 and J6 axis gearbox	0.5H	390ml												
	17	Replacing cable of mechanical unit	4.0H	-												
	18	Replacing M/H(Material Handling) conduit (option)	1.0H	-									●			
	19	Check broken of fluoric resin ring.	0.1H	-	○	○	○	○	○	○	○	○	●	○	○	○
Controller	20	Check the robot cable, teach pendant cable and robot connecting cable	0.2H	-		○			○				○			
	21	Cleaning the controller ventilation system	0.2H	-	○	○	○	○	○	○	○	○	○	○	○	○
	22	Replacing batteries *1 *3	0.1H	-												

*1 Refer to the “REPLACING UNITS Chapter of MAINTENANCE” in the following manuals.

R-30iB/R-30iB Plus CONTROLLER MAINTENANCE MANUAL (B-83195EN),

R-30iB Mate/R-30iB Mate Plus CONTROLLER MAINTENANCE MANUAL (B-83525EN)

*2 ●: requires order of parts

○: does not require order of parts

*3 Regardless of the operating time, replace the mechanical unit batteries at 1.5 year, replace controller batteries at 4 years.

3 years 11520	12480	13440	14400	4 years 15360	16320	17280	18240	5 years 19200	20160	21120	22080	6 years 23040	24000	24960	25920	7 years 26880	27840	28800	29760	8 years 30720	Item
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	Overhaul	1
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		2
○				○				○				○				○					3
○				○				○				○				○					4
○				○				○				○				○					5
○				○				○				○				○					6
○				○				○				○				○					7
○				○				○				○				○					8
○				○				○				○				○					9
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		10
●						●						●						●			11
●												●									12
●												●									13
●												●									14
●												●									15
●												●									16
				●																	17
				●								●									18
○	○	○	○	●	○	○	○	○	○	○	○	●	○	○	○	○	○	○	○		19
○				○				○				○				○					20
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		21
				●																	22

B STRENGTH OF BOLT AND BOLT TORQUE LIST

NOTE

When applying LOCTITE to a part, spread the LOCTITE on the entire length of the engaging part of the female thread. If applied to the male threads, poor adhesion can occur, potentially loosening the bolt. Clean the bolts and the threaded holes and wipe off any oil on the engaging section. Make sure that there is no solvent left in the threaded holes. When finished, remove all the excess LOCTITE when you are finished screwing the bolts into the threaded holes.

Use the following strength bolts. Comply with any bolt specification instructions.

Hexagon socket head bolt made of steel:

Size M22 or less: Tensile strength 1200N/mm² or more

Size M24 or more: Tensile strength 1000N/mm² or more

All size plating bolt: Tensile strength 1000N/mm² or more




Hexagon bolt, stainless bolt, special shape bolt (button bolt, low-head bolt, flush bolt .etc.)

Tensile strength 400N/mm² or more

Refer to the following tables if the bolts tightening torque is not specified.

Recommended bolt tightening torques

Unit: Nm

Nominal diameter	Hexagon socket head bolt (steel)		Hexagon socket head bolt (stainless)		Hexagon socket head button bolt Hexagon socket head flush bolt Low-head bolt (steel)		Hexagon bolt (steel)	
	Tightening torque		Tightening torque		Tightening torque		Tightening torque	
	Upper limit	Lower limit	Upper limit	Lower limit	Upper limit	Lower limit	Upper limit	Lower limit
M3	1.8	1.3	0.76	0.53	—	—	—	—
M4	4.0	2.8	1.8	1.3	1.8	1.3	1.7	1.2
M5	7.9	5.6	3.4	2.5	4.0	2.8	3.2	2.3
M6	14	9.6	5.8	4.1	7.9	5.6	5.5	3.8
M8	32	23	14	9.8	14	9.6	13	9.3
M10	66	46	27	19	32	23	26	19
M12	110	78	48	33	—	—	45	31
(M14)	180	130	76	53	—	—	73	51
M16	270	190	120	82	—	—	98	69
(M18)	380	260	160	110	—	—	140	96
M20	530	370	230	160	—	—	190	130
(M22)	730	510	—	—	—	—	—	—
M24	930	650	—	—	—	—	—	—
(M27)	1400	960	—	—	—	—	—	—
M30	1800	1300	—	—	—	—	—	—
M36	3200	2300	—	—	—	—	—	—
								

C INSULATION ABOUT ARC WELDING ROBOT

The arc welding robot performs welding, using a welding torch attached to its end effector mounting face via a bracket. Because a high welding current flows through the welding torch, the insulating material must not permit bolting directly from the welding torch bracket to mounting face plate.

If no due consideration is taken, a poor insulation caused by a pileup of spatter can allow the welding current to leak into robot mechanical units, possibly damaging the motor or melting the mechanical unit cable jackets.

C.1 INSULATION AT THE WRIST

Please be careful to the following contents.

- Insulate the end effector mounting surface. Insulation material which is inserted between the end effector mounting surface and the welding torch bracket must be different, and bolt them separately referring to Fig. C.1 (a).
- Insert the insulating material between the torch bracket and faceplate to ensure the two are electrically isolated. When installing the insulating material, be sure to set the crack in the torch holder away from that of the insulating material to prevent spatter from getting in the cracks.
- Allow a sufficient distance (at least 5 mm) at the insulating materials in case a pileup of spatter should occur.




Fig.C.1 (a) Insulation at the wrist

- Even after the insulation is reinforced, it is likely that, if a pileup of spatter grows excessively, current may leak. Periodically remove the spatter.

C.2 INSULATION AT THE ADDITIONAL AXIS

If welding fixtures are installed to the additional axis, Perform insulation against between welding fixtures and the additional axis to prevent welding electric current intrusion. If the follower unit is used, perform insulation against between welding fixtures and follower unit to prevent welding electric current intrusion into the housing.




Fig. C.2 (a) Insulation at the additional axis

INDEX

<A>

ABOUT SWITCHING BETWEEN MOVEMENT TYPES	28
ADJUSTABLE MECHANICAL STOPPER AND LIMIT SWITCH SETTING (OPTION)	69
ADJUSTING LIMIT SWITCH (OPTION)	77
AIR PIPING (OPTION)	51
AIR SUPPLY (OPTION)	50
Angle of Mounting Surface Setting	9
AXIS LIMITS SETUP	65

BASIC SPECIFICATIONS	13
----------------------------	----

<C>

CHANGE AXIS LIMIT BY DCS (OPTION)	66
CHANGING THE MOTION RANGE BY THE LIMIT SWITCH (OPTION)	76
Changing the parameter setting	73
Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper	85,103
CHECK POINTS	81,99
Check the Failure of the Wrist Part Fluoric Resin Ring	101
Check the Mechanical Unit Cables and Connectors	83,102
Check the Oil Sight Glasses	101
CHECKS AND MAINTENANCE	95
CHECKS AND MAINTENANCE (M-710iC/12L)	95
CHECKS AND MAINTENANCE (M-710iC/20L/20M)	78
CHECKS AND MAINTENANCE	78
CONFIGURATION OF THE SEVERE DUST/LIQUID PROTECTION PACKAGE	142
Confirmation of Oil Seepage	81,99
Confirmation of the Air Control Set	100
Confirmation of the Air Control Set (option)	82
CONNECTION WITH THE CONTROLLER	12

<D>

Daily Checks	78,95
--------------------	-------

<E>

END EFFECTOR INSTALLATION TO WRIST	43
EQUIPMENT INSTALLATION TO THE ROBOT	43
EQUIPMENT MOUNTING FACE	45

<G>

Grease replacement procedure for the J4-axis gearbox ..	92
Grease replacement procedure for the J5-axis gearbox ..	92
Grease replacement procedure of the J1, J2, J3-axis reducer	90
Grease replacement procedure of the J1, J2, J3-axis reducer and J4-axis gearbox	105
Greasing	87

</>

INSTALLATION	6
INSTALLATION CONDITIONS	11
Installation Method	7
Installing adjustable mechanical stopper option	70
INSULATION ABOUT ARC WELDING ROBOT	151
INSULATION AT THE ADDITIONAL AXIS	152
INSULATION AT THE WRIST	151
INTERFACE FOR OPTION CABLE (OPTION)	52

<L>

LOAD CONDITIONS ON J3 CASING	27
LOAD SETTING	47

<M>

MAINTENANCE	86,104
MAINTENANCE AREA	11
MASTERING	115
MASTERING DATA ENTRY	130
MECHANICAL UNIT OPERATING SPACE AND INTERFERENCE AREA	17

<O>

Oil replacement procedure for the J5/J6- axis gearbox ..	109
OPERATING SPACE FOR WALL/INCLINED SURFACE MOUNTED ROBOTS	30
OVERVIEW	115,141

<P>

Periodic Check and Maintenance	79,96
PERIODIC MAINTENANCE TABLE	145
PIPING AND WIRING TO THE END EFFECTOR	49
PREFACE	p-1
Procedure for releasing remaining pressure from the grease bath (J1 to J4-axis)	109
Procedure for releasing remaining pressure from the oil bath (J5/J6-axis)	114
Procedure for releasing remaining pressure within the grease bath	93

<Q>

QUICK MASTERING	121
QUICK MASTERING FOR SINGLE AXIS	123

<R>

Replacing the Batteries (1.5 Year checks)	86,104
Replacing the Grease and Oil of the Drive Mechanism (3-years (11520 Hours) Checks)	105
Replacing the Grease of the Drive Mechanism (3-years (11520 Hours) Checks)	88
RESETTING ALARMS AND PREPARING FOR MASTERING	116
ROBOT CONFIGURATION	13

<S>

SAFETY PRECAUTIONS	s-1
SEVERE DUST/LIQUID PROTECTION PACKAGE (OPTION).....	141
SINGLE AXIS MASTERING	126
STORAGE	94,114
STRENGTH OF BOLT AND BOLT TORQUE LIST	150

<T>

The maximum stopping distance (position) of adjustable mechanical stopper	74
TRANSPORTATION	1
TRANSPORTATION AND INSTALLATION.....	1
Transportation with an End Effector Attached.....	5
TROUBLESHOOTING	133

<V>

VERIFYING MASTERING	132
---------------------------	-----

<W>

WRIST LOAD CONDITIONS	25
-----------------------------	----

<Z>

ZERO POINT POSITION AND MOTION LIMIT	20
ZERO POSITION MASTERING	117

REVISION RECORD

Edition	Date	Contents
10	Mar., 2022	<ul style="list-style-type: none"> • Addition of M-710iC/20L (A05B-1125-B255) and M-710iC/12L (A05B-1125-B256) • Correction of errors
09	Jul., 2017	<ul style="list-style-type: none"> • Addition of R-30iB Plus, R-30iB Mate Plus Controller • Correction of errors
08	Jan.,2016	<ul style="list-style-type: none"> • Addition of M-710iC/20M • Addition of quick mastering for single axis • Correction of errors
07	Aug.,2014	<ul style="list-style-type: none"> • Addition of M-710iC/12L • Correction of errors
06	Mar.,2014	<ul style="list-style-type: none"> • Addition of R-30iB Mate • Addition of note for IP ratio • Correction of errors
05	Apr.,2012	<ul style="list-style-type: none"> • Addition of R-30iB • Addition of note for low temperature • Change of specification of mechanical unit cables • Addition of check of oil seepage • Correction of errors
04	Jun.,2010	<ul style="list-style-type: none"> • Addition of stop type of robot • Addition of stopping time and distance when control stop is executed • Addition of stopping distance of stopper. • Addition of check of stopper • Corrections of errors
03	Jan.,2008	<ul style="list-style-type: none"> • Addition of Procedure to move arm without drive power in emergency or abnormal situations • Addition of notes on transportation with an end effector attached • Addition of cable for sensor and severe dust/liquid protection package • Addition of Stopping time and distance when emergency stop
02	Sep., 2007	<ul style="list-style-type: none"> • Change the name of controller (from R-J3iC to R-30iA) • Addition of severe dust/liquid protection package • Corrections of errors
01	Aug., 2006	

B-82514EN/10

