

# **FANUC Robot series**

**R-30*i*B/R-30*i*B Mate CONTROLLER**

***i*RVision**

**OPERATOR'S MANUAL (Reference)**

**B-83304EN/04**

- **Original Instructions**

Thank you very much for purchasing FANUC Robot.

Before using the Robot, be sure to read the "FANUC Robot SAFETY HANDBOOK (B-80687EN)" and understand the content.

- No part of this manual may be reproduced in any form.
- The appearance and specifications of this product are subject to change without notice.

The products in this manual are controlled based on Japan's "Foreign Exchange and Foreign Trade Law". The export from Japan may be subject to an export license by the government of Japan. Further, re-export to another country may be subject to the license of the government of the country from where the product is re-exported. Furthermore, the product may also be controlled by re-export regulations of the United States government. Should you wish to export or re-export these products, please contact FANUC for advice.

In this manual, we endeavor to include all pertinent matters. There are, however, a very large number of operations that must not or cannot be performed, and if the manual contained them all, it would be enormous in volume. It is, therefore, requested to assume that any operations that are not explicitly described as being possible are "not possible".

# SAFETY PRECAUTIONS

---

This chapter describes the precautions which must be followed to ensure the safe use of the robot. Before using the robot, be sure to read this chapter thoroughly.

For detailed functions of the robot operation, read the relevant operator's manual to understand fully its specification.

For the safety of the operator and the system, follow all safety precautions when operating a robot and its peripheral equipments installed in a work cell.

In addition, refer to the "FANUC Robot SAFETY HANDBOOK (B-80687EN)".

## 1 DEFINITION OF USER

---

The personnel can be classified as follows.

**Operator:**

- Turns the robot controller power on/off
- Starts the robot program from operator panel

**Programmer:**

- Operates the robot
- Teaches the robot inside the safety fence

**Maintenance engineer:**

- Operates the robot
- Teaches the robot inside the safety fence
- Maintenance (repair, adjustment, replacement)



- Operator is not allowed to work in the safety fence.
- Programmer and maintenance engineer is allowed to work in the safety fence. Works carried out in the safety fence include transportation, installation, teaching, adjustment, and maintenance.
- To work inside the safety fence, the person must be trained on proper robot operation.

During the operation, programming, and maintenance of your robotic system, the programmer, operator, and maintenance engineer should take additional care of their safety by wearing the following safety items.

- Adequate clothes for the operation
- Safety shoes
- A helmet

## 2 DEFINITION OF SAFETY NOTATIONS

To ensure the safety of users and prevent damage to the machine, this manual indicates each precaution on safety with "WARNING" or "CAUTION" according to its severity. Supplementary information is indicated by "NOTE". Read the contents of each "WARNING", "CAUTION" and "NOTE" before using the robot.

Symbol	Definitions
 <b>WARNING</b>	Used if hazard resulting in the death or serious injury of the user will be expected to occur if he or she fails to follow the approved procedure.
 <b>CAUTION</b>	Used if a hazard resulting in the minor or moderate injury of the user, or equipment damage may be expected to occur if he or she fails to follow the approved procedure.
<b>NOTE</b>	Used if a supplementary explanation not related to any of WARNING and CAUTION is to be indicated.

- Check this manual thoroughly, and keep it handy for the future reference.

## 3 SAFETY OF THE USER

User safety is the primary safety consideration. Because it is very dangerous to enter the operating space of the robot during automatic operation, adequate safety precautions must be observed.

The following lists the general safety precautions. Careful consideration must be made to ensure user safety.

- (1) Have the robot system users attend the training courses held by FANUC.

FANUC provides various training courses. Contact our sales office for details.
--

- (2) Even when the robot is stationary, it is possible that the robot is still in a ready to move state, and is waiting for a signal. In this state, the robot is regarded as still in motion. To ensure user safety, provide the system with an alarm to indicate visually or aurally that the robot is in motion.
- (3) Install a safety fence with a gate so that no user can enter the work area without passing through the gate. Install an interlocking device, a safety plug, and so forth in the safety gate so that the robot is stopped as the safety gate is opened.

The controller is designed to receive this interlocking signal of the door switch. When the gate is opened and this signal received, the controller stops the robot (Please refer to "STOP TYPE OF ROBOT" in "SAFETY PRECAUTIONS" for detail of stop type). For connection, see Fig. 3 (b).
---

- (4) Provide the peripheral equipments with appropriate earth (Class A, Class B, Class C, and Class D).
- (5) Try to install the peripheral equipments outside the robot operating space.
- (6) Draw an outline on the floor, clearly indicating the range of the robot operating space, including the tools such as a hand.
- (7) Install a mat switch or photoelectric switch on the floor with an interlock to a visual or aural alarm that stops the robot when a user enters the work area.
- (8) If necessary, install a safety lock so that no one except the user in charge can turn on the power of the robot.

The circuit breaker installed in the controller is designed to disable anyone from turning it on when it is locked with a padlock.
--

- (9) When adjusting each peripheral equipment independently, be sure to turn off the power of the robot.
- (10) Operators should be ungloved while manipulating the operator panel or teach pendant. Operation with gloved fingers could cause an operation error.
- (11) Programs, system variables, and other information can be saved on memory card or USB memories. Be sure to save the data periodically in case the data is lost in an accident. (refer to Controller OPERATOR'S MANUAL.)
- (12) The robot should be transported and installed by accurately following the procedures recommended by FANUC. Wrong transportation or installation may cause the robot to fall, resulting in severe injury to workers.
- (13) In the first operation of the robot after installation, the operation should be restricted to low speeds. Then, the speed should be gradually increased to check the operation of the robot.
- (14) Before the robot is started, it should be checked that no one is inside the safety fence. At the same time, a check must be made to ensure that there is no risk of hazardous situations. If detected, such a situation should be eliminated before the operation.
- (15) When the robot is used, the following precautions should be taken. Otherwise, the robot and peripheral equipment can be adversely affected, or workers can be severely injured.
  - Avoid using the robot in a flammable environment.
  - Avoid using the robot in an explosive environment.
  - Avoid using the robot in an environment full of radiation.
  - Avoid using the robot under water or at high humidity.
  - Avoid using the robot to carry a person or animal.
  - Avoid using the robot as a stepladder. (Never climb up on or hang from the robot.)
- (16) When connecting the peripheral equipments related to stop (safety fence etc.) and each signal (external emergency, fence etc.) of robot, be sure to confirm the stop movement and do not take the wrong connection.
- (17) When preparing footstep, please consider security for installation and maintenance work in high place according to Fig. 3 (c). Please consider footstep and safety belt mounting position.




Fig. 3 (a) Safety fence and safety gate

**⚠ WARNING**

When you close a fence, please confirm that there is not a person from all directions of the robot.




Fig. 3 (b) Connection diagram for the signal of safety fence




Fig. 3 (c) Pedestal for maintenance

### 3.1 SAFETY OF THE OPERATOR

An operator refers to a person who turns on and off the robot system and starts a robot program from, for example, the operator panel during daily operation. Operators cannot work inside of the safety fence.

- (1) If the robot does not need to be operated, turn off the robot controller power or press the EMERGENCY STOP button during working.
- (2) Operate the robot system outside the operating space of the robot.
- (3) Install a safety fence or safety door to avoid the accidental entry of a person other than an operator in charge or keep operator out from the hazardous place.
- (4) Install one or more necessary quantity of EMERGENCY STOP button(s) within the operator's reach in appropriate location(s) based on the system layout.

The robot controller is designed to be connected to an external EMERGENCY STOP button. With this connection, the controller stops the robot operation (Please refer to "STOP TYPE OF ROBOT" in "SAFETY PRECAUTIONS" for detail of stop type) when the external EMERGENCY STOP button is pressed. See the diagram below for connection.




Fig. 3.1 Connection diagram for external emergency stop button

## 3.2 SAFETY OF THE PROGRAMMER

While teaching the robot, the operator must enter the robot operation area. The programmer must ensure the safety especially.

- (1) Unless it is specifically necessary to enter the robot operating space, carry out all tasks outside the operating space.
- (2) Before teaching the robot, check that the robot and its peripheral equipments are all in the normal operating condition.
- (3) If it is inevitable to enter the robot operating space to teach the robot, check the locations, settings, and other conditions of the safety devices (such as the EMERGENCY STOP button, the DEADMAN switch on the teach pendant) before entering the area.
- (4) The programmer must be extremely careful not to let anyone else enter the robot operating space.
- (5) Programming should be done outside the area of the safety fence as far as possible. If programming needs to be done inside the safety fence, the programmer should take the following precautions:
  - Before entering the area of the safety fence, ensure that there is no risk of dangerous situations in the area.
  - Be prepared to press the emergency stop button whenever necessary.
  - Robot motions should be made at low speeds.
  - Before starting programming, check the whole robot system status to ensure that no remote instruction to the peripheral equipment or motion would be dangerous to the user.

Our operator panel is provided with an emergency stop button and a key switch (mode switch) for selecting the automatic operation (AUTO) and the teach modes (T1 and T2). Before entering the inside of the safety fence for the purpose of teaching, set the switch to a teach mode, remove the key from the mode switch to prevent other people from changing the operation mode carelessly, then open the safety gate. If the safety gate is opened with the automatic operation set, the robot stops (Please refer to "STOP TYPE OF ROBOT" in "SAFETY PRECAUTIONS" for detail of stop type). After the switch is set to a teach mode, the safety gate is disabled. The programmer should understand that the safety gate is disabled and is responsible for keeping other people from entering the inside of the safety fence.

Our teach pendant is provided with a DEADMAN switch as well as an emergency stop button. These button and switch function as follows:

- (1) Emergency stop button: Causes the stop of the robot (Please refer to "STOP TYPE OF ROBOT" in "SAFETY PRECAUTIONS" for detail of stop type) when pressed.
- (2) DEADMAN switch: Functions differently depending on the teach pendant enable/disable switch setting status.
  - (a) Enable: Servo power is turned off when the operator releases the DEADMAN switch or when the operator presses the switch strongly.
  - (b) Disable: The DEADMAN switch is disabled.(Note) The DEADMAN switch is provided to stop the robot when the operator releases the teach pendant or presses the pendant strongly in case of emergency. The R-30iB/R-30iB Mate employs a 3-position DEADMAN switch, which allows the robot to operate when the 3-position DEADMAN switch is pressed to its intermediate point. When the operator releases the DEADMAN switch or presses the switch strongly, the robot stops immediately.

The operator's intention of starting teaching is determined by the controller through the dual operation of setting the teach pendant enable/disable switch to the enable position and pressing the DEADMAN switch. The operator should make sure that the robot could operate in such conditions and be responsible in carrying out tasks safely.

Based on the risk assessment by FANUC, number of operation of DEADMAN SW should not exceed about 10000 times per year.



The teach pendant, operator panel, and peripheral equipment interface send each robot start signal. However the validity of each signal changes as follows depending on the mode switch and the DEADMAN switch of the operator panel, the teach pendant enable switch and the remote condition on the software.

Mode	Teach pendant enable switch	Software remote condition	Teach pendant	Operator panel	Peripheral equipment
AUTO mode	On	Local	Not allowed	Not allowed	Not allowed
		Remote	Not allowed	Not allowed	Not allowed
	Off	Local	Not allowed	Allowed to start	Not allowed
		Remote	Not allowed	Not allowed	Allowed to start
T1, T2 mode	On	Local	Allowed to start	Not allowed	Not allowed
		Remote	Allowed to start	Not allowed	Not allowed
	Off	Local	Not allowed	Not allowed	Not allowed
		Remote	Not allowed	Not allowed	Not allowed

**T1,T2 mode: DEADMAN switch is effective.**

- (6) To start the system using the operator box or operator panel, make certain that nobody is the robot operating space area and that there are no abnormalities in the robot operating space.
- (7) When a program is completed, be sure to carry out a test operation according to the following procedure.
  - (a) Run the program for at least one operation cycle in the single step mode at low speed.
  - (b) Run the program for at least one operation cycle in continuous operation at low speed.
  - (c) Run the program for one operation cycle in continuous operation at the intermediate speed and check that no abnormalities occur due to a delay in timing.
  - (d) Run the program for one operation cycle in continuous operation at the normal operating speed and check that the system operates automatically without trouble.
  - (e) After checking the completeness of the program through the test operation above, execute it in the automatic operation.
- (8) While operating the system in the automatic operation, the programmer should leave the safety fence.

### 3.3 SAFETY OF THE MAINTENANCE ENGINEER

For the safety of maintenance engineer personnel, pay utmost attention to the following.

- (1) During operation, never enter the robot operating space.
- (2) A hazardous situation may arise when the robot or the system, are kept with their power-on during maintenance operations. Therefore, for any maintenance operation, the robot and the system should be put into the power-off state. If necessary, a lock should be in place in order to prevent any other person from turning on the robot and/or the system. In case maintenance needs to be executed in the power-on state, the emergency stop button must be pressed.
- (3) If it becomes necessary to enter the robot operating space while the power is on, press the emergency stop button on the operator box or operator panel, or the teach pendant before entering the range. The maintenance worker must indicate that maintenance work is in progress and be careful not to allow other people to operate the robot carelessly.
- (4) When entering the area enclosed by the safety fence, the worker must check the whole robot system in order to make sure no dangerous situations exist. In case the worker needs to enter the safety area whilst a dangerous situation exists, extreme care must be taken, and whole robot system status must be carefully monitored.
- (5) Before the maintenance of the pneumatic system is started, the supply pressure should be shut off and the pressure in the piping should be reduced to zero.
- (6) Before the start of maintenance work, check that the robot and its peripheral equipments are all in the normal operating condition.

- (7) Do not operate the robot in the automatic operation while anybody is in the robot operating space.
- (8) When you maintain the robot alongside a wall or instrument, or when multiple users are working nearby, make certain that their escape path is not obstructed.
- (9) When a tool is mounted on the robot, or when any movable device other than the robot is installed, such as belt conveyor, pay careful attention to its motion.
- (10) If necessary, have a user who is familiar with the robot system stand beside the operator panel and observe the work being performed. If any danger arises, the user should be ready to press the EMERGENCY STOP button at any time.
- (11) When replacing a part, please contact your local FANUC representative. If a wrong procedure is followed, an accident may occur, causing damage to the robot and injury to the user.
- (12) When replacing or reinstalling components, take care to prevent foreign material from entering the system.
- (13) When handling each unit or printed circuit board in the controller during inspection, turn off the circuit breaker to protect against electric shock.  
If there are two cabinets, turn off the both circuit breaker.
- (14) A part should be replaced with a part recommended by FANUC. If other parts are used, malfunction or damage would occur. Especially, a fuse that is not recommended by FANUC should not be used. Such a fuse may cause a fire.
- (15) When restarting the robot system after completing maintenance work, make sure in advance that there is no person in the operating space and that the robot and the peripheral equipments are not abnormal.
- (16) When a motor or brake is removed, the robot arm should be supported with a crane or other equipment beforehand so that the arm would not fall during the removal.
- (17) Whenever grease is spilled on the floor, it should be removed as quickly as possible to prevent dangerous falls.
- (18) The following parts are heated. If a maintenance user needs to touch such a part in the heated state, the user should wear heat-resistant gloves or use other protective tools.
  - Servo motor
  - Inside the controller
  - Reducer
  - Gearbox
  - Wrist unit
- (19) Maintenance should be done under suitable light. Care must be taken that the light would not cause any danger.
- (20) When a motor, reducer, or other heavy load is handled, a crane or other equipment should be used to protect maintenance workers from excessive load. Otherwise, the maintenance workers would be severely injured.
- (21) The robot should not be stepped on or climbed up during maintenance. If it is attempted, the robot would be adversely affected. In addition, a misstep can cause injury to the worker.
- (22) When performing maintenance work in high place, secure a footstep and wear safety belt.
- (23) After the maintenance is completed, spilled oil or water and metal chips should be removed from the floor around the robot and within the safety fence.
- (24) When a part is replaced, all bolts and other related components should put back into their original places. A careful check must be given to ensure that no components are missing or left not mounted.
- (25) In case robot motion is required during maintenance, the following precautions should be taken :
  - Foresee an escape route. And during the maintenance motion itself, monitor continuously the whole robot system so that your escape route will not become blocked by the robot, or by peripheral equipment.
  - Always pay attention to potentially dangerous situations, and be prepared to press the emergency stop button whenever necessary.
- (26) The robot should be periodically inspected. (Refer to the robot mechanical manual and controller maintenance manual.) A failure to do the periodical inspection can adversely affect the performance or service life of the robot and may cause an accident

- (27) After a part is replaced, a test execution should be given for the robot according to a predetermined method. (See TESTING section of "Controller operator's manual".) During the test execution, the maintenance worker should work outside the safety fence.

## 4 SAFETY OF THE TOOLS AND PERIPHERAL EQUIPMENTS

---

### 4.1 PRECAUTIONS IN PROGRAMMING

---

- (1) Use a limit switch or other sensor to detect a dangerous condition and, if necessary, design the program to stop the robot when the sensor signal is received.
- (2) Design the program to stop the robot when an abnormality occurs in any other robots or peripheral equipments, even though the robot itself is normal.
- (3) For a system in which the robot and its peripheral equipments are in synchronous motion, particular care must be taken in programming so that they do not interfere with each other.
- (4) Provide a suitable interface between the robot and its peripheral equipments so that the robot can detect the states of all devices in the system and can be stopped according to the states.

### 4.2 PRECAUTIONS FOR MECHANISM

---

- (1) Keep the component cells of the robot system clean, operate the robot where insulated from the influence of oil, water, and dust.
- (2) Don't use unconfirmed liquid for cutting fluid and cleaning fluid.
- (3) Adopt limit switches or mechanical stoppers to limit the robot motion, and avoid the robot from collisions against peripheral equipments or tools.
- (4) Observe the following precautions about the mechanical unit cables. Failure to follow precautions may cause problems.
  - Use mechanical unit cable that have required user interface.
  - Do not add user cable or hose to inside of the mechanical unit.
  - Please do not obstruct the movement of the mechanical unit when cables are added to outside of mechanical unit.
  - In the case of the model that a cable is exposed, please do not perform remodeling (Adding a protective cover and fix an outside cable more) obstructing the behavior of the outcrop of the cable.
  - When installing user peripheral equipment on the robot mechanical unit, please pay attention that the device does not interfere with the robot itself.
- (5) The frequent power-off stop for the robot during operation causes the trouble of the robot. Please avoid the system construction that power-off stop would be operated routinely. (Refer to bad case example.) Please perform power-off stop after reducing the speed of the robot and stopping it by hold stop or cycle stop when it is not urgent. (Please refer to "STOP TYPE OF ROBOT" in "SAFETY PRECAUTIONS" for detail of stop type.)

(Bad case example)

- Whenever poor product is generated, a line stops by emergency stop and power-off of the robot is incurred.
- When alteration is necessary, safety switch is operated by opening safety fence and power-off stop is incurred for the robot during operation.
- An operator pushes the emergency stop button frequently, and a line stops.
- An area sensor or a mat switch connected to safety signal operates routinely and power-off stop is incurred for the robot.

- Power-off stop is regularly incurred due to an inappropriate setting for Dual Check Safety (DCS).
- (6) Power-off stop of Robot is executed when collision detection alarm (SRVO-050) etc. occurs. Please try to avoid unnecessary power-off stops. It may cause the trouble of the robot, too. So remove the causes of the alarm.

## **5 SAFETY OF THE ROBOT MECHANICAL UNIT**

---

### **5.1 PRECAUTIONS IN OPERATION**

---

- (1) When operating the robot in the jog mode, set it at an appropriate speed so that the operator can manage the robot in any eventuality.
- (2) Before pressing the jog key, be sure you know in advance what motion the robot will perform in the jog mode.

### **5.2 PRECAUTIONS IN PROGRAMMING**

---

- (1) When the operating spaces of robots overlap, make certain that the motions of the robots do not interfere with each other.
- (2) Be sure to specify the predetermined work origin in a motion program for the robot and program the motion so that it starts from the origin and terminates at the origin. Make it possible for the operator to easily distinguish at a glance that the robot motion has terminated.

### **5.3 PRECAUTIONS FOR MECHANISMS**

---

Keep the robot operation area clean, and operate the robot in an environment free of grease, water, and dust.

### **5.4 PROCEDURE TO MOVE ARM WITHOUT DRIVE POWER IN EMERGENCY OR ABNORMAL SITUATIONS**

---

For emergency or abnormal situations (e.g. persons trapped in or pinched by the robot), brake release unit can be used to move the robot axes without drive power.

Please refer to controller maintenance manual and mechanical unit operator's manual for using method of brake release unit and method of supporting robot.

## **6 SAFETY OF THE END EFFECTOR**

---

### **6.1 PRECAUTIONS IN PROGRAMMING**

---

- (1) To control the pneumatic, hydraulic and electric actuators, carefully consider the necessary time delay after issuing each control command up to actual motion and ensure safe control.
- (2) Provide the end effector with a limit switch, and control the robot system by monitoring the state of the end effector.

# 7 STOP TYPE OF ROBOT

The following three robot stop types exist:

## Power-Off Stop (Category 0 following IEC 60204-1)

Servo power is turned off and the robot stops immediately. Servo power is turned off when the robot is moving, and the path of the deceleration is uncontrolled.

The following processing is performed at Power-Off stop.

- An alarm is generated and servo power is turned off.
- The robot operation is stopped immediately. Execution of the program is paused.

Frequent Power-Off stop of the robot during operation can cause failures of the robot.

Avoid system designs that require routine or frequent Power-Off stop conditions.

## Controlled stop (Category 1 following IEC 60204-1)

The robot is decelerated until it stops, and servo power is turned off.

The following processing is performed at Controlled stop.

- The alarm "SRVO-199 Controlled stop" occurs along with a decelerated stop. Execution of the program is paused.
- An alarm is generated and servo power is turned off.

## Hold (Category 2 following IEC 60204-1)

The robot is decelerated until it stops, and servo power remains on.

The following processing is performed at Hold.

- The robot operation is decelerated until it stops. Execution of the program is paused.

### WARNING

The stopping distance and stopping time of Controlled stop are longer than the stopping distance and stopping time of Power-Off stop. A risk assessment for the whole robot system, which takes into consideration the increased stopping distance and stopping time, is necessary when Controlled stop is used.

When the emergency stop button is pressed or the FENCE is open, the stop type of robot is Power-Off stop or Controlled stop. The configuration of stop type for each situation is called *stop pattern*. The stop pattern is different according to the controller type or option configuration.

There are the following 3 Stop patterns.

Stop pattern	Mode	Emergency stop button	External Emergency stop	FENCE open	SVOFF input	Servo disconnect
A	AUTO	P-Stop	P-Stop	C-Stop	C-Stop	P-Stop
	T1	P-Stop	P-Stop	-	C-Stop	P-Stop
	T2	P-Stop	P-Stop	-	C-Stop	P-Stop
B	AUTO	P-Stop	P-Stop	P-Stop	P-Stop	P-Stop
	T1	P-Stop	P-Stop	-	P-Stop	P-Stop
	T2	P-Stop	P-Stop	-	P-Stop	P-Stop
C	AUTO	C-Stop	C-Stop	C-Stop	C-Stop	C-Stop
	T1	P-Stop	P-Stop	-	C-Stop	P-Stop
	T2	P-Stop	P-Stop	-	C-Stop	P-Stop

P-Stop: Power-Off stop

C-Stop: Controlled stop

-: Disable

The following table indicates the Stop pattern according to the controller type or option configuration.

Option	R-30iB/ R-30iB Mate
Standard	A (*)
Controlled stop by E-Stop (A05B-2600-J570)	C (*)

(\*) R-30iB / R-30iB Mate does not have servo disconnect. / R-30iB Mate does not have SVOFF input.

The stop pattern of the controller is displayed in "Stop pattern" line in software version screen. Please refer to "Software version" in operator's manual of controller for the detail of software version screen.

### "Controlled stop by E-Stop" option

When "Controlled stop by E-Stop" (A05B-2600-J570) option is specified, the stop type of the following alarms becomes

Controlled stop but only in AUTO mode. In T1 or T2 mode, the stop type is Power-Off stop which is the normal operation of the system.

Alarm	Condition
SRVO-001 Operator panel E-stop	Operator panel emergency stop is pressed.
SRVO-002 Teach pendant E-stop	Teach pendant emergency stop is pressed.
SRVO-007 External emergency stops	External emergency stop input (EES1-EES11, EES2-EES21) is open.
SRVO-408 DCS SSO Ext Emergency Stop	In DCS Safe I/O connect function, SSO[3] is OFF.
SRVO-409 DCS SSO Servo Disconnect	In DCS Safe I/O connect function, SSO[4] is OFF.

Controlled stop is different from Power-Off stop as follows:

- In Controlled stop, the robot is stopped on the program path. This function is effective for a system where the robot can interfere with other devices if it deviates from the program path.
- In Controlled stop, physical impact is less than Power-Off stop. This function is effective for systems where the physical impact to the mechanical unit or EOAT (End Of Arm Tool) should be minimized.
- The stopping distance and stopping time of Controlled stop is longer than the stopping distance and stopping time of Power-Off stop, depending on the robot model and axis. Please refer to the operator's manual of a particular robot model for the data of stopping distance and stopping time.

When this option is loaded, this function cannot be disabled.

The stop type of DCS Position and Speed Check functions is not affected by the loading of this option.

#### WARNING

The stopping distance and stopping time of Controlled stop are longer than the stopping distance and stopping time of Power-Off stop. A risk assessment for the whole robot system, which takes into consideration the increased stopping distance and stopping time, is necessary when this option is loaded.

151124

# TABLE OF CONTENTS

<b>SAFETY PRECAUTIONS</b> .....	<b>s-1</b>
<b>1 PREFACE</b> .....	<b>1</b>
1.1 OVERVIEW OF THE MANUAL .....	1
1.2 RELATED MANUALS .....	2
<b>2 ABOUT VISION SYSTEM</b> .....	<b>4</b>
2.1 BASIC CONFIGURATION .....	4
2.2 VISION-GUIDED ROBOT MOTION .....	4
2.3 FIXED FRAME OFFSET AND TOOL OFFSET .....	5
2.4 FIXED CAMERA AND ROBOT-MOUNTED CAMERA .....	5
2.5 CAMERA CALIBRATION .....	6
2.6 VISION DATA .....	6
2.6.1 Types of Vision Data.....	6
2.6.2 Maximum Vision Data That can be Created .....	7
2.6.3 To Create More Vision Data .....	7
2.7 USER FRAME AND USER TOOL .....	8
<b>3 BASIC OPERATIONS</b> .....	<b>10</b>
3.1 VISION SETUP.....	10
3.1.1 Creating New Vision Data.....	12
3.1.2 Deleting Vision Data .....	13
3.1.3 Copying Vision Data .....	13
3.1.4 Verifying Vision Data Detail Information .....	14
3.1.5 Editing Vision Data .....	14
3.1.6 Setting a Filter to List of Vision Data .....	16
3.2 VISION RUN-TIME .....	18
3.2.1 Setting Filter to Vision Runtime.....	19
3.2.2 Freezing Vision Runtime.....	20
3.3 VISION LOG .....	21
3.4 VISION CONFIG.....	24
3.5 BACKING UP VISION DATA .....	27
3.5.1 Backing up Vision Data .....	27
3.5.2 Restoring Vision Data .....	27
3.6 INTER-CONTROLLER COMMUNICATION .....	27
3.7 FREQUENTLY-USED OPERATIONS .....	27
3.7.1 Text Box .....	27
3.7.2 Drop-Down Box .....	28
3.7.3 List View .....	28
3.7.4 Image Display Control .....	29
3.7.5 Tree View .....	33
3.7.6 Result View .....	37
3.7.7 Tab.....	37
3.7.8 Setting Points.....	38
3.7.9 Window Setup .....	38
3.7.10 Segmented-Line Setup .....	40
3.7.11 Circle Setup .....	43
3.7.12 Single Line Setup .....	44

3.7.13	Double Line Setup.....	45
3.7.14	Editing Masks.....	47
3.7.15	Setting Exposure Mode.....	53
3.7.16	Sorting.....	55
3.7.17	Image Playback.....	56
3.8	PASSWORD PROTECTION OF VISION DATA.....	58
<b>4</b>	<b>CAMERA SETUP .....</b>	<b>59</b>
4.1	KOWA DIGITAL CAMERA .....	59
4.1.1	Grayscale Camera.....	60
4.1.2	Color Camera .....	61
4.2	SONY ANALOG CAMERA .....	63
4.3	KOWA USB CAMERA .....	64
4.4	BASLER USB CAMERA.....	65
<b>5</b>	<b>CAMERA CALIBRATION .....</b>	<b>66</b>
5.1	GRID PATTERN CALIBRATION .....	66
5.1.1	Calibrating Camera.....	66
5.1.2	Checking Calibration Points.....	69
5.1.3	Checking Calibration Data .....	70
5.1.4	Automatic Re-Calibration .....	71
5.2	ROBOT-GENERATED GRID CALIBRATION.....	73
5.2.1	Camera Calibration Tools.....	73
5.2.2	Checking Calibration Points.....	75
5.2.3	Checking Calibration Data .....	76
5.2.4	Automatic Re-Calibration .....	77
5.3	3D LASER VISION CALIBRATION .....	77
5.3.1	Calibrating Camera.....	77
5.3.2	Checking Calibration Points.....	80
5.3.3	Checking Calibration Data .....	81
5.3.4	Automatic Re-Calibration .....	83
5.4	VISUAL TRACKING CALIBRATION.....	84
5.4.1	Calibrating Camera.....	84
5.4.2	Checking Calibration Points.....	88
5.4.3	Checking Calibration Data .....	89
<b>6</b>	<b>VISION PROCESSES .....</b>	<b>91</b>
6.1	2D SINGLE VIEW VISION PROCESS .....	91
6.1.1	Setting up a Vision Process.....	91
6.1.2	Running a Test.....	95
6.1.3	Setting the Reference Position.....	96
6.1.4	Overridable Parameters .....	97
6.2	2D MULTI-VIEW VISION PROCESS .....	97
6.2.1	Setting up a Vision Process.....	98
6.2.2	Setting up a Camera View.....	101
6.2.3	Running a Test.....	102
6.2.4	Setting the Reference Position.....	103
6.2.5	Overridable Parameters .....	103
6.3	DEPALLETIZING VISION PROCESS .....	104
6.3.1	Setting up a Vision Process.....	104
6.3.2	Running a Test.....	109
6.3.3	Setting the Reference Position.....	110
6.3.4	Overridable Parameters .....	110



<b>6.4</b>	<b>2D CALIBRATION-FREE VISION PROCESS</b> .....	<b>111</b>
6.4.1	Setting up a Vision Process .....	111
6.4.2	Learning .....	113
6.4.3	Destination Pose .....	116
6.4.4	Test Run .....	117
6.4.5	Setup Guidelines.....	118
6.4.6	Advanced Mode .....	121
<b>6.5</b>	<b>3D TRI-VIEW VISION PROCESS</b> .....	<b>123</b>
6.5.1	Application Consideration.....	123
6.5.1.1	What to consider .....	123
6.5.1.2	Camera position .....	124
6.5.2	Setting up a Vision Process .....	125
6.5.3	Setting up a Camera View .....	127
6.5.4	Running a Test.....	129
6.5.5	Setting the Reference Position.....	130
6.5.6	Overridable Parameters .....	131
<b>6.6</b>	<b>3DL SINGLE VIEW VISION PROCESS</b> .....	<b>131</b>
6.6.1	Setting up a Vision Process .....	132
6.6.1.1	2D Measurement setups.....	134
6.6.1.2	Laser measurement setups .....	135
6.6.1.3	Reference data .....	136
6.6.2	Running a Test.....	137
6.6.3	Setting the Reference Position.....	138
6.6.4	Overridable Parameters .....	138
<b>6.7</b>	<b>3DL MULTI-VIEW VISION PROCESS</b> .....	<b>139</b>
6.7.1	Setting up a Vision Process .....	139
6.7.2	Setting up a Camera View .....	142
6.7.2.1	2D measurement setups .....	143
6.7.2.2	Laser measurement setups .....	143
6.7.2.3	Reference data .....	144
6.7.3	Running a Test.....	145
6.7.4	Setting the Reference Position.....	146
6.7.5	Overridable Parameters .....	146
<b>6.8</b>	<b>3DL CROSS-SECTION VISION PROCESS</b> .....	<b>147</b>
6.8.1	Setting up a Vision Process .....	147
6.8.1.1	Laser measurement setup.....	149
6.8.1.2	2D measurement setups .....	151
6.8.2	Running a Test.....	152
6.8.3	Overridable Parameters .....	153
<b>6.9</b>	<b>3DL CURVED SURFACE SINGLE VIEW VISION PROCESS</b> .....	<b>153</b>
6.9.1	Setting up a Vision Process .....	154
6.9.1.1	2D measurement setups .....	156
6.9.1.2	Laser measurement setup.....	157
6.9.1.3	Reference data .....	158
6.9.2	Running a Test.....	159
6.9.3	Setting the Reference Position.....	160
6.9.4	Overridable Parameters .....	160
<b>6.10</b>	<b>SINGLE VIEW VISUAL TRACKING</b> .....	<b>161</b>
6.10.1	Setting up a Vision Process .....	161
6.10.2	Running a Test.....	165
6.10.3	Setting the Reference Position.....	166
6.10.4	Overridable Parameters .....	167
<b>6.11</b>	<b>BIN-PICK SEARCH VISION PROCESS</b> .....	<b>167</b>
6.11.1	Setting up a Vision Process .....	167

6.11.2	Running a Test.....	171
6.11.3	Setting the Reference Position.....	172
6.11.4	Overridable Parameters .....	173
<b>6.12</b>	<b>SINGLE VIEW INSPECTION VISION PROCESS .....</b>	<b>173</b>
6.12.1	Setting up a Vision Process .....	173
6.12.2	Setting a Measurement Plane .....	174
6.12.3	Running a Test.....	176
6.12.4	Overridable Parameters .....	176
<b>6.13</b>	<b>READER VISION PROCESS .....</b>	<b>177</b>
6.13.1	Setting up a Vision Process .....	177
6.13.2	Running a Test.....	178
6.13.3	Overridable Parameters .....	179
<b>6.14</b>	<b>IMAGE TO POINTS VISION PROCESS .....</b>	<b>179</b>
6.14.1	Setting up a Vision Process .....	180
6.14.2	Running a Test.....	181
6.14.3	Overridable Parameters .....	182
<b>6.15</b>	<b>3D AREA SENSOR .....</b>	<b>182</b>
6.15.1	Projection FOV and Standoff of Projector Unit.....	182
6.15.2	Setting up a Vision Process .....	186
6.15.3	Setting up a Camera View.....	190
6.15.4	Setup Procedures .....	190
6.15.5	Supplementary Explanation .....	193
6.15.6	Overridable Parameters .....	194
<b>6.16</b>	<b>3D AREA SENSOR VISION PROCESS.....</b>	<b>194</b>
6.16.1	Setting up a Vision Process .....	195
6.16.2	Running a Test.....	198
6.16.3	Setting the Reference Position.....	199
6.16.4	Overridable Parameters .....	199
<b>6.17</b>	<b>FLOATING FRAME VISION PROCESS.....</b>	<b>200</b>
6.17.1	Setting up a Vision Process .....	201
6.17.2	Running a Test.....	204
6.17.3	Setting the Reference Position.....	205
6.17.4	Overridable Parameters .....	205
<b>7</b>	<b>COMMAND TOOLS .....</b>	<b>207</b>
<b>7.1</b>	<b>GPM LOCATOR TOOL .....</b>	<b>207</b>
7.1.1	Setting up a Model .....	207
7.1.2	Adjusting the Location Parameters .....	212
7.1.3	Running a Test.....	215
7.1.4	Model Learning .....	216
7.1.4.1	Overview of Model Learning Wizard.....	217
7.1.4.2	Select Method to Add Images.....	219
7.1.4.3	Add Logged Images.....	220
7.1.4.4	Add Snapped Images .....	223
7.1.4.5	Confirm Images and Results.....	224
7.1.4.6	Remove Needless Features .....	228
7.1.4.7	Average Model Shape.....	229
7.1.4.8	Confirm Learning Model .....	229
7.1.5	Overridable Parameters .....	231
7.1.6	Setup Guidelines.....	232
7.1.6.1	Overview and functions.....	232
7.1.6.2	Model pattern.....	236
7.1.6.3	Found Pattern.....	239
7.1.6.4	Location parameters.....	241

<b>7.2</b>	<b>CURVED SURFACE LOCATOR TOOL .....</b>	<b>248</b>
7.2.1	Setting up a Model .....	248
7.2.2	Adjusting the Location Parameters .....	250
7.2.3	Running a Test.....	253
7.2.4	Overridable Parameters .....	254
7.2.5	Setup Guidelines.....	254
	7.2.5.1 Overview and functions.....	254
	7.2.5.2 Lighting environment .....	258
	7.2.5.3 Model pattern.....	258
<b>7.3</b>	<b>BLOB LOCATOR TOOL .....</b>	<b>260</b>
7.3.1	Image Binarization .....	260
7.3.2	Teaching a Model.....	262
7.3.3	Adjusting the Location Parameters .....	263
7.3.4	Running a Test.....	266
7.3.5	Overridable Parameters .....	267
<b>7.4</b>	<b>LINE LOCATOR TOOL.....</b>	<b>268</b>
7.4.1	Setting up a Model .....	268
7.4.2	Adjusting the Location Parameters .....	270
7.4.3	Running a Test.....	273
7.4.4	Overridable Parameters .....	274
7.4.5	Guideline .....	274
<b>7.5</b>	<b>COMBINATION LOCATOR TOOL .....</b>	<b>275</b>
7.5.1	Setup.....	275
7.5.2	Running a Test.....	276
7.5.3	Overridable Parameters .....	276
<b>7.6</b>	<b>EDGE PAIR LOCATOR TOOL .....</b>	<b>277</b>
7.6.1	Setting the Search Window .....	277
7.6.2	Teaching a Model.....	278
7.6.3	Adjusting the Location Parameters .....	278
7.6.4	Running a Test.....	280
7.6.5	Overridable Parameters .....	281
<b>7.7</b>	<b>HISTOGRAM TOOL .....</b>	<b>281</b>
7.7.1	Setting the Measurement Area .....	282
7.7.2	Running a Test.....	284
7.7.3	Overridable Parameters .....	285
<b>7.8</b>	<b>EDGE HISTOGRAM TOOL .....</b>	<b>285</b>
7.8.1	Setting the Measurement Area .....	286
7.8.2	Running a Test.....	291
7.8.3	Overridable Parameters .....	292
<b>7.9</b>	<b>CONDITIONAL EXECUTION TOOL.....</b>	<b>293</b>
7.9.1	Setting the Parameters .....	293
7.9.2	Running a Test.....	295
7.9.3	Overridable Parameters .....	295
<b>7.10</b>	<b>MULTI-LOCATOR TOOL.....</b>	<b>296</b>
7.10.1	Adding Child Tools .....	296
7.10.2	Setting the Register .....	296
7.10.3	Running a Test.....	297
7.10.4	Overridable Parameters .....	297
<b>7.11</b>	<b>MULTI-WINDOW TOOL .....</b>	<b>298</b>
7.11.1	Setting the Register .....	298
7.11.2	Setting a Window .....	299
7.11.3	Running a Test.....	299
7.11.4	Overridable Parameters .....	300

<b>7.12</b>	<b>POSITION ADJUSTMENT TOOL</b> .....	<b>300</b>
	7.12.1 Setting Parameters.....	300
	7.12.2 Running a Test.....	303
	7.12.3 Overridable Parameters.....	304
<b>7.13</b>	<b>MEASUREMENT OUTPUT TOOL</b> .....	<b>304</b>
	7.13.1 Setting the Measurement Values.....	304
	7.13.2 Running a Test.....	305
	7.13.3 Overridable Parameters.....	306
<b>7.14</b>	<b>3DL PLANE COMMAND TOOL</b> .....	<b>306</b>
	7.14.1 Setting the Measurement Area.....	306
	7.14.2 Adjusting the Location Parameters.....	307
	7.14.3 Running a Test.....	309
	7.14.4 Overridable Parameters.....	310
<b>7.15</b>	<b>3DL DISPL COMMAND TOOL</b> .....	<b>311</b>
	7.15.1 Setting the Measurement Area.....	311
	7.15.2 Adjusting the Location Parameters.....	312
	7.15.3 Running a Test.....	313
	7.15.4 Overridable Parameters.....	314
<b>7.16</b>	<b>3DL CYLINDER TOOL</b> .....	<b>314</b>
	7.16.1 Setting the Measurement Area.....	315
	7.16.2 Adjusting the Location Parameters.....	316
	7.16.3 Running a Test.....	317
	7.16.4 Overridable Parameters.....	318
<b>7.17</b>	<b>EVALUATION TOOL</b> .....	<b>319</b>
	7.17.1 Setting the Parameters.....	319
	7.17.2 Running a Test.....	322
	7.17.3 Overridable Parameters.....	323
<b>7.18</b>	<b>SURFACE FLAW INSPECTION TOOL</b> .....	<b>323</b>
	7.18.1 Adjusting the Search Parameters.....	323
	7.18.2 Image Preprocessing.....	325
	7.18.2.1 Background removal.....	325
	7.18.2.2 Filters.....	326
	7.18.3 Adjusting the Range Parameters.....	327
	7.18.4 Display Modes.....	328
	7.18.5 Running a Test.....	329
	7.18.6 Overridable Parameters.....	330
<b>7.19</b>	<b>BEAD INSPECTION TOOL</b> .....	<b>332</b>
	7.19.1 Setting up an Inspection Line.....	332
	7.19.2 Adjusting Parameters.....	334
	7.19.3 Running a Test.....	335
	7.19.4 Overridable Parameters.....	336
	7.19.5 Available Child Tools.....	336
<b>7.20</b>	<b>COUNT TOOL</b> .....	<b>337</b>
	7.20.1 Setting the Parameters.....	337
	7.20.2 Running a Test.....	338
	7.20.3 Overridable Parameters.....	338
<b>7.21</b>	<b>ARITHMETIC CALCULATION TOOL</b> .....	<b>339</b>
	7.21.1 Setting the Parameters.....	339
	7.21.2 Running a Test.....	340
	7.21.3 Overridable Parameters.....	340
<b>7.22</b>	<b>GEOMETRIC CALCULATION TOOL</b> .....	<b>341</b>
	7.22.1 Setting the Parameters.....	341
	7.22.2 Running a Test.....	342

	7.22.3	Overridable Parameters .....	343
<b>7.23</b>		<b>STATISTIC CALCULATION TOOL.....</b>	<b>343</b>
	7.23.1	Setting the Parameters .....	343
	7.23.2	Running a Test.....	344
	7.23.3	Overridable Parameters .....	345
<b>7.24</b>		<b>POSITION CALCULATION TOOL.....</b>	<b>345</b>
	7.24.1	Setting the Parameters .....	345
	7.24.2	Running a Test.....	349
	7.24.3	Overridable Parameters .....	350
<b>7.25</b>		<b>WINDOW SHIFT TOOL.....</b>	<b>350</b>
	7.25.1	Setting the Parameters .....	351
	7.25.1.1	Shifting windows based on a locator tool's results .....	352
	7.25.1.2	Shifting windows based on another vision process' results .....	352
	7.25.1.3	Shifting windows based on interference avoidance results .....	354
	7.25.2	Running a Test.....	354
	7.25.3	Overridable Parameters .....	355
<b>7.26</b>		<b>IMAGE PREPROCESS TOOL.....</b>	<b>355</b>
	7.26.1	Setting the Paramters.....	355
	7.26.2	Running a Test.....	355
	7.26.3	Overridable Parameters .....	355
<b>7.27</b>		<b>IMAGE FILTER TOOL .....</b>	<b>356</b>
	7.27.1	Setting the Parameters .....	356
	7.27.2	Running a Test.....	358
	7.27.3	Overridable Parameters .....	358
	7.27.4	Filters.....	358
<b>7.28</b>		<b>COLOR EXTRACTION TOOL .....</b>	<b>373</b>
	7.28.1	Setting the Parameters .....	374
	7.28.2	Training the Color Extraction Parameters.....	375
	7.28.3	Running a Test.....	378
	7.28.4	Overridable Parameters .....	379
<b>7.29</b>		<b>1-D BARCODE TOOL .....</b>	<b>379</b>
	7.29.1	Setting the Parameters .....	380
	7.29.2	Running a Test.....	382
	7.29.3	Overridable Parameters .....	383
	7.29.4	Terminologies.....	384
<b>7.30</b>		<b>2-D BARCODE TOOL .....</b>	<b>386</b>
	7.30.1	Setting the Parameters .....	386
	7.30.2	Running a Test.....	389
	7.30.3	Overridable Parameters .....	390
	7.30.4	Terminologies.....	390
<b>7.31</b>		<b>EDGE POINTS LOCATOR TOOL .....</b>	<b>394</b>
	7.31.1	Adjusting the Parameters.....	394
	7.31.2	Running a Test.....	396
	7.31.3	Overridable Parameters .....	397
<b>7.32</b>		<b>SELECTED EDGE POINTS LOCATOR TOOL .....</b>	<b>397</b>
	7.32.1	Adjusting the Parameters.....	397
	7.32.2	Running a Test.....	401
	7.32.3	Overridable Parameters .....	402
<b>7.33</b>		<b>SEARCH AREA RESTRICTION TOOL .....</b>	<b>402</b>
	7.33.1	Setting the Parameters .....	403
	7.33.2	Setting a Position where Plied Workpieces State Changed.....	404
	7.33.3	Running a Test.....	404
	7.33.4	Overridable Parameters .....	405

<b>7.34</b>	<b>AREA SENSOR PREPROCESS TOOL</b> .....	<b>405</b>
	7.34.1 Setting the Parameters of Bottom Removal .....	406
	7.34.2 Setting the Parameters of Container Removal.....	406
	7.34.3 Setting the Parameters of Outlier Removal .....	408
	7.34.4 Setting the Parameters .....	409
	7.34.5 Running a Test.....	409
	7.34.6 Overridable Parameter.....	410
<b>7.35</b>	<b>AREA SENSOR PEAK LOCATOR TOOL</b> .....	<b>410</b>
	7.35.1 Setting the Parameters .....	411
	7.35.2 Running a Test.....	412
	7.35.3 Overridable Parameter.....	413
<b>7.36</b>	<b>AREA SENSOR BLOB LOCATOR TOOL</b> .....	<b>414</b>
	7.36.1 Setting the Parameters .....	414
	7.36.2 Running a Test.....	419
	7.36.3 Overridable Parameter.....	421
<b>7.37</b>	<b>AREA SENSOR COG TOOL</b> .....	<b>421</b>
	7.37.1 Setting the Measurement Area .....	422
	7.37.2 Setting the Parameters .....	423
	7.37.3 Running a Test.....	424
	7.37.4 Overridable Parameter.....	425
<b>7.38</b>	<b>AREA SENSOR PLANE TOOL</b> .....	<b>425</b>
	7.38.1 Setting the Measurement Area .....	426
	7.38.2 Setting the Parameters .....	426
	7.38.3 Running a Test.....	427
	7.38.4 Overridable Parameter.....	428
<b>7.39</b>	<b>OBSTRUCTION MEASUREMENT TOOL</b> .....	<b>429</b>
	7.39.1 Setting the Measurement Area .....	430
	7.39.2 Setting the Parameters .....	431
	7.39.3 Running a Test.....	432
	7.39.4 Overridable Parameter.....	433
<b>7.40</b>	<b>AREA SENSOR GF LOCATOR TOOL</b> .....	<b>433</b>
	7.40.1 Setting the Parameters .....	434
	7.40.2 Running a Test.....	436
	7.40.3 Overridable Parameter.....	437
<b>7.41</b>	<b>COLOR SORTING TOOL</b> .....	<b>438</b>
	7.41.1 Setting the parameters .....	439
	7.41.2 Running a Test.....	444
	7.41.3 Overridable Parameters .....	445
<b>7.42</b>	<b>AREA SENSOR BOX LOCATOR TOOL</b> .....	<b>445</b>
	7.42.1 Setting the Parameters .....	446
	7.42.2 Running a Test.....	449
	7.42.3 Overridable Parameter.....	450
<b>7.43</b>	<b>AREA SENSOR CYLINDER LOCATOR TOOL</b> .....	<b>450</b>
	7.43.1 Setting the Preprocess Tool.....	451
	7.43.2 Setting up a Model .....	451
	7.43.3 Setting the Parameters for Finding 3D Blobs.....	452
	7.43.4 Setting the Parameters for Finding Cylinder .....	452
	7.43.5 Running a Test.....	453
	7.43.6 Overridable Parameter.....	454
<b>7.44</b>	<b>COLOR COMPONENT TOOL</b> .....	<b>454</b>
	7.44.1 Setting the Parameters .....	455
	7.44.2 Running a Test.....	456
	7.44.3 Overridable Parameters .....	456

7.45	IMAGE ARITHMETIC TOOL .....	457
7.45.1	Setting the Parameters .....	457
7.45.2	Running a Test.....	460
7.45.3	Overridable Parameters .....	460
7.45.4	Examples .....	460
7.46	FLAT FIELD TOOL .....	463
7.46.1	Setting the Parameters .....	463
7.46.2	Running a Test.....	467
7.46.3	Overridable Parameters .....	467
<b>8</b>	<b>APPLICATION DATA .....</b>	<b>468</b>
8.1	VISION OVERRIDE .....	468
8.2	OFFSET LIMIT .....	469
<b>9</b>	<b>STARTING FROM A ROBOT PROGRAM.....</b>	<b>471</b>
9.1	VISION REGISTERS.....	471
9.1.1	Vision Register List Screen .....	471
9.1.2	Detail Screen of a Vision Register .....	472
9.1.3	Changing the Number of Vision Registers.....	474
9.2	PROGRAM COMMANDS.....	474
9.2.1	Vision Offset .....	474
9.2.1.1	VOFFSET.....	474
9.2.1.2	VOFFSET CONDITION.....	475
9.2.1.3	LOCK VREG .....	475
9.2.1.4	UNLOCK VREG.....	476
9.2.2	Vision Execution .....	476
9.2.2.1	RUN_FIND .....	476
9.2.2.2	GET_OFFSET .....	476
9.2.2.3	GET_NFOUND.....	477
9.2.2.4	GET_PASSFAIL .....	477
9.2.2.5	GET_READING .....	478
9.2.2.6	SET_REFERENCE .....	478
9.2.2.7	CAMERA_CALIB .....	478
9.2.2.8	OVERRIDE.....	479
9.2.3	Vision Registers .....	479
9.2.3.1	Model ID.....	479
9.2.3.2	Measurement value.....	479
9.2.3.3	Encoder count.....	479
9.2.3.4	Found position .....	479
9.2.3.5	Offset data.....	480
9.3	ASYNCHRONOUS EXECUTION .....	480
9.4	KAREL TOOLS.....	481
9.4.1	IRVSNAP, IRVNFIND .....	481
9.4.2	IRVLEDON, IRVLEDOFF.....	483
9.4.3	ACQVAMAP, CLRVAMAP .....	484
9.4.4	IRVTRAIN.....	487
9.4.4.1	Model Train File.....	488
9.4.4.2	Operation Methods .....	497
9.4.4.3	Precautions.....	501
9.4.5	IRVBKLSH.....	502
9.4.6	IRVHOMING.....	503
9.4.7	IRVMUXOFF, IRVMUXON, IRVMUXCHK .....	503
9.4.8	IRVGETMSR, IRVGETMSL .....	506
9.4.9	IRVOVRDANYVP .....	508
9.4.10	BPGETAABB, BPGETOBB .....	509

<b>10</b>	<b>UTILITY MENU</b>	<b>513</b>
10.1	ROBOT-GENERATED GRID CALIBRATION	513
10.1.1	Overview	513
10.1.2	Structure of the Menus	514
10.1.2.1	Main menu	514
10.1.2.2	Calibration data menu	516
10.1.2.3	Target position menu	517
10.1.2.4	Start position menu	518
10.1.3	Performing Calibration	518
10.1.3.1	Selecting and mounting the target	518
10.1.3.2	Preparing camera calibration tool	520
10.1.3.3	Selecting calibration data	521
10.1.3.4	Measuring target position	521
10.1.3.5	Generating calibration program	524
10.1.3.6	Executing calibration program	526
10.2	GRID FRAME SETTING	527
10.2.1	Overview	528
10.2.2	Setting the Parameters	529
10.2.3	Run Measurement	533
10.2.4	Troubleshooting	535
10.3	VISION LOG MENU	536
10.3.1	Setting the Device	536
10.3.2	Exporting Vision Log of a Specified Date	537
10.3.3	Exporting Vision Logs of All Dates	538
10.3.4	Deleting a Vision Log of a Specified Date	538
10.3.5	Deleting Vision Logs of All Dates	539
10.3.6	Importing a Vision Log of a Specified Date	539
10.3.7	Refreshing the Display	540
10.3.8	File Configuration of the Exported Vision Log	540
<b>11</b>	<b>CALIBRATION GRID</b>	<b>541</b>
11.1	CALIBRATION GRID	541
11.2	CALIBRATION GRID FRAME	541
11.2.1	Setting Based on Touch-up	542
11.2.2	Setting Based on Measurement with a Camera	543
<b>12</b>	<b>OTHER OPTIONS</b>	<b>544</b>
12.1	VISION SUPPORT TOOLS	544
12.1.1	OFS_RJ3	545
12.1.2	MATRIX	547
12.1.3	INVERSE	549
12.1.4	MERGE3D2	550
12.1.5	LOADNOM and SAVENOM	552
12.1.6	ADJ_OFS	554
12.1.7	SORT_RJ3	555
12.1.8	CHK_POS	558
12.1.9	STVS1	560
12.1.10	GETCROSS	561
12.1.11	VL_EXPORT	562
12.2	DATA TRANSFER BETWEEN ROBOTS	563
12.2.1	RSETNREG, RSETPREG	563
12.3	4D GRAPHICS	564
12.3.1	IRVDISPLAY4D	568



12.4	iRCONNECT .....	568
12.4.1	IRVICONN .....	569

## APPENDIX

<b>A</b>	<b>TEACHING FROM PC .....</b>	<b>573</b>
A.1	CONNECTING A SETUP PC .....	573
A.1.1	Setup PC .....	573
A.1.2	Communication Cable .....	573
A.1.3	Connecting a Communication Cable .....	573
A.1.4	Determining the IP Addresses .....	574
A.1.5	Setting the IP Address of the Robot Controller .....	574
A.1.6	Setting the IP Address of the PC .....	575
A.1.7	Modifying Settings of Internet Explorer .....	576
A.1.8	Modifying Setting of Windows Firewall .....	580
A.2	OPENING VISION PAGES .....	582
A.2.1	Installing Vision UIF Controls .....	583
A.3	OPERATIONS ON PC .....	587
A.3.1	Function Keys .....	587
A.3.2	Vision Data List Screen .....	587
A.3.3	Vision Data Edit Screen .....	588
A.3.4	Moving Control Point .....	590
A.3.5	Editing Mask .....	590
A.4	RESTRICTING LOGIN TO VISION SETUP .....	593
A.4.1	Setting Password Protection .....	593
A.4.2	Canceling a Password .....	594
A.5	FREQUENTLY ASKED QUESTIONS .....	595
A.5.1	PC UIF Troubles .....	595
A.5.2	Vision UIF Control Cannot be Installed .....	598
<b>B</b>	<b>iPENDANT FIRMWARE UPDATE .....</b>	<b>599</b>
B.1	PROCEDURES A .....	600
B.2	PROCEDURES B .....	601

## ADDITIONAL INFORMATION



# 1 PREFACE

This chapter describes an overview of this manual which should be noted before operating the *iR*Vision function.

## 1.1 OVERVIEW OF THE MANUAL

### Overview

This manual is the reference manual for *iR*Vision on the R-30*i*B/R-30*i*B Mate controller. This manual describes each functions which are provided by *iR*Vision. When you would like to know the meanings (e.g. the items on *iR*Vision setup screen, the arguments of the instruction, and so on), please refer to this manual. When you start up the robot system which uses *iR*Vision, please refer to manuals which are introduced in “1.2 RELATED MANUALS”.

#### CAUTION

This manual is based on the R-30*i*B system software version V8.30P/18. Note that the functions and settings not described in this manual may be available, and some notation differences are present, depending on the software version.

### Contents of this manual

<b>Chapter 1</b>	Preface
<b>Chapter 2</b>	Describes the vision guide robot motion
<b>Chapter 3</b>	Describes the basic operations
<b>Chapter 4</b>	Describes how to set up camera set up tools
<b>Chapter 5</b>	Describes how to set up camera calibration tools
<b>Chapter 6</b>	Describes how to set up vision processes
<b>Chapter 7</b>	Describes how to set up the command tools
<b>Chapter 8</b>	Describes how to set up application data
<b>Chapter 9</b>	Describes how to start <i>iR</i> Vision from a robot program
<b>Chapter 10</b>	Describes how to use <i>iR</i> Vision utility menus
<b>Chapter 11</b>	Describes the calibration grid and how to set up the calibration grid frame
<b>Chapter 12</b>	Describes how to use the vision support tools
<b>Appendix A</b>	Describes how to setup a PC for <i>iR</i> Vision and how to open <i>iR</i> Vision pages on the PC

## 1.2 RELATED MANUALS

---

This section introduces related manual.

### **R-30iB/R-30iB Mate CONTROLLER OPERATOR'S MANUAL (Basic Operation) B-83284EN**

This is the main manual of R-30iB/R-30iB Mate Controller. This manual describes the following items for manipulating workpieces with the robot:

- Setting the system for manipulating workpieces
- Operating the robot
- Creating and changing a program
- Executing a program
- Status indications
- Backup and restore robot programs.

This manual is used on an applicable design, robot installation, robot teaching.

### **R-30iB CONTROLLER MAINTENANCE MANUAL B-83195EN**

This manual describes the maintenance and connection of R-30iB Controller.

### **R-30iB Mate CONTROLLER MAINTENANCE MANUAL B-83525EN**

This manual describes the maintenance and connection of R-30iB Mate Controller.

### **R-30iB/R-30iB Mate CONTROLLER OPERATOR'S MANUAL (Alarm Code List) B-83284EN-1**

This manual describes the error code listings, causes, and remedies of R-30iB/R-30iB Mate Controller.

### **R-30iB/R-30iB Mate CONTROLLER Optional Function OPERATOR'S MANUAL B83284EN-2**

This manual describes the software optional functions of R-30iB/R-30iB Mate Controller.

### **R-30iB/R-30iB Mate CONTROLLER Sensor Mechanical Unit / Control Unit OPERATOR'S MANUAL B-83434EN**

This manual describes the connection between sensors which is a camera or 3D Laser Sensor and R-30iB/R-30iB Mate Controller, and maintenance of sensors.

### **R-30iB/R-30iB Mate CONTROLLER iRVision 2D Vision Application OPERATOR'S MANUAL B-83304EN-1**

This manual is desired to first refer to when you start up systems of iRVision 2D Compensation and 2.5D Compensation. This manual describes startup procedures of iRVision 2D Compensation and 2.5D Compensation system, creating programs, caution, technical know-how, response to several cases, and so on.

### **R-30iB/R-30iB Mate CONTROLLER iRVision 3D Laser Vision Sensor Application OPERATOR'S MANUAL B-83304EN-2**

This manual is desired to first refer to when you start up systems of iRVision 3D Laser Sensor Compensation. This manual describes startup procedures of iRVision 3D Laser Sensor Compensation, creating programs, caution, technical know-how, response to several cases, and so on.

**R-30iB/R-30iB Mate CONTROLLER iRVision Inspection Application  
OPERATOR'S MANUAL B-83304EN-3**

This manual is desired to first refer to when you start up systems of inspection which uses *iRVision*. This manual describes startup procedures of inspection system which uses *iRVision*, creating programs, caution, technical know-how, response to several cases, and so on.

**R-30iB CONTROLLER iRPickTool OPERATOR'S MANUAL B-83604EN**

This manual is desired to first refer to when you start up systems of *iRVision* Visual Tracking. This manual describes startup procedures of *iRVision* Visual Tracking system, creating programs, caution, technical know-how, response to several cases, and so on.

**R-30iB/R-30iB Mate CONTROLLER iRVision Bin Picking Application  
OPERATOR'S MANUAL B-83304EN-5**

This manual is desired to first refer to when you start up systems of *iRVision* Bin Picking. This manual describes startup procedures of *iRVision* Bin Picking system, creating programs, caution, technical know-how, response to several cases, and so on.

**R-30iA/R-30iA Mate/R-30iB/R-30iB Mate CONTROLLER Ethernet Function  
OPERATOR'S MANUAL B-82974EN**

This manual describes the robot networking options such as FTP, RIPE, PC Share, and so on.

## 2 ABOUT VISION SYSTEM

This chapter explains vision-guided robot motion using *iR*Vision (*integral Robot Vision*).


### 2.1 BASIC CONFIGURATION

This section describes the basic configuration of the *iR*Vision system.

This manual describes the standard *iR*Vision configuration. Some applications might require special components. Refer to the application-specific *iR*Vision OPERATOR'S MANUAL for more information.

*iR*Vision consists of the following components:

- Camera and lens, or three-dimensional laser sensor
- Camera cable
- Lighting Equipment
- Camera multiplexer (used if needed)



For detailed information about the connection method between the Robot Controller and a camera, please refer to “R-30iB/R-30iB Mate CONTROLLER Sensor Mechanical / Control unit OPERATOR’S MANUAL”.

### 2.2 VISION-GUIDED ROBOT MOTION

FANUC robots are teaching-playback robots. In a teaching-playback system, specific tasks are taught to robots in advance, which then in turn work exactly as they are taught. A series of instructions that specify what robots are to do is called a *robot program*. The process of generating robot programs is called *teaching*, and the act of executing the taught robot programs is called *playback*. Teaching-playback robots play back the motion just as it was taught. Conversely speaking, what this type of robot can do is limited to what it is taught in advance. This means that, if you want the robot to manipulate every workpiece in the same way, you need to place every workpiece at exactly the same position. *iR*Vision is a visual sensor system designed to eliminate such restrictions. *iR*Vision measures the position of each workpiece by using cameras, and it adjusts the robot motion so that the robot can manipulate the workpiece in the same way as programmed even if the position of the workpiece is different from the workpiece position set when the robot program was taught.

#### Relative position offset

There are two methods for vision-guided robot motion - *absolute positioning* and *relative position offset*. With absolute positioning, the sensor measures the absolute position of the workpiece and the robot moves directly to that position. With relative position offset, the sensor measures how the workpiece

has moved relative to the position set when the robot program was taught. The robot then adjusts the taught position by this relative position before moving to it. *iRVision* adopts the latter approach - relative position offset.

### Reference position and actual position

The relative position of the workpiece used for offsetting the robot position is called the *offset data*. Offset data is calculated from the position of the workpiece set when the robot program was taught and the current workpiece position. The position of the workpiece set when the robot program was taught is called as the *reference position*, and the current workpiece position is called the *actual position*. The offset data is the difference between the reference position and the actual position. *iRVision* measures the reference position when a robot program is taught, and stores it internally. The operation of teaching the reference position to *iRVision* is called *reference position setting*.

## 2.3 FIXED FRAME OFFSET AND TOOL OFFSET


There are two kinds of robot position offset, *fixed frame offset* and *tool offset*. *iRVision* supports both kinds of robot position offset.

### Fixed frame offset

With fixed frame offset, the workpiece offset is measured in a coordinate frame fixed with respect to the robot base. A workpiece placed on a fixed surface or a container is viewed by a camera, and the vision system measures its position. The robot then adjusts its taught positions so that it can manipulate (pick up, for example) the workpiece properly.

### Tool offset

With tool offset, the workpiece offset is measured in a coordinate frame that moves with the robot tool. This method is useful for grippers where the part position in the gripper can vary, such as vacuum grippers. A workpiece held by the robot is viewed by a camera, and the vision system measures its position relative to the gripper. The robot then offsets its taught positions so that it can manipulate (place, for example) the workpiece properly.



Fixed frame offset

Tool offset

## 2.4 FIXED CAMERA AND ROBOT-MOUNTED CAMERA


A camera can be installed as a fixed camera or a robot-mounted camera. *iRVision* supports both of these positioning methods.

### Fixed camera

A fixed camera is attached to the top of the pedestal or another fixed structure. In this method, the camera always sees the same view from the same distance. An advantage of a fixed camera is that the robot cycle time can be reduced because *iR*Vision can take and process a picture while the robot performs another task.

### Robot-mounted camera

The robot-mounted camera is mounted on the wrist unit of the robot. By moving the robot, measurement can be done at different locations or with different distances between the workpiece and the camera. When a robot-mounted camera is used, *iR*Vision calculates the position of the workpiece while taking into account the camera movement resulting from the robot being moved.



## 2.5 CAMERA CALIBRATION

*iR*Vision finds parts in an image snapped from a camera. In order to compensate the robot based on the positional information that *iR*Vision found, the positional information needs to be converted from the camera coordinate system to a robot coordinate system (user frame or tool frame). In order to perform such data conversion, data which describes where the camera is placed and where the camera is looking is required. The data is called 'camera calibration'. Calibrating cameras accurately is very important so that your robot can be compensated accurately.

## 2.6 VISION DATA

Data entered by the user during *iR*Vision setup is called *vision data*. Like robot programs and I/O settings, vision data is stored in memory in the robot controller.



### CAUTION

Do not turn off the robot controller while saving vision data. Doing so may corrupt the FROM module memory and may interfere with normal robot operation.

### 2.6.1 Types of Vision Data

There are four types of vision data:

#### Camera Setup

Camera Setup data sets the camera port number, the type of the camera, the camera mounting method, and so on.



### **Camera Calibration**

Camera Calibration data establishes the mathematical correspondence between the coordinate system of camera images and the coordinate system in which the robot moves.

### **Vision Process**

Vision Process data is defining the image processing, location, and measurement to be performed by iR-Vision during production operation.

### **Application Data**

Application data are settings specific to an application.

## **2.6.2 Maximum Vision Data That can be Created**

---

Maximum number of vision data that can be created on your robot controller cannot be generally determined because it varies with various conditions. A guide for roughly estimating the maximum number of vision data that can be created on your robot controller is given here.

Vision data is stored in FROM of the robot controller. Accordingly, the capacity for storing vision data depends on the amount of free space in FROM of your robot controller. The more options that are installed, the smaller the free space of FROM is. The free space of FROM of your robot controller can be checked by selecting STATUS / Memory on the teach pendant.

The R-30iB controller has the automatic backup function, which automatically stores the backup of all user data such as robot programs periodically. The default destination of automatic backup is FROM (FRA:) and the two latest backups are saved by default. Accordingly, the capacity that can be used to store vision data is approximately one fourth of (free space – 1 MB) of FROM.

The maximum number of vision data that can be created also depends on the size of the vision data to be created. Generally, a vision process has the greatest size and its size depends on the model pattern taught in the locator tools. The size of a vision process ranges from about several KB to hundreds KB.

For example, assume that the free space of FROM is 10 MB and the average size of vision data is 100 KB. The capacity that can be used to store vision data would be about 2.2 MB, which is one fourth of 9 MB. Thus, the estimated number of vision data that can be created is approximately 22 (2.2 MB/100 KB).

## **2.6.3 To Create More Vision Data**

---

Vision data is stored in the FROM module of the robot controller. When free space on the FROM module is used up, no more vision data can be created. To create more vision data, free space can be increased as described below.

### **Disable automatic backup**

By default, the R-30iB/ R-30iB Mate controller is configured to make the backup automatically. By default, automatic backups are stored on the FROM and the most recent two sets are preserved. By disabling automatic backup, vision data about three times larger can be created. For the procedure for modifying the setting of the automatic backup function, refer to the “R-30iB/R-30iB Mate CONTROLLER OPERATOR’S MANUAL (Basic Operation)”.

### **Change the automatic backup destination to MC:**

By default, automatic backups are stored on FROM and the most recent two sets are preserved. By changing the automatic backup destination device from FRA: (FROM) to MC:, vision data about three times larger can be created on FROM. For the procedure for modifying the setting of the automatic

backup function, refer to “R-30iB/R-30iB Mate CONTROLLER OPERATOR’S MANUAL (Basic Operation)”.

### Exchange FROM module

For use with the R-30iB/R-30iB Mate controller, FROM modules of three different sizes are available: 32MB, 64MB and 128MB. If the size of FROM module on your controller is not large enough, replace FROM module with a larger one. By doing so, more vision data can be created. For FROM module replacement, consult with your FANUC technical representative.

## 2.7 USER FRAME AND USER TOOL

Position and posture of the robot are represented based on the frames. The user frame defines the working space for the robot to work. The user tool defines the position and orientation of the tooling (end effector). The origin of the user tool is also called TCP (Tool Center Point).

FANUC robots are teaching-playback robots. Robots of this method play back taught motion only. Therefore, in robot systems that do not use vision, you do not have to use frames because the robots just repeat the taught motion regardless of how accurate the frames are set up.

On the other hand, in robot systems that use a vision system, frames are very important. For instance, when the vision system returns the instruction to move 10 mm in X direction or to rotate 30 degrees around the Z-axis, the robot motion completely depends on the accurate definition of the frames.

### User Frame

The user frame defines the working space in which the robot works. The offset data from the vision system, (for example to move 10 mm in X direction or to rotate 30 degrees around the Z-axis,) are all respective to the user frame. Therefore it is very important to teach the user frame as accurately as possible. If the user frame was set up inaccurately, the robot would move to an incorrect direction or rotate around an incorrect axis.

In the case of a 2-dimensional fixed-frame offset vision application, the user frame covers another important role. It defines the 2-dimensional work plane in the real 3-dimensional space. The 2-D work plane for *iR*Vision must be parallel to the X-Y plane of the user frame.

See also the “R-30iB/R-30iB Mate CONTROLLER OPERATOR’S MANUAL (Basic Operation)” for information regarding detailed user frame setup procedures.

#### NOTE

Do not change the posture of the robot while teaching a user frame. If it is changed, the taught user frame will be less accurate.

### User Tool

The user tool defines the position and orientation of the robot tooling (end effector). In a robot system that uses vision, it is very important to teach an accurate TCP (Tool Center Point) of the pointer tool that is used during teaching the user frame. If the TCP is less accurate, the taught user frame will also be less accurate. In the case of a 2-dimensional tool-offset vision application, the user tool covers another important role, namely defining the 2-dimensional work plane.

See also the “R-30iB/R-30iB Mate CONTROLLER OPERATOR’S MANUAL (Basic Operation)” for information regarding detailed user tool setup procedures.

## Sharing User Frame

When two or more robots work together, it is necessary to configure the system so that these robots physically share the same user frame. This is called the sharing of the user frame. Specifically, the sharing of the user frame is needed in the following cases:

- Multiple robots are offset with a single set of offset data.
- The robot to be offset is different from the robot that has the camera.

User frame sharing requires that all robots use the same user frame number. For example, user frame 5 of robot 1 needs to be physically the same as user frame 5 of robot 2.



### **CAUTION**

If robots share user frames of different numbers, *iR*Vision cannot offset the robots correctly. Make sure that the robots share the same user frame number.

## Dynamic UFrame

*iR*Vision can offset the robot on Dynamic UFrame. But there are the following limitations. For details of the Dynamic UFrame function, refer to “R-30*i*B/R-30*i*B Mate CONTROLLER Coordinated Motion Function OPERATOR’s MANUAL”.

- Select Dynamic UFrame for [Offset Frame] of Vision Process.
- Generally, don’t select Dynamic UFrame for [Application Frame] of Camera Calibration.
- However, when the camera moves with Dynamic UFrame, for example when the camera is fixed on the positioner, select Dynamic UFrame for [Application Frame] of Camera Calibration.
- Don’t move Dynamic UFrame while performing RUN\_FIND and GET\_OFFSET commands. This means that, Dynamic UFrame must be at the same position after RUN\_FIND is called until GET\_OFFSET is called.

# 3 BASIC OPERATIONS

---

This chapter describes the basic operations for using *iR*Vision.

If you select “8 *iR*Vision” from MENU key, the following sub menus are displayed.

## Vision Setup

Displays the Vision Setup screen. For details, see Section 3.1, “VISION SEUTP”.

## Vision Runtime

Displays the Vision Runtime screen. For details, see Section 3.2, “VISION RUN-TIME”.

## Vision Log

Displays the Vision Log screen. For details, see Section 3.3, “VISION LOG”.

## Vision Config

Displays the Vision Config screen. For details, see Section 3.4, “VISION CONFIG”.

## Vision Utilities

Displays the Vision Utilities screen. For details, see Chapter 10, “VISION UTILITIES”.

### CAUTION

You need to use the *i*Pendant with touch panel, when you teach vision data on the *i*Pendant.

### NOTE


You can set up the *iR*Vision by using the *i*Pendant or the PC. This manual is written on the assumption that it is operated using the *i*Pendant. For operating on a PC, refer to the Chapter A, "TEACHING FROM PC"

## 3.1 VISION SETUP

---

On the Vision Setup screen, you can create, teach and test vision data. The Vision Setup screen is displayed with the following steps.

- 1 Press MENU key on the *i*Pendant.
- 2 Select [8 *iR*Vision], and then [1 Vision Setup].
- 3 The *i*Pendant displays the Vision Setup screen.



The Vision Setup screen shows the list of vision data. The following items can be displayed in the list.

### Name

The name of vision data is displayed. A name of up to 34 alphanumeric characters can be set.

### Comment

Any character string is indicated to provide additional information about vision data. A comment consisting of up to 50 one-byte or 25 two-byte characters can be set.

### Type

The type of vision data is displayed.

### Created

The time and date at which corresponding vision data was created for the first time is indicated.

### Modified

The time and date at which corresponding vision data was modified last is indicated.

### Size

The size of a vision data file in bytes is indicated. There is a limit to the size of a vision data file, and this limit is 2 MB by default.

### F1 [TYPE]

Brings you to another *iR*Vision menu screen.

### F2 CREATE

Creates a new vision data. For details, see Section 3.1.1, “Creating New Vision Data”.

### F3 EDIT

Opens the vision data edit screen. For details, see Section 3.1.5, “Editing Vision Data”.

### F4 [VTYPE]

Selects a type of vision data to be displayed in the vision data list.

- Camera Setup Tools
- Camera Calibration Tools
- Vision Process Tools
- Application Setup Tools

## F5 [ATTR]

Selects an item to be displayed in the second column of the vision data list.

- Comment
- Type
- Created
- Modified
- Size

## F6 COPY

Makes a copy of the vision data. For details, see Section 3.1.3, “Copy vision data”.

## F7 DETAIL

Displays the vision data detail screen. In vision data detail screen, you can verify type, created date and time, last modified date and time of the vision data. And you can also change name and comment of the vision data. For details, see Section 3.1.4, “Verifying Vision Data Detail Information”.

## F8 DELETE

Deletes the vision data. For details, see Section 3.1.2, “Deleting Vision Data”.

## F9 FILTER

Sets a filter to the list of vision data. For details, see Section 3.1.6, “Setting a Filter to List of Vision Data”.

## 3.1.1 Creating New Vision Data

To create new vision data, perform the following steps.

- 1 Press F2 CREATE.

The screenshot displays the 'iRvision Setup Main - Camera Setup Tools' dialog box. At the top, there is a status bar with buttons for 'Busy', 'Stop', 'Hold', 'Pause', 'Run', 'I/O', 'Prod', and 'Stop'. To the right of these buttons, it shows 'JOB LINE 0 T1 ABORTED JOINT' and a '10%' progress indicator. The main area of the dialog is a form titled 'Create new vision data' with the following fields:

- Type: KOWA Digital Camera (dropdown menu)
- Name: camera (text input field)
- Comment: (empty text input field)

At the bottom of the dialog, there are 'OK' and 'CANCEL' buttons.

- 2 In [Type], select the type of the vision data you are going to create.

- 3 In [Name], enter the name of the vision data you are going to create. The name can be up to 34 alphanumeric characters in length. The name must contain no spaces, not contain the symbol other than underscore, and start with start with a letter.
- 4 In [Comment], enter any character string providing additional information about the vision data if necessary. The comment can be up to 50 one-byte or 25 two-byte characters.
- 5 Press F4 OK.

**⚠ CAUTION**

The following names are not usable as the name of the vision data:  
 CON, PRN, AUX, NUL, COM1, COM2, COM3, COM4, COM5, COM6, COM7,  
 COM8, COM9, LPT1, LPT2, LPT3, LPT4, LPT5, LPT6, LPT7, LPT8, LPT9.

### 3.1.2 Deleting Vision Data

To delete vision data, perform the following steps.

- 1 In the list, select the vision data to be deleted.
- 2 Press F8 DELETE.




- 3 Press F4 OK.

### 3.1.3 Copying Vision Data

To make a copy of vision data, perform the following steps.

- 1 In the list, tap the vision data to be copied.
- 2 Press F6 COPY.




- 3 In [Name], enter the vision data name of the copy destination.
- 4 Press F4 OK.

### 3.1.4 Verifying Vision Data Detail Information

To display detailed information of vision data, perform the following steps.

- 1 In the list, tap the vision data to be verified.
- 2 Press F7 DETAIL.



- 3 In [Name], enter a new vision data name if you want to rename the vision data.
- 4 In [Comment], enter a new comment string if you want to change the comment.
- 5 Press F4 OK.


### 3.1.5 Editing Vision Data

To edit vision data, perform the following steps.



- 1 In the list, tap the vision data to be edited.
- 2 Press F3 EDIT.

The vision data edit screen has the following structure.



- A This area shows either the image display control, which shows an image from the camera, or the tree view, which describes the vision data structure. When a tool is selected in the tree view, the setting items for the tool are indicated in area B. For information on how to use the image display control, see Subsection 3.7.4, “Image Display Control”. For details about the tree view, see Subsection 3.7.5, “Tree View”.
- B This area shows the setting items for a vision tool selected in the tree view. At the top of this area, the name of the selected vision tool is displayed. Background of the vision tool name will be green when the vision tool is trained, or red when not trained. For details about setting items of individual vision tools, see Chapter 6, “VISION PROCESS”, and Chapter 7, “COMMAND TOOL”.
- C This area shows testing result of a vision tool selected in the tree view. This area is closed by default, and can be opened by pressing the “Result” tab. For details, see Chapter 6, “VISION PROCESS”, and Chapter 7, “COMMAND TOOL”.

## F1 [TYPE]

Brings you to another iRVision menu screen.

## F2 LIVE

Starts the camera live image display. See also 3.7.4 “Image Display Control”.

## F3 SNAP

Snaps a new camera image. See also 3.7.4 “Image Display Control”.

## F4 FIND

Performs a test detection of the selected vision tool. For details, see Chapter 6, “VISION PROCESS”, and Chapter 7, “COMMAND TOOL”.

## F5 END\_EDIT

Ends editing the vision data and brings you back to the vision data list screen. When the vision data is modified, a popup message will appear to confirm if you want to save the changes.

**F6 LASER ON/OFF**

Turns on or off the slit lasers of the 3D laser vision sensor. This operation is available only when the selected camera is the 3D laser vision sensor. See also Subsection 3.7.4 “Image Display Control”.

**F7 PLAYBACK**

Brings you to the image playback mode. About the image playback mode, see Subsection 3.7.17 “Image Playback”.

**F8 CONT\_S+F**

Continuously performs image snapping and test detection.

**F9 SNAP+FINE**

Performs a new image snapping and test detection.

**F10 SAVE**

Saves the vision data.

**⚠ CAUTION**

- 1 The new settings made by modifying the contents of the vision data edit screen are not saved until F5 END\_EDIT or F10 SAVE is pressed. You need to save the vision data so that the new settings are effective to the production operation.
- 2 Visiting another menu screen such as DATA/REGISTER does not save the vision data. The vision data is still under edit, and you can continue to edit the vision data after visiting back the *iR*Vision Setup screen.
- 3 The maximum number of vision data edit screen that you can open at the same time is limited to 1.
- 4 The vision data edit screen can be opened even during production operation to tune or change parameters. However, operations that can affect the production operation, i.e. snapping an image or performing test detection, are prohibit. When you want to make such operation, enable the Teach Pendant, or switch to the T1/T2 mode. Meantime, it is recommended that the vision data edit screen is not opened or left opened during production operation.


**NOTE**

To restore the original data after making modifications to the contents of the edit screen, close the edit screen by pressing F5 END\_EDIT without pressing F10 SAVE. The popup message to confirm if you don't want to save the modifications is shown. Then press F4 EXIT W/O SAVE.

**3.1.6 Setting a Filter to List of Vision Data**

By setting up a filter, the number of vision data displayed on screen can be reduced.

- 1 Press F9 FILTER in the list screen of vision data.
- 2 Filter Settings screen is displayed. Set up at least one of Type, Name and Comment.



## Type

Select a type of vision data that you want to display on the list screen of vision data. For example, if [KOWA Digital Camera] is selected as the type, only KOWA Digital Camera is displayed on the list screen. If [ALL] is selected as the type, all types of vision data are displayed on the list.

## Name

Specify a text string that should be included in the vision data name. Only vision data with the name including the specified text string are displayed on the list screen. When not specified, filtering is not performed with the vision data name.

## Comment

Specify a text string that should be included in the comment of vision data. Only the vision data with the comment including the specified text string are displayed on the list screen. When not specified, the filtering is not performed with the vision data comment.

## F2 CLEAR

Clear the setting of filter.


## F4 OK

The setting of filter is applied.

## F5 CANCEL

Filter Setting screen is closed and moves to the list screen of vision data.


While a filter is enabled, "Filter Enabled" is displayed on the list screen of vision data.




## 3.2 VISION RUN-TIME

On the Vision Runtime screen, you can monitor execution of vision processes during production operation. The Vision Runtime screen is displayed with the following steps.

- 1 Press MENU key on the *i*Pendant.
- 2 Select [8 *i*RVision], and then [2 Vision Runtime].
- 3 The *i*Pendant displays the vision runtime monitor screen.



Press F5 ZOOM+ to display the image larger.




Press F5 ZOOM- to change the display back.

### 3.2.1 Setting Filter to Vision Runtime

The filter setting enables to show only the specified vision processes on the Vision Runtime screen.

Press F3 FILTER to display the filter setting page.



On the filter setting page, set the following parameters. The filter setting can be done individually for iPendant and PC. The filter setting is kept even after rebooting the controller.

#### Enabled

Check this item to enable the filter. By default, it is not checked.

#### Type of Vis.Proc

Select the type of vision process to be displayed. Only the specified type of vision process is displayed. By default, all types of vision process are displayed.

## Name of Vis.Proc

Specify text strings that should be included in the vision process name and select whether the vision processes should be displayed or not. You don't have to specify entire name of the vision processes. You can specify multiple text strings by separating them with a white space.

## Display data including any of the following

Vision Runtime displays vision processes only when the vision process name includes any of the specified text strings.

## Display data not including any of the following

Vision Runtime displays vision processes when the vision process name does not include any of the specified text strings. In other words, it does not display vision processes when the vision process name includes any of the specified text strings.


## OK

Save the filter setting, and return to the previous page.

## CANCEL

Cancel the filter setting, and return to the previous page.


If the filter is enabled, "Filtered" is displayed on the title bar as shown below.



## 3.2.2 Freezing Vision Runtime

You can temporarily freeze the Vision Runtime screen. While being frozen, the Vision Runtime screen is not updated even if the controller runs a vision process.

Press F4 FREEZE to freeze the Vision Runtime screen.



Press F4 UNFREEZE to resume updating the Vision Runtime screen.

## 3.3 VISION LOG

*iR*Vision can write information about the execution of vision processes to the vision log.

### Recording the Vision Log

By default, *iR*Vision is configured to NOT record the vision log. To enable the vision log, please refer to 3.4 “VISION CONFIG”.

The vision log is recorded in the external memory device (MC: for R-30*i*B controller or UD1: for R-30*i*B Mate controller). If no memory device is inserted, the vision log is not recorded even when *iR*Vision is configured to record the vision log. When the free space of the memory device is less than the specified value (1 MB by default), old vision logs are deleted to make enough free space for writing a new vision log. *iR*Vision can delete only vision logs when the free space of the memory device is less than the specified value. If there are no vision logs which can be deleted, CVIS-130 “No free disk space to log” alarm is posted and the vision log will not be recorded.

**⚠ CAUTION**

- 1 Deleting old vision logs takes time. To avoid the need to do so, it is recommended to delete or to export vision logs to an external device on a regular basis to ensure that the memory device has enough free space. For information about how to export vision logs to an external device or how to delete them, see Section 10.3, "VISION LOG MENU".
- 2 If the free space of a memory device falls below the specified value as a result of other files being written to the memory device, the vision log function will try to delete vision logs until the free space is larger than the required value in the next vision execution. In this case, it may take time before the next vision execution can start, if there is a lot of data to be deleted. For example, storing everything to the memory card could cause such a case. However, it will not cause any problems if there is a backup already written to the memory card and its size is as large as that of new backup.
- 3 If you have vision logs recorded in a memory card with one controller and then execute a vision process with that memory card inserted into another controller, the vision logs recorded with the original controller may get overwritten.
- 4 Be sure to format Memory Card or USB memory with FAT16.

**Logging Images**

Images snapped by vision processes can be saved along with the vision log. The logged images that are saved can be used for future troubleshooting, as well as when performing a test run of a vision process. For information about how to run a test using logged images, see Subsection 3.7.17, "Image Playback". Images are saved as a part of the vision log on a memory device. Whether to save images to the vision log is specified for each vision process. In the edit screen for a vision process, select one of the following:

**Do Not Log**

Do not save any images to the vision log.

**Log Failed Images**

Save images only when the vision operation fails.

**Log All Images**

Save all images.

**⚠ CAUTION**

If you choose to save logged images, you cannot start next test detection without finishing preceding record of the vision log. Select [Log All Images] only when necessary for troubleshooting. Normally, select [Do Not Log] or [Log Failed Images]. The time required to log vision data depends on the type of vision process; see the section pertaining to the vision process concerned. The speed of the memory device is also a factor.

**NOTE**


If you have the vision log disabled in the Vision Config screen, logged images are not saved even when you set the vision process to save logged images.



## Viewing the Vision Log

On the Vision Log screen, you can view recorded vision logs. The Vision Runtime screen is displayed with the following steps.

- 1 Press MENU key on the *i*Pendant.
- 2 Select [8 *i*RVision], and then [Vision Log].
- 3 The *i*Pendant displays the vision log screen.



From the dropdown boxes in the upper right part of the screen, select the date and vision data name you want to view. If you want to view vision logs of all existing vision data, select [All Data].

The vision logs of the selected vision data recorded on the selected date are displayed on the right side of the screen. Tap a line in the list on the right side of the screen. The list in the lower part of the screen displays the detailed results of the selected execution. If any image has been saved during that execution, the saved image is displayed in the upper left part.

## File Configuration of the Vision Log

By default, the vision log is recorded in the folder MC:/VISION/LOG/. A sub-folder is created for each day under the folder and the vision log and images for the day are saved in the created sub-folder. For example,

MC:/VISION/LOG/Y12APR10/

is the sub-folder for April 10, 2012.

Under the sub-folder for the sub-folder of each day, three types of files are saved.

.VL      Logged data file  
 .PNG     Logged image file(Graphics)

### **CAUTION**

If the file name, the folder name or the folder structure was changed, the correspondence between the logged data and logged image becomes incorrect, and eventually the file cannot be utilized. Therefore, do not change the folder structure and file name when you copy them to another device.


The kinds of results that are displayed on the setup page are recorded in the Logged data file.

For detail of the log pass of the vision log, refer to the Section 3.4 "VISION CONFIG".

## 3.4 VISION CONFIG

On the Vision Config screen, you can set the system variables related to *iR*Vision. The Vision Config screen is displayed with the following steps.

- 1 Press MENU key on the *i*Pendant.
- 2 Select [8 *iR*Vision], and then [4 Vision Config].
- 3 The *i*Pendant displays the Vision Config screen.



### Disable Runtime Display

When this item is checked, the system does not perform any processing related to the vision runtime display and the Vision Runtime screen does not display any information. Network traffic as well as the time required for vision processing is reduced. By default, it is not checked.

### Runtime Display Buffer Size

The buffer size for images to be displayed on the Vision Runtime is selected from the following two items.

#### 640 x 512

By default, this size is selected. When the camera image is larger than this size, the image will be shrunk to fit the buffer, and displayed on the Vision Runtime screen.

#### 1280 x 1024

The buffer size is configured 4 times the default size. When you use a digital camera and you select a camera mode which is larger than 640x480 pixels, images displayed on the Vision Runtime can be high-resolution. However, resolution of images displayed on *i*Pendant cannot be higher than that of *i*Pendant display itself.

**⚠ CAUTION**

- 1 The memory usage increases about 2 MB when the “1280 x 1024” is selected as the buffer size. Please verify free space of the temporary pool before selecting the “1280 x 1024” mode.
- 2 Changing the size of Runtime Display Buffer requires rebooting the controller.

**Disable Images for iRConnect**

When this item is checked, the system does not perform any processing related to saving images for iRConnect function and images are not sent to your mobile device. Network traffic as well as the time required for vision processing is reduced. By default, it is not checked. This field is only visible if the R818 iRConnect option is loaded

**iRConnect Image Buffer Size**

The maximum size of images to be sent to your mobile device with the iRConnect function is selected from the following items. This field is only visible if the R818 iRConnect option is loaded

**640 x 512**

By default, this size is selected. When the camera image is larger than this size, the image will be shrunk to be smaller than this size, and then sent to your mobile device.

**1280 x 1024**

When you use a digital camera and you select a camera mode which is larger than 640x480 pixels, images sent to your mobile device can be high-resolution. This item is available only when the Runtime Display Buffer Size is set to “1280 x 1024”.

**⚠ CAUTION**

The memory usage increases about 2 MB when the “1280 x 1024” is selected as the buffer size. Please verify free space of the temporary pool before selecting the “1280 x 1024” mode.

**Decimal Comma**

When this item is checked, a comma (,) is used in place of a period (.) as a decimal point. This item is provided for use in Europe. By default, it is not checked.

**Enable Logging**

When this item is not checked, the system does not perform any processing related to saving of the vision log or logged images. By default, it is not checked. To enable the vision log, check it on.

**Log Path**

This item is used to specify the destination folder of the vision log or logged images. The available storage units for the vision log is Memory Card (MC:) and USB memory (UD1:) and PC Share (C1:). The default path is “MC:/VISION/LOG” for R-30iB and “UD1:/VISION/LOG” for R-30iB Mate.

**NOTE**

Press F1 KEYBOARD to open the software keyboard after tapping the text box of [Log Path].

**Data Path**

This item is used to specify the destination folder of vision data. This item is read-only and cannot be changed.

### Model Train File Path

This item is used to specify the destination folder for storing model train files and image files used with External Model Train function. This item is read-only and cannot be changed. Refer to 9.4.4 “IRVTRAIN” for External Model Train function.

### Allow test run in production

The vision data edit screen can be displayed even during production operation, namely when the teach pendant is disabled and the controller is in the AUTO mode. However, operations which can affect production operation (e.g., snapping an image, doing a test detection and so on) are forbidden on the edit screen during production operation. If this item is checked, you are allowed to do such operations even during production operation.



#### CAUTION

Snapping an image or performing a test during production operation may increase cycle time, stop the system due to lack of memories, and so on.

### Plot 4D Graphics during RUN\_FIND

When this item is checked, the calibration data and found results are displayed on the 4D Display screen when calling RUN\_FIND from an application program. This item is disabled by default because it can affect cycle time.

### 3D Map Storage Area

This item is used to specify the size of 3D Map Storage Area in DRAM. The size of 3D Map Storage Area is specified by the number of blocks, instead of in bytes. A block can store one normal-density 3D map. The item also shows number of coarse-density 3D maps and fine-density 3D maps that can be stored on the right for your reference. Storing a coarse-density 3D map requires one block, and storing a fine-density 3D map requires four blocks. Determine densities and number of 3D maps that you need to have simultaneously, and then calculate number of blocks for them. For example, when storing one coarse-density 3D map and one fine-3D map simultaneously requires 5 blocks. If you don't have them simultaneously, and you use them one after another, required number of blocks is 4.



#### CAUTION

- 1 Changing the size of 3D Map Storage Area requires rebooting the controller.
- 2 3D maps consume a large amount of memory. Increasing the size of 3D Map Storage Area will decrease the free space of the temporary memory pool. When you increase the size of 3D Map Storage Area, be sure to confirm the free space of the temporary memory pool after restarting the controller. If the free space of the pool is less than 3 MB, decrease the size of 3D Map Storage Area.

### Clipboard

This item shows the name of vision data and vision tool in the clipboard. The clipboard is used for the copy/paste operation. Contents of a vision tool can be copied to the clipboard and pasted from the clipboard tool to another tool in the same vision process or another vision process. Press [Clear] to clear the clipboard. Cycling power will also clear the clipboard.

## 3.5 BACKING UP VISION DATA

---

Vision Data is considered as the part of robot data (e.g., program). So, backing up and restoring Vision Data are considered as robot data.

### 3.5.1 Backing up Vision Data

---

Vision Data is saved when “All of the Above” is selected from the [Backup] function key on the FILE menu on the teach pendant of the robot. For details, refer to the “R-30iB/R-30iB Mate CONTROLLER OPERATOR’S MANUAL (Basic Operation)”.

### 3.5.2 Restoring Vision Data

---

Vision Data can be restored in two ways. One is to restore all Vision Data together with other robot data at Controlled Start. The other is to restore a specific Vision Data in the FILE menu. To restore a specific Vision Data, get a list of files with the extension VD and specify the file you want to restore. For details of the procedure, refer to the “R-30iB/R-30iB Mate CONTROLLER OPERATOR’S MANUAL (Basic Operation)”.

## 3.6 INTER-CONTROLLER COMMUNICATION

---

iRVision communicates with another robot controller in the following cases:

- Visual tracking system in which multiple robots participate
- Car body compensation system in which multiple robots uses the same vision offset
- Robot system in which a camera is mounted on a robot connected to another controller (Connect the camera cable to a controller with which iRVision option is installed)
- Robot system in which a camera calibration plate is held by a robot connected to another controller

For these inter-controller communications, ROS Interface Packet over Ethernet (RIPE) function is used. For details about the RIPE function, please refer to “R-30iA/R-30iA Mate/R-30iB/R-30iB Mate CONTROLLER Ethernet Function OPERATOR’S MANUAL”.

## 3.7 FREQUENTLY-USED OPERATIONS

---

This section describes operations frequently used during iRVision setup.

### 3.7.1 Text Box


---

In a text box, a value or a character string is entered.

Exposure Time:  ms.

- 1 Tap a text box.
- 2 Numeric values are inputted by using value hardkeys of *i*Pendant.
- 3 Text strings are inputted by using software keyboard.

If a text box for a text string is tapped, the software keyboard automatically appears on the screen of iPendant as follows.



- A Inputting keys.
- B Cursor keys and Space key.
- C Exchanging keys of inputting keys. You can input one byte character if [abc] is tapped. You can input numeric number and special symbol (e.g., @, #, \$, %) if [123] is tapped.

To finish inputting string, tap the [Exit] button.

For more information of software keyboard, please refer to “R-30iB/R-30iB Mate CONTROLLER OPERATOR’S MANUAL (Basic Operation)”.

### 3.7.2 Drop-Down Box

An item is selected from options.

Camera Type:

- 1 Tap a drop-down box.
- 2 From the displayed options, select a desired item.

### 3.7.3 List View


A list view is a table for displaying found results and other data.

#	Row(V)	Column(H)	Score	Contrast	Fit Error	Angle
1	132.6	479.4	99.8	173.4	0.163	-0.2
2	33.1	478.1	78.9	173.2	0.274	179.7

- 1 When a column header of the table is tapped, the table contents are sorted by the values of the column.
- 2 When a row of a table is tapped, the tapped line is highlighted.

## 3.7.4 Image Display Control

An image is displayed.



### Displaying live image

A live image from the camera is displayed. This is used when making camera and lens adjustments.

- 1 To start displaying the live image, press F2 LIVE.
- 2 To stop displaying the live image, press F2 STOP.

#### **CAUTION**

While the live image is being displayed, no other operation can be performed. Before another operation can be performed, the live image display must be stopped.

### Snapping an image

One image is snapped from the camera.

- 1 Press F3 SNAP.

### Turning the lasers of the 3D laser sensor ON or OFF

The laser of the three-dimensional laser sensor is turned on or off.

- 1 Press F6 Laser ON
- 2 When the F6 Laser OFF, the laser is turned off.

#### **NOTE**


The F6 LASER ON/OFF is only available only when the vision data is related to the three-dimensional laser sensor.

### Saving an image to a file

An image currently displayed in the image display control is saved to a memory card or a USB memory in the robot controller.

Images are saved in the PNG format. A PNG formatted image can be viewed using Windows Photo Viewer.

- 1 Tap  button. The following dialog is displayed:




- 2 Select the destination drive and folder in the folder tree.
- 3 Enter the file name of the destination in the [File] text box.
- 4 Press F4 OK.

 **CAUTION**  
An image currently displayed in the image display control is saved. The image with Graphics cannot be saved.

### Loading an image file

An image file in a memory card or a USB memory of the robot controller is loaded. After it is loaded, the image can be used for vision process setup and testing. Image Files in the BMP or PNG format can be loaded.

- 1 Tap  button. The following dialog is displayed:






- 2 Select the drive and folder that contains the image file to load in the folder tree.
- 3 Select a file to load in the [File] list.
- 4 Press F4 OK. The loaded image file appears in the image display control.

**NOTE**

Depending on settings of your vision process, test detection may not be available with an image loaded from an image file when additional information is required, for example position of robot holding the camera, laser images for 3DL sensor and so no). In those cases, an alarm indicating that test detection is not available will be posted. To test such a vision process, use logged images. For details, see Subsection 3.7.17, "Image Playback".

**Zoom Level**

The zoom level dropdown box is used to change display magnification of the image.



The following zoom levels are available.

- 12.5%
- 25%
- 33.3%
- 50%
- 100%
- 200%
- 400%
- 800%


**Scrolling an image**



When an image cannot fit in the display area, scroll bars are displayed on the image display control.

- 1 Tap on the scroll bar displayed on the right side or at the bottom of the image and move the bar vertically or horizontally. Or swipe the touch panel of *iPendant*.

**Maximizing the Image Display Control**


The size of the image display control can be maximized.





- 1 Tap  button to maximize image.
- 2 Tap  button to turn back.

### Displaying Center Line


Image center line can be displayed on the image display control.






- 1 Tap  button to display center line.
- 2 Tap  button to turn back.

### Check the grayscale/RGB value


The sampling tool shows the location and grayscale/RGB values of the selected pixel on the image.



- 1 Tap  button to enable the sampling tool.
- 2 Tap an arbitrary pixel on the image.
- 3 The location and grayscale of the pixel that is shown by  mark are indicated. If a color camera is used, the values of RGB are indicated.
- 4 Tap  button to disable the sampling tool.

### 3.7.5 Tree View

In the following figure, the surrounded area by the dot line on the *iR*Vision setup screen is called a tree view. The tree view is displayed if the tree tab is selected. The tree view indicates the structure of vision data.



In the above figure, for example, the 2D single-view vision process includes two GPM locator tools. Under the GPM Locator Tool 1, one histogram tool and one conditional execution tool is present. Elements that make up a vision process, such as the GPM locator tools, histogram tool, and conditional execution tool are called *command tools*.

When a vision process is executed, its command tools are executed sequentially from the top, and finally the vision process calculates offset data.

The measurement window of a command tool such as the Histogram 1 that is placed under the GPM Locator Tool 1 is shifted and rotated dynamically according to the position of the found workpiece by the GPM Locator Tool 1.

One of the tools displayed in the tree view is always highlighted. It is the tool currently selected in the setup window, and setting and testing can be performed for this tool.

The color of each tool displayed in the tree view indicates the setup status of the tool. When a tool is displayed in green, setup is complete for the tool. When a tool is displayed in red, at least one item requires setup. When all tools of a vision process are displayed in green, the vision process is completely set up.

#### Selecting a tool

Select the tool to be set up.


- 1 Tap the icon or the name of a tool in the tree view.
- 2 The tapped tool is highlighted, and the corresponding setting page and test page are displayed.

#### Adding a tool

A new command tool is added to a vision data.

- 1 Select a parent tool (one level higher) under which a new tool is to be inserted.

- 2 Tap the  button.




- 3 In [Type], select the type of the command tool to be inserted.
- 4 In [Name], enter the name of the command tool to be inserted.
- 5 Press F4 OK.

### Renaming a tool

The name of a command tool in a vision process is changed.

- 1 Select the tool to be renamed.
- 2 Tap the  button.




- 3 Type a new tool name.
- 4 Press F4 OK.


#### NOTE

The name of the top-level tool (the vision process) is also shown in the comment field of that vision process in the main vision process list page.

## Copying a tool

A copy of a command tool in a vision data is made.


- 1 Select the command tool to be copied.
- 2 Tap the  button.




- 3 In [Name], enter the copy destination name.
- 4 Press F4 OK.

## Copying a tool to the clipboard

This operation copies the contents of the selected vision process or command tool to the clipboard. Once the contents of a tool is copied to the clipboard it is available for pasting to another like tool using the Paste From Clipboard button. This function does not copy the selected tool's children. Only the contents of the selected tool are copied. Copying the children must be done separately.

- 1 Select the tool to be copied to the clipboard.
- 2 Tap the  button




- 3 Press F4 OK button


**NOTE**

The name of the tool in the clipboard and the name of the vision data that it was copied from are displayed on the Vision Config page.

**Pasting a tool from the clipboard**

This operation replaces the contents of the selected tool with the ones in the clipboard.

- 1 Select the tool to be pasted from the clipboard.
- 2 Tap the  button




- 3 Press F4 OK button


**NOTE**

- 1 The Paste From Clipboard operation is only allowed if the tool in the clipboard is the same type as the selected tool. For example; if a GPM locator tool is in the clipboard, the paste clip button will be grayed out unless the selected tool is a GPM locator tool.
- 2 The Paste From Clipboard operation is not allowed if the tool in the clipboard is not dynamically located but the selected tool is dynamically located. For example; if a parent GPM locator tool is in the clipboard, it cannot be pasted to a child GPM locator because the parent does not have a dynamically located search window but the child does. The Paste From Clipboard button will be grayed out if the selected tool is dynamically located and the tool in the clipboard is not.

**Deleting a tool**

A command tool is deleted from a vision process.

- 1 Select the command tool to be deleted.
- 2 Tap the  button.



3 Press F4 OK.

**CAUTION**  
 After a command tool is deleted, it cannot be restored. If a command tool is deleted by mistake, end editing the vision data without saving it, then open the edit screen for the vision data again to start over using the original vision data.

### Changing the order of a tool

The order of a command tool is changed to change the execution sequence.

- 1 Select a command tool of which order is to be changed.
- 2 To move the command tool upward, tap the button.
- 3 To move the command tool downward, tap the button.

**NOTE**  
 It is not possible to change the level of a command tool in the tree hierarchy.

### 3.7.6 Result View


Result View displays the detection results of vision process or command tool.

Results										
Time to Run:	Pixels	Max.	Min.	Median	Mode	Mean	Std. Dev.	In Range(%)	Out of Range(%)	
0.0 ms	420	31	23	25	25	25.4	1.3	0.0	100.0	

By default, Result View is invisible. Result View is displayed by tapping button of the result tab. If button is tapped again, the display area of Result View expands. Tap button to close the result view.

### 3.7.7 Tab

When setting items cannot fit in a window, the screen display is changed by using tabs.






In the above example, there are three tabs, [Setup], [Data] and [Points], and the white tab with black font, which is [Setup], is currently selected. To switch to another tab, press a light-colored tab.

### 3.7.8 Setting Points

Positions such as the model origin are set on an image graphically.

- 1 When the button for setting a point is tapped in the setup window for a tool, the display of the image display control changes as follows:



- 2 Tap the position of the point which you want to configure on the image.
- 3 Adjust the position of  by using the cursor keys of the iPendant. Or tap the position to which you want to move  on the image.
- 4 To change the position of  back to the default, press F2 RESET.
- 5 To cancel the previous operation, press F1 UNDO.
- 6 To complete the setting, press F4 OK.
- 7 To cancel the setting, press F5 CANCEL.

#### NOTE


While setting points, it is also possible to zoom in/out and scroll the image to make operations easy.

### 3.7.9 Window Setup


A window such as a search area is set graphically on the image.




- 1 When the button for setting an area is tapped in the setup screen for a tool, the display of the image display control changes as follows:



- 2 The position and size of the window is controlled by moving the control points. As shown below, a window has 9 control points. The position of the window can be moved by moving the control point 5. The size of the window can be changed by moving the control points 1 to 4 and 6 to 9. A control point is displayed as a small solid square. The midair square is displayed around the selected control point. In the figure below, the control point 5 is selected. By tapping arbitrary position on the image, the selected control point moves to the tapped position. If a control point except the selected one is tapped, the tapped control point gets selected. You are also able to adjust the position of control points by using the cursor keys of the *i*Pendant. When the cursor keys of the *i*Pendant are pressed, the control points move by 1 pixel to the direction of the cursor keys. If the cursor keys are pressed with SHIFT key, the control point moves by 10 pixels.

When  button is tap, the window is set the whole image.

When  button is tap, the control points number is displayed.




- 3 To move the position of the window, select the control point 5, and then tap the position which you want to move the control point to on the image.
- 4 To change the size of the window, select one of the control points 1 to 4 and 6 to 9, and then tap the position which you want to move the selected control point to on the image.
- 5 To put the size and position of the window back on the original, press F2 RESET.
- 6 To undo the previous operation, press F1 UNDO.
- 7 To complete the window setting, press F4 OK.
- 8 To cancel the window setting, press F5 CANCEL.

**NOTE**

- 1 During window setup, it is also possible to zoom in/out and scroll the image to make operations easy.
- 2 You can also select or move the control point by hardware key of the *i*Pendant.

Some tools such as the histogram tool and the edge pair locator tool allow you to rotate the rectangular window. In this case, you will see an additional horizontal line from the rectangular window as shown below. An additional line has the control point for rotation on the tip. You can rotate the rectangular window by selecting the control point and moving it.




### 3.7.10 Segmented-Line Setup

A segmented-line is set graphically on the image. There are two procedures, one for creating a new segmented-line and the other is to edit an existing segmented-line.


#### Creating Segmented-Line

Perform the following steps to create a new segmented-line.

- 1 When the button for creating a new segmented-line is tapped in the setup screen for a tool, the display of the image display control changes as follows:




- 2 Tap where you want to place a vertex of the segmented-line in turn on the image. A vertex is created where you tapped. You can adjust the position of the vertex by using the cursor keys.
- 3 Tapping the first vertex of the segmented-line closes the segmented-line, and creates a polygon. Once it is closed, you can add no more vertexes.
- 4 If you want to edit the created segmented-line, press F2 EDIT. Please refer to [Edit Segmented-Line] described later.



- 5 To complete creating the segmented-line, press F4 OK.
- 6 To cancel creating the segmented-line, press F5 CANCEL.

### Editing Segmented-Line

When the button for editing a segmented-line is tapped in the setup screen for a tool or F2 EDIT is pressed during creating a new segmented-line, the display of the image display control changes as follows:



On this screen, you can move, add, delete verteces of the segmented-line. And you can also make a part of the segmented-line an arc.

### Move vertex

Perform the following steps to move a vertex.

- 1 Select the vertex you want to move by pressing F8 PREV and F9 NEXT or tapping the vertex itself on the image.
- 2 Move the vertex by pressing the cursor keys or tapping where you want to move the vertex to on the image.

### Add vertex

Perform the following steps to add a vertex. The new vertex is added between the selected vertex and the following vertex.

- 1 Select the start vertex of the segment on which you want to add a vertex by pressing F8 PREV and F9 NEXT or tapping the vertex itself on the image.
- 2 Add the vertex by pressing F6 ADD.

### Delete vertex

Perform the following steps to delete the vertex.

- 1 Select the vertex you want to delete by pressing F8 PREV and F9 NEXT or tapping the vertex itself on the image.
- 2 Delete the vertex by pressing F7 DELETE.

### Make arc

Perform the following steps to make a part of the segmented-line an arc. An arc is composed of three vertices, and specifying a vertex as an arc point creates an arc using the vertex and vertices in front and behind.


- 1 Select the vertex you change to make an arc point by pressing F8 PREV and F9 NEXT or tapping the vertex itself on the image.
- 2 Make the vertex an arc point by pressing F10 ARC.

If you want to make an arc back to lines, press F10 UN-ARC after selecting the arc point.


### 3.7.11 Circle Setup

A circle is set graphically on the image.


- 1 When the button for adding/editing a circle is tapped in the setup screen for a tool, the display of the image display control changes as follows:



- 2 The position and the size of a circle are controlled by moving the four control points. Moving the control point 0 moves the circle without changing its size. Moving the control points 1 to 3 moves the circle so that the circle passes on the three control points. A control point is displayed as a small solid square. The midair square is displayed around the selected control point. In the figure below, the control point 0 is selected. By tapping arbitrary position on the image, the selected control point moves to the tapped position. If a control point except the selected one is tapped, the tapped control point gets selected. You are also able to adjust the position of control points by using the cursor keys of the *iPendant*. When the cursor keys of the *iPendant* are pressed, the control points move by 1 pixel to the direction of the cursor keys. If the cursor keys are pressed with SHIFT key, the control point moves by 10 pixels.



- 3 Move the control points of a circle and adjust the position and the size of a circle.




- 4 To complete the circle setting, press F4 OK.
- 5 To cancel the circle setting, press F5 CANCEL.

### 3.7.12 Single Line Setup

A single line is set graphically on the image.

- 1 When the button for adding/editing a single line is tapped in the setup screen for a tool, the display of the image display control changes as follows:




- 2 The position, angle and length of a single line are controlled by moving the three control points. Moving the middle control point moves the single line without changing its length and angle. Moving the control points of the both ends changes the position, angle and length of the single line. A control point is displayed as a small solid square. The midair square is displayed around the selected control point. In the figure below, the control point 0 is selected. By tapping arbitrary position on the image, the selected control point moves to the tapped position. If a control point except the selected one is tapped, the tapped control point gets selected. You are also able to adjust the position of control points by using the cursor keys of the *iPendant*.

When the cursor keys of the *i*Pendant are pressed, the control points move by 1 pixel to the direction of the cursor keys. If the cursor keys are pressed with SHIFT key, the control point moves by 10 pixels.



- 3 Move the control points of the single line and adjust its position, angle and length.




- 4 To complete the single line setting, press F4 OK.
- 5 To cancel the single line setting, press F5 CANCEL.


### 3.7.13 Double Line Setup

A double line is set graphically on the image.

- 1 When the button for adding/editing the double line is tapped in the setup screen for a tool, the display of the image display control changes as follows:




- 2 The position, angle, length and width of a double line are controlled by moving the five control points. Moving the center control point moves the double line without changing its length, angle and width. Moving the two control points on the dotted lines changes the position, angle and length of the double line. Moving the other two control points, which are on the solid lines, changes the width of the double line. In the following figure, the dotted lines indicate the width direction of the double line. Teach so that two solid lines overlap with the lines on the image. A control point is displayed as a small solid square. The midair square is displayed around the selected control point. In the figure below, the control point 0 is selected. By tapping arbitrary position on the image, the selected control point moves to the tapped position. If a control point except the selected one is tapped, the tapped control point gets selected. You are also able to adjust the position of control points by using the cursor keys of the *iPendant*. When the cursor keys of the *iPendant* are pressed, the control points move by 1 pixel to the direction of the cursor keys. If the cursor keys are pressed with SHIFT key, the control point moves by 10 pixels.



- 3 Move the control points of the double line and adjust the position, angle, length and width of the double line.






- 4 To complete the double line setting, press F4 OK.
- 5 To cancel the double line setting, press F5 CANCEL.

### 3.7.14 Editing Masks

Masks are edited on the image graphically.

- 1 When the button for editing masks is tapped in the setup screen for a tool, the display of the image display control changes as follows:



#### NOTE


- 1 Masked parts are filled in red. When mask editing is performed for the first time, begin with the display where no red part is present.
- 2 In the window for editing masks, it is also possible to enlarge, reduce, and scroll the image to make operations easy.


**NOTE**

The Drawing Freehand function and the Erasing Freehand function can be used only when a PC is used for editing mask. For details, refer to A.3.5, "Editing Mask".


**Drawing polygonal lines**

A mask is drawn with polygonal lines.

- 1 Tap  button.
- 2 Select the thickness of pen from three items "Thin", "Medium" and "Thick" by using the drop-down box of pen.
- 3 Tap vertex of polygonal lines in turn on the image.
- 4 If the first vertex of the polygonal lines is tapped, the polygonal lines get closed and create a polygon. Vertices of polygon become control points. The control points can be selected moved in a similar manner as Subsection 3.7.10 "Segmented-Line Setup".
- 5 If you want to edit the created segmented-line, press F2 EDIT. For details of the operation, refer to 3.7.10 "Segmented-Line Setup".





- 6 If you press F3 DRAW, the mask in the shape of the configured polygonal lines is drawn.
- 7 If you press F4 ERASE, the mask is erased along the configured polygonal lines.




### Drawing a rectangle

A filled rectangle is drawn.

- 1 Tap  button.
- 2 Tap an arbitrary position on the image, then a rectangle is displayed.





- 3 A rectangle has 9 control points and can be moved in a similar manner as Subsection 3.7.9 “Window Setup”.
- 4 If you press F3 DRAW, the mask in the shape of the rectangle is drawn.
- 5 If you press F4 ERASE, the mask in the shape of the rectangle is erased.




### Drawing an ellipse

A filled ellipse is drawn.


- 1 Tap  button.
- 2 Tap an arbitrary position on the image, then an ellipse is displayed.



- 3 The position, the size and the angle of an ellipse are controlled by moving the six control points. Moving the control point 5 moves the ellipse without changing its size and angle. Moving the control points 2, 4, 6 and 8 moves the ellipse with changing its size. Moving the control point 0 rotates the ellipse. A control point is displayed as a small solid square. In the figure below, the control point 5 is selected. By tapping arbitrary position on the image, the selected control point moves to the tapped position. If a control point except the selected one is tapped, the tapped control point gets selected.





- 4 If you press F3 DRAW, the mask in the shape of the ellipse is drawn.
- 5 If you press F4 ERASE, the mask in the shape of the ellipse is erased.




**Drawing a circle**

A filled circle is drawn.

- 1 Tap  button.
- 2 Tap an arbitrary position on the image, then a circle is displayed.




- 3 A circle has 4 control points, and can be moved in the same manner as Subsection 3.7.11 “Circle Setup”.
- 4 If you press F3 DRAW, the mask in the shape of the circle is drawn.
- 5 If you press F4 ERASE, the mask in the shape of the circle is erased.



### Filling in a closed area

An enclosed area is filled.


- 1 Tap  button.
- 2 Tap the position which you want to fill on the image.

#### NOTE

If the tapped area is not completely enclosed by a red line, the entire image is filled. So, when drawing freehand or with polygonal lines, make sure that the contour line is connected properly.

### Clearing in a closed area

An enclosed area is unmasked.

- 1 Tap  button.
- 2 Tap the position which you want to erase on the image.

### Filling the entire image

The entire image is filled.

- 1 Tap [Mask All] button.

### Clearing the entire image

The entire image is unmasked.

- 1 Tap [Unmask All] button.

### Undoing

The most recently performed operation is canceled to restore the previous state.

- 1 Press F1 UNDO.

## Ending editing

Mask editing is ended.

- 1 To complete mask editing, press F4 OK.
- 2 To cancel mask editing, press F5 CANCEL.

## 3.7.15 Setting Exposure Mode

Most vision processes, except some vision processes such as visual tracking, support image snap functions called *automatic exposure* and *multi-exposure* as well as usual image snapping where a specified exposure time is used. Vision processes use the same user interface to set an exposure mode.

Exposure Mode:	Fixed	
Exposure Time:	33.333 ms	↓ ↓ ↑ ↑
Auto Exposure Area:	Not Trained	Train
Auto Exposure Adjust:	0	Mask
Multi Exposures:	1 , 33.333 - 33.333 ms	
Multi Exposure Area:	(0,0) 494×652	Train
Multi Exposure Mode:	Deviation	Mask

## Exposure Mode

Select an exposure mode.

### Fixed

Always uses a specified exposure time for image snapping.

### Auto

Automatically selects an exposure time for image snapping according to the brightness of the surrounding environment that changes from time to time. By saving a reference image in advance, an appropriate exposure time is selected so that the snapped image has the same brightness as that of the reference image.

## Exposure Time

This item also called the electronic shutter speed. When [Fixed] is specified in [Exposure Mode], specify an exposure time. When [Auto] is specified in [Exposure Mode], this item cannot be modified, and the exposure time selected by software when the latest image was snapped is shown.

## Auto Exposure Area

Specify the photometric area for automatic exposure. The image displayed when the photometric area is set is used as the reference image for automatic exposure.

Perform the following steps to set the photometric area:

- 1 Set [Fixed] in [Exposure Mode].
- 2 Adjust the exposure time to obtain appropriate brightness for the image.
- 3 Set [Auto] in [Exposure Mode].
- 4 If [Auto Exposure Area] is [Not trained], the window opens to set the photometric area. For the operation method, see Subsection 3.7.9, “Window Setup”. In the case of [Trained], tap the [Train] button to set the photometric area.
- 5 If there is any area to be ignored in the photometric area, tap the [Mask] button to mask the area to be ignored. For information on how to set a mask, see Subsection 3.7.14, “Editing Masks”.

**NOTE**

- 1 In [Auto Exposure Mode], a completely white or black area of the image cannot be specified. Set an area in intermediate gray shades as the photometric area.
- 2 Areas that show large changes in brightness are not appropriate for [Auto Exposure Area]. For example, in an area that might contain a workpiece, it is impossible to make stable measurements because the visible brightness changes largely depending on whether the workpiece is present or not. Choose a background area instead.

**Auto Exposure Adjust**

Fine adjustments can be made for automatic exposure to obtain slightly brighter or darker images than the set reference image. A value from -5 to +5 can be selected. As the value increases in the positive direction, snapped images become brighter, and as the value decreases in the negative direction, snapped images become darker.

**Multi Exposure**

The multi-exposure function snaps multiple images by changing exposure time and combines them to generate an image with a wide dynamic range. Specify the number of images to be snapped.

A value from 1 to 6 can be specified. As more images are snapped, a wider dynamic range results, but a longer time is required for image snapping.

**Multi Exposure Area**

Specify the photometric area used for multi-exposure. Image synthesis is performed based on the brightness in the photometric area. As the default, the photometric area is set full screen. Usually, it is not necessary to change.

To set the photometric area, tap the [Train] button to set a window. For information on how to set a window, see Subsection 3.7.9, “Window Setup”.

When the photometric area includes an area of which brightness is to be ignored, tap the [Mask] button to mask the area to be ignored. For information on how to set a mask, see Subsection 3.7.14, “Editing Masks”.

**Multi Exposure Mode**

Select a method for image synthesis in multi-exposure.

**Deviation**

The standard deviation of the image brightness in the photometric area is calculated, and synthesis is performed so that slight halation occurs in the image. This is the default setting.

**Maximum**

Synthesis is performed so that no halation occurs in the image in the photometric area. If halation occurs at even one point in the photometric area, the other part becomes relatively dark.

**Average**

Synthesis is performed simply averaging the gray level of pixels. This method can provide the widest dynamic range but might make the entire image darker.



## 3.7.16 Sorting

Some vision processes support a function for sorting detected targets based on the specified value. The operation of the sort function is common to the vision processes.

Sort by:	Parent Cmd. Tool Level ▾
Sort key:	Score ▾
Sort order:	Desc. ▾

- 1 Select a sort level used as the sort key in the [Sort By] drop-down box.
- 2 Select a measurement value used as the sort key in the [Sort Key] drop-down box.
- 3 Select an order of sort in the [Sort Order] drop-down box.

The following items are provided for the [Sort By] drop-down box.

### Vision Process Level

Targets are sorted based on a value such as X, Y, or Z which are calculated by the vision process.


### Parent Command Tool Level

Targets are sorted based on a measurement value such as Vt, Hz, the size, or the score of the parent locator tool.


### Child Command Tool Level

Targets are sorted based on a measurement value of the child tool, such as histogram or length measurement, placed under the locator tool.


When found results are to be sorted by the measurement results of a child tool added to a locator tool, such as a histogram, the child tool must be placed as the first child tool. In the configuration shown below, for example, when sorting by the results of Histogram 2 is to be performed, change the order of Histogram 1 and Histogram 2.



When there are multiple locator tools, and sorting by the results of child tools of the locator tools is to be performed, the results of the child tools can be used as the sorting key only when the first child tools of all locator tools are of the same type. In case of (a) below, for example, sorting by histogram results is possible; in case of (b), however, sorting by histogram results and length measurement results is not permitted.



(a)



(b)

Some types of vision processes allow you to sort found results with the following methods. To use the following methods, select [Vision Process Level] for the [Sort By] dropdown box.

### Shortest Path

The shortest path sorting method sorts the found results to minimize the total (X, Y) distance traveled to send the robot to each result in sequence along a continuous path. If the robot has a multi-pick gripper that can pick up all of the parts, and if the parts are to be picked up with only (X, Y) offsets, this sorting option will minimize the length of the robot path.

### Shortest Path Theta

The shortest path Theta sorting method sorts the found results to minimize the total (X, Y, Theta) distance traveled to send the robot to each result in sequence along a continuous path. The angle Theta is scaled such that a rotation of 180 degrees is equivalent to an (X, Y) displacement from the top left corner of the image to the bottom right corner of the image. If the robot has a multi-pick gripper that can pick up all of the parts, and if the parts are to be picked up with (X, Y) and rotation offsets, this sorting option will minimize the length and wrist rotation of the robot path.

## 3.7.17 Image Playback


Images logged during production operation can be used to test and adjust location parameters. When location parameters have been changed, for example, this function is useful to use past images to check for any problem.

When the camera is mounted on a robot, both the image and the robot's position are logged, so it is possible to reproduce the situation in which production operation was performed including the position data of the robot.


For information on how to save logged images, see Section 3.3, "VISION LOG".

Below are the steps for image playback,

- 1 Press F7 PLAYBACK.



2 The bottom of the setup frame and the function key labels change as follows.



- A Select the time zone which logged image was saved. When you first start image playback mode, all logged image which can use on the vision process are selected. If you want to use the image which is saved on the specified time zone, select the specified time zone. Such as the above example, the image which is saved from 0:00 to 24:00 on August 7 of 2014.
- B Display the total number of the logged image which is saved in the time zone which is specified on “A” and the logged image number which is displayed on the screen. The above example shows that there are 3 images which are saved from 0:00 to 24:00 on August 7 of 2014, and the first image of these images is displayed.

**F1 [TYPE]**

Brings you to another iR-Vision menu screen.

**F2 PREV**

Loads the previous image.

**F3 NEXT**

Loads the next image.

**F4 FIND**

Performs a test detection by using the image displayed on the image display.

**F5 END\_EDIT**

Ends editing the vision data and brings you back to the vision data list screen. When the vision data is modified, a popup message will appear to confirm if you want to save the changes.

**F7 CAMERA**

Finish the image playback mode.

**F8 [FUNC]**

Performs the following operation.

- First image: Loads the first logged image.
- Last image: Loads the last logged image.
- Forward playback: Executes the operation which loads the next image and performs a test detection by using it repeatedly.
- Reverse playback: Executes the operation which loads the previous image and performs a test detection by using it repeatedly.

**F10 SAVE**

Saves the vision data.

**NOTE**

Even in the image playback mode, it is possible to change parameters or perform a test detection of individual vision tools.

**CAUTION**

In the image playback mode, SAVE IMAGE, LOAD IMAGE, LIVE, SNAP, LASER ON/OFF, 2-3D SNAP, CONT S+F and SNAP+FIND buttons are not available.

## 3.8 PASSWORD PROTECTION OF VISION DATA

You can restrict the operations to *iR*Vision by using the password function. As shown in the following table, the operations can be restricted according to the level of password. As for the password function, refer to “9.10 PASSWORD FUNCTION” in the “R-30/B/R-30/B Mate CONTROLLER OPERATOR’S MANUAL (Basic Operation)”.


Level	Restricted operation and edit
Install Setup	Operations to <i>iR</i> Vision are not restricted.
Program Operator	<ul style="list-style-type: none"> <li>• In the Vision Setup page, the following operations to vision data are restricted: Creating new vision data, deleting vision data, saving vision data, changing vision data name, and changing vision data comment.</li> <li>• In the Vision Config page, any item can be not changed.</li> <li>• In the Vision Utilities page, the following operations are restricted; LIVE, FIND, EXECUTE, Log Export, and changing items.</li> </ul>

# 4 CAMERA SETUP

This chapter describes how to set up camera setup tools.

## 4.1 KOWA DIGITAL CAMERA

When the KOWA Digital Camera setup window is opened, the following screen is displayed.



### Channel

Select the channel to which the camera is connected. When multiplexers are not used, only a camera can be connected. When multiplexers are used, up to 16 cameras can be connected.

### Camera Type

The type of the connected camera is displayed.

### Def. Exposure Time

Set the exposure time for capturing images in this window.

### Robot Mounted Cam.

Check this check box when the camera is mounted on the robot end of arm tool.

### Robot Holding Cam.

When a robot-mounted camera is used, set the robot that is holding the camera.

### Use Strobe

Check this check box when a stroboscopic light is used. LED light can flash synchronizing with image acquisition of the camera by connecting the trigger signal line from the CCU or the Digital MUX to the strobe light power supply unit.

**⚠ CAUTION**

- 1 The cable connecting CCU/Digital MUX and the strobe power supply unit, the strobe power supply unit, and the strobe light should be arranged by a customer.
- 2 Uncheck this check box if you want to use the camera as the 3D laser vision sensor. By default, the box is not checked.
- 3 The LED light of Camera Package does not support the strobe function.

**Gain**


Change this value to adjust the brightness of an image. The image becomes brighter when this value is increased, and the image becomes darker when this value is decreased. But the image becomes noisy when this value is increased too much. The default value is 1.

**Camera Parameters**

The internal specifications of the selected camera are indicated.

**4.1.1 Grayscale Camera**

When a grayscale camera is connected to the selected channel, the following screen is displayed.



**Mode**

Select a camera mode (image size) from the following:

Camera	Image size	Note
SC130E B/W	1/8" QVGA (320 pixel × 240 pixel)	–
	1/3.6" QVGA (320 pixel × 240 pixel)	Compared to the "1/8" QVGA (320 × 240)", the camera has nearly doubled size of FOV.
	1/3.6" VGA (640 pixel × 480 pixel)	By default, this mode is selected.
	1/1.8" VGA (640 pixel × 480 pixel)	Compared to the "1/3.6" VGA (640 × 480)", the camera has doubled size of FOV.
	1/2.5" XGA (1024 pixel × 768 pixel)	–
	1/1.8" SXGA (1280 pixel × 1024 pixel)	–
	VGA_WIDE (1280 pixel × 480 pixel)	–
	VGA_TALL (640 pixel × 960 pixel)	–
SC130C	1/6" QVGA (320 pixel × 240 pixel)	–


Camera	Image size	Note
(Old model)	1/3" QVGA (320 pixel × 240 pixel)	Compared to the "1/6" QVGA (320 × 240)", the camera has doubled size of FOV.
	1/3" VGA (640 pixel × 480 pixel)	By default, this mode is selected.
	2/3" VGA (640 pixel × 480 pixel)	Compared to the "1/3" VGA (640 × 480)", the camera has doubled size of FOV.
	1/1.8" XGA (1024 pixel × 768 pixel)	–
	2/3" SXGA (1280 pixel × 1024 pixel)	–
	VGA_WIDE (1280 pixel × 480 pixel)	–

**⚠ CAUTION**

- 1 When you changed this Mode, you need to re-calibrate cameras and retrain locator tools, and so on.
- 2 When the 3D laser vision sensor with the KOWA Digital Camera is used, select the 1/1.8" VGA as the camera mode (image size) on the camera setup page.

### 4.1.2 Color Camera

When a color camera is connected to the selected channel, the following screen is displayed.



#### Mode

Select a camera mode (image size) from the following:

Camera	Image size	Note
SC130E COLOR	1/3.6" QVGA (320 pixel × 240 pixel)	–
	1/1.8" VGA (640 pixel × 480 pixel)	By default, this mode is selected.
SC310M (Old model)	1/6" QVGA (320 pixel × 240 pixel)	–
	1/3" VGA (640 pixel × 480 pixel)	By default, this mode is selected.
	1/2" XGA (1024 pixel × 768 pixel)	–

#### Gamma

From the drop-down box, select a gamma value to be used from 1.0, 1.4, and 2.0. The dynamic range of an image becomes larger (dark areas become brighter and bright areas become darker) when this value is increased. But the resolution of color is declined when this value is increased. The default value is 1.


## Enable color extract on Camera

Check this check box to allow color extraction on Camera.

Usually, color extraction is performed by the Color Extraction Tool inserted in a vision process. But when this check box is checked, color extraction is performed on camera if no command tools in the vision process use the color image except for one Color Extraction Tool. When color extraction is performed on camera, the camera transfers a color extracted grayscale image to the controller instead of a color image. A color extracted grayscale image is smaller than a color image in size, so the vision process execution time will be shorter. About the Color Extraction Tool, please refer to Section 7.27 “Color Extraction Tool”.

## White Balance

Adjust the proportion of RGB gains to capture a white object as white pixels on an image.




Put a white object in the field of view and tap the [Set] button to set a measurement area on the white target, then the proportion of RGB gains is calculated. At this time, the measurement area must not include any colors except white. When the [Reset] button is tapped, the proportion of RGB gains is set to the default value. The image becomes reddish when the R gain is increased, the image becomes greenish when the G gain is increased, the image becomes bluish when the B gain is increased. The default value is (1.0:1.0:1.0).



## 4.2 SONY ANALOG CAMERA

When the Sony Analog Camera setup window is opened, the following screen is displayed:



### Port Number

Select the port number of the port to which the camera is connected. When a multiplexer is not connected, only port 1 can be selected. When a multiplexer is connected, port 1 to 4 can be selected. Up to 4 cameras and 3D laser sensors in all can be connected.

### Camera Type

Select the type of the camera connected.

### Def. Exposure Time

Set the exposure time to be applied when camera images are snapped using this window.

### Robot Mounted Cam.

Check this check box when the camera is mounted on the robot end of arm tooling.

### Robot Holding the Cam.

When a robot-mounted camera is used, set the robot that is holding the camera.

### Camera Parameters

The internal specifications of the selected camera are indicated.


## 4.3 KOWA USB CAMERA

The Kowa USB camera is used when the *iR*Vision function is used on ROBOGUIDE.

### CAUTION

- 1 To use USB Camera, you must install driver software in your PC. If your OS of PC is Windows XP, please install software by using the CD which is bundled in KOWA USB Camera. If your OS of PC is Windows 7, please contact your FANUC technical representative. Windows Vista is not supported.
- 2 Connect the USB camera before starting the ROBOGUIDE.

When the KOWA USB Camera window is opened, the following screen is displayed:



### Serial Number

Select a camera from a list of USB cameras currently connected to the PC.

### Exposure Time

Set the exposure time used to snap a camera image on this screen.

### Robot Mounted Cam.

Check this box when using a hand camera.

### Robot Holding the Cam.

When using a hand camera, set the robot having the camera.

### Camera Parameters

These items indicate the internal specification of the selected camera.

## 4.4 BASLER USB CAMERA


The BASLER USB camera is used when the *iR*Vision function is used on ROBOGUIDE. This function supports the following two types.

- BASLER acA640-120um
- BASLER acA640-20um (Custom model for FANUC robot)

### ⚠ NOTE

- 1 The cameras are dedicated for USB3.0 port on PC. USB2.0 port is not available.
- 2 To use BASLER USB Camera, you need to install BASLER pylon Camera Software Suite to your PC. It can be downloaded from BASLER web page.
- 3 When you install the software, make sure to add the Additional Runtimes / pylon C Runtime in the Custom Setup step of the installer.
- 4 acA640-20um works with the same driver for acA640-120um.
- 5 Connect the BASLER USB camera before starting the ROBOGUIDE.

When the BASLER USB Camera setup is opened, the following page is displayed:



### Serial Number

Select a camera from a list of BASLER USB cameras currently connected to the PC.

### Def. Exposure Time

Set the exposure time used to snap a camera image on this screen.

### Robot-Mounted Cam.

Check this box when using a hand camera.

### Robot Holding Cam.

When using a hand camera, set the robot having the camera.

### Camera Parameters

These items indicate the internal specification of the selected camera.


# 5 CAMERA CALIBRATION

This chapter describes how to set up camera calibration tools.

## 5.1 GRID PATTERN CALIBRATION

The grid pattern calibration is the standard method to calibrate the camera, and can be used in many vision applications. A fixture called the calibration grid is used to calibrate a camera. For information about the calibration grid, see Chapter 11, “CALIBRATION GRID”.

When the grid pattern calibration setup window is opened, the following is displayed:



### 5.1.1 Calibrating Camera

Calibrate the camera.

#### Robot to be offset

Specify the target robot position offset by setting its controller and group number.

#### Application Frame

Specify the robot's user frame to be used for camera calibration. Measurement results are converted to values in the set this frame before output.

In many cases, the base frame of the Robot is set up in [Application Frame].

In the following cases, the user frame is set up and is set up in [Application Frame].

- The camera is mounted in other robot which is not the robot for compensation.
- The calibration grid is mounted in other robot which is not the robot for compensation.

#### CAUTION

The application frame must be set before the camera calibration is performed. If the application frame is changed after calibrating the camera, calibrate the camera again.

## Camera

Select the camera you want to calibrate.

## Exposure Time

Set the exposure time to be applied when camera images are snapped using this window.



### CAUTION

The value you set here will not be used during vision process runtime.

## Grid Spacing

Set the spacing between grid points on the calibration grid to be used.

## Number of Planes

Choose between 1-plane calibration and 2-plane calibration.

When a robot-mounted camera is used or when the calibration grid plate is mounted on the robot end of arm tooling, 2-plane calibration should be selected. When a fixed camera and stationary fixture are used, 1-plane calibration should be selected.

## Robot-Held Cal. Grid

Select the installation method of the calibration grid.

### No

The calibration grid is secured to a table or another place to perform calibration.

### Yes

The calibration grid is mounted on the robot end of arm tooling to perform calibration.

## Robot Holding Grid

If you choose [Yes] for [Robot-Held Cal. Grid], specify the robot that is holding the calibration grid.

## Cal. Grid Frame

Calibration grid frame indicates the position and orientation of the calibration grid when the camera calibration was performed.

When the calibration grid is secured in a fixed location, its position relative to the robot base frame should be set in a user frame area. On this screen, you select the user frame number in which the calibration grid frame information has been set.

When the calibration grid is attached to the robot end of arm tooling, its position relative to the robot mechanical interface frame (the robot wrist flange) should be set in a user tool area. On this screen, you select the user tool number in which the calibration grid frame information has been set.

Detailed information on how to teach the calibration grid frame is described in Section 10.2, “GRID FRAME SETTING”.

## Projection

Usually, select [Perspective]. When the telecentric lens is used, select [Orthogonal].

## Override Focal Dist.

Usually, leave this item set to [No]. When the grid pattern is found, the focal distance will be calculated automatically. When 2-plane calibration is performed, a value close to the nominal focal distance of the

lens is calculated. (For example, when the nominal f value of the lens used is 12 mm, 12.1 mm might be calculated.) A correct calibration can be regarded as having been made if the calculated value is close to the nominal value. When the calibration grid is placed to be perpendicular to the optical axis of the camera and 1-plane calibration is performed, select [Yes] and set the value of the nominal focal distance of the lens because theoretically it is difficult to calculate a correct focal distance.

### Fixture Position Status

When the calibration grid is in a fixed location, tap the [Set] button. Based on the data of the specified frames, *iRVision* calculates how and where the calibration grid is positioned in the application user frame, and saves the result.



#### CAUTION

If the position of the calibration grid is changed, e.g., when re-calibrating the camera, it is necessary to recalculate the fixture position by setting the user frame again that contains the calibration grid frame and then tapping the [Set] button to update the fixture position.

When the calibration grid is mounted on the robot end of arm tooling, this button is disabled. The positioning information of the grid pattern is calculated and saved when you perform the next step of finding the grid pattern.

### Finding the grid pattern

The grid pattern is found to calculate calibration data.


- 1 To capture the image of the calibration grid, press F3 SNAP.




#### CAUTION

The calibration grid does not have to fill the field of view, but the calibration will be less accurate if circles of the grid pattern appear only a part in the image. Make sure that the image is filled with circles of the grid pattern; do not care about some of the circles appearing outside the image.

- 2 Tap the [Find] button of [1<sup>st</sup> Plane].
- 3 Specify the grid range with the displayed red rectangle.



- 4 Press F4 OK.
- 5 When the grid pattern is found successfully, crosshairs (+) appear at the center of each of the found circles.



- 6 Check that blue crosshairs (+) appear in the four large circles. Also, check that green crosshairs (+) appear in small circles. There might be one or two undetected small circles.


For 1-plane calibration, this completes the procedure for calibration.

For 2-plane calibration, jog the robot that has the camera or the robot that has the calibration grid to change the distance between the camera and calibration grid. Generally, move the robot by about 150 mm, then repeat the above steps for the 2<sup>nd</sup> plane.

### 5.1.2 Checking Calibration Points

Check the calibration points that have been found.

If you tap the [Points] tab, a page like the one shown below appears.



The image has a green and a red crosshair at the center of each circle that has been found. The green cross hair shows where the calibration point was found in the image, the red cross hairs shows the calculated position of where the calibration point should be. Since green crosshairs are plotted after red crosshairs, only a green crosshair is visible if a green and a red crosshair are plotted at the same position.

**Plane**

Display the calibration points of the previous or next calibration plane. Use these items in the case of 2-plane calibration.

**Vt, Hz**

The coordinate values of the found calibration points on the image are displayed.

**X, Y, Z**

The coordinate values of the grid points on the calibration grid frame are displayed.

**Error**


The distance between the centers of the green crosshairs and red crosshairs plotted on the image is displayed. A smaller value indicates more accurate calibration.

**Deleting a calibration point**

If a crosshair is displayed at a location where no grid point is present, enter the index number of that point in the text box to the left of the [Delete] button and then tap the [Delete] button. The specified point is deleted from the list, and the calibration data is automatically recalculated.

**5.1.3 Checking Calibration Data**

Check the calculated calibration data. Tap the [Data] tab.



**Focal Distance**

The calculated focal distance of the lens is displayed. Check that the value is appropriate for the lens in use. The focal length is a label on the lens. In the case of 1-plane calibration, if the W and P values in the [Position of Camera Relative to Calibration Grid] section are both less than several ± degrees, the focal distance cannot be measured accurately. Therefore, in the [Setup] tab, set [Override Focal Distance] to [Yes] and enter the nominal focal distance of the lens in use. If you enter the focal distance, the calibration data is automatically recalculated. Note the user can compare the Z value in Position of



Camera relative to Cal Grid with the measured distance of camera lens to grid (Z value). Please modify focal distance until the two Z values are close.

### **Lens Distortion**

The calculated lens distortion coefficient is displayed. A larger absolute value indicates greater lens distortion. Generally, lenses with shorter focal distances are said to have greater distortion. Grid pattern calibration returns accurate coordinates by using this calculated lens distortion when accurately converting the image frame to the robot frame.

### **Magnification**

The size of a pixel in millimeters on the grid pattern plane (1<sup>st</sup> plane in the case of 2-plane calibration) is displayed. The value indicates how many millimeters are equivalent to a pixel. If the grid pattern plane is not vertical to the optical axis of the camera, the magnification near the center of the image is displayed.

### **Image Center**

The coordinates of the center of the image are displayed.

### **CCD Vertical Spacing**

The physical size of a pixel of the light receiving element of the camera in use is displayed.

### **Aspect Ratio**

The aspect ratio of a pixel of the image is displayed.

### **Maximum / Mean Error**

The average and maximum errors of all the calibration points shown in the [Points] tab table are displayed.

### **Position of Camera Relative to Cal. Grid**

The position of the camera relative to the calibration grid frame is displayed. For the calibration grid frame, see Chapter 11, "CALIBRATION GRID". In the case of 2-plane calibration, it is relative to the calibration grid frame of the 1<sup>st</sup> plane.

### **Position of Cal. Grid Relative to App UFrame**

The position of the calibration grid relative to the user frame selected in [Application Frame:] of the [Setup] tab is displayed. It indicates the position where the calibration grid was located when the camera was calibrated. In the case of 2-plane calibration, the calibration grid position on the 1<sup>st</sup> plane is displayed.

### **Position of Robot Holding Camera**

The position of the robot that was holding the camera at the time of calibration is displayed. It indicates the position of the mechanical interface frame (the wrist flange) of the robot relative to the user frame selected in [Application Frame:] of the [Setup] tab. The value is displayed only for a robot-mounted camera. In the case of 2-plane calibration, it is the robot position at the time of finding calibration grid for the 1<sup>st</sup> plane.

## **5.1.4 Automatic Re-Calibration**

---

If the position of the camera is changed or the camera is replaced for some reason after the system is put into operation, the camera needs to be re-calibrated. In such a case, the use of automatic re-calibration allows you to restore the camera to its proper position with ease. Since no manual operation is involved in re-calibrating the camera, automatic re-calibration prevents the operator's mistakes and other human errors.

Performing automatic re-calibration requires that a robot program for automatic re-calibration be taught in advance. Shown below is a program example for carrying out 2-plane calibration with a robot mounted camera. In P[1], the position of the robot to detect calibration plane 1 is specified. Calibration plane 2 is 100 mm higher in the Z direction than calibration plane 1. In the case of 1-plane calibration, the 18 and subsequent lines are unnecessary.

```

1: UFRAME_NUM=1
2: UTOOL_NUM=1
3: J P[1] 100% FINE
4:
5: PR[99]=LPOS
6: PR[99,1]=0
7: PR[99,2]=0
8: PR[99,4]=0
9: PR[99,5]=0
10: PR[99,6]=0
11:
12: ! Find plane-1
13: PR[99,3]=0
14: J P[1] 100% FINE OFFSET,PR[99]
15: CALL IRVBKLSH(1)
16: VISION CAMERA_CALIB 'CALIB1' REQUEST=1
17:
18: ! Find plane-2
19: PR[99,3]=100
20: J P[1] 100% FINE OFFSET,PR[99]
21: CALL IRVBKLSH(1)
22: VISION CAMERA_CALIB 'CALIB1' REQUEST=2
23: END

```

To perform automatic re-calibration, execute the created robot program.




### CAUTION

- 1 Automatic re-calibration does not reset the calibration grid frame. Make sure that the calibration grid is securely fixed at the position where it was initially calibrated and is not moved.
- 2 If the calibration grid is robot mounted, do not change the values of the tool frame containing the calibration grid frame. The values of the tool frame are referenced when the position of the calibration grid is calculated from the robot position.

## 5.2 ROBOT-GENERATED GRID CALIBRATION

Robot-generated grid calibration is a general-purpose camera calibration function suitable for the calibration of a wide-view-angle camera. Selecting [Robot-Generated Grid Calibration] displays a page like the one shown below.



### NOTE

In Robot-generated grid calibration, the preconfiguration is executed in setup page and the calibration is executed in *iRVision* Utility menu. For details of the calibration step in *iRVision* Utility menu, please refer to the Section 10.1 “Robot-Generated Grid Calibration”.

### 5.2.1 Camera Calibration Tools

If you select [Robot-Generated Grid Calibration] in the tree view, and tap [Setup] tab, a setting screen will be displayed.

#### Application Frame

Specify the robot's user frame to be used for camera calibration. Measurement results are converted to values in the set this frame before output.

In many cases, the base frame of the Robot is set up in [Application Frame].

In the following cases, the user frame is set up and is set up in [Application Frame].

- The camera is mounted on a different robot from the one to be offset.
- The robot should move along a different plane from the XY plane of the base frame, for example when the camera is fixed sideways.

### ⚠ CAUTION

The application frame must be set in the robot controller before the camera calibration is performed. If the application frame is changed after calibrating the camera, calibrate the camera again.

## Camera

From the drop-down box, choose the camera to be calibrated. When you select a camera name, the corresponding camera positioning state is displayed to the left of the drop-down box.

The aperture and the focus of the lens need to be adjusted to be optimal for the detection of the work before calibrating. The robot target should be set mid way between the two planes and in the middle on the camera view.

If the aperture and the focus of the lens haven't been adjusted yet, adjust them here. Temporary, fully open the aperture of the lens and adjust the exposure time to a good brightness. Focus the lens. Set Exposure time to 33.0 milliseconds and close the aperture of the lens to a good brightness. When the calibration is executed, execute the target detection by not changing configuration of the camera but the exposure time. The first aperture adjustment is performed to reduce the camera depth of field to a minimum range, this provides the highest tuning ratio for the focus ring. The second aperture adjustment is performed to allow the greatest brightness range at the Vision Process level for the Exposure Time.

## Exposure Time of Camera

Set the exposure time to make sure that the target is detected easily. This exposure time setting is used only for calibration. For details of the individual items to be set, see Subsection 3.7.15, "Setting an Exposure Mode".

## Image Logging Mode


From the drop-down box, select whether to save images in the vision log. However, if you have the vision log disabled in the system variable, logged images are not saved.

## Plane spacing

Specify the spacing between calibration planes 1 and 2. A calibration plane spacing is enlarged as much as possible within the range which the focus of lens suits. When the spacing is too close, the accuracy of calibration may not be acquired. If you enter a positive value when the Z-axis of the application user frame is directed toward the camera, or if you enter a negative value when the Z-axis is in the opposite direction, calibration plane 2 is located closer to the camera relative to calibration plane 1. This reduces the risk of the robot interfering with peripheral equipment when moving.


## Initial position

Specify the measurement start position. This start position should be set so that the target mounted on the robot end of arm tooling comes roughly at the center of the camera's field of view. The height of the start position is equal to that of the calibration plane 1. During camera calibration, the robot moves in parallel to the XY plane of the application frame, while maintaining the posture of the start position. Jog the robot to a place that is appropriate as the start position, and tap the RECORD button.



## 5.2.2 Checking Calibration Points

If you select [Robot-Generated Grid Calibration] in the tree view, and tap [Points] tab, a page like the one shown below appears.



The image has a blue crosshair plotted on each calibration point in calibration plane 1 and a green crosshair plotted on each calibration point in calibration plane 2, at the center of each circle that has been found. A calibration point number is shown at the lower right of each crosshair. A red crosshair shows the 3D position of an individual circle that is obtained by projecting the circle onto the image by means of the calculated calibration data. Since blue and green crosshairs are plotted after red crosshairs, a red crosshair is not visible if a blue or green crosshair and a red crosshair are plotted at the same position.

### Vt, Hz

The coordinate values of the found calibration points on the image are displayed.

### X, Y, Z

The coordinate values of the grid points on the user frame to be offset are displayed.

### Error


The distance between the centers of the blue and green crosshairs and the centers of the red crosshairs plotted on the image is displayed. A smaller value indicates more accurate calibration.

### Deleting a calibration point

If a crosshair is displayed at a location where no calibration point is present, select that point by tapping it in the list or enter the index number of the point in the text box to the left of the [Delete] button, and then tap the [Delete] button. The specified point is deleted from the list, and the calibration data is automatically recalculated.

## 5.2.3 Checking Calibration Data

If you select the [Robot-Generated Grid Calibration] in the tree view, and tap the [Data] tab, a page like the one shown below appears.



### Focal Distance

The calculated focal distance of the lens is displayed. Check that the value is appropriate for the lens in use.

### Lens Distortion

The calculated lens distortion coefficient is displayed. A larger absolute value indicates greater lens distortion. Generally, lenses with shorter focal distances are said to have greater distortion. Robot-generated grid calibration returns accurate coordinates by using this calculated lens distortion when accurately converting the image frame to the robot frame.

### Magnification

The size of a pixel in millimeters on calibration plane 1 is displayed. The value indicates how many millimeters are equivalent to a pixel on the image.

### Image Center

The position where the light passing through the center of the lens is projected is displayed. A typical lens is designed so that the light passing through the center of the lens is projected at the center of the image. Check that the image center is set to be near the center of the image.

### CCD Vertical Spacing

The physical size of a pixel of the light receiving element of the camera in use is displayed.

### Aspect Ratio

The aspect ratio of a pixel of the image is displayed.

### Maximum / Mean Error

The average and maximum errors of all the calibration points shown in the [Points] tab table are displayed.

### Pos. of Fixed Camera Relative to App UFrame

The position of the fixed camera relative to the user frame to be offset is displayed.

## 5.2.4 Automatic Re-Calibration


If the position of the camera is changed or the camera is replaced for some reason after the system is put into operation, the camera needs to be re-calibrated. In such a case, the use of automatic re-calibration allows you to restore the camera to its proper position with ease. Since no manual operation is involved in re-calibrating the camera, automatic re-calibration prevents the operator's mistakes and other human errors. Robot-generated grid calibration automatically generates a calibration program. By executing this program from the first line, you can perform re-calibration.

**⚠ CAUTION**  
 Automatic re-calibration does not reset the target positioning information. Make sure that the target is securely fixed at the position where it was initially calibrated and is not moved.

## 5.3 3D LASER VISION CALIBRATION

The 3DL Calibration is the method to calibrate the 3D laser vision sensor.

When 3DL calibration setup window is opened, the following is displayed.



**NOTE**  
 When you use the camera of a 3D laser vision sensor for 2D application, the 3DL calibration can be used for the 2D application.

### 5.3.1 Calibrating Camera

Calibrate the camera.

#### Robot to be offset

Specify the target robot position offset by setting its controller and group number.

## Application Frame

Specify the user frame number to be used for robot position offset. Measurement results are converted to values in the set this frame before output.

In many cases, the base frame of the Robot is set up in [Application Frame].

In the following cases, the user frame is set up and is set up in [Application Frame].

- The camera is mounted in other robot which is not the robot for compensation .
- The calibration grid is mounted in other robot which is not the robot for compensation.



### CAUTION

The application frame must be set in the robot controller before the camera calibration is performed. If the application frame is changed after calibrating the camera, calibrate the camera again.

## Camera

Select the camera you want to calibrate.



### CAUTION

When the 3D laser vision sensor with the KOWA Digital Camera is used, select the 1/1.8" VGA as the camera mode (image size) on the camera setup page. Refer to the Subsection 4.1.1, "Grayscale Camera".

## Exposure Time

Set the exposure time to be applied when the grid pattern is found in this window, with a value ranging from 0.04 to 250. The unit is ms.

## Laser Exposure Time

Set the exposure time to be applied when laser slits are found in this window. The unit is ms.

## Grid Spacing

Enter the spacing between grid points on the calibration grid used. The unit is mm.

## Number of Planes

Show the number of planes to be calibrated. Two planes are selected. This setting cannot be changed.

## Robot-Held Cal. Grid

Select the installation status of the calibration grid. Select [No] if the calibration grid is not moved with respect to the user frame, or select [Yes] if the calibration grid is mounted on the robot.

## Robot Holding Grid

This item is set only when [Yes] is selected in [Robot-Held Cal. Grid]. Select the robot that has the calibration plate. In [Group], set the group number of the robot.

## Cal. Grid Frame

Calibration grid frame indicates the position and orientation of the calibration grid when the camera calibration was performed.

When the calibration grid is in a fixed location, its position relative to the robot base frame should be set in a user frame area. On this screen, you select the user frame number in which the calibration grid frame information has been set.



When the calibration grid is attached to the robot end of arm tooling, its position relative to the robot mechanical interface frame (the robot wrist flange) should be set in a user tool area. On this screen, you select the user tool number in which the calibration grid frame information has been set.

Detailed information on how to set the calibration grid frame is described in Section 10.2, “GRID FRAME SETTING”.

## Projection

[Perspective] is selected. This setting cannot be changed.

## Override Focal Length

The focal distance of the lens used. [No] is selected. This setting cannot be changed.

## Min. Laser Contrast

Set the threshold of contrast applicable when a laser point sequence is to be found. Set a value ranging from 1 to 254. The default value is 50.

## Min. Num. Laser Points

Set the minimum number of laser points required for calibration with a value ranging from 1 to 479. The default value is 50.

## Max Line Fit Error

Set the margin to be applied when a laser point sequence is regarded as being on a calculated straight line, with a value ranging from 0 to 10. The unit is mm and the default value is 3 mm.

## Fixture Position Status

The current setting is indicated. This item can be set only when [No] is selected in [Calib. Grid Held by Robot]. When the [Set] button is tapped, the values in the application user frame specified in [Application Frame] are registered as the position of the calibration grid.

### CAUTION

If the position of the calibration grid is changed, e.g., when re-calibrating the camera, it is necessary to recalculate the position of the calibration grid by setting the application user frame again that contains the calibration grid frame and tapping the [Set] button for the position of the calibration grid.

This button is disabled when the calibration grid is robot mounted. The position information of the calibration grid is automatically calculated and saved when the grid pattern is found.

## 1<sup>st</sup> Plane, 2<sup>nd</sup> Plane


The current calibration plane status is indicated. To find the grid pattern, perform the following steps with the calibration grid mounted or fixed in the frame specified in [Calib. Grid Held by Robot].

- 1 Place the calibration grid at a distance of about 350 mm (550 mm when the stand off of your 3D laser sensor is 600 mm) from the 3D laser sensor so that they face each other.

### CAUTION

The calibration grid does not have to fill the field of view, but the calibration will be less accurate if circles of the grid pattern appear only a part in the image. Make sure that the image is filled with circles of the grid pattern; do not care about some of the circles appearing outside the image.

- 2 Tap the [Snap and Find] button of [1<sup>st</sup> Plane].
- 3 Teach the search window for the grid pattern and laser point sequence so that only the grid pattern is fit in the search window, and press F4 OK.




- 4 Check that almost all circles are found and the laser slits are found clearly. If the location is successful, [Found] is indicated in [1<sup>st</sup> Plane].
- 5 Place the calibration grid at a distance of about 450 mm (650 mm when the stand off of your 3D laser sensor is 600 mm) from the 3D laser sensor so that they face each other.
- 6 Tap the [Snap and Find] button of [2<sup>nd</sup> Plane].
- 7 Teach the search window for the grid pattern and laser point sequence so that only the grid pattern is fit in the search window, and press F4 OK.
- 8 Check that almost all circles are found and the laser slits are found clearly. If the location is successful, [Found] is indicated in [2<sup>nd</sup> Plane].

### 5.3.2 Checking Calibration Points

Check the calibration points that have been found.

When the [Points] tab is tapped, a screen like the one shown below appears.



- 1 Check for any crosshairs that appear in a place other than the grid points.
- 2 If there is an incorrect point, enter the number of that point in the text box on the right of [Point Number], then tap [Delete] button.

The image has a green and a yellow crosshair at the center of each circle that has been found. The green cross hair shows where the calibration point was found in the image, the yellow cross hairs shows the calculated position of where the calibration point should be. Since green crosshairs are plotted after yellow crosshairs, only a green crosshair is visible if a green and a yellow crosshair are plotted at the same position.

**Plane**

Display the calibration points of the previous or next calibration plane. Use these items in the case of 2-plane calibration.

**Vt, Hz**

The coordinate values of the found calibration points on the image are displayed.

**X, Y, Z**

The coordinate values of the grid points on the calibration grid frame are displayed.

**Error**


The distance between the centers of the green crosshairs and yellow crosshairs plotted on the image is displayed. A smaller value indicates more accurate calibration.

**Deleting a calibration point**

If a crosshair is displayed at a location where no grid point is present, enter the index number of that point in the text box to the left of the [Delete] button and then tap the [Delete] button. The specified point is deleted from the list, and the calibration data is automatically recalculated.

**5.3.3 Checking Calibration Data**

Tap the [Data] tab.



**Focal Distance**

The calculated focal distance of the lens is displayed. Check that the value is appropriate for the lens in use.

## Lens Distortion

The calculated lens distortion coefficient is displayed. A larger absolute value indicates greater lens distortion. Generally, lenses with shorter focal distances are said to have greater distortion. Grid pattern calibration returns accurate coordinates by using this calculated lens distortion when accurately converting the image frame to the robot frame.

## Magnification

The size of a pixel in millimeters on the 1<sup>st</sup> grid pattern plane is displayed. The value indicates how many millimeters are equivalent to a pixel. If the grid pattern plane is not vertical to the optical axis of the camera, the magnification near the center of the image is displayed.

## Image Center

The coordinates of the center of the image are displayed.

## CCD Vertical Spacing

The physical size of a pixel of the light receiving element of the camera in use is displayed.

## Aspect Ratio

The aspect ratio of a pixel of the image is displayed.

## Maximum / Mean Error

The average and maximum errors of each calibration point shown in the [Points] tab table are displayed.

## Position of Camera relative to Cal. Grid

The position of the camera relative to the calibration grid frame of the 1<sup>st</sup> plane is displayed. For grid frame setting, see Chapter 11, "CALIBRATION GRID".

## Laser1 Plane Relative to Calibration Grid

The laser 1 plane relative to the calibration grid frame of the 1<sup>st</sup> plane is displayed

## Laser2 Plane Relative to Calibration Grid

The laser 2 plane relative to the calibration grid frame of the 1<sup>st</sup> plane is displayed.

## Position of Cal. Grid relative to App UFrame

The position of the calibration grid frame of the 1<sup>st</sup> plane relative to the user frame selected in [Application Frame:] of the [Setup] tab is displayed. It indicates the position where the calibration grid was located when the camera was calibrated.

## Position of Robot Holding Camera

The position of the robot that was holding the camera at the time of finding calibration grid for the 1<sup>st</sup> plane is displayed. It indicates the position of the mechanical interface frame (the wrist flange) of the robot relative to the user frame selected in [Application Frame:] of the [Setup] tab. The value is displayed only for a robot-mounted camera.

## Camera Frame Relative to Robot

[Camera frame relative to the robot] on the [Data] tab indicates the position of the frame which shows the shooting direction of the camera relative to the mechanical interface frame of the robot (the wrist flange of the robot) when the 3D laser sensor is robot mounted. The camera frame is defined so that the origin is located 400 mm (or 600mm; depending on the standoff of the 3D laser sensor) from the camera unit window on the optical axis of the camera and the Z-axis is located parallel to the optical axis of the camera. If this value is set for the user tool of the robot and a jog is performed on the basis of the user

tool, it is possible to jog the robot without changing the camera distance or to rotate the camera about the optical axis.

### Laser Frame Relative to Robot

[Laser frame relative to the robot] on the [Data] tab indicates the position of the frame which shows the laser emitting direction relative to the mechanical interface frame of the robot (the wrist flange of the robot) when the 3D laser sensor is robot mounted. This frame is defined so that the origin is located 400 mm (or 600mm; depending on the standoff of the 3D laser sensor) from the camera unit window of the camera on the line of intersection of two slit laser beams and the Z-axis is located parallel to the line of intersection of the two slit laser beams. If this value is set for the user tool of the robot and a jog is performed on the basis of the user tool, it is possible to move the robot in parallel with the two slit laser beams or to rotate the camera about the laser beams.

## 5.3.4 Automatic Re-Calibration

If the position of the 3D laser sensor is changed or the sensor is replaced for some reason after the system is put into operation, the 3D laser sensor needs to be re-calibrated. In such a case, the use of automatic re-calibration allows you to restore the sensor to its proper position with ease. Since no manual operation is involved in re-calibrating the sensor, automatic re-calibration prevents the operator's mistakes and other human errors. Performing automatic re-calibration requires that a robot program for automatic re-calibration be taught in advance. A program example is shown below. In P[1], the position of the robot to detect calibration plane 1 is specified. Calibration plane 2 is 100 mm higher in the Z direction than calibration plane 1.

```

1: UFRAME_NUM=1
2: UTOOL_NUM=1
3: J P[1] 100% FINE
4:
5: PR[99]=LPOS
6: PR[99,1]=0
7: PR[99,2]=0
8: PR[99,4]=0
9: PR[99,5]=0
10: PR[99,6]=0
11:
12: ! Find plane-1
13: PR[99,3]=0
14: J P[1] 100% FINE OFFSET,PR[99]
15: CALL IRVBKLSH(1)
16: VISION CAMERA_CALIB 'CALIB1' REQUEST=1
17:
18: ! Find plane-2
19: PR[99,3]=100
20: J P[1] 100% FINE OFFSET,PR[99]
21: CALL IRVBKLSH(1)
22: VISION CAMERA_CALIB 'CALIB1' REQUEST=2
23: END

```


To perform automatic re-calibration, execute the created robot program.

**⚠ CAUTION**

- 1 Automatic re-calibration does not reset the calibration grid frame. Make sure that the calibration grid is securely fixed at the position where it was initially calibrated and is not moved.
- 2 If the calibration grid is robot mounted, do not change the values of the tool frame containing the calibration grid frame. The values of the tool frame are referenced when the position of the calibration grid is calculated from the robot position.

## 5.4 VISUAL TRACKING CALIBRATION

The visual tracking calibration is the camera calibration method dedicated to the visual tracking application. When camera calibration of visual tracking is selected, the following is displayed:



### 5.4.1 Calibrating Camera

Calibrate the camera.

#### Camera

Select a camera to be used.

#### Conveyor Name

Select a Conveyor of visual tracking to be used. About the Conveyors, refer to “R-30iB/ R-30iB Mate CONTROLLER iRPickTool OPERATOR'S MANUAL”. If you add or delete a conveyor on the iRPickTool setup screen after you open this screen, click the [Refresh] button to refresh options of the [Conveyor Name] dropdown box.

On V8.10P or V8.13P of controllers, this item is shown as “Line Name”. About the Lines, refer to “R-30iB CONTROLLER iRvision Visual Tracking OPERATOR'S MANUAL”.

#### Exposure Time

Enter the shutter speed of the camera.

## Grid Spacing

Enter the spacing between grid points on the calibration grid used.

## Projection

Select [Perspective].

## Override Focal Length

Select [Yes], and enter the focal distance of the lens used in the text box to the right.

## Calibration Wizard


Perform the following steps in the wizard to perform camera calibration:



### CAUTION

Make sure that the tracking frame has been set before camera calibration is performed. If the tracking frame is changed after camera calibration is performed, camera calibration must be performed again.

- 1 Tap the [Calibration Wizard] button with the calibration grid placed within the camera field of view.




- 2 Check that the grid pattern on the calibration grid is displayed on the screen, then press F4 OK. The Image will expand with the search area set to enclose a large area. Adjust the anchor points as necessary.





### CAUTION

The calibration grid does not have to fill the field of view, but the calibration will be less accurate if circles of the grid pattern appear only a part in the image. Make sure that the image is filled with circles of the grid pattern; do not care about some of the circles appearing outside the image.

- 3 Enclose the grid pattern with a red rectangular window, then press F4 OK. As many full circles as possible should be enclosed.



4 Upon completion of grid pattern location, the screen shown below is displayed.





5 Move the conveyor so that the calibration grid comes in front of a robot connected to the controller on which the iRVision setup screen is opened.



**⚠ CAUTION**  
Be careful not to move the calibration plate.

6 Jog the robot so the TCP is on the origin of the calibration grid, and press F4 OK.






- 7 Jog the robot so the TCP is on a point on the positive X-axis of the calibration grid, then press F4 OK.



- 8 Jog the robot so that the TCP is on a point on the positive Y-axis of the calibration grid, then press F4 OK.




9 Press F4 OK.

### 5.4.2 Checking Calibration Points

Check the calibration points that have been found.

When the [Points] tab is tapped, a screen like the one shown below appears.



The image has a green and a red crosshair at the center of each circle that has been found. A green crosshair shows the position of a calibration point detected from the image, and a red crosshair the 3D position of an individual circle. These represent the positions obtained by projecting the points onto the image by means of the calculated calibration data. Since green crosshairs are plotted after red crosshairs, only a green crosshair is visible if a green and a red crosshair are plotted at the same position.

#### Vt, Hz

The coordinate values of the found calibration points on the image are displayed.

### X, Y, Z


The coordinate values of the grid points on the calibration grid frame are displayed.

### Error

The distance between the centers of the green crosshairs and red crosshairs plotted on the image is displayed. A smaller value indicates more accurate calibration.


### Deleting a calibration point

If a crosshair is displayed at a location where no grid point is present, enter the index number of that point in the text box to the left of the [Delete] button and then tap the [Delete] button. The specified point is deleted from the list, and the calibration data is automatically recalculated. The user can Double tap the Err header to sort the column. In the example below #73 has a large error. Tap on 73 and point in the image is highlighted. In this case 73 is a false circle. Enter 73 as the Point Number and tap the [Delete] button. The point is removed and a new calculation is performed.



## 5.4.3 Checking Calibration Data

Check the calculated calibration data. Tap the [Data] tab.



## **Focal Distance**

The calculated focal distance of the lens is displayed. Check that the value is appropriate for the lens in use.

If the W and P values in the [Position of Camera Relative to Calibration Grid] section are both less than several  $\pm$  degrees, the focal distance cannot be measured accurately. Therefore, in the [Setup] tab, set [Override Focal Distance] to [Yes] and enter the nominal focal distance of the lens in use. If you enter the focal distance, the calibration data is automatically recalculated.

## **Lens Distortion**

The calculated lens distortion coefficient is displayed. A larger absolute value indicates greater lens distortion. Generally, lenses with shorter focal distances are said to have greater distortion. Visual tracking calibration returns accurate coordinates by using this calculated lens distortion when accurately converting the image frame to the robot frame.

## **Magnification**

The size of a pixel in millimeters on the grid pattern plane is displayed. The value indicates how many millimeters are equivalent to a pixel. If the grid pattern plane is not vertical to the optical axis of the camera, the magnification near the center of the image is displayed.

## **Image Center**

The coordinates of the center of the image are displayed.

## **CCD Vertical Spacing**

The physical size of a pixel of the light receiving element of the camera in use is displayed.

## **Aspect Ratio**

The aspect ratio of a pixel of the image is displayed.

## **Maximum / Mean Error**

The average and maximum errors of each calibration point shown in the [Points] tab table are displayed.

## **Position of Camera relative to Calibration Grid**

The position of the camera relative to the calibration grid frame is displayed.  
For grid frame setting, see Chapter 11, "CALIBRATION GRID".

## **Position of Cal. Grid Relative to Tracking Frame**


The position of the calibration grid relative to the tracking frame when the grid pattern is detected. For tracking frame, refer to "R-30iB/ R-30iB Mate CONTROLLER iRPickTool OPERATOR'S MANUAL" for V8.20P and later versions of controller, or "R-30iB CONTROLLER iRVision Visual Tracking OPERATOR'S MANUAL" for V8.10P and V8.13P of controllers.

# 6 VISION PROCESSES

This chapter explains how to set up vision processes.


## 6.1 2D SINGLE VIEW VISION PROCESS

This is a vision process that detects the two-dimensional position of the workpiece with a single camera, and offsets the robot position.




### 6.1.1 Setting up a Vision Process

If you open the setup page of [2D Single-view Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



## Camera Calibration

Select the camera calibration you want to use.

## Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

## Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

## Multiple Locator Find Mode

If you have created more than one locator tool, select how to execute those tools.

### Find Best

All the locator tools will be executed, and the best result will be chosen. This is effective when you want to identify the type or put location reliability before processing time.

### Find First

The locator tools will be executed sequentially from the top until the specified number of workpieces has been found. The subsequent locator tools will not be executed once the number of found exceeds the specified number. For your information, the duplicate check is executed every time one locator tool is executed, the number of found, which is compared to the specified number, does not include duplicated workpieces.

## Number to Find

Enter the maximum number of workpieces to be found per measurement. The specifiable range is 1 to 100.

## Offset Mode

Select the robot position offset mode.

### Fixed Frame Offset

The fixed frame offset data will be calculated.

**Tool Offset**

The tool offset data will be calculated.

**Found Position**


The found position will be output as is, instead of the offset data. This option is provided for any required special offset mode. Do not select it under normal conditions.

**Robot Holding the Part**

If you have chosen [Tool Offset] for [Offset Mode], specify the robot that is holding the workpiece.

**Offset Frame**

A 2D vision process measures displacement of a workpiece on a plane. The plane is called the offset plane. The offset plane is defined as a plane parallel to the XY plane of the offset frame. Here, specify the offset frame. If you have chosen [Fixed Frame Offset] for [Offset Mode], specify a user frame as the offset frame. If you have chosen [Tool Offset] for [Offset Mode], specify a user tool. The following are examples of the offset frame in the case of Fixed Frame Offset.



When the workpiece is moved horizontally

When the workpiece is moved on an inclined plane:

**NOTE**

The Z height of the offset plane is specified as [Part Z height] discussed below. Here, you determine the gradient of the offset plane.

**Image Logging Mode**

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

**Do Not Log**

Do not save any images to the vision log.

**Log Failed Images**

Save images only when the vision operation fails.

**Log All Images**

Save all images.

**CAUTION**

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to log images depends on the type of storage device in use. Use this function after checking whether the delay of logging images is acceptable for your application.

**Setting the Sorting Parameters**

Set the sorting parameters to be applied when more than one workpieces have been found. For details, see Subsection 3.7.16, “Sorting”.

**Delete Duplicates If <**

The position and angle of each found result are checked to see whether the result is the same as another result. If there are multiple found results within the specified pixels and angle, the results are assumed to indicate the same workpiece and only the found result with the highest score is output.

**Ref. Data To Use**

The reference data is used to calculate offset data from the found result. The reference data mainly consists of two types of data described below.

**Part Z Height**

Height of the found part of the workpiece as seen from the offset frame.

**Ref. Pos. Status**

Position of the workpiece found when the robot position is taught. The offset data is the difference between the actual workpiece position found when running the vision process and the reference position.

A vision process might have more than one set of reference data. Under normal conditions, only one set of reference data is used. However, for example, if there are two types of workpiece, each having a different height, the vision process uses two sets of reference data because it needs to set a different part Z height for each of the workpieces.

**Ref. Data Index To Use**

Choose one of the following to specify how to determine the reference data to use.

**This Index**

The same reference data is used to calculate the offset data.

**Model ID**

Different reference data is used depending on the model ID of the found workpiece. Choose this in such cases as when there are two or more types of workpieces having different heights.

**ID**

If [This Index] is selected in [Ref.Data Index To Use], enter the reference data ID to use.

**Measurements in mm**

If this is checked, child command tools will output length measurement values after converting them to millimeters. This function is available only when this vision process has only a single reference data.

**Adding reference data**


You can add reference data as follows.



- 1 Tap  button.
- 2 In [Model ID], enter the model ID for which to use the reference data.

### Deleting reference data

You can delete reference data as follows, if there is more than one set.

- 1 Select the reference data you want to delete using the index drop-down list
- 2 Tap  button.
- 3 A popup message is display to confirm. Press F4 OK.

### Part Z Height

Enter the height of the trained features on the workpiece above or below the offset frame.

### Ref. Pos. Status

If the reference position is set, [Set] is displayed in green; otherwise, [Not Set] is displayed in red.

### Reference Position X,Y,R


The coordinate values of the set reference position are displayed.

### Offset Limit

Specify the condition used to check whether the calculated offset value is within the specified range. By default, [None selected] is set, in which case the offset limit check is not made. For information about the offset limit check conditions, see Section 8.2, "OFFSET LIMIT".

## 6.1.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Found

The number of found workpieces is displayed.

### Time to Find

The time the vision process took is displayed in milliseconds.

## Found Result Table

The following values are displayed.

### X,Y

Coordinate values of the model origin of the found workpiece (units: mm).

### R

Rotation angle of the found workpiece around the Z axis (units: degrees).

### Model ID

Model ID of the found workpiece.

### Score

Score of the found workpiece.

### Contrast


Contrast of the found workpiece.

### Fit Err.

Elasticity of the found workpiece (units: pixels).

## 6.1.3 Setting the Reference Position

Set the reference position. The offset value is calculated based on the relationship between the reference position you set here and the found position.



- 1 Open the vision process Setup Page.
- 2 Place a workpiece in the camera view for which you want to set the reference position.
- 3 Enter the proper Part Z Height, the height of the found edges above or below the application user frame.
- 4 Press F3 SNAP and then press F4 FIND to find the workpiece.
- 5 Tap the [Set Ref] button.
- 6 Check that [Ref. Pos. Status] is set to [Set] and that a value is displayed for each reference position element.

Teach the robot the position where the workpiece is when the reference position is set. Teach the position to the robot without moving the workpiece.

## 6.1.4 Overridable Parameters

---

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Exposure Time

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.


### Number of Exposure

Specify a number between 1 and 6.

## 6.2 2D MULTI-VIEW VISION PROCESS

---


This is a vision process that detects the two-dimensional position of the workpiece by finding multiple features on different parts of it, and then offsets the robot position. It is effective when the workpiece is too large for the camera to capture its entire image.




In this process, a tool called Camera View is located under the vision process. One camera view corresponds to one measurement point. While the standard number of camera views is two, this number can be increased to a maximum of four.

## 6.2.1 Setting up a Vision Process

If you open the setup page of [2D Multi-View Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



### Offset Mode

Select the robot position offset mode.

### Fixed Frame Offset

The fixed frame offset data will be calculated.

### Tool Offset


The tool offset data will be calculated.

### Robot Holding the Part

If you have chosen [Tool Offset] in [Offset Mode], specify the robot holding the workpiece.

### Offset Frame

A 2D vision process measures the displacement of a workpiece on a plane. The plane is called the offset plane. The offset plane is defined as a plane parallel to the XY plane of the offset frame. Here, specify the offset frame. If you have chosen [Fixed Frame Offset] for [Offset Mode], specify a user frame as the offset frame. If you have chosen [Tool Offset] for [Offset Mode], specify a user tool. The following are examples of the offset frame in the case of Fixed Frame Offset.



When the workpiece is moved horizontally


When the workpiece is moved on an inclined plane:

**NOTE**  
 The Z height of the offset plane is specified as [Part Z height] discussed below. Here, you determine the gradient of the offset plane.

### Combine Error Limit

The combine error limit is the distance the found targets for each camera view move independently of each other. The figure below shows the original found location for each of the three views as the small black targets, and it shows the current found location for each view as the larger target. In the example below there is a combine error, since the relationship between the three targets changed from the original reference position find to the current find, as seen by the size and shape of the triangle changing.

If the calculated combine error limit is greater than the user specified limit, the workpiece will not be found. Typically a sudden increase in the combine error is due to incorrect calibration of one or more of the camera views, or physical changes in the workpiece.



**Min. Pos. among pts**

Specify allowable minimum distance between measurement points. If the distance between measurement points is shorter than the distance you specify here, an alarm is generated. This item is intended to prevent the robot from receiving an incorrect position offset in case the same workpiece feature is incorrectly found in multiple camera views. Under the normal conditions, the value does not need to be changed.

**Image Logging Mode**

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

**Do Not Log**

Do not save any images to the vision log.

**Log Failed Images**

Save images only when the vision operation fails.

**Log All Images**

Save all images.

**CAUTION**

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

**Ref. Pos. Status**

If the reference position is set, [Set] is displayed in green; otherwise, [Not Set] is displayed in red.

**Average Reference X, Y**


The average reference position of each camera view is displayed. The [Offset Limit] described next is to check the location or travel distance of this reference position.

**Offset Limit**

Specify the condition used to check whether the calculated offset value is within the specified range. By default, [None selected] is set, in which case the offset limit check is not made. For information about the offset limit check conditions, see Section 8.2, "OFFSET LIMIT".

## 6.2.2 Setting up a Camera View

If you select [Camera View 1] in the tree view, a screen like the one shown below appears.



### Camera Calibration

Select the camera calibration you want to use.

### Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

### Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

### Multiple Locator Find Mode

If you have created more than one locator tool, select one of the following to specify how to execute those tools.

#### Find Best

All the locator tools will be executed, and the best result will be chosen. This is effective when you want to identify the type or put location reliability before processing time.

#### Find First

The locator tools will be executed sequentially in the order they are listed in the tree view, and the first result that is found will be output. Because the location process will stop as soon as a workpiece is found and the subsequent locator tools will not be executed, this is effective when you place priority on processing time.

### Part Z Height


Enter the height of the trained features on the workpiece above or below the offset frame.

### Reference Position X,Y

The coordinate values of the set reference position are displayed.

## 6.2.3 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected. There are two ways to run a test. One is to test the entire vision process, and the other is to test each camera view individually. If you intend to perform position offset using a fixed camera, testing the entire vision process at one time is easier. In the case of a robot-mounted camera or tool offset, where the robot position in camera view 1 differs from that in camera view 2, test each camera view individually.



### Combine

Alignment deviation between the point found when the reference position is set and the point found when the test is run (units: mm). This value becomes nearly 0 if there are no differences between workpieces and no location error.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

#### X,Y

Coordinate values of the model origin of the found workpiece (units: mm).

#### Model ID

Model ID of the found workpiece.

#### Score

Score of the found workpiece.

#### Contrast

Contrast of the found workpiece.


#### Fit Err.

Elasticity of the found workpiece (units: pixels).



## 6.2.4 Setting the Reference Position

Set the reference position. The offset value is calculated based on the relationship between the reference position you set here and the found position.



- 1 Open the Setup Page for the vision process.
- 2 Place a workpiece in the camera view for which you want to set the reference position.
- 3 Make sure to enter the proper Part Z Height of the locators in each camera view.  
The Part Z Height is the height of the found edges, above or below the application user frame.
- 4 Press F3 SNAP and then press F4 FIND to find the workpiece.
- 5 Tap the [Set] button.
- 6 Check that [Ref. Pos. Status] is set to [Set] and that a value is displayed for each reference position element.

Teach the robot the position where the workpiece is when the reference position is set. Teach the position to the robot without moving the workpiece.

## 6.2.5 Overridable Parameters

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Exposure Time


Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

### Number of Exposure

Specify a number between 1 and 6.


## 6.3 DEPALLETIZING VISION PROCESS

The Depalletizing Vision Process is a vision process that performs vertical-direction position offset in addition to the regular two-dimensional position offset. The height of the workpiece is measured based on the apparent size of the workpiece captured by the camera.




### 6.3.1 Setting up a Vision Process

If you open the setup page of [Depalletizing Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



## Camera Calibration

Select the camera calibration you want to use.

## Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

## Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

## Multiple Locator Find Mode

If you have created more than one locator tool, select how to execute those tools.

### Find Best

All the locator tools will be executed, and the best result will be chosen. This is effective when you want to identify the type or put location reliability before processing time.

### Find First

The locator tools will be executed sequentially from the top until the specified number of workpieces has been found. The subsequent locator tools will not be executed once the number of found exceeds the specified number. For your information, the duplicate check is executed every time one locator tool is executed, the number of found, which is compared to the specified number, does not include duplicated workpieces.

## App. Z Mode

Specify how to calculate the height of the workpiece.

### Calc. From Found Scale

The Z-direction height of the workpiece will be calculated from the found workpiece size.

When [Use layer height] is checked, the number of the layer at which the workpiece is placed is determined from the size of the workpiece found by the vision process. The position of the workpiece is calculated based on the height information corresponding to the layer. The height can be calculated stably even when there is a little size measurement error because the same height information is used for each individual layer.

When [Output layer] is checked, the determined layer of the workpiece can be output to the vision

register as a measurement value. Specify the number of the measurement value to which to output the tier in [No.].

### Use Register Value


The value stored in the specified register of the robot controller will be used as the Z-direction height.

### Number to Find

Enter the maximum number of workpieces to be found per measurement. The specifiable range is 1 to 100.

### Offset Frame

A 2D vision process measures the displacement of a workpiece on a plane. The plane is called offset plane. The offset plane is defined as a plane parallel to the XY plane of the offset frame. Here, specify the offset frame. If you have chosen [Fixed Frame Offset] for [Offset Mode], specify a user frame as the offset frame. If you have chosen [Tool Offset] for [Offset Mode], specify a user tool. The following are examples of the offset frame in the case of Fixed Frame Offset.



When the workpiece is moved horizontally

When the workpiece is moved on an inclined plane:

#### NOTE

The Z height of the offset plane is specified as [Reference Height] discussed below. Here, you determine the gradient of the offset plane.

### Image Logging Mode

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

#### Do Not Log

Do not save any images to the vision log.

#### Log Failed Image

Save images only when the vision operation fails.

#### Log All Image

Save all images.

**CAUTION**

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

**Setting the Sorting Parameters**

Set the sorting parameters to be applied when more than one workpiece has been found. For details, see Subsection 3.7.16, “Sorting”.

**Delete Duplicates If <**

The position and angle of each found result is checked to see whether the result is the same as another result. If there are multiple found results within the specified pixels and angle, the results are assumed to indicate the same workpiece and only the found result with the highest score is output.

**Reference Data**

The reference data is used to calculate offset data from the found result. The reference data mainly consists of two types of data described below.

**App. Z Coordinate**

This item is used to determine the Z-direction height of the workpiece. If you have chosen [Use Register Value] in [App Z Mode], specify the number of the register of the robot controller that stores the Z-direction height. If you have chosen [Calculate From Found Size] in [App Z Mode], specify two sets of Z-direction height and size data used as the reference.

**Reference Position**

Position of the workpiece found when the robot position is taught. The offset data is the difference between the actual workpiece position found when running the vision process and the reference position.

A vision process might have more than one set of reference data. Under normal conditions, only one set of reference data is used. However, for example, if there are two types of workpiece, the vision process uses two sets of reference data because it needs to set the parameters and reference position to determine the Z-direction height for each workpiece.


**Adding reference data**

You can add or delete reference data as follows.

- 1 Tap  button.
- 2 In [Model ID], enter the model ID for which to use the reference data.

**Deleting reference data**

You can delete reference data as follows, if there is more than one set.

- 1 Select the reference data you want to delete using the index drop-down list
- 2 Tap  button.
- 3 A popup message is displayed to confirm. Press F4 OK.

**Register Number**

Use this item when [Use Register Value] is chosen in [App. Z Mode]. Specify the number of the register that stores the workpiece height.

### Layer error threshold

The layer at which the workpiece is placed is automatically determined based on information of the found size and height corresponding to the reference layer taught in advance. The calculated layer may have a margin of error depending on the found size. Set a value between 1% and 50% as the permissible calculation error in [Layer error threshold]. For example, assume that a value of 20% is specified. When the height of the workpiece calculated from the found size is within a range between  $\pm 20\%$  of the reference height for the layer, the layer is determined. If the height is outside the range, an alarm is issued because the layer cannot be determined.

### Setting the Reference Height and Size

Use this item when [Calculate From Found Scale] is chosen in [App. Z Mode]. Set the relationship between the actual Z-direction height of the workpiece and the apparent size of the workpiece captured by the camera.

- 1 Place one workpiece, and touch up the workpiece surface using touch-up pins. Enter this height data in [Reference Height 1].
- 2 Press F3 SNAP and then press F4 FIND to find the workpiece. Then, tap the [Set Scale] button and set [Reference Scale 1].
- 3 Place n workpieces, and touch up the workpiece surface using touch-up pins. Enter this height data in [Reference Height 2].
- 4 Press F3 SNAP and then press F4 FIND to find the workpiece. Then, tap the [Set Scale] button and set [Reference Scale 2].

### Setting the Reference Layer

Use this option when [Use layer height] is checked in [App. Z Mode]. Enter the number of the tier containing the workpiece with which the reference height and size are set.

### Reference Position Status

If the reference position is set, [Trained] is displayed in green; otherwise, [Not Trained] is displayed in red.

### Reference Position X,Y,Z,R


The coordinates of the set reference position are displayed.

### Offset Limit

Specify the condition used to check whether the calculated offset value is within the specified range. By default, [None selected] is set, in which case the offset limit check is not made. For information about the offset limit check conditions, see Section 8.2, "OFFSET LIMIT".

## 6.3.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Found

The number of found workpieces is displayed.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

### X,Y,Z

Coordinate values of the model origin of the found workpiece (units: mm).

### Roll

Rotation angle of the found workpiece around the Z axis (units: degrees).

### Model ID

Model ID of the found workpiece.

### Score

Score of the found workpiece.

### Size

Size of the found workpiece

### Contrast

Contrast of the found workpiece.

### Fit Err.

Elasticity of the found workpiece (units: pixels).

## Layer


Number of the layer containing the workpiece that is calculated from the found size.

### NOTE

If you run a find test without setting the reference Z-direction height or size when [Calculate From Found Scale] is chosen in [App. Z Mode], \*\*\*\*\* is displayed for X, Y, Z, and R because these values cannot be calculated.

## 6.3.3 Setting the Reference Position

Set the reference position. The offset value is calculated based on the relationship between the reference position you set here and the found position.



- 1 Open the vision process setup page.
- 2 Place a workpiece in the camera view for which you want to set the reference position.
- 3 Press F3 SNAP and then press F4 FIND to find the workpiece.
- 4 Tap the [Set] button.
- 5 Check that [Ref. Pos. Status] is set to [Set] and that a value is displayed for each reference position element.

Teach the robot the position where the workpiece is when the reference position is set. Teach the position to the robot without moving the workpiece.

## 6.3.4 Overridable Parameters

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Exposure Time

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.


### Number of Exposure

Specify a number between 1 and 6.



## 6.4 2D CALIBRATION-FREE VISION PROCESS

This is a vision process that does not require a camera calibration. In addition, user frames and the other related setups are also not required. Thus, in comparison to a conventional 2D Single-view vision process, the ease of installing a vision application has improved.



To execute this vision process, a KAREL program IRVHOMING is called instead of VISION RUN\_FIND. For detail, refer to Section 9.4.6 IRVHOMING. When IRVHOMING is executed, the robot moves automatically to match the found pose with the destination pose trained at setup. Offset data is calculated as the difference between the robot position where the destination pose was trained, and the final robot position after homing in on the target part.


2D Calibration-free Vision Process supports the following types of applications:

- Fixed-frame Offset with a robot-mounted camera.
- Tool Offset with a fixed-mounted camera.


Because every 2D Calibration-free Vision Process detection is accompanied by a robot motion, the detection tends to take a little longer than a conventional 2D Single-view Vision Process.

### 6.4.1 Setting up a Vision Process

If you open the setup page of [2D Calibration-free Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



## Camera Setup

Select the camera you want to use. In 2D Calibration-free Vision Process, the offset type is determined by how the camera is mounted. If the application is a fixed-frame offset using a robot-mounted camera, select a camera setup with [Robot-Mounted Cam] checked. If the application is a tool offset with a fixed-mounted camera, select a camera setup with [Robot-Mounted Cam] not checked. Depending on the selected camera, either [Robot Mounted Camera – Fixed Frame Offset] or [Fixed Mounted Camera – Tool Offset] is displayed on the [Camera Setup] row.

## Exposure Time

Set the camera's exposure time to be applied when running the vision process. The auto- and multi-exposure modes are not available with this vision process.

## Image Logging Mode

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

### Do Not Log

Do not save any images to the vision log.

### Log Failed Images

Save images only when the vision operation fails.

### Log All Images

Save all images.



## CAUTION

The execution of the next detection cannot start until the image logging operation for the preceding detection is completed. The time required to log images depends on the type of storage device in use. Use this function after checking whether the delay of logging images is acceptable for your application.

**Priority**

Specify the priority order when multiple targets are found in a single detection. The default is [High Score].

**From Image Left**

The robot will work starting from the target found closest to the left side of the image.

**From Image Right**

The robot will work starting from the target found closest to the right side of the image.

**From Image Top**

The robot will work starting from the target found closest to the top of the image.

**From Image Bottom**

The robot will work starting from the target found closest to the bottom of the image.

**High Score**

The robot will work starting from the target found with the highest score.

**Largest**

The robot will work starting from the largest target found.

**Dist Accuracy**

In a program execution, a distance threshold to consider the target has reached the destination pose. The default is 0.1mm.

**Angle Accuracy**

In a program execution, an angle threshold to consider the target has reached the destination pose. The default is 0.1 degrees.

**Offset Height**

When the checkbox is checked, the robot will compensate the work distance based on the found size during IRVHOMING execution. This will result in the vision process to calculate the offset in Z direction, making it act similar to a Depalletizing Vision Process. However, the detection will take a bit longer. The checkbox is initially not checked.

**CAUTION**

When enabling the height offset, make sure to enable the Scale DOF of the GPM locator tool. If the Scale DOF is not enabled, the offset height may not be calculated correctly and the EOAT may collide with parts and/or peripheral devices.

**6.4.2 Learning**

---

When a Calibration-free Vision Process is created, there is no information how to move the robot in order to match the found pose of a part on the image with the destination pose. Thus, a “Learning Process” is required to obtain the robot compensation direction. Since the robot motion is involved, the learning process can only be executed from the teach pendant.


The learning process is done by detecting markers placed on the plane where the targets are placed. Even when [Offset Height] is enabled for depalletizing applications, the markers should be placed at the same height.

The markers for learning do not have to be created specially; generic circular stickers or circles printed on a sheet of paper will suffice. However, the markers must be the same size and thickness if multiple markers are prepared.

## Status


The label denotes the learning process status. [Trained] is displayed in green if the learning process is complete; [In Process] in black if the learning process has started; or [Not Learned] in red if the learning process has not been started.

A popup message shown on the following diagram is displayed when the [Learn] button is tapped. Pressing F4 EXECUTE while holding down the SHIFT key will start the learning process. The detection results are shown on the image display screen.



The SHIFT key must be held down throughout the process, or the process will pause. If paused, the process can be resumed by tapping the [Learn] button again and pressing F3 RESUME while holding down the SHIFT key.

A popup message shown on the following diagram is displayed when the learning process is completed.



### Num Learned

The number of marker locations used for the learning process is displayed. Two markers placed at the same location will only count as one location. The status becomes [Learned] when 5 or more marker locations are learned.


The learning data can be cleared as follows.

- 1 Tap [Clear] button.
- 2 A popup message is displayed to confirm. Press F4 OK.


### Robot Position

When the learning process is started, the robot position where the learning started is recorded. The label becomes [Set] in green when the position is recorded, and [Not Set] in red if not recorded.

A popup message shown on the following diagram is displayed when the [MoveTo] button is tapped. Pressing F4 EXECUTE while holding down the SHIFT key will move the robot to the recorded position.



The SHIFT key must be held down throughout the motion. When the robot moves to the recorded position, a popup message shown on the following diagram is shown. The motion pauses if the SHIFT key is released. When the motion is paused, a popup messaged “Motion interrupted” is displayed.



### 6.4.3 Destination Pose

The destination pose to move the found pose to is trained. When the vision process is executed, the robot moves to a position such that the target is found with the same pose as the destination pose.

#### Status

The label becomes [Set] in green when the pose is set, and [Not Set] in red if not set.


#### Robot Position

When the destination pose is set, the robot position where the image used for setting the destination pose was captured is recorded. The label becomes [Set] in green when the position is recorded, and [Not Set] in red if not recorded.

The robot can be move to the recorded position by tapping the [MoveTo] buttn. A popup message “Motion is complete” is displayed when the robot moves to the recorded position. The motion pauses if the SHIFT key is released. When the motion is paused, a popup messaged “Motion interrupted” is displayed.

## 6.4.4 Test Run

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Found

The number of found targets is displayed.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

#### Row, Column

Coordinate values of the model origin of the found target (units: pixels).

#### Angle

Rotation angle of the found target (unit: degrees).

#### Scale

Scale of the found target (unit: %).

#### Model ID

Model ID of the found target.

#### Score

Score of the found target.

#### Contrast


Contrast of the found target.

#### Fit Err.

Elasticity of the found target (units: pixels).


## 6.4.5 Setup Guidelines

In this section, a basic training procedure for 2D Calibration-free Vision Process is described. The procedures are common to both fixed-frame offset and tool offset.




### Detection Position

Determine the robot position to run vision detection. Set the camera to a live mode, and move the robot such that the camera optical axis is more or less perpendicular to the target plane (such as the table where the targets are placed in the case of fixed-frame offset, and the plane where the gripping error occurs in the case of tool offset), and the measurement area fits within the camera field of view. Once the detection position is determined, adjust the lens focus and aperture.








## Learning

Learning is started from the vision process setup page. Below are some pointers when starting the learning process.

- Learning data is acquired by observing markers placed at five or more locations.
- For fixed-frame offset, place the markers on the plane where the targets are placed.
- For tool offset, place the markers on the same plane of a target or a plate held by a robot.
- The markers can be placed all at the same time, or can be placed one at a time in five different locations.
- The locations of the placement can be arbitrary, but the markers should not form a line.
- The learning is done more accurately by spreading the markers widely on the measurement field.
- The diagram below shows an example of the placement seen in the measurement field.
- The learning process can proceed smoothly by placing the markers to resemble a five on dice.




Learning is executed with the following procedures.

- 1 Move the robot to a position to start learning. Usually, this is the same as the detection position. When starting the learning process from a different position, choose the position such that the robot posture is identical to the posture at the detection position.
- 2 Enable the teach pendant.
- 3 If another program is running or paused, end the program.
- 4 Reset the alarm.

- 5 Tap the [Learn] button.
- 6 While holding the SHIFT key, press F4 EXECUTE.

If the learning process does not complete with the markers detected within the field of view, the following popup message is displayed and the learning will pause.



After moving the markers, press F4 EXECUTE while holding down the SHIFT key to continue learning. Markers placed at the same location will not advance the learning process, so give a generous displacement to each marker before proceeding. When the number of detected markers reaches the required amount, the learning process will end.

In the case of fixed-frame offset using a robot-mounted camera, if the measurement field is larger than the camera field of view, spread the markers throughout the measurement field and proceed with learning in sections with various starting positions. In such a case, the robot posture for each position must coincide with the initial posture of the position where the learning was started.

#### NOTE


If the image of the marker or the background is saturated, a detection size variance may occur which would result in an inaccurate learning data. In order to obtain an accurate learning data, the marker material and the lighting source should be carefully considered so that the markers detected from the same height would be found with the same size. For fixed-frame offset using a robot-mounted camera, the use of a ring-light at the camera mount is recommended.

### Train Model

With the robot positioned at the detection position, place a target more or less in the middle of the camera field of view and train the GPM locator tool model.

### Set Destination Pose

With the robot positioned at the detection position, set the destination position in the vision process setup page.



- 1 Place a target which you want to set the destination pose for, in the camera view.
- 2 Press F3 SNAP and then press F4 FIND to find the target.
- 3 Tap the [Set] button.
- 4 Check that [Status] becomes [Set].

## Teach Robot Program

While keeping the target at the position where the destination pose was set, teach the robot program (such as handling paths).

Shown below is an example for executing a calibration-free vision process, and offsetting the robot motion.

```

1:J P[1] 100% FINE
2: CALL IRVHOMING('NOCAL', 1000)
3: VISION GET_OFFSET 'NOCAL' VR[1] JMP LBL[10]
4:L P[2] 500mm/sec FINE VOFFSET, VR[1]

```

- Train the detection position at P[1].
- Select the vision program to run in the first argument of IRVHOMING.
- Specify the motion speed (mm/sec) in the second argument of IRVHOMING.

## 6.4.6 Advanced Mode

In the 2D Calibration-free Vision Process setup page, seldom used items are hidden in order to improve the ease of use for beginners. To display all the items, set the system variable \$VP2N\_CFG.ADVANCED to TRUE and reopen the vision process. The setup page in this state is called to be in advanced mode.

If an item only shown in advanced mode is changed, the setup page for that particular vision process will be displayed in advanced mode even after reverting the system variable \$VP2N\_CFG.ADVANCED to FALSE.

The items shown in advanced mode are described below.

## Multi Exposure

Multi-exposure can be used in advanced mode. For detailed information about the individual items to be set, see Subsection 3.7.15, “Setting Exposure Mode”.

## Robot Holding the Part

If you have chosen [Tool Offset] for [Offset Mode], specify the robot that is holding the target.

## Sorting Parameters

Set the sorting parameters to be applied when more than one target have been found. For details, see Subsection 3.7.16, “Sorting”.

## Dest. Pose To Use

Choose one of the following to specify how to determine the destination pose to use.

### This Index

The same destination pose is used to move the robot.

### Model ID

Different destination pose is used depending on the model ID of the found target. Choose this in cases when there are two or more types of targets with different models.

## ID

If [This Index] is selected in [Dest. Pose To Use], enter the destination pose ID to use.

## Fixed Plane

A plane on which the robot is moved to compensate the found work displacement is called an offset plane. In general, the offset plane is determined with the learning process, but by enabling this checkbox, the offset plane can be fixed to the XY plane of a specific user frame. If a robot with 5 or less axes is used, this checkbox is checked automatically.

## UF

When [Fixed Plane] is checked, select the user frame number to use as the offset plane.


## Adding a Destination Pose

You can add a destination pose as follows.

- 1 Tap  button.
- 2 In [Model ID], enter the model ID for which to use the destination pose.

## Deleting a Destination Pose

You can delete a destination pose as follows, if there is more than one set.

- 1 Select the destination pose you want to delete using the index drop-down list
- 2 Tap  button.
- 3 A popup message is display to confirm. Press F4 OK.

## Index

Select the destination pose to display.

## Model ID

Specify the model ID of the found result to set the destination pose for.

### Destination Pose Row, Column

The image coordinate values of the set destination pose are displayed.

### Destination Angle


The destination angle is displayed.

### Destination Scale

The destination scale is displayed.

## 6.5 3D TRI-VIEW VISION PROCESS

This vision process detects three parts of a large workpiece, such as a vehicle, by using three cameras respectively, and offsets the robot based on the calculated 3D position of the workpiece. Upon detection of a part, the three cameras respectively measure a gaze line from the camera to the detection target. By applying a triangle whose shape is known to these three gaze lines, the vision process determines where each detection target is located on the gaze line and obtains the 3D position and posture data of the workpiece.



There is a tool called “Camera View” beneath this vision process. One camera view handles one measurement point. The number of camera views is three and cannot be changed.

### 6.5.1 Application Consideration

This subsection describes the detection targets, camera position, and other factors to consider.

#### 6.5.1.1 What to consider

In determining the detection targets, note the following:

- The accurate relative positional relationship among the three detection targets must be able to be calculated from a drawing or other information.
- There must be no difference in relative relationship among the positions of the three detection targets or the positions where the work is done.
- Three detection targets must be available that are sufficiently apart from each other to cover the entire workpiece.
- The triangle whose vertexes are the three detection target points must not be extremely long lengthwise.

- The detection targets must not appear different in shape.
- The detection targets must not have any part near them that is similar in shape.

In the case of a vehicle, the reference holes are suitable as the detection targets.


### 6.5.1.2 Camera position

#### Determining the camera view

Determine the size of the camera view so that the detection targets stay in the view even if they maximally deviate. Making the camera view extremely large may make it impossible to ensure the required offset accuracy.

#### Determining the camera position

The vision process finds detection targets and measures three gaze lines. Position the camera so that any two gaze lines are not close to being parallel and that the angle formed by any two gaze lines is sufficiently wide (preferably 60 degrees or more).




#### Determining the lens focal distance

The focal distance of the lens to be used is determined by the size of the camera view and the distance between the camera and detection target. In the case of the XC-56 camera, the focal distance  $f$  (mm) is roughly calculated by the following equation:

$$f = 3.55 \times L \div W$$


L: Distance between the camera and detection target (mm)

W: Size of the camera view (mm)




### 6.5.2 Setting up a Vision Process

If you open the setup page of [3D Tri-View Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.




## Offset Mode

In the 3D tri-view vision process, only the fixed frame offset is available. The offset data for the fixed frame offset is calculated.

## Combine Error Limit

The combine error limit is the distance the found targets for each camera view move independently of each other. The figure below shows the original found location for each of the three views as the small black targets, and it shows the current found location for each view as the larger target. In the example below there is a combine error, since the relationship between the three targets changed from the original reference position find to the current find, as seen by the size and shape of the triangle changing.

If the calculated combine error limit is greater than the user specified limit, the workpiece will not be found. Typically a sudden increase in the combine error is due to incorrect calibration of one or more of the camera views, or physical changes in the workpiece.



## Image Logging Mode

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

## Do Not Log

Do not save any images to the vision log.



### Log Failed Images

Save images only when the vision operation fails.

### Log All Images

Save all images.

**⚠ CAUTION**  
 The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

### Setting the Reference Position

If the reference position is set, [Set] is displayed in green. Otherwise, [Not Set] is displayed in red.

### Average Reference X,Y,Z

The average reference position of each camera view is displayed. The [Offset Limit] described next is to check the location or travel distance of this reference position.

### Compute Error Estimation


If you check this box, the error estimation is computed when the vision process succeeds in finding a workpiece.

### Offset Limit

Specify the condition used to check whether the calculated offset value is within the specified range. By default, [None selected] is set, in which case the offset limit check is not made. For information about the offset limit check conditions, see Section 8.2, "OFFSET LIMIT".

## 6.5.3 Setting up a Camera View

If you select [Camera View 1] in the tree view, a screen like the one shown below appears.



## Camera Calibration

Select the camera calibration you want to use. The camera calibration must be the grid pattern calibration, and the projection method must be [Perspective]. To prevent the location accuracy from deteriorating, it is recommended to select “2” as the number of calibration planes when performing the calibration. Note also that all the camera calibration must have the same application user frame selected.

## Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

## Setting the Exposure Time

Set the camera’s exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, “Setting Exposure Mode”.

## Multiple Locator Mode

If you have created more than one locator tool, select how to execute those tools from the following:

### Find Best

All the locator tools will be executed, and the best result will be chosen. This is effective when you want to identify the type or put location reliability before processing time.

### Find First

The locator tools in the tree view will be executed sequentially from the top, and the result that is located first will be output. The location process will stop as soon as a workpiece is found, leaving the subsequent locator tools unexecuted. This is effective when greater emphasis is put on the processing time.


## Camera Target Dist.

Enter an approximate distance between the camera and the target to find. If you select calibration data, the distance between the camera at the time of calibration and the origin of the calibration grid is set as the default. Also, when the reference position is set, this value is overwritten by the camera-to-target distance resulting from the location process of the vision process.

## Fundamental Data X, Y, Z

Enter the position of the target to find in a given frame. For example, you may enter the coordinates of the target on the drawing.

Fundamental data input example: The following figure shows an example of fundamental data input using the CAD data of the workpiece. The coordinates of the target shown in CAD data are input as the fundamental data.



### Reference Position X, Y, Z

The coordinates of the set reference position are displayed.

### Compute Error

If this checkbox is checked and the detection of the vision process became successful, the detection error in the locator tool on the image is calculated.

### Offset Limit

Specify the condition used to check whether the calculated offset value is within the specified range. By default, [None selected] is set, in which case the offset limit check is not made. For information about the offset limit check conditions, see Section 8.2, "OFFSET LIMIT".

## 6.5.4 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected. There are two ways to run a test. One is to test the entire vision process, and the other is to test each camera view individually. In the case of a fixed camera, testing the entire vision process at one time is easier. In the case of a robot-mounted camera, where the robot position differs for each camera view, test each camera view individually.

Combine Error	Time to Find:	View	X	Y	Z	Model ID	Score	Camera Target Dist.
29.2 mm/pi	46 ms	1	36.7	25.3	628.7	1	99.6	333.2
		2	329.7	174.9	693.6	1	100.0	401.6
		3	-276.6	616.2	680.5	1	100.0	384.4

### Combine

Alignment deviation between the point found when the reference position is set and the point found when the test is run (units: mm). This value becomes nearly 0 if there are no differences between targets to find and no location error.

### Error

This estimation indicates how much the detection error in the locator tool on the image affects the calculated 3D position of the workpiece. For example, when this value is 8.0 mm/pix, 0.1 pix of detection error can cause  $8.0 \times 0.1 = 0.8$  mm of variable of the measured 3D position. You cannot estimate total compensation accuracy only from this value, but if this value is too large for your application, reconsider changing camera layout.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found results table

The following values are displayed.

#### X,Y,Z

Coordinates of the model origin of the found target (units: mm).

#### Model ID

Model ID of the found workpiece.

#### Score

Score of the found workpiece.

#### Camera Target Dist.

Distance between the camera and the model origin of the found target (unit: mm).

## 6.5.5 Setting the Reference Position

Set the reference position. The offset value is calculated based on the relationship between the reference position you set here and the found position.

The screenshot shows the iRvision Setup Main - VPCB interface. At the top, there are status buttons (Busy, Stop, Hold, Fault, Run, I/O, Prod, Stop) and a job status bar indicating 'JOB LINE 0 T2 ABORTED JOINT' with a 5% progress indicator. The main window is titled '3-D Tri-View Vision Process' and contains several configuration options:

- Offset Mode: Fixed Frame Offset
- Combine Error Limit: 5.000 mm
- Image Logging Mode: Log Failed Images
- Ref. Pos. Status: Set
- Average Reference X: 29.904 mm
- Average Reference Y: 272.123 mm
- Average Reference Z: 667.586 mm
- Compute Error:
- Limit Check Select: None selected

Below the settings is a 'Results' table:

Combine	--- mm	View	X	Y	Z	Model ID	Score	Camera Target Dist.
Error	29.2 mm/pi	1	36.7	25.3	628.7	1	99.6	333.2
Time to Find:	46 ms	2	329.7	174.9	693.6	1	100.0	401.6
		3	-276.6	616.2	680.5	1	100.0	384.4

At the bottom of the interface, there are buttons for '[ TYPE ]', 'SNAP', 'FIND', 'END EDIT', and '>'.

- 1 Open the vision process setup page.
- 2 In the view of each camera, place a workpiece for which you want to set the reference position.
- 3 Snap the image with each camera view ready for finding the workpiece, and then press F4 FIND to find the workpiece.
- 4 Tap the [Set] button.
- 5 Check that [Ref. Pos. Status] is set to [Set] and that a value is displayed for each reference position element.

Teach the robot the position where the workpiece is when the reference position is set. Teach the position to the robot without moving the workpiece.

### 6.5.6 Overridable Parameters

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

#### Exposure Time


Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

#### Number of Exposure

Specify a number between 1 and 6.


## 6.6 3DL SINGLE VIEW VISION PROCESS

The 3DL Single-View Vision Process measures the three-dimensional position and posture of the workpiece and adjusts the handling of the workpiece by the robot.




## 6.6.1 Setting up a Vision Process

If you open the setup page of [3DL Single View Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



### Camera Calibration

Select the camera calibration you want to use.

### Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

### Offset Mode

Select the robot position offset mode.

**Fixed Frame Offset**

The fixed frame offset data will be calculated.

**Tool Offset**

The tool offset data will be calculated.

**Found Position (User)**

The found position will be output as is, instead of the offset data. This option is provided for any required specified offset mode. Do not select it under normal conditions. The found position is relative to the application user frame.

**Found Position (Tool)**

The found position will be output, instead of the offset data, after being converted to a value as seen from the tool frame. This option is provided for any required specified offset mode. Do not select it under normal conditions

**Robot Holding Part**

If you have chosen [Tool Offset] or [Found Position (Tool)] for [Offset Type], specify the robot holding the workpiece.

**Offset Frame**

A 3DL single view vision process measures the offset data with respect to the plane which is selected in this item. If you have chosen [Fixed Frame Offset] for [Offset Mode], specify a user frame as the offset frame. If you have chosen [Tool Offset] for [Offset Mode], specify a user tool.

**Setting the Light**

Use this function to have an external light turned on or off as appropriate for the vision process executed with the 3D laser sensor. By using this function, you can have the light turned on, for example, when finding two-dimensional features during one three-dimensional measurement, or have it turned off when finding the two laser lines. It is common to have an LED ring light mounted to the 3D laser sensor to provide controlled lighting. Set the function as follows.

- 1 In [Light Output Signal Type], specify the type of signal - DO or RO - that turns on or off the light.
- 2 In [Light Output Signal Number], enter the number of the output point to which the ON/OFF signal is connected. For example, when connecting the signal to RO[1], enter 1.
- 3 In [Light Output Signal Polarity], set the relationship between the signal output and turning on or off the light. To turn on the light when the signal is ON, set [Signal=ON->Light=ON]. To turn it off when the signal is ON, set [Signal=OFF->Light=ON].
- 4 In [Light ON snap delay], set the wait time when you want to snap just after the light ON. Under normal conditions, set 0.

If you use our genuine LED light, set the items as follows.

- 1 In [Light Output Signal Type], select MUX.
- 2 In [LED Channel], select the port number of MUX to which the 3D laser sensor is connected.
- 3 In [LED Intensity], specify a number between 1 and 16 as the intensity of LED light

**Lean Angle Limit**

Any workpiece found with an angle greater than the lean angle limit from the reference position is treated as not being found.

## Image Logging Mode

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

### Do Not Log

Do not save any images to the vision log.

### Log Failed Images

Save images only when the vision operation fails.

### Log All Images

Save all images.



### CAUTION

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

## Image Display Mode

Change the image to be displayed in the Setup Page.

### 2D Image

The camera-captured image is displayed.

### Laser Slit Image 1

The image of laser slit 1 is displayed.

### Laser Slit Image 2

The image of laser slit 2 is displayed.

## 6.6.1.1 2D Measurement setups

Perform the 2D measurement setups.

2D Measurement Setups	
Exposure Mode:	Fixed <input type="button" value="v"/>
Exposure Time:	33.333 ms <input type="button" value="v"/> <input type="button" value="v"/> <input type="button" value="v"/> <input type="button" value="v"/>
Auto Exposure Area:	Not Trained <input type="button" value="Train"/>
Auto Exposure Adjust:	0 <input type="button" value="v"/> <input type="button" value="Mask"/>
Multi Exposures:	1 <input type="button" value="v"/> , 33.333 - 33.333 ms
Multi Exposure Area:	(0,0) 0x0 <input type="button" value="Train"/>
Multi Exposure Mode:	Deviation <input type="button" value="v"/> <input type="button" value="Mask"/>
Light For Snap:	Not Used <input type="button" value="v"/>
Multiple Locator Mode:	Find Best <input type="button" value="v"/>
	Best Result of Each Tool <input type="button" value="v"/>



## Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

## Light for Snap

Set whether to turn on or off the light when snapping an image for two-dimensional measurement.

## Multiple Locator Find Mode

From the upper drop-down box, select which locator tools to execute in the case that multiple locator tools have been made.

### Find Best

All the locator tools are executed. This is effective when you want to identify the type or put location reliability before processing time.

### Find First

The locator tools are executed sequentially from the top. The location process stops as soon as a locator tool detects workpieces. The subsequent locator tools are not executed.

From the lower drop-down box, select which results of each locator tool to use in the case that the tool has multiple results.

### Best Result of Each Loc. Tool

The result having the highest score is selected for each locator tool. The measurement uses only the selected results.

### All Result of Each Loc. Tool

All the results are used in descending order of scores until the measurement succeeds. This is effective when you want to eliminate measurement failure caused by misdetection of a locator tool.

## 6.6.1.2 Laser measurement setups

Perform the laser measurement setups.

-Laser Measurement Setup

Exposure Time:	1,000 ms
Multi Exposures:	1, 1.00 - 1.00 ms
Number of Snaps:	1
Bright. Scale Mode:	Maximum
Light For Snap:	Not Used

## Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

## Number of Snaps

Use this item when you want to snap multiple images during one exposure time and to obtain an average image. This setting is valid only when 1 is set in [Multi Exposure].

## Bright. Scale Mode

Specify a method for coordinating the brightness for multi-exposure.

**Maximum**

After all laser images are summed up, the brightness of the whole image is scaled so that the brightness in the photometric area is lower than 256. If halation occurs at even one point in the photometric area, the image becomes relatively dark as a whole.

**Summation**

After all laser images are summed up, the brightness of the pixel, brightness of which is higher than 256, is clipped. The brightness of whole image is kept and the brightness of pixels in which halation occurs is only suppressed to the maximum displayable brightness.

**Light for Snap**

Set whether to turn on or off the light when snapping an image for laser measurement.

**NOTE**

If more than one laser measurement tool, such as 3DL plane command tool or 3DL displacement command tool, has been created, the tools will be executed sequentially from the top, and the measurement process will stop as soon as a measurement succeeds, leaving the subsequent tools unexecuted.

**6.6.1.3 Reference data**

Reference Data

Ref. Pos. Status: **Not Set**

Reference X:  mm

Reference Y:  mm

Reference Z:  mm

Reference W:  °

Reference P:  °

Reference R:  °

Limit Check Select:

**Reference Position Status**

If the reference position is set, [Set] is displayed in green; otherwise, [Not Set] is displayed in red.

**Reference Position X,Y,Z,W,P,R**


The coordinate values of the set reference position are displayed.

**Offset Limit**

Specify the condition used to check whether the calculated offset value is within the specified range. By default, [None selected] is set, in which case the offset limit check is not made. For information about the offset limit check conditions, see Section 8.2, "OFFSET LIMIT".

## 6.6.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Found

The number of found workpieces is displayed.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

### X,Y,Z

Coordinate values of the model origin of the found workpiece (units: mm).

### W,P,R

Rotation angle of the found workpiece around the X, Y, and Z axis (units: degrees).

### Laser ID

Laser measurement ID of the found workpiece.

### Model ID

Model ID of the found workpiece.

### Score

Score of the found workpiece.

### Contrast

Contrast of the found workpiece.

### Fit Err.

Elasticity of the found workpiece (units: pixels).

### Lean Angle

Inclination angle of the found workpiece (units: degrees).

## 6.6.3 Setting the Reference Position

---

Set the reference position. The offset value is calculated based on the relationship between the reference position you set here and the found position.

- 1 Open the Setup Page for the vision process.
- 2 Place a workpiece in the camera view for which you want to set the reference position.
- 3 Press F3 SNAP and then press F4 FIND to find the workpiece.
- 4 Tap the [Set] button.
- 5 Check that [Ref. Pos. Status] is set to [Set] and that a value is displayed for each reference position element.

Teach the robot the position where the workpiece is when the reference position is set. Teach the position to the robot without moving the workpiece.

## 6.6.4 Overridable Parameters

---

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Exposure Time

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

### Number of Exposure

Specify a number between 1 and 6.

### Laser Exposure Time


Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

### Number of Laser Exposure

Specify a number between 1 and 6.


## 6.7 3DL MULTI-VIEW VISION PROCESS

The 3DL multi-view vision process is used to find the position of the workpiece by finding multiple parts of it. It is effective when the workpiece is too large for the camera to capture its entire image and when the orientation of the workpiece is tilted.




### 6.7.1 Setting up a Vision Process

If you open the setup page of [3DL Multi View Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



## Offset Mode

Select the robot position offset mode.

### Fixed Frame Offset

The fixed frame offset data will be calculated.

### Tool Offset

The tool offset data will be calculated.

## Robot Holding Part

If you have chosen [Tool Offset] for [Offset Mode], specify the robot holding the workpiece.


## Offset Frame

A 3DL multi-view vision process measures the offset data with respect to the plane which is selected in this item. If you have chosen [Fixed Frame Offset] for [Offset Mode], specify a user frame as the offset frame. If you have chosen [Tool Offset] for [Offset Mode], specify a user tool.

## Combine Error Limit

The combine error limit is the distance the found targets for each camera view move independently of each other. The figure below shows the original found location for each of the three views as the small black targets, and it shows the current found location for each view as the larger target. In the example below there is a combine error, since the relationship between the three targets changed from the original reference position find to the current find, as seen by the size and shape of the triangle changing.

If the calculated combine error limit is greater than the user specified limit, the workpiece will not be found. Typically a sudden increase in the combine error is due to incorrect calibration of one or more of the camera views, or physical changes in the workpiece.



## Image Logging Mode

Specify whether to save log images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

### Do Not Log

Do not save any images to the vision log.

### Log Failed Images

Save images only when the vision operation fails.

### Log All Images

Save all images.



### CAUTION

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

## Reference Position Status

If the reference position is set, [Trained] is displayed in green; otherwise, [Not Trained] is displayed in red.

## Average Reference X, Y, Z


The average reference position of each camera view is displayed. The offset limit check described next is to check the location or travel distance of this reference position.

## Offset Limit

Specify the condition used to check whether the calculated offset value is within the specified range. By default, [None selected] is set, in which case the offset limit check is not made. For information about the offset limit check conditions, see Section 8.2, "OFFSET LIMIT".

## 6.7.2 Setting up a Camera View

If you select [Plane Camera View 1] in the tree view, a screen like the one shown below appears.



### Camera Calibration

Select the camera calibration you want to use.

### Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

### Setting the Light

Use this function to have an external light turned on or off as appropriate for the vision process executed with the 3D laser sensor. By using this function, you can have the light turned on, for example, when finding two-dimensional features during one three-dimensional measurement, or have it turned off when finding the two laser lines. It is common to have an LED ring light mounted to the 3D laser sensor to provide controlled lighting. Set the function as follows.

- 1 In [Light Output Signal Type], specify the type of signal - DO or RO - that turns on or off the light.
- 2 In [Light Signal Number], enter the number of the output point to which the ON/OFF signal is connected. For example, when connecting the signal to RO[1], enter 1.
- 3 In [Light Output Signal Polarity], set the relationship between the signal output and turning on or off the light. To turn on the light when the signal is ON, set [Signal=ON->Light=ON]. To turn it off when the signal is ON, set [Signal=OFF->Light=ON].
- 4 In [Light on snap delay], set the wait time from the output of the light ON signal until an image is snapped. Under normal conditions, set 0.

If you use our genuine LED light, set the function as follows.

- 1 In [Light Output Signal Type], select MUX.
- 2 In [LED Channel], select the port number of MUX to which the 3D laser sensor is connected.
- 3 In [LED Intensity], specify a number between 1 and 16 as the intensity of LED light

### Lean Angle Limit

Any workpiece found with an angle greater than the lean angle limit from the reference position is treated as not being found.



## 6.7.2.1 2D measurement setups

---

Perform the 2D measurement setups.

2D Measurement Setups

Exposure Mode: Fixed

Exposure Time: 33.333 ms

Auto Exposure Area: Not Trained Train

Auto Exposure Adjust: 0 Mask

Multi Exposures: 1, 33.333 - 33.333 ms

Multi Exposure Area: (0,0) 0x0 Train

Multi Exposure Mode: Deviation Mask

Light For Snap: Not Used

Multiple Locator Mode: Find Best

Best Result of Each Tool

### Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, “Setting Exposure Mode”.

### Light for Snap

Set whether to turn on or off the light when snapping an image for two-dimensional measurement.

### Multiple Locator Find Mode

From the upper drop-down box, select which locator tools to execute in the case that multiple locator tools have been made.

#### Find Best

All the locator tools are executed. This is effective when you want to identify the type or put location reliability before processing time.

#### Find First

The locator tools are executed sequentially from the top. The location process stops as soon as a locator tool detects workpieces. The subsequent locator tools are not executed.

From the lower drop-down box, select which results of each locator tool to use in the case that the tool has multiple results.

#### Best Result of Each Loc. Tool

The result having the highest score is selected for each locator tool. The measurement uses only the selected results.

#### All Result of Each Loc. Tool

All the results are used in descending order of scores until the measurement succeeds. This is effective when you want to eliminate measurement failure caused by misdetection of a locator tool.

## 6.7.2.2 Laser measurement setups

---

Perform the laser measurement setups.

-Laser Measurement Setup

Exposure Time: 1.000 ms

Multi Exposures: 1, 1.00 - 1.00 ms

Number of Snaps: 1

Bright. Scale Mode: Maximum

Light For Snap: Not Used

## Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

## Number of Snaps

Use this item when you want to snap multiple images during one exposure time and to obtain an average image. This setting is valid only when 1 is set in [Multi Exposure].

## Bright. Scale Mode

Specify a method for coordinating the brightness at the time of laser image synthesis in multi-exposure.

### Maximum

After all laser images are summed up, the brightness of the whole image is scaled so that the brightness in the photometric area is lower than 256. If halation occurs at even one point in the photometric area, the image becomes relatively dark as a whole.

### Summation

After all laser images are summed up, the brightness of the pixel, brightness of which is higher than 256, is clipped. The brightness of whole image is kept and the brightness of pixels in which halation occurs is only suppressed to the maximum displayable brightness.

## Light for Snap

Set whether to turn on or off the light when snapping an image for laser measurement.

### NOTE

If more than one laser measurement tool, such as 3DL plane command tool, has been created, the tools will be executed sequentially from the top, and the measurement process will stop as soon as a measurement succeeds, leaving the subsequent tools unexecuted.

## 6.7.2.3 Reference data

Reference Data

Reference X:  mm

Reference Y:  mm

Reference Z:  mm

Reference W:  °

Reference P:  °


Reference R:  °

## Reference X,Y,Z,W,P,R

The coordinate values of the set reference position are displayed.

## 6.7.3 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Combine

Alignment deviation between the point found when the reference position is set and the point found when the test is run (units: mm). This value becomes nearly 0 if there are no differences between targets to find and no location error.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

#### X,Y,Z

Coordinate values of the model origin of the found workpiece (units: mm).

#### W,P,R

Rotation angle of the found workpiece around the X, Y, and Z axes (units: degrees).

#### Laser ID

Laser measurement ID of the found workpiece.

#### Model ID

Model ID of the found workpiece.

#### Score

Score of the found workpiece.

#### Contrast

Contrast of the found workpiece.

**Fit Err.**

Elasticity of the found workpiece (units: pixels).

**Lean Angle**

Inclination angle of the found workpiece (units: degrees).

## 6.7.4 Setting the Reference Position

---

Set the reference position. The offset value is calculated based on the relationship between the reference position you set here and the found position.

- 1 Open the vision process Setup Page.
- 2 Place a workpiece in the camera view for which you want to set the reference position.
- 3 Press F3 SNAP and then press F4 FIND to find the workpiece.
- 4 Tap the [Set] button.
- 5 Check that [Ref. Pos. Status] is set to [Set] and that a value is displayed for each reference position element.

Teach the robot the position where the workpiece is when the reference position is set. Teach the position to the robot without moving the workpiece.

## 6.7.5 Overridable Parameters

---

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

**Exposure Time**

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

**Number of Exposure**

Specify a number between 1 and 6.

**Laser Exposure Time**

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

**Number of Laser Exposure**


Specify a number between 1 and 6.

## 6.8 3DL CROSS-SECTION VISION PROCESS

This function is typically used for a workpiece to which a “3DL vision process” cannot be applied. It illuminates the workpiece with the laser, collects height information of the illuminated part, and generates a cross-sectional image of the workpiece. Then, it executes a GPM locator tool on the generated cross-sectional image and calculates the three-dimensional position of the target section.


**CAUTION**  
 This function performs only measurement. To adjust the handling of the workpiece by the robot, offset data must be calculated using a robot program.

The lower right image shows the cross section image. The arrow direction of a laser slit indicates the vertical direction and the height indicates the horizontal direction as shown at lower left. In the following images, ○ and ○ connected with a line with an arrow indicate the same section.




### 6.8.1 Setting up a Vision Process

If you open the setup page of [3DL Cross-Section Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



## Camera Calibration

Select the camera calibration you want to use.

## Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

## Output Mode

Select the mode in which to output measurement results.

### Found Position (User)

The found position in the application user frame will be output as is.

### Found Position (Tool)

The found position will be output after being converted to a value in the specified user tool. It is mainly used to measure the error of the workpiece grasped by robot when 3D-sensor is secured.

## Robot Holding the Part

If you have chosen [Found Position (Tool)] for [Output Mode], specify the robot that is holding the workpiece.

## Offset Frame

A 3DL cross-section vision process measures the offset data with respect to the plane which is selected in this item. If you have chosen [Found Position (User)] for [Output Mode], specify a user frame as the offset frame. If you have chosen [Found Position (Tool)] for [Output Mode], specify a user tool.

## Image Logging Mode

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

### Do Not Log

Do not save any images to the vision log.

## Log Failed Images

Save images only when the vision operation fails.

## Log All Images

Save all images.



### CAUTION

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

## Image Display Mode

Change the image to be displayed. The setting in [Runtime] is used when the image is displayed on the runtime monitor; the setting in [Setup] is used when it is displayed on the Setup Page.

### 2D Image

The camera-captured image is displayed.

### Laser Slit Image

The laser slit image is displayed.

### Cross-sectional Image

The cross-sectional image of the workpiece is displayed.

## 6.8.1.1 Laser measurement setup

Perform the laser measurement setups.

-Laser Measurement Setup-

Not Trained Train

Search Narrow Area: Enable

Window Mask: Enable  Edit

Laser Number:

Effective Z Range:  mm

Exposure Time:  ms ⏴ ⏵

Multi Exposures:  , 1.00 - 1.00 ms

Number of Snaps:

Bright. Scale Mode:

Min Laser Points:

Min Laser Contrast:


Cross Section Scale:  mm/pix ⏴ ⏵

Multiple Locator Mode:

## Setting the measurement area

Set the measurement area as follows.

- 1 Press F6 Laser ON to turn on the laser
- 2 Press F2 LIVE to change to the live image display.

- 3 Jog the robot so that the section to be measured is at the center of the image. You can make positioning easier to do by tapping  button, which displays the center line of the window.
- 4 Adjust the distance between the 3D laser sensor and workpiece so that the laser intersection point comes around the center of the measurement section. In this case, the distance between the 3D laser sensor camera and measurement section is about 400 mm.
- 5 Press F2 STOP to stop the live image, then press F6 Laser OFF to turn off the laser.
- 6 Tap the [Train] button.
- 7 Enclose the workpiece to be taught within the displayed red rectangle, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.

### Search Narrow Area


If the area to be measured is small and the available points are few, enable [Search Narrow Area], which lets you increase the number of points to be used for the measurement. Note that this increases the processing time as well. Therefore, enable this item only when necessary.

### Window Mask

If there is a region you want to remove from the measurement area, set a mask. To create a mask in the measurement area, tap the [Edit Mask] button. Even when you have edited a mask, the tool will ignore the mask if you uncheck the [Enable] check box. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.

### Laser Number

Specify one of the two laser slits that you want to use to generate the cross-sectional image.



- 1: Laser slit with which the workpiece is illuminated from the lower left to the upper right on the image.
- 2: Laser slit with which the workpiece is illuminated from the upper left to the lower right on the image.

### Effective Z Range

Specify the range within which points are to be used as a Z value when the cross-sectional image is generated. Set a range which actually contains the measurement section as much as possible.

### Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, “Setting Exposure Mode”.

### Number of Snaps

Use this item when you want to snap multiple images during one exposure time to obtain an average image. This setting is valid only when a value of 1 is set in [Multi Exposure].

### Bright. Scale Mode

This item is valid only when a value of 2 or greater is set in [Number of Snaps]. Select the pixel output mode when the maximum value obtained by the sum of the brightness values of pixels exceeds 255.



## Maximum

Each pixel in the area is adjusted with the same ratio so that the brightness of the brightest pixel is set to 255 and output them.

## Summation

Pixels output as is unless the brightness of any pixel does not exceed 255 regardless of the brightness of the brightest pixel. This item is effective when the workpiece has a very bright part such as a mirror finished surface and an appropriate image cannot be obtained with the maximum brightness.

## Min Laser Points

If the number of effective points found in the measurement area, excluding the mask area, is below this threshold, the measurement result is invalid. If the laser point found result varies because of a small measurement area or change in image brightness, lowering the minimum number of laser points might make location possible. Note that, because the inclination of the workpiece plane is calculated from the found points, measurement accuracy can degrade as the number of points decreases. The number of effective laser points to be found depends on the [Min. Laser Contrast] shown below.

## Min Laser Contrast

This is the threshold for finding points of the laser applied to the measurement area, excluding the mask area. [Min. Num. Laser Points] and [Min. Laser Contrast] above should be confined to those cases where adjusting other settings never yields accurate found results. Forcing the tool to find laser points or changing the values inadvertently might result in inaccurate calculation of the detection position.



### CAUTION

Before changing location parameters [Min. Num. Laser Points] and [Min. Laser Contrast], check that the laser measurement exposure time in the vision process has been adjusted so that an image is captured adequately.

## Cross Section Scale

Set the resolution (mm/pixel) of the generated cross-sectional image.

## Multi-Locator Mode

If you have created more than one locator tool, select how to execute those tools.

### Find Best


All the locator tools will be executed, and the best result will be chosen. This is effective when you want to identify the type or put location accuracy before processing time.

### Find First

The locator tools will be executed sequentially from the top. The location process will stop as soon as the specified number of workpieces have been found. The subsequent locator tools will not be executed.

## 6.8.1.2 2D measurement setups

Perform the 2D measurement setups.




## Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

The exposure time specified here is used only setup mode. In runtime the 3DL cross-section vision process, finds the workpiece by using the cross-section image generated from the laser image, so the 2D image is not snapped. Therefore the exposure time specified here is not used during runtime.

## 6.8.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Found

The number of found workpieces is displayed.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Results table

The following values are displayed.

### X, Y, Z

Coordinates of the model origin of the found workpiece using the cross-sectional image (units: mm).

### W, P, R

These values are all 0 (units: degrees).

### Model ID

Model ID of the found workpiece using the cross-sectional image.

### Score

Score of the found workpiece using the cross-sectional image.

**Contrast**

Contrast of the found workpiece using the cross-sectional image.

**Fit Err.**

Elasticity of the found workpiece using the cross-sectional image (units: pixels).

**Laser Points**

Number of laser points used to generate the cross-sectional image.

### 6.8.3 Overridable Parameters

---

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

**Laser Exposure Time**

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.


**Number of Laser Exposure**

Specify a number between 1 and 6.

## 6.9 3DL CURVED SURFACE SINGLE VIEW VISION PROCESS


---

Of the 3DL vision processes, this one measures the three-dimensional position and posture of a workpiece - particularly a circular cylinder having a curved surface - and adjusts the handling of the workpiece by the robot. The curved surface locator tool and cylinder command tool can be used.




## 6.9.1 Setting up a Vision Process

If you select [3DL Curved Surface Single Proc], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



### Camera Calibration

From the dropdown box, select the camera calibration you want to use.

### Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

### Offset Mode

From the dropdown box, select one of the following robot position offset modes:

#### Fixed Frame Offset

The fixed frame offset data will be calculated.

**Tool Offset**

The tool offset data will be calculated.

**Found Position (User)**

The found position will be output as is, instead of the offset data. This option is provided for any required specified offset mode. Do not select it under normal conditions.

**Found Position (Tool)**

The found position will be output, instead of the offset data, after being converted to a value as seen from the tool frame. This option is provided for any required specified offset mode. Do not select it under normal conditions.

**Robot Holding Part**

If you have chosen [Tool Offset] or [Found Position (Tool)] for [Offset Mode], specify the robot holding the workpiece.

**Offset Frame**

A 3DL curved surface single vision process measures the offset data with respect to the plane which is selected in this item. If you have chosen [Fixed Frame Offset] for [Offset Mode], specify a user frame as the offset frame. If you have chosen [Tool Offset] for [Offset Mode], specify a user tool.

**Setting the Light**

Use this function to have an external light turned on or off as appropriate for the vision process executed with the 3D laser sensor. By using this function, you can have the light turned on, for example, when finding two-dimensional features during one three-dimensional measurement, or have it turned off when finding the laser lines. Set the function as follows.

- 1 In [Light Output Signal Type], specify the type of signal - DO or RO - that turns on or off the light.
- 2 In [Light Output Signal Number], enter the number of the output point to which the ON/OFF signal is connected. For example, when connecting the signal to RO[1], enter 1.
- 3 In [Light Output Signal Polarity], set the relationship between the signal output and turning on or off the light. To turn on the light when the signal is ON, set [Signal=On->Light On]. To turn it off when the signal is ON, set [Signal=Off->Light On].
- 4 In [Light on Snap Delay], set the wait time from the output of the light ON signal until an image is snapped. Under normal conditions, set 0.

If you use our genuine LED light, set the function as follows.

- 1 In [Light Output Signal Type], select MUX.
- 2 In [LED Channel], select the port number of MUX to which the 3D laser sensor is connected.
- 3 In [LED Intensity], specify a number between 1 and 16 as the intensity of LED light

**Lean Angle Limit**

Any workpiece found with an angle greater than the lean angle limit from the reference position is treated as not being found.

**Image Logging Mode**

From the drop down box, select one of the following image logging modes. Note that when the vision log is disabled on the Vision Config page, images are not saved.

**Do Not Log**

Do not save any images to the vision log. This mode enables the fastest logging and consumes the least amount of memory card space.

**Log Failed Images**

Save images only when the vision operation fails. This mode is effective when you want to analyze failed images later for corrective action.

**Log All Images**

Save all images. This mode is effective when you want to obtain a large amount of image data for adjusting the location parameters.

**CAUTION**

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

**Image Display Mode**

Select the items to be displayed in the vision image display area.

**2D Image**

The 2D image and location result are displayed.

**Laser Slit Image 1**

The slit image of laser 1 is displayed.

**Laser Slit Image 2**

The slit image of laser 2 is displayed.

**6.9.1.1 2D measurement setups**

Perform the 2D measurement setups.

2D Measurement Setups

Exposure Mode: Fixed

Exposure Time: 33.333 ms

Auto Exposure Area: Not Trained Train

Auto Exposure Adjust: 0 Mask

Multi Exposures: 1, 33.333 - 33.333 ms

Multi Exposure Area: (0,0) 0x0 Train

Multi Exposure Mode: Deviation Mask

Light For Snap: Not Used

Multiple Locator Mode: Find Best Best Result of Each Tool

**Setting the Exposure Time**

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

## Light For Snap

Set whether to turn on or off the light when snapping an image for 2D measurement.

## Multiple Locator Find Mode

From the upper drop-down box, select which locator tools to execute in the case that multiple locator tools have been made.

### Find Best

All the locator tools are executed. This is effective when you want to identify the type or put location reliability before processing time.

### Find First

The locator tools are executed sequentially from the top. The location process stops as soon as a locator tool detects workpieces. The subsequent locator tools are not executed.

From the lower drop-down box, select which results of each locator tool to use in the case that the tool has multiple results.

### Best Result of Each Loc. Tool


The result having the highest score is selected for each locator tool. The measurement uses only the selected results.

### All Result of Each Loc. Tool

All the results are used in descending order of scores until the measurement succeeds. This is effective when you want to eliminate measurement failure caused by misdetection of a locator tool.

## 6.9.1.2 Laser measurement setup

Perform the laser measurement setups.



### Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

### Number of Snaps

Use this item when you want to snap multiple images during one exposure time and to obtain an average image. This setting is valid only when 1 is set in [Multi Exposures].

### Bright. Scale Mode

Specify a method for coordinating the brightness when laser images obtained by multi-exposure are combined.

### Maximum

After all laser images are summed up, the brightness of the whole image is scaled so that the brightness in the photometric area is lower than 256. If halation occurs at even one point in the photometric area, the image becomes relatively dark as a whole.

### Summation

After all laser images are summed up, the brightness of the pixel, brightness of which is higher than 256, is clipped. The brightness of whole image is kept and the brightness of pixels in which halation occurs is only suppressed to 255.

### Light For Snap

Set whether to turn on or off the light when snapping an image for laser measurement.

#### NOTE

If more than one laser measurement tool, such as cylinder command tool or 3DL displ. command tool, has been created, the tools will be executed sequentially from the top, and the measurement process will stop as soon as a measurement succeeds, leaving the subsequent tools unexecuted.

### 6.9.1.3 Reference data

Reference Data	
Ref. Pos. Status:	Not Set <input type="button" value="Set"/>
Reference X:	<input type="text"/> mm
Reference Y:	<input type="text"/> mm
Reference Z:	<input type="text"/> mm
Reference W:	<input type="text"/> °
Reference P:	<input type="text"/> °
Reference R:	<input type="text"/> °
Limit Check Select:	<input type="text" value="None selected"/> ▼

### Setting the Reference Position

If the reference position is set, [Set] is displayed in green. Otherwise, [Not Set] is displayed in red.

### Reference X, Y, Z, W, P, R

The coordinates of the set reference position are displayed.


### Offset Limit

Specify the condition used to check whether the calculated offset value is within the specified range. By default, [None selected] is set, in which case the offset limit check is not made. For information about the offset limit check conditions, see Section 8.2, "OFFSET LIMIT".



## 6.9.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Found

The number of found workpieces is displayed.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

### X, Y, Z

Coordinates of the model origin of the found workpiece (unit: mm).

### W, P, R

Rotation angle of the found workpiece around the X, Y, and Z axis (unit: degrees).

### Laser ID

Laser measurement ID of the found workpiece.

### Model ID

Model ID of the found workpiece.

### Score

Score of the found workpiece.

### Contrast

Contrast of the found workpiece.

### Fit Err.

Elasticity of the found workpiece (unit: pixels).

### Lean Angle

Inclination angle of the found workpiece in the normal direction at the reference position (unit: degrees).

## 6.9.3 Setting the Reference Position

---

Set the reference position.

The offset value is calculated based on the relationship between the reference position you set here and the found position.

- 1 Open the vision process Setup Page.
- 2 Place a workpiece in the camera view for which you want to set the reference position.
- 3 Press F3 SNAP and then press F4 FIND to find the workpiece.
- 4 Tap the [Set] button.
- 5 Check that [Ref. Pos. Status] is set to [Set] and that a value is displayed for each reference position element.

Teach the robot the position where the workpiece is when the reference position is set.

Teach the position to the robot without moving the workpiece.

## 6.9.4 Overridable Parameters

---

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Exposure Time

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

### Number of Exposure

Specify a number between 1 and 6.

### Laser Exposure Time


Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

### Number of Laser Exposure

Specify a number between 1 and 6.


## 6.10 SINGLE VIEW VISUAL TRACKING

This is a vision process for a two-dimensional application that finds a workpiece being carried on a conveyor with a single camera and picks up the workpiece without stopping the conveyor.




### 6.10.1 Setting up a Vision Process

If you open the setup page of [Single View Visual Tracking], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



## Camera Calibration

Select the camera calibration you want to use.

The selectable camera calibrations are only those for visual tracking.

## Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

## Conveyor Name

The name of the Conveyor specified for the selected camera calibration is displayed. For detailed information about the Conveyor, refer to “R-30iB/R-30iB Mate CONTROLLER iRPickTool OPERATOR'S MANUAL”. For V8.10P or V8.13P of controllers, this setup item is shown as “Line Name”. About the Line, refer to “R-30iB CONTROLLER iR-Vision Visual Tracking OPERATOR'S MANUAL”.

## Exposure Time

Specify the exposure time for the camera to capture an image.

As the exposure time, specify the smallest possible value that does not cause the image of the moving conveyor to blur. As a guide, the value should be so small that the conveyor travels no more than 0.5 pixels during the exposure time.

## Image Logging Mode

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved. While the options shown below are available, choose [Do Not Log] for visual tracking under normal conditions, because the image saving processing takes time.

### Do Not Log

Do not save any images to the vision log.

### Log Failed Images

Save images only when the vision operation fails.

### Log All Images

Save all images.

**CAUTION**

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

**Runtime Image**

Specify how to display an image on the runtime monitor.

**Display With 100%**

The image will be displayed at a magnification of 100% on the runtime monitor.

**Display With 50%**

The image will be displayed at a magnification of 50% on the runtime monitor.

**Don't Display**

No image will be displayed on the runtime monitor.

Since displaying an image on the runtime monitor takes time, choose an option as appropriate for the system's tracking time requirement. If you choose [Don't Display], no image will be displayed on the runtime monitor, allowing the vision process to run fastest. While [Display with 50%] takes more time than [Don't Display], it is faster than [Display with 100%].

**Ref. Data Index To Use**

Choose one of the following to specify how to determine the reference data to use.

**This Index**

The same reference data is used to calculate the offset data.

**Model ID**

Different reference data is used depending on the model ID of the found workpiece. Choose this in such cases as when there are two types of workpiece having different heights.

**Delete Duplicates if <**

The position and angle of each found result is checked to see whether the result is the same as another result. If there are multiple found results within the specified pixels and angle, the results are assumed to be the same workpiece and only the found result with the highest score is output.

**Reference Data**

The reference data is used to calculate offset data from the found result. The reference data mainly consists of two types of data described below.

**Part Z Height**

Height of the found part of the workpiece as seen from the tracking frame.

**Reference Position**

Position of the workpiece found when the robot position is taught. The offset data is the difference between the actual workpiece position found when running the vision process and the reference position.

A vision process might have more than one set of reference data. Under normal conditions, only one set of reference data is used. However, for example, if there are two types of workpieces being carried on the conveyor, each having a different height, the vision process uses two sets of reference data because it needs to set a different “Z-direction height” for each of the workpieces.

## ID

If [This Index] is selected in [Ref. Data To Use], enter the reference data ID to use.


## Adding reference data

You can add reference data as follows.

- 1 Tap  button.
- 2 In [Model ID], enter the model ID for which to use the reference data.

## Deleting reference data

You can delete reference data as follows, if there is more than one set.

- 1 Select the reference data you want to delete using the index drop-down list
- 2 Tap  button.
- 3 A popup message is displayed to confirm. Press F4 OK.

## Part Z Height

Enter the height of the found part of the workpiece as seen from the tracking frame.



### CAUTION

This is not the height from the surface of the conveyor. For example, if a thick calibration grid is used to set up the tracking frame, then the value to be set is obtained by subtracting the thickness of the calibration grid from the height of the workpiece.

## Ref. Pos. Status


If the reference position is set, [Set] is displayed in green; otherwise, [Not Set] is displayed in red.

## Reference Position X,Y,R

The coordinates of the set reference position are displayed.

## 6.10.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Found

The number of found workpieces is displayed.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

### X,Y

Coordinate values of the model origin of the found workpiece (units: mm).

### Roll

Rotation angle of the found workpiece around the Z axis (units: degrees).

### Model ID

Model ID of the found workpiece.

### Score

Score of the found workpiece.

### Contrast

Contrast of the found workpiece.


### Fit Err.

Elasticity of the found workpiece (units: pixels).


## 6.10.3 Setting the Reference Position

Set the reference position. The offset value is calculated based on the relationship between the reference position you set here and the found position.

- 1 Open the vision process Setup Page.



- 2 In [ID] in [Reference Data], choose the reference data for which to set the reference position.
- 3 Place a workpiece in the camera view.
- 4 Press F3 SNAP and then press F4 FIND to find the workpiece.
- 5 Check that the workpiece has been found correctly, and tap the [Set] button.
- 6 When the reference position is set, the following message appears.



- 7 Check the message, and press F4 OK.

The encoder value of the conveyor at the time of the reference position setting is set as the trigger for each robot. Run the conveyor without moving the workpiece on it until the workpiece comes in front of a robot, and teach the robot position.




## 6.10.4 Overridable Parameters

This vision process has no overridable parameters that can be overridden with Vision Override.

## 6.11 BIN-PICK SEARCH VISION PROCESS


This vision process determines the location, X, Y, Z, and R of the workpiece and it also determines the yaw and pitch based on where the part is in the field of view. The height, or Z, is estimated based on the found scale of the workpiece.

The yaw and pitch are not the actual orientation of the workpiece but its position relative to the camera. This allows a simple bolt item pick-up system with a magnetic gripper to pick-up the workpiece without coming into contact with exterior walls.




### 6.11.1 Setting up a Vision Process

If you open the setup page of [Bin-Pick Search Vis.Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



## Camera Calibration

Select the camera calibration you want to use.

## Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

## Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

## Multiple Locator Find Mode

If you have created more than one locator tool, select how to execute those tools.

### Find Best

All the locator tools will be executed, and the best result will be chosen. This is effective when you want to identify the type or put location reliability before processing time.

### Find First

The locator tools will be executed sequentially from the top until the specified number of workpieces has been found. The subsequent locator tools will not be executed once the number of found exceeds the specified number.

## Number to Find

Enter the maximum number of workpieces to be found per measurement. The specifiable range is 1 to 100.

## Image Logging Mode

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

## Do Not Log

Do not save any images to the vision log.

### Log Failed Images

Save images only when the vision operation fails.

### Log All Images

Save all images.



#### **CAUTION**

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

### Delete Duplicates If <

The position and angle of each found result are checked to see whether the result is duplicated with another result. If there are multiple found results within the specified pixels and angle, the results are assumed to indicate the same workpiece and only the found result with the highest score is output.

### Sorting Priority

Specify the priority to determine the pick-up order to be applied when more than one workpiece has been found. The [Bin-Pick Search Vis.Process] calculates the priority using the results of the following five items and sorts the results unlike other vision processes. You can specify which items are used for priority calculation and how much these items reflect the calculation by checking [Enabled] for each required item and setting weight for them. Priorities calculated according to these settings are relative values for comparing workpieces with each other. The same priority is not always given to a found workpiece with the same size and score because calculation is performed so that the average priority of all workpieces found at a time is almost 50.

#### Height

Priority is given to a workpiece with the largest Z value in the application user frame.

#### Score

Priority is given to a workpiece with a high score in the found result.

#### Aspect


Priority is given to a workpiece with a high ellipticity, that is, a small inclination.

#### Diff.Height

Priority is given to a workpiece with the closest Z value to that of the workpiece last picked out. To use this mode, check the checkbox of the [Enb.] and set the textbox of the [Weight] to a value greater than 0. Then, the textbox of the [Register Num.] is enabled. Modify your TP program so that it set a register to the Z value of the workpiece last picked out, and set the textbox of the [Register Num.] to the number of the register.

#### Child N Found

As a pattern match model, the entire workpiece is taught to the parent pattern match tool. Then, as a child tool of the parent pattern match, part of the workpiece is taught. Priority is given to a workpiece with the maximum number of child tools. Use this item when you want to give priority to a workpiece with a small section hidden by another workpiece.



## Reference Data

The reference data is used to calculate offset data from the found results. The vision processes can have more than one reference data. Typically, the vision process only has one reference data. However, in such a case two types of workpieces are mixed, it is required to set the parameter which used to determine the Z-direction height of the workpiece, the reference data and so on for each types of workpieces, so two reference data are used.


## Adding reference data

You can add reference data as follows.

- 1 Tap  button.
- 2 In [Model ID], enter the model ID for which to use the reference data.

## Deleting reference data

You can delete reference data as follows, if there is more than one set.

- 1 Select the reference data you want to delete using the index drop-down list
- 2 Tap  button.
- 3 A popup message is displayed to confirm. Press F4 OK.

## Register Number

Use this item when [Use Register Value] is chosen in [App. Z Mode]. Specify the number of the register that stores the workpiece height.

## Setting the Reference Height and Size

Use this item when [Calculate From Found Scale] is chosen in [App. Z Mode]. Set the relationship between the actual Z-direction height of the workpiece and the apparent size of the workpiece captured by the camera.

- 1 Place one workpiece in the field of view. Determine the height of the workpiece above or below the application user frame, this can be done using the robot with a pointer tool if desired. Enter this height data in [Reference Height 1].
- 2 Press F3 SNAP and then press F4 FIND to find the workpiece. Then, tap the [Set] button and set [Reference Scale 1].
- 3 Place a second workpiece in the field of view at a different height than the first. Determine the height of the workpiece above or below the application user frame, enter this height data in [Reference Height 2].
- 4 Press F3 SNAP and then press F4 FIND to find the workpiece. Then, tap the [Set] button and set [Reference Scale 2].

## Ref. Pos. Status

If the reference position is set, [Set] is displayed in green; otherwise, [Not Set] is displayed in red.

## Reference X, Y, Z, W, P, R


The coordinates of the set reference position are displayed.

## Offset Limit

Specify the condition used to check whether the calculated offset value is within the specified range. By default, [None selected] is set, in which case the offset limit check is not made. For information about the offset limit check conditions, see Section 8.2, "OFFSET LIMIT".

## 6.11.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Found

The number of found workpieces is displayed.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Results table

The following values are displayed.

#### X, Y, Z

Coordinates of the model origin of the found workpiece (units: mm).

#### W, P

Inclination of the gaze line connecting the camera and found workpiece (units: degrees).

#### R

Rotation angle of the found workpiece around the Z-axis (units: degrees).

#### Model ID

Model ID of the found workpiece.

#### Score

Score of the found workpiece.

**Size**

Size of the found workpiece.

**Contrast**

Contrast of the found workpiece.

**Fit Err.**

Elasticity of the found workpiece (units: pixels).

**Priority**


Pick-up priority given to the found workpiece.

**NOTE**

If you run a find test without setting the reference Z-direction height or size, \*\*\*\*\* is displayed for X, Y, Z, W, P, and R because these values cannot be calculated.

### 6.11.3 Setting the Reference Position

Set the reference position. The offset value is calculated based on the relationship between the reference position you set here and the found position.



- 1 Place a workpiece on center of the camera view to setup the reference position. By placing a workpiece on center of the camera view, teaching of the robot position becomes easy.
- 2 Press F3 SNAP and then press F4 FIND to find the workpiece.
- 3 Tap the [Set] button.
- 4 Check that [Ref. Pos. Status] is set to [Set] and that a value is displayed for each reference position element.

Teach the robot the position where the workpiece is when the reference position is set. Teach the position to the robot without moving the workpiece.

## 6.11.4 Overridable Parameters

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Exposure Time

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

### Number of Exposure


Specify a number between 1 and 6.

## 6.12 SINGLE VIEW INSPECTION VISION PROCESS


The single view inspection vision process, unlike ordinary vision processes intended for robot position offsetting, makes “pass or fail” judgment as to inspection results.

### 6.12.1 Setting up a Vision Process

If you open the setup page of [Single-View Inspection], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



## Camera Setup

Select the camera to be used.

## Setting the Exposure Time

Set the exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, “Setting Exposure Mode”.

## Image Logging Mode

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

### Do Not Log

Do not save any images to the vision log.

### Log Failed Images

Save images only when the inspection result is “fail” or when judgment cannot be made.

### Log All Images

Save all images.



### CAUTION

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

## 6.12.2 Setting a Measurement Plane

In a single view inspection vision process, measure length is either evaluated as the number of pixels on the image or as a value converted into millimeters. To convert length into millimeters, mount the calibration grid at the same height as the measurement plane, snap the grid pattern with the camera, and set the measurement plane information. In this tutorial, the measurement plane is set because the width of the connector needs to be evaluated in millimeters.



## Grid Spacing

Input the grid spacing of the calibration grid in millimeters.

## Override Focal Dist.

Select [Yes] and input the nominal focal distance of the lens in millimeters.

It is possible to select [No] to calculate the focal distance automatically. However, when the camera optical axis is perpendicular with the calibration grid, the focal distance cannot be calculated correctly. If the focal distance calculated automatically deviates from the nominal focal distance by  $\pm 10\%$  or more, select [Yes] and input the nominal focal distance of the lens used.

## Height from Plane

The measurement plane offset value needs to be specified when the height of the measurement plane to be set (height of the target to be measured) differs from the height of the grid pattern plane of the placed calibration grid. Input a positive value in millimeters when the measurement plane to be set is closer to the camera than the grid pattern plane or a negative value when the measurement plane is farther from the camera than the grid pattern plane.

## Teaching a Measurement Plane

Snap an image of the calibration grid and set the measurement plane. Press F3 SNAP to capture the image and tap the [Train] button.

Adjust the red rectangle so that the grid is included in the frame. Since the calibration grid is generally placed so that the grid is displayed over the entire field of view, the red rectangle is set to the full screen mode. When the F4 OK is pressed, the calibration grid is detected and the measurement plane is set.

When the measurement plane is set, the average scale on the set measurement plane is displayed in [Scale Conversion]. The scale indicates the conversion factor between one pixel on the image and the length in millimeters on the measurement plane, and its unit is mm/pix. When there is lens distortion or the camera optical axis is not perpendicular to the measurement plane, the scale is not even in the image. So the shown scale is the average value.

When the [Train] button is tapped and the measurement plane has already been taught, a message would appear asking whether the measurement plane information should be changed or the change should be canceled. If there are command tools that had already been taught, a change in the measurement plane may change their measurement results. If the measurement plane is re-taught, these command tools may need to be taught again as necessary.




### CAUTION

When the measurement plane is taught after command tools had been taught, it is recommended to re-train those command tools that have measurement values subjected to millimeter conversion.

## 6.12.3 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Time to Find

The time the vision process took is displayed in milliseconds.

### Result

The result of the single view inspection is displayed.

### Found Result Table

These evaluation results are displayed.

### Cond. No

Number of the conditional expression.

### Condition

Conditional expression that is set.

### Value

Evaluation target value evaluated with the conditional expression.

### Cond. Result

Evaluation result of the conditional expression

## 6.12.4 Overridable Parameters

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Exposure Time

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

### Number of Exposure


Specify a number between 1 and 6.

## 6.13 READER VISION PROCESS


Reader vision process, unlike ordinary vision processes that returns vision offset to compensate robot positions, reads the barcode and returns a result string.

### 6.13.1 Setting up a Vision Process

If you open the setup page of [Reader Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



### Camera

Select a camera to be used.

### Setting the Exposure Time

Set the exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, “Setting Exposure Mode”.

### Image Logging Mode

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

#### Do Not Log

Do not save any images to the vision log.

#### Log Failed Images

Save images only when the vision operation fails.


#### Log All Images

Save all images.

**⚠ CAUTION**  
 The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

## 6.13.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



#### Time to Find

The time the vision process took is displayed in milliseconds.

#### Found Result Table

The following values are displayed.

**Model ID**

Model ID of the found barcode.

**Score**

Score of the found barcode

**String Result**

String of the found barcode.

### 6.13.3 Overridable Parameters

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

**Exposure Time**


Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

**Number of Exposure**

Specify a number between 1 and 6.

## 6.14 IMAGE TO POINTS VISION PROCESS


This vision process extracts points on the outline of a workpiece and output view lines data which go through the points. The 3-D positions of extracted points can be obtained by calculating the points of intersection of the view lines and the plane corresponding to the workpiece surface. The 3-D positions can be used to generate a robot motion path automatically.

**CAUTION**


This vision process does not use program commands for *iR*Vision because specific applications use this vision process and each application provides KAREL programs to execute this vision process.

## 6.14.1 Setting up a Vision Process

If you open the setup page of [Image To Points], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



### Camera Calibration

Select the camera calibration you want to use. You can use the following types of camera calibrations.

- Grid Pattern Calibration
- Robot-Generated Grid Calibration
- 3D Laser Vision Calibration

### Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

### Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process.

### Image Logging Mode

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

#### Do Not Log

Do not save any images to the vision log.

#### Log Failed Images

Save images only when the vision operation fails.

#### Log All Images

Save all images.

**⚠ CAUTION**  
 The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

### Runtime Display:

Select what will be displayed on the runtime monitor.

#### Image and Graphics


The camera image and found results will be displayed.

#### Image Only

Only the camera image will be displayed. When [Image Only] is selected, the process time is faster than [Image and Graphics] at runtime.

## 6.14.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Found Chains

The number of found chains is displayed.

### Found Points

The total number of the points extracted from found chains is displayed.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

#### Model ID

Model ID of each found chain.

#### Num Points

The number of points extracted from each found chain.

## 6.14.3 Overridable Parameters

---

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Exposure Time

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

### Number of Exposure

Specify a number between 1 and 6.

## 6.15 3D AREA SENSOR

---

This vision process acquires a 3D map with 3D Area Sensor. In order to discriminate this vision process from the equipment of 3D Area Sensor, this document encloses the name of this vision process in parentheses like [3D Area Sensor].



#### CAUTION

This vision process only acquires a 3D map. In order to find position of workpieces, you need to setup a 3D Area Sensor Vision Process in addition.

### 6.15.1 Projection FOV and Standoff of Projector Unit

---

3D Area Sensor is composed of three units, two camera units and one projector unit. The projector unit projects stripe patterns very quickly and two camera units snap their images, and then 3D information in a wide area is calculated at once. In this document, one element of the acquired 3D information is referred to as “3D point”, and a whole set of the 3D information is referred to as “3D map”.


The camera units and the projector unit of 3D Area Sensor should be mounted on a solid pedestal. Each unit of 3D Area Sensor needs to be settled properly with reference to the target container so that 3D Area Sensor comes into its own.




**CAUTION**  
3D Area Sensor cannot be mounted on a robot.

**Standard Layout**

The figure below shows the side view of the standard layout of 3D Area Sensor. Two camera units and a projector unit are mounted on the same upper beam.



And the figure below shows the overhead view of the standard layout.



As you can see in the figures above, two camera units and a projector unit should be located roughly on a line. When the camera standoff is constant, the longer the distance between cameras is, the more accurate the Z depth information you will get, but the more blind area, in other words area where one camera can see but another camera cannot, you will be likely to have. Therefore, in order to avoid workpieces being behind the sidewall of the container, camera units should be located above the container area.

The distance between cameras, the camera standoff and the Z accuracy of a 3D point have the following relationship. The accuracy of a found workpiece depends on the command tool to be used. Because the position of a workpiece is calculated using many 3D points, the accuracy of a found workpiece is generally better than that of a single 3D point.

$$Z \text{ accuracy of 3D point} = \pm \frac{\text{Longer Side of Camera FOV} \times \text{Camera Standoff}}{\text{Number of Pixels of Longer Side of the Image} \times \text{Distance Between Cameras}}$$

The following table shows typical examples of measurement area, layout, and Z accuracy of a 3D point when a 3D map is acquired for a flat surface.

Measurement Area (Container Size)			Distance Between Cameras	Standoff		Z Accuracy	
Long Side	Short Side	Depth		3DA/1300	3DA/400	3DA/1300	3DA/400
1340mm	1000mm	1000mm	1340mm	2438mm		±2.0mm	
1200mm	900mm	896mm	1200mm	2200mm			
1100mm	825mm	821mm	1100mm	2030mm			
1000mm	750mm	746mm	1000mm	1860mm			
900mm	675mm	672mm	900mm	1691mm			
800mm	600mm	597mm	800mm	1521mm			
700mm	525mm	522mm	700mm	1351mm			
600mm	450mm	448mm	600mm	1181mm			
500mm	375mm	373mm	500mm	1011mm			
400mm	300mm	299mm	400mm		880mm		±1.0mm
300mm	225mm	224mm	300mm		675mm		
200mm	150mm	149mm	200mm		470mm		

Typical measurement area, layout, Z accuracy

**⚠ CAUTION**

- 1 Select a somewhat larger layout so that the container is seen in the field of view even if the container position is shifted a little.
- 2 Make sure that there is enough space between 3D Area Sensor and the container for the robot to move around.
- 3 The standoff of the two camera units should be the same.
- 4 Depending on the size of container and the required Z accuracy, there is a case that mounting the camera units and the projector unit at different heights is preferable.
- 5 Ex ante testing is recommended, because the ambient light, material of the workpiece and the setting of 3D Area Sensor can affect the actual measurement area and the actual Z accuracy.

**Camera Calibration**

Grid Pattern Calibration and Robot-Generated Grid Calibration are available to calibrate the camera units of 3D Area Sensor. Two camera units need to be calibrated in respect to the same application frame.

**⚠ CAUTION**

Z axis of the application frame should be perpendicular to the floor of the container and its +Z direction should toward the sensor.

## Projection FOV and Standoff of Projector Unit

The FOV of the projector unit should cover the upper opening of the container.

For normal density mode, 3D Area Sensor calculates 239x192 points in the projector FOV. So the spatial density of measured 3D points depends on the projector FOV size. Therefore, the larger the projector FOV is, the longer the spatial distance of measured 3D points is.

Illumination power of the projector unit is limited. Therefore, the larger the projector FOV is, the lower the intensity of the pattern projected over workpieces is. In order to get a good contrast between bright stripes and dark stripes of the projected patterns and eventually to acquire a 3D map as stably as possible, the projector FOV should be as narrow as possible. Especially it is important when the color of the workpiece is similar to that of the projector light and/or the reflection ratio of the workpiece surface is low.

Determine the projector FOV size based on the above advices first, and determine the projector standoff based on the selected projector FOV then.

## FOV of Cameras

The FOV of the camera units should cover the upper opening of the container too. The camera FOV size affects the detection accuracy of the projected patterns. For example, if the camera FOV was too wide in comparison with the projector FOV, it would be difficult to detect the patterns accurately, because each pattern that appears on a camera image would not be clear enough. Settle the camera unit so that their FOV and the FOV of the projector unit are almost the same as possible. The optical axis of each camera unit should roughly pass through the center point of the upper opening of the container.

## Ambient Lights

Ambient lights can affect the robustness of 3D Area Sensor. The stronger the ambient lights are, the less stable the measurement results of 3D Area Sensor can be. If the intensity of ambient lights is too strong, shade the container from the ambient lights.

### Hint

Empirically 3D Area Sensor can acquire a 3D map stably when the intensity of ambient lights is less than a half of that of the projector.




### CAUTION


The lighting interfered with the pattern projected by the projector should be turned off while 3D Area Sensor is acquiring.

## 6.15.2 Setting up a Vision Process


If you open the setup page of [3D Area Sensor], a screen like the one shown below appears.



If you scroll down the setup page, a screen like the one shown below appears.



If you select the [Tree] tab, a screen like the one shown below appears.



### Projector ID

Select the ID number of the projector unit to use when multiple projector units are connected to the robot controller. Select [1] when only one projector unit is connected.

### Check IO

Press the [Start] button to check if the connected projector unit works correctly. After creating a [3D Area Sensor], you should perform this operation once to make its status [OK]. When its status is [NG], you cannot acquire a 3D map.

### Projector Type

The type of the selected projector unit is displayed. When the projector unit is not connected this item is blank.

### Projector Version

The firmware version of the selected projector unit is displayed. When the projector unit is not connected, this item is blank.

### Intensity

Select the intensity of the projector light that is used when a 3D map is acquired. By default, [11] is selected. The higher the number is, the brighter the projected pattern is, but the larger the Min. Cycle (mentioned later) is.



#### CAUTION

When F4 PRJ\_ON is used to continuously project a pattern, the intensity of projector light is automatically reduced to an allowable level.

### Exposure

Specify the camera exposure time for 3D map acquisition. This value is commonly used to two camera units. The default value is 8ms. The longer the exposure time is, the longer the Min. Cycle is.

**Hint**

When the ambient light is a fluorescent light or a mercury lamp, the brightness of the ambient light changes periodically. In such a case, set the exposure time to a multiple of the blinking period of the ambient light. This will make the 3D map acquisition stable.

**3D Map Density**

Select the density mode of 3D map. Only available modes with the selected projector unit are displayed as options.

**Normal**

It measures  $239 \times 192$  3D points in the FOV of the 3D Area Sensor.

**Coarse**

It measures  $119 \times 96$  3D points in the FOV of the 3D Area Sensor. Acquisition time is faster than that of the Normal mode.

**Fine**

It measures  $479 \times 384$  3D points in the FOV of the 3D Area Sensor. Acquisition time is slower than that of the Normal mode.

**Std. Z Height**

Set the middle height of the container in the application frame.

**Remove Noise**

Check this checkbox when you want to remove 3D points with a large error.

**Hint**

Time to acquire a 3D map increases about 200~300 ms when this check box is checked.

**Application Frame**

User frame number selected as Application Frame in the camera calibrations is displayed.

**Min. Cycle**

The minimum interval time between successive 3D map acquisitions is displayed. The Min. Cycle depends on the selected exposure time and the selected projector intensity. The higher the projector intensity is or the longer the exposure time is, the longer the Min. Cycle is.

**⚠ CAUTION**

When you try to acquire a next 3D map before the minimum interval time has passed after the last 3D map acquisition, 3D Area Sensor will automatically wait until the minimum interval time has passed and then start to acquire a 3D map.

**Test Projector Pattern**

Select a projector pattern that is projected when F4 PRJ\_ON is pressed.

**Display Mode**

Select the display mode of 3D map.

**Gray Scale**

The acquired 3D map is displayed as a grayscale image. Image pixel brightness indicates the Z height. The higher the Z height is, the brighter the pixel is. Where 3D points could not be measured is displayed in black.

**Color**

The acquired 3D map is displayed as a color image. Image pixel color indicates the Z height. 3D points with larger Z height are displayed in red, and 3D points with smaller Z height are displayed in blue. Where the 3D point could not be measured is displayed in black.

**3D Map Info**

Information about the last 3D map is displayed.

**Date**

Date when the last 3D map is acquired

**Time**

Time to acquire the last 3D map

**Num. Points.**

Number of 3D points included in the last 3D map

**Size**

Grid size of the 3D map

**XY Interval**

Average interval between adjacent 3D points in XY direction

**Z average**

Average Z height of 3D points included in the last 3D map

**Z Variation**

Z height variation of 3D points included in the last 3D map

**Min. Max.**

Minimum and maximum value of X, Y and Z value of 3D points included in the last 3D map

**F3 ACQ 3DMAP**


Press F3 ACQ\_3DMAP to manually acquire a new 3D map.

**F4 PRJ ON**

Press F4 PRJ\_ON to manually turn on the projector. The projector projects the pattern continuously. This is used for confirming the projection area. The intensity of the projector light is automatically reduced to an allowable level.

### 6.15.3 Setting up a Camera View

If you open the setup page of a [Camera View] on the tree view, a screen like the one shown below appears.



#### Camera Calib.

Select a camera calibration for this camera view.

#### Test Snap Pattern

Select a pattern that the projector unit will project when F2 LIVE or F3 SNAP is pressed.

#### F2 LIVE

Press F2 LIVE to start the live image display. The selected Test Snap Pattern will be projected.

#### F3 SNAP

Press F3 SNAP to snap a new image. The selected Test Snap Pattern will be projected.

### 6.15.4 Setup Procedures

3D Area Sensor is setup in the following procedures.

#### Preparation before Setup

- 1 Determine the projector standoff so that the projector FOV covers the upper opening of the container and the projected patterns are in focus from the top to the bottom of the container.
- 2 Determine the camera standoff and the distance between cameras based on the length of a longer side of the container and the required Z accuracy.
- 3 Prepare a solid pedestal based on the determined projector standoff, camera standoff and the distance between cameras.

#### Camera Setup

- 1 Create a Digital Camera Setup data and open its setup page.
- 2 Set [Channel] to the channel to which one camera of the 3D Area Sensor is connected.
- 3 Set [Mode] to [1/1.8" SXGA (1280 x 1024)].
- 4 Press F3 SNAP and confirm that a snapped image is displayed on the setup page.
- 5 For the other camera of the 3D Area Sensor, do the above same procedures.



**CAUTION**

For cameras of 3D Area Sensor, be sure to set [Mode] to [1/1.8" SXGA (1280 x 1024)].

### Creating Camera Calibration and Vision Process

- 1 Create two new Camera Calibration data corresponding to two camera units of the 3D Area Sensor, and select the Digital Camera Setup data that you created in the previous procedure. Grid Pattern Calibration and Robot-Generated Grid Calibration are available.
- 2 Create a new [3D Area Sensor] and open its setup page.
- 3 Select [Camera View 1] in the tree view, and select one of the created Camera Calibration data for [Camera Calib.].
- 4 Select [Camera View 2] in the tree view, and select the other Camera Calibration data for [Camera Calib.].
- 5 Select the projector ID for [Projector ID], and press the [Start] button of [Check IO].
- 6 Confirm that the projector unit projects some patterns.


**CAUTION**

Camera will be calibrated in a later procedure after layout adjustment of the camera units and the projector unit are finished.

### Layout Adjustment

Adjust the relative position among the container, the projector unit and the camera units based on the position of the container or the projector unit.

- 1 Open the setup page of [3D Area Sensor], set [Test Projection Pattern] to [Frame], and press F4 PRJ\_ON. Then the following pattern is projected.



- 2 Adjust the position of the container or the projector unit so that the projected pattern covers the upper opening of the container and the center of the pattern is almost at the center of the container.
- 3 Select [Camera View 1] in the tree view and open its setup page.
- 4 Select [Frame] for [Test Snap Pattern].
- 5 Press F2 LIVE to start the live image display, and adjust the position and direction of the camera unit so that the center of the pattern appears almost at the center of the image and the image covers the upper opening of the container.
- 6 Adjust the position of the other camera unit so that the distance between cameras is equal to the length determined in advance.
- 7 Select [Camera View 2] in the tree view, and open its setup page.
- 8 Select [Frame] for [Test Snap Pattern].

- 9 Press F2 LIVE to start the live image display, and adjust the direction of the camera unit so that the center of pattern appears almost at the center of the image and the image covers the upper opening of the container.

**Hint**

About the layout of the 3D Area Sensor, please see the section 6.15.1, "Projection FOV and Standoff of Projector Unit".

**Adjustment of the Camera Units and the Projector Unit**

- 1 Pile some workpieces up to half of the container.
- 2 Set the diaphragm of two camera units to F4.0.
- 3 Open the setup page of [3D Area Sensor] and set [Intensity] to [11].
- 4 Set [Exposure Time] to a multiple of the half blinking period of the ambient lighting. When the ambient lighting is not blinking, use the default exposure time. For example, when the ambient light is blinking with 50 Hz, the exposure time should be set to a multiple of 10ms.
- 5 Select [Camera View 1] in the tree view and open its setup page.
- 6 Set [Test Snap Pattern] to [Black]. Press F2 LIVE to start the live image display, adjust the focus of the camera unit.
- 7 During the live image display, confirm that the brightness of the image does not change. When it changes, the selected exposure time is not good for the ambient light. Adjust it again.
- 8 Set [Test Snap Pattern] to [Stripe], and press F2 LIVE to start the live image display.
- 9 When halation occurs at bright stripes, change the projector intensity to low.
- 10 When bright stripes are not bright enough, open the diaphragm of the lens.
- 11 Adjust the diaphragm and the projector intensity with changing position of workpieces in the container.
- 12 Press F2 LIVE to start the live image display, and adjust the camera focus again.
- 13 Set the diaphragm of the other camera unit to be the same as the first one.
- 14 Select [Camera View 2] in the tree view, and open its setup page.
- 15 Set [Test Snap Pattern] to [Stripe], and press F2 LIVE to start the live image display. Confirm that brightness of stripes in two cameras is almost the same, and then adjust the focus of the cameras.

**Hint**

The above adjustment can be made before setting up [3D Area Sensor] and/or camera calibrations.

**⚠ CAUTION**

- 1 In order to snap projected patterns under a same condition, diaphragm of two camera units should be the same.
- 2 The more the diaphragm is opened, the narrower the focal depth of a camera is. When the diaphragm of a camera is opened, confirm that the camera is in focus in the entire Z range of the container.

**Camera Calibration**

- 1 Setup the application frame as a user frame. Measured 3D points in a 3D map are represented in respective to the application frame. Z axis of the application frame needs to be perpendicular to the floor of the container, and its +Z direction needs to be toward the sensor.
- 2 Select the trained application frame as [Application Frame] in the camera calibration setup page.
- 3 Calibrate two cameras. For the detailed procedures, see the section 5.1, "GRID PATTERN CALIBRATION" and the section 5.2, "ROBOT-GENERATED GRID CALIBRATION". When you use Grid Pattern Calibration, calibrate the camera in the 2-plane mode.

## Setup Conditions of 3D Map Acquisition

- 1 Open the setup page of [3D Area Sensor].
- 2 Set [Std. Z Height] to the middle height of the container in the application frame.
- 3 Set the Z range where 3D points should be measured.
- 4 Set the X and Y range accordingly.
- 5 Press F3 ACQ\_3DMAP and confirm that a 3D map can be acquired properly.
- 6 Set [Display Mode] to [Color], and confirm that lower 3D points are displayed in blue. Check the [Remove Noise] checkbox when the acquired 3D map is noisy.

### 6.15.5 Supplementary Explanation

Supplementary explanation about 3D Area Sensor shows below.

#### Exchange of Camera Unit

When you exchange a camera unit, you need to recalibrate the camera unit. After the camera calibration, confirm accuracy of measured 3D map.

#### Exchange of Projector Unit

When you exchange the projector unit, you may need to adjust the projector intensity. You don't have to recalibrate the camera units.


#### Affect of Shadow

3D map can be acquired even when a robot, a solid pedestal or an equipment casts a shadow on the container, as long as the patterns are projected over workpieces in the container. However if the robot moves and the shadow of the robot moves during a 3D map acquisition, 3D points cannot be obtained in the area where the shadow of the robot has swept. So when you want to move the robot during a 3D map acquisition, be careful about the shadow of the robot. Blocking ambient lightings that make the shadow is also effective.


#### Projector Intensity

You can check whether the projector intensity is proper or not by acquiring a 3D map with placing a flat plane in the FOV of 3D Area Sensor.

When the projector intensity is proper, you will be able to get a 3D map as shown below. The density of 3D points is generally uniform. FYI: The black points are where 3D point could not be measured.




When the projector intensity is too low, 3D points in a 3D map is something like dotted, because the cameras cannot detect patterns. The following is an example of 3D map acquired with low projector intensity. As you can see, the surround area of the 3D map is like pepper and salt.



When the above 3D map is acquired, try to set the projector intensity higher.

When the projector intensity is too high, 3D points of a 3D map are linearly defective, because the snapped images are fogged by halation. The following is an example of 3D map acquired with high projector intensity. As you can see, 3D points are linearly lost at the center of the 3D map.



When the above 3D map is acquired, try to set the projector intensity lower.

## 6.15.6 Overridable Parameters

---

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Intensity

Specify a number between 1 and 13.

### Exposure Time

Specify a number in milliseconds.


## 6.16 3D AREA SENSOR VISION PROCESS

---


This is a vision process that detects the three-dimensional position of the workpiece with a single 3D Area Sensor, and offset the robot position.

## 6.16.1 Setting up a Vision Process

If you open the setup page of [3D Area Sensor Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



### Area Sensor

Select the 3D area sensor you want to use.

### Camera Calibration

Camera calibration of 3D area sensor selected as the 1st and 2nd calibration are listed in a drop-down box. Select the camera calibration you want to use for 2D measurement.

### Camera

The name of the camera specified for the selected camera calibration is displayed.

## Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

## Multiple Locator Mode

If you have created more than one locator tool, select how to execute those tools.

### Find Best

All the locator tools will be executed, and the best result will be chosen. This is effective when you want to identify the type or put location reliability before processing time.

### Find First

The locator tools will be executed sequentially from the top until the specified number of workpieces has been found. The subsequent locator tools will not be executed once the number of found exceeds the specified number. For your information, the duplicate check is executed every time one locator tool is executed, the number of found, which is compared to the specified number, does not include duplicated workpieces.

## Number to Find

Enter the maximum number of workpieces to be found per measurement. The specifiable range is 1 to 100.

## Offset Frame

Specify a user frame number. A 3D area sensor vision process measures the offset data with respect to this specified user frame.

## Range

Set the range of X, Y and Z to be measured in respect to the application frame. The measured 3D map consists of only 3D points that are in the range. Z range needs to be set, but X and Y ranges are optional.

## Image Logging Mode

Specify whether to save image and 3D map to the vision log when running the vision process. However, if you have the vision log disabled in the system variable, logged images are not saved.

### Do Not Log

Do not save any image and 3D map to the vision log

### Log Failed Images

Save image and 3D map only when the vision operation fails.

### Log All Images

Save all images and 3D maps.



### CAUTION

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

## Setting the Sorting Parameter

Set the sorting parameters to be applied when more than one workpiece have been found. For details, see Subsection 3.7.16, "Sorting".

## Delete Duplicate if

The position and angle of each found result on the camera image are checked to see whether the result is the same as another result. If there are multiple found results within the specified pixels and angle, the results are assumed to indicate the same workpiece and only the found result with the most reliable result is output.

### Dup. Check Key

Select the key for the duplication check. If there are multiple found results within the specified pixels and angle, the result of that the selected key value is the highest or lowest in these found results is output. You can specify the following items as the duplication check key.

- Score
- Measurement1-10

### Dup. Check Order

Specify the order of the duplication check. If you select the [Score] in the [Dup. Check Key], the [Remove Low Result] is automatically specified.

#### Remove Low Result

The result of that the selected key value is the highest in the found results within the specified pixels and angle is output.

#### Remove High Result

The result of that the selected key value is the lowest in the found results within the specified pixels and angle is output.

## Image Display Mode

Select the image display mode for the Setup Page.

### 2D image

2D camera image and a container are displayed.

### 3D Map

3D map is displayed.

## Ref. Data To Use

Choose one of the following to specify how to determine the reference data to use.

### This Index

The same reference data is used to calculate the offset data

### Model ID


Difference reference data is used depending on the model ID of the found workpiece.

## ID

If the [This Index] is selected in the [Ref. Data To Use], enter the reference data ID to use.


## Adding reference data

You can add reference data as follows.

- 1 Tap  button.
- 2 In [Model ID], enter the model ID for which to use the reference data.

## Deleting reference data

You can delete reference data as follows, if there is more than one set.

- 1 Select the reference data you want to delete using the index drop-down list
- 2 Tap  button.

## Ref. Pos. Status

If the reference position is set, [Set] is displayed on green; otherwise, [Not Set] is displayed in red.

## Reference Position X, Y, Z, W, P, R

The coordinate values of the set reference position are displayed.

## Offset Limit


Specify the condition used to check whether the calculated offset values is within the specified range. By default, [Not Selected] is set, in which case the offset limit check is not made. For information about the offset limit check conditions, see Section 8.2, “OFFSET LIMT”.

## F6 2-3D Snap

An image is snapped and a 3D map is acquired.

## 6.16.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



## Found

The number of found workpieces is displayed.



### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

#### X, Y, Z

Coordinate values of the model origin of the found workpiece (units: mm).

#### W, P, R

Rotation angle of the found workpiece around the X, Y, and Z axis (units: degrees).

#### Model ID

Model ID of the found workpiece.

#### Sort

The value of the selected sorting key is displayed.

#### Dup. Chk,

The value of the selected duplication check key is displayed.

## 6.16.3 Setting the Reference Position

---

Set the reference position. The offset value is calculated based on the relationship between the reference position you set here and the found position.

- 1 Open the Setup Page for the vision process.
- 2 Place a workpiece in the camera view for which you want to set the reference position.
- 3 Press F6 2-3D SNAP and then press F4 FIND to find the workpiece.
- 4 Tap the [Set] button.
- 5 Check that [Ref. Pos. Status] is set to [Set] and that a value is displayed for each reference position element.

Teach the robot the position where the workpiece is when the reference position is set. Teach the position to the robot without moving the workpiece.

## 6.16.4 Overridable Parameters

---

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 "VISION OVERRIDE" and 9.2.2.8 "OVERRIDE" for details.

### Exposure Time

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

### Number of Exposure


Specify a number between 1 and 6.

## 6.17 FLOATING FRAME VISION PROCESS

The Floating Frame Vision Process finds targets with the robot-mounted camera and offsets the robot. By setting the relationship between the offset plane and the camera in advance and carefully keeping it while in measurement, it allows measuring the targets with various robot postures. This vision process should only be used for special cases as shown in examples below.


### Example 1

When the same target needs to be measured on multiple planes facing various directions.



### Example 2

When the target is on a curved surface, for example part of a car body, and setting the user frame on it is difficult.




#### NOTE

For two-dimensional vision application with a robot-mounted camera, usually the 2D Single-view Vision Process described in “6.1 2D SINGLE VIEW VISION PROCESS” should be used, because it can offset a robot more accurately and easily than the Floating Frame Vision Process. The Floating Frame Vision Process should be used only for special cases as shown in the examples above.


- 2 Once the relationship between the offset plane and the camera is set in advance, this vision process assumes that the offset plane moves along together the camera mounted on the robot with keeping the relationship when the robot moves. Therefore, when you teach the robot position for measurement, you should be careful so that the relationship between the actual offset plane, on which the target is, and the camera is exactly identical to the one set in advance. If the relationship is not identical, the robot will not be offset correctly.

## 6.17.1 Setting up a Vision Process

If you open the setup page of [Floating Frame Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



### Camera Calibration

Select the camera calibration you want to use.

### Camera Setup

The name of the camera specified for the selected camera calibration is displayed.

### Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

## Multiple Locator Find Mode

If you have created more than one locator tool, select how to execute those tools.

### Find Best

All the locator tools will be executed, and the best result will be chosen. This is effective when you want to identify the type or put location reliability before processing time.

### Find First

The locator tools will be executed sequentially from the top until the specified number of targets has been found. The subsequent locator tools will not be executed once the number of found exceeds the specified number. For your information, the duplicate check is executed every time one locator tool is executed, the number of found, which is compared to the specified number, does not include duplicated targets.

## Number to Find

Enter the maximum number of targets to be found per measurement. The specifiable range is 1 to 100.

## Image Logging Mode

Specify whether to save images to the vision log when running the vision process. Note that when the vision log is disabled on the Vision Config page, images are not saved.

### Do Not Log

Do not save any images to the vision log.

### Log Failed Images

Save images only when the vision operation fails.

### Log All Images

Save all images.



### CAUTION

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to log images depends on the type of storage device in use. Use this function after checking whether the delay of logging images is acceptable for your application.

## Setting the Sorting Parameters

Set the sorting parameters to be applied when more than one workpiece has been found. For details, see Subsection 3.7.16, "Sorting".

## Delete Duplicates If <

The position and angle of each found result are checked to see whether the result is the same as another result. If there are multiple found results within the specified pixels and angle, the results are assumed to indicate the same workpiece and only the found result with the highest score is output.

## Relation between Robot and Offset plane

Record the relationship between the offset plane and the camera (more specifically, the position of the robot holding the camera). The actual measurement needs to be performed while keeping the relationship recorded in this process.

**Offset Plane: UF**

Select the user frame whose XY plane indicates the offset plane.

**Robot Pos,**

Move the robot so that the camera mounted on the robot is in the expected relationship with respect to the offset plane, and record the robot position. If the robot position is recorded, [recorded] is displayed in green; otherwise, [Not Recorded] is displayed in red.

**Robot Position in UF,**

This is the relationship between the offset plane and the camera. The position of the robot mechanical interface frame (the robot wrist flange) relative to the user frame selected as the offset plane is displayed.

**Ref. Data To Use**

The reference data is used to calculate offset data from the found result. The reference data mainly consists of two types of data described below.

**Part Z Height**

Height of the target to be detected with respect to the offset plane.

**Ref. Pos. Status**

Position of the target found when the robot position is taught. The offset data is the difference between the actual target position found when running the vision process and the reference position.

A vision process might have more than one set of reference data. Under normal conditions, only one set of reference data is used. However, for example, if there are two types of target, each having a different height, the vision process uses two sets of reference data because it needs to set a different part Z height for each of the targets.

**Ref. Data Index To Use**

Choose one of the following to specify how to determine the reference data to use.

**This Index**

The same reference data is used to calculate the offset data.

**Model ID**

Different reference data is used depending on the model ID of the found target. Choose this in such cases as when there are two or more types of target having different heights.

**ID**

If [This Index] is selected in [Ref.Data Index To Use], enter the reference data ID to use.


**Adding reference data**

You can add reference data as follows.

- 1 Tap  button.
- 2 In [Model ID], enter the model ID for which to use the reference data.

**Deleting reference data**

You can delete reference data as follows, if there is more than one set.

- 1 Select the reference data you want to delete using the index drop-down list
- 2 Tap  button.
- 3 A popup message is display to confirm. Press F4 OK.

## Part Z Height

Enter the height of the target to be detected above or below the offset plane.

## Ref. Pos. Status

If the reference position is set, [Set] is displayed in green; otherwise, [Not Set] is displayed in red.

## Reference Position X, Y, W, P, R


The coordinate values of the set reference position with respect to the user frame selected as the offset plane are displayed.

## Offset Limit

Specify the condition used to check whether the calculated offset value is within the specified range. By default, [None selected] is set, in which case the offset limit check is not made. For information about the offset limit check conditions, see Section 8.2, "OFFSET LIMIT".

## 6.17.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



## Found

The number of found workpieces is displayed.

## Time to Find

The time the vision process took is displayed in milliseconds.

## Found Result Table

The following values are displayed.

### X, Y, Z

The coordinate values of the model origin of the found target with respect to the user frame selected as the offset plane (units: mm).

**W, P, R**

Rotation angle of the found target around the X, Y and Z axis of the user frame selected as the offset plane (units: degrees).

**Model ID**

Model ID of the found target.

**Score**

Score of the found target.

**Contrast**


Contrast of the found target.

**Fit Err.**

Elasticity of the found target (units: pixels).

### 6.17.3 Setting the Reference Position

Set the reference position. The offset value is calculated based on the relationship between the reference position you set here and the found position.



- 1 Open the vision process Setup Page.
- 2 Place a target in the camera view for which you want to set the reference position.
- 3 Enter the proper Part Z Height, the height of the target above or below the offset plane.
- 4 Press F3 SNAP and then press F4 FIND to find the target.
- 5 Tap the [Set Ref] button.
- 6 Check that [Ref. Pos. Status] is set to [Set] and that a value is displayed for each reference position element.

Teach the robot the position where the target is when the reference position is set. Teach the position to the robot without moving the target.

### 6.17.4 Overridable Parameters

This vision process has the following overridable parameters that can be overridden with Vision Override. See 8.1 "VISION OVERRIDE" and 9.2.2.8 "OVERRIDE" for details.

**Exposure Time**

Specify a number in milliseconds. If [Exposure Mode] of the vision process is set to [Auto], [Exposure Mode] is temporarily changed to [Fixed] to use the specified exposure time when you override the exposure time of the vision process.

**Number of Exposure**

Specify a number between 1 and 6.




# 7 COMMAND TOOLS

This chapter explains how to set the command tools.

## 7.1 GPM LOCATOR TOOL

The GPM Locator tool employs the image processing tool that is the core of *iR*Vision. It checks a camera-captured image for the same pattern as a model pattern taught in advance and outputs its location. If you select the GPM Locator tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.



### Input Image

Select the image which is used for training model and detection. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this GPM Locator Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”

### 7.1.1 Setting up a Model


Teach the model pattern of the workpiece you want to find.

#### Teaching the model pattern

Teach the model pattern as follows.


- 1 Press F2 LIVE to change to the live image display.
- 2 Place the workpiece near the center of the camera view.
- 3 Press F2 STOP and then press F3 SNAP to snap the image of the workpiece.
- 4 Tap the [Teach Pattern] button.

- 5 Enclose the workpiece within the red rectangle that appears, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.



### Adding or editing graphical shapes

If needed, you can add graphical shapes such as segmented-lines, rectangles or circles to the model pattern as its feature. You can create the model pattern only with graphical shapes, or add graphical shapes to the model pattern which has been trained with an image. To add graphical shapes to the model pattern or to edit existing graphical shapes of the model pattern, tap the [GEdit] button.






If the model pattern is not trained, the magenta rectangle is displayed on the image display before the above the screen. Specify the image area you want to set as the background of the model pattern, in a similar manner to “Teaching the model pattern”.

On this screen, the selected graphical shape is plotted in magenta, the other graphical shapes are plotted in cyan, and features from the image are plotted in green over the model image. Red triangles indicate the dark/light polarity of the selected graphical shape as shown in the above figure.

The peak of the red triangles points toward the light side. For detailed information about the light/dark polarity, see Subsection 7.1.6, “Setup Guidelines”.

### F1 [ADD]

Add a graphical shape to the model pattern. Select the type of graphical shape you want to add from the popup menu. The choices are “segmented-line”, “rectangle” and “circle”. For detailed information about how to edit each type of graphical shape, see Subsection 3.7.10, “Setting Segmented-Line”, Subsection 3.7.9, “Window Setup”, or Subsection 3.7.11, “Circle Setup” .

You can also add a graphical shape by tapping the , ,  buttons

### F2 INVERT

Invert the dark/light polarity of the selected graphical shape.

#### NOTE

If you are not sure which is the right dark/light polarity, try to perform the test detection of the GPM Locator Tool with changing the dark/light polarity.

### F3 EDIT

Edit the selected graphical shape. For detailed information about how to edit each type of graphical shape, see Subsection 3.7.10, “Segmented-Line Setup”, Subsection 3.7.9, “Window Setup”, or Subsection 3.7.11, “Circle Setup” .

### F4 OK

Retrain the model pattern with the trained graphical shapes, and return to the previous setup page.

### F5 CANCEL

Cancel retraining the model pattern, and return to the previous setup page.

### F6 DELETE

Delete the selected graphical shape. If there are not graphical shapes, this function key is disabled.

### F7 PREV

Select the previous graphical shape of the selected one. If the number of graphical shapes is smaller than 2, this function key is disabled.


### F8 NEXT

Select the next graphical shape of the selected one. If the number of graphical shapes is smaller than 2, this function key is disabled.

## Training Stability

The evaluation results for items [Location], [Orientation], and [Scale] of the taught model pattern are displayed as one of the following three levels:

- Good: Can be determined stably.
- Poor: Cannot be determined very stably.
- None: Cannot be determined.



If Poor or None is displayed for an item, perform the relevant operation as follows.

### Location:

- Poor: Use the emphasis area or change the part to be taught as a model pattern.
- None: Change the part to be taught as a model.

### Orientation:

- Poor: Use the emphasis area or change the part to be taught as a model pattern.
- None: Uncheck the [Orientation] check box.

### Scale:

- Poor: Use an emphasis area or change the part to be taught as a model pattern.
- None: Uncheck the [Scale] check box.


### NOTE

For detailed information about items such as a model pattern, which can be found stably, see Subsection 7.1.6.2, “Model Pattern” in Subsection 7.1.6, “Setup Guidelines”.


## Training Mask



If the taught model pattern has any unnecessary items in the background, any unwanted or incorrect features not found in all other parts, or any blemishes, you can remove them from the pattern by filling that part with the color of red.

To edit a training mask, tap the [Edit] button on the [Training Mask] line. When an enlarged view of the model pattern appears on the image display control, fill the unnecessary part of the model pattern with the color of red. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.



## Model Origin

The “model origin” is the point that numerically represents the location of the found pattern. The coordinate values (Row, Column) of the location of the found pattern indicate the location of the model origin. When the found result is displayed on the image, a  appears at the model origin.

To move the model origin manually, tap the [Set Org] button. An enlarged view of the model pattern appears on the image display control, and  appears at the current position of the model origin. Move the  with the mouse to move the model origin. For detailed information about the operation method, see Subsection 3.7.8, “Setting a Point”.

If the taught model pattern is rotatable, you can calculate the rotation center and set the model origin there. For example, when the taught model pattern is a circular hole, the model origin can be set at the center of the circle. To set the model origin at the rotation center, tap the [Cen Org] button. If the model pattern is rotatable, the rotation center is calculated and the model origin is set at the rotation center. If the model pattern is not rotatable and the rotation center cannot be calculated, a message to that effect appears.

## Emphasis Area

Use an emphasis area when the position of the workpiece cannot be determined correctly unless attention is paid to a small characteristic part of that workpiece.

To set an emphasis area in the model pattern, tap the [Edit] button on the [Emphasis Area] line. When an enlarged view of the model pattern appears on the image display control, fill the part where you want to set an emphasis area with the color of blue. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.

When an emphasis area is used to stabilize orientation calculation or prevent incorrect location, the target object fails to be found if the emphasis area cannot be found. In other words, if the emphasis area cannot be found, the target object goes undetected even when the object itself is detectable.


## Bias

The bias function adds bias to the found pose of this GPM Locator Tool so that the tool outputs the same found position data as another GPM Locator Tool that has already been taught when a same workpiece is detected. When this function is used, the same position data is output for a workpieces as far as placed

at the same position regardless of whether the workpiece is found by this GPM Locator Tool or another existing GPM Locator Tool, which allows position offset using the same reference position data.

Set the bias as follows:

- 1 Open the window for setting the GPM Locator Tool you want to set the bias.
- 2 Tap the [Set] button in [Model Origin Bias].
- 3 The following page appears. Select the GPM Locator Tool which is already trained as the [Base Tool].



- 4 Press F4 OK. The tool attempts to find the workpiece using the model image of the reference tool. When the tool finds the workpiece successfully, the bias is set. When the bias is set properly, the model origin is changed so that the tool outputs the same found position as the reference tool.

Usually, the [Use Nearest Result] check box should be unchecked. Then, when the tool finds two or more workpieces in the image, the bias is calculated on the basis of the found workpiece which has the highest score.

In case you want the tool to calculate the bias on the basis of another workpiece in the image, move the model origin of the tool near the model origin of the reference tool manually and check this box. Then, the bias is calculated on the basis of the found workpiece of the model origin of which is the nearest from the model origin the reference tool.

## Model Learning

Model learning uses a user defined set of images to optimize the trained model pattern. To use the model learning function, click the model learning [Start] button. For details, see Subsection 7.1.4 "Model Learning".

### 7.1.2 Adjusting the Location Parameters

Adjust the location parameters.

## Model ID

When you have taught two or more GPM Locator tools and want to identify which tool was used to detect the workpiece, assign a distinct model ID to each tool. The model ID of the tool, which found the

workpieces, is reported to the robot controller along with offset data. This enables the robot program to identify the type of the found workpieces.

### Score Threshold

The accuracy of the found result is expressed by a score, with the highest score being 100. The target object is successfully found if its score is equal to or higher than this threshold value. If the score is lower, the target object is not found. Set a value between 10 and 100. The default value is 70. Setting a small value might lead to inaccurate location.

### Contrast Threshold

Specify the contrast threshold for the search. The default value is 50. If you set a small value, the tool will be able to find the target in obscure images as well but take longer to complete the location process. The minimum value is 1. If the tool is prone to inadequately find blemishes and other unwanted edges with low contrast, try setting a larger value. Those image features whose contrast is lower than the threshold are ignored. Selecting the [Image+Edges] in [Image Display Mode] lets you check the image features extracted based on the current threshold.

### Area Overlap

If the ratio of overlap of the found objects is higher than the ratio specified here, then the found result for the workpiece with the lower score is deleted, leaving only the one with the higher score. The ratio of overlap is determined by the area where the models' external rectangular frames overlap. If you specify 100% as the limit value, the found results will not be deleted even if the workpieces overlap.

### Elasticity

Specify a pixel value to indicate how much the pattern in the image is allowed to be deviated (distorted) in geometry from the taught model. Setting a large value enables the tool to find the target in images that are greatly deviated in geometry. However, the larger the value is, the more likely inaccurate location becomes.

### EA Score Threshold

Besides the score threshold for the entire model, specify the score threshold for the emphasis area alone indicating how high the score must be for the object to be found. The default value is 70 points.

### Allow Floating EA

This can be specified to allow the tool to find an object even if the position of the emphasis area is deviated by two to three pixels relative to the position of the entire model pattern.

### Ignore Polarity

This can be specified to perform detection ignoring dark/light polarity of a trained model pattern. See 7.1.6 "Setup Guidelines" for polarity.

### Search Window

Specify the range of the area of the image to be searched. The narrower the range is, the faster the location process ends. The default value is the entire image. To change the search window, tap the [Set] button. When a rectangle appears on the image, adjust its geometry, as when teaching a model. For detailed information about the operation method, see Subsection 3.7.9, "Setting a Window".

### Run-Time Mask

Specify an area of the search window that you do not want processed, as an arbitrary geometry. Use this function when you want to specify a search window of an arbitrary geometry, such as a circle- or donut-shaped window. The filled area will be masked in the rectangle specified as the search window and will not be subject to the image processing. To change the run-time mask, tap the [Edit] button. For detailed information about the operation method, see Subsection 3.7.14, "Editing Masks".

## DOF - Orientation

Specify the range of orientation subject to be searched. The tool searches for a model rotated in the range specified by [Minimum] and [Maximum], with the orientation of the taught model being 0 degrees. The specifiable value range is from -360 to +360 degrees for both [Minimum] and [Maximum]. The narrower the orientation range is, the faster the search process ends. If a range wider than 360 degrees is specified, the range is automatically corrected to the range of -180 to +180 degrees when the vision process runs.

If you uncheck this box, the orientation is ignored and the tool searches only for a model having the orientation specified in [Nominal].

By default, the orientation search is enabled and the range is from -180 to +180 degrees.

When it is a child tool of another locator tool, specify the range relatively in respect to a parent tool's found result.

## DOF - Scale

Specify the range of scale to be searched. With the size of the taught model being 100%, the tool searches for a model expanded or reduced by the ratio specified in [Minimum] and [Maximum]. The specifiable value range is from 25% to 400% for both [Minimum] and [Maximum]. The narrower the size range is, the faster the search process ends.

If you uncheck this box, the scale is ignored and the tool searches only for a model having the scale specified in [Nominal].

By default, the scale search is disabled.

When it is a child tool of another locator tool, specify the range relatively in respect to a parent tool's found result.

## DOF - Aspect

Specify the range of aspect ratios to be searched. With the ratio of the taught model being 100%, the tool searches for a model flattened by the ratio specified in [Minimum] and [Maximum]. The specifiable value range is from 50% to 100% for both [Minimum] and [Maximum]. The narrower the aspect ratio range is, the faster the search process ends.

If you uncheck this box, the aspect ratio is ignored and the tool searches only for a model having the aspect ratio specified in [Nominal].

By default, the aspect ratio search is disabled.

When it is a child tool of another locator tool, specify the range relatively in respect to a parent tool's found result.

## Time-out

If the location process takes longer than the time specified here, the tool ends the process without finding all of the workpieces.

## Result Plotting Mode

Select how the found results are to be displayed on the image after the process is run.

### Plot Everything

The origin, features, and rectangle of the model will be displayed.

### Plot Edges

Only the origin and features of the model will be displayed.

### Plot Bounding Box

Only the origin and rectangle of the model will be displayed.



**Plot Only Origin**

Only the origin of the model will be displayed.

**Plot Nothing**

Nothing will be displayed.

**Image Display Mode**

Select the image display mode for the Setup Page.

**Image**

Only the camera image will be displayed.

**Image+Results**

The camera image and found results will be displayed.

**Image+Edges**

The camera image and features of the image will be displayed.

**Pattern**

The taught model pattern will be displayed. The features will be indicated in green, and the emphasis area in blue.

**Pattern+Mask+EA**


The taught model pattern, with an area overlaid that is masked as the emphasis area, will be displayed.

**Show Almost Found**

If there is any workpiece that failed to be found because it fell just short of meeting the score, contrast, orientation, scale, and/or other conditions, its test result is displayed. The result appears in a red rectangle on the image.

**7.1.3 Running a Test**

Press F4 FIND to run a test and see if the tool can find workpieces properly.



**Found**

The number of found workpieces is displayed.

**Almost Found**

The number of workpieces that failed to be found because they were slightly outside the specified range is displayed. "0" is displayed if the [Show Almost Found] check box is not checked.

**Time to Find**

The time the location process took is displayed in milliseconds.

**Found Result Table**

The following values are displayed.

**Row, Column**

Coordinate values of the model origin of the found pattern (units: pixels).

**Score**

Score of the found pattern.

**EA Score**

Score for the emphasis area only. This is displayed only when the box for the emphasis area is checked.

**Contrast**

Contrast of the found pattern.

**Fit Error**

Deviation of the found pattern from the model pattern (units: pixels).

**Angle**

Orientation of the found pattern (units: degrees). This is displayed only when the box for the orientation search is checked.

**Scale**

Scale of the found pattern (units: %). This is displayed only when the box for the scale search is checked.

**Aspect**

Aspect ratio of the found pattern (units: %). This is displayed only when the box for the aspect ratio search is checked.

**Skew**

Skew angle of the found pattern (units:degrees). This is displayed only when the box for the aspect ratio search is checked.

---

**7.1.4 Model Learning**

---

Model learning is a function the finds the trained model in multiple different images and performs learning based on the detection results. The learning function changes the trained model based on the detection results. By performing model learning, the model pattern will be optimized in the points below.


- Removing any needless/unreliable features of the model pattern.

- Averaging the shape of the model pattern against variations in the shapes of the workpieces detected.

The optimized model pattern will improve the scores of the found targets, which will allow the score threshold to be increased. Increasing the score threshold will reduce the possibility of false detection and shorten the time to find.


### Hint

- 1 Model learning uses images containing the target. Images that can be used are:
  - Images saved to the vision log  
To use images saved in the vision log, you must create the vision log before starting model learning. The vision log can be created by running a TP program with the vision instructions or by pressing Snap and Find on the vision setup page. To log images, Enable Logging must be checked on the Vision Config screen and Log All Images must be selected on the vision process. For information about the vision log, see Section 3.3, "VISION LOG".
  - Images newly snapped on the model learning screen  
To use images newly snapped on the model learning screen, place workpieces in the camera view and snap images in the process of model learning.
- 2 In model learning, information necessary for model learning is saved to the same device as the folder specified for the [Log Path] on the Vision Config screen. Before starting model learning, insert the memory device specified in the [Log Path]. During model learning, "Enable Logging" on the Vision Config screen does not need to be checked.




### 7.1.4.1 Overview of Model Learning Wizard

Model learning is setup using the Model Learning Wizard. Follow the steps of the Model Learning Wizard to complete the model learning. The steps of the Model Learning Wizard are shown below in the flowchart. The areas enclosed in rectangles represent the steps of the wizard.



Each screen of the model learning wizard is shown below.



**A** Area displaying information about the steps of the wizard. Displayed in the upper part is the flow of the wizard. Displayed in the middle is an explanation of the task to carry out in the present step. Displayed in the lower part are the number of images used in the last learning and the number of detection results, as well as the number of images added in the present learning and the number of detection results.

**B** Area in which to carry out the task in the present step. You mainly use this area to perform operations and confirmations in each step.

C Tool bar of the wizard. Displayed on the left side is the title of the present step. Displayed on the right side are tools such as the drop-down box for changing the zoom magnification of the image displayed in area B and the text box for switching pages.

The function keys to use with the model learning wizard differ from step to step, but the function keys listed below are the common ones that are used throughout the model learning wizard.

F3 < BACK

Go back to the last step.

F4 NEXT >

Go to the next step.


F5 CANCEL

Cancel model learning and return to the GPM Locator tool setting screen. Any added images and detection results are discarded.

### 7.1.4.2 Select Method to Add Images

On the GPM Locator tool setting screen, click the Start button of [Model Learning] to start the model learning wizard.

The first time the model learning is executed on the current GPM locator, the screen below appears. On this screen, the method to add the images to use in model learning is selected.



In the area enclosed in a red frame border, tap the item you want to select.


#### Images logged in Vision Log

Perform learning by using the images already logged in the vision log.

#### Images newly snapped

Snap images in the next step, and perform learning by using the snapped images.

If model learning has already been executed for the current GPM locator then the screen below appears.



In this case, select the method to add the images used in learning from the choices below.

### Add logged images and learn again

In addition to the images last used, use the logged images selected in the next step in learning.

### Add snapped images and learn again

In addition to the images last used, use the newly snapped images in the next step in learning.

### Learn again with the same images

Do not add new images, but learn again with the images last used.


Press F4 NEXT to go to the next step.

- "Images logged in Vision Log" or "Add logged images and learn again" → Subsection 7.1.4.3 "Add Logged Images"
- "Images newly snapped" or "Add snapped images and learn again" → Subsection 7.1.4.4 "Add Snapped Images"
- "Learn again with the same images" → Subsection 7.1.4.5 "Confirm Images and Results"

## 7.1.4.3 Add Logged Images

In this step, select the logged images to use in model learning.





As shown in the figure below, the logged images in the selected period are displayed in thumbnail format.







First, select a period of logged images from the drop-down box located in the upper part of the screen. The logged images in the period selected here are displayed on the screen.




**Hint**  
 If the logged images in the selected period cannot be displayed on a single page, they are displayed on more than one page. To change pages, either press F1 PREV PAGE and F2 NEXT PAGE as appropriate or enter a value directly in the text box displaying the page number, [Page], in the tool bar.

On the thumbnail of a logged image, either a  or  icon is displayed.  indicates a selected logged image, and  indicates a deselected logged image. In the initial state, all logged images are selected.

Tapping a  icon deselects the logged image, and the icon changes to .

Tapping a  icon selects the logged image, and the icon changes to .



On this screen, the function keys below can be used.

### F1 PREV PAGE

Display the logged images on the previous page.

### F2 NEXT PAGE

Display the logged images on the next page.


### F6 CHECK ALL

Select all logged images.

### F7 UNCHECK ALL

Deselect all logged images.


Tapping a logged image enlarges the logged image.



Pressing F5 RETURN or tapping the screen returns you to the original thumbnail screen.




After the completion of the selection of the logged images to use in learning, press F4 NEXT >. The screen below appears. Detection is performed for the selected logged images.



Upon the completion of detection, you automatically go to the next step (Subsection 7.1.4.5 "Confirm Images and Results").

### 7.1.4.4 Add Snapped Images


In this step, snap the images are used in model learning. A live image from the camera is displayed, shown in the figure below.



Add snapped images with the procedure below.

- 1 Place target objects in the camera view. Use the live image to confirm the target objects are properly within the field of view.
- 2 Press F1 FIND to snap the images and perform detection.

- 3 Upon the completion of detection, detection results are plotted on the images shown in the figure below.  
The F1 and F2 function keys change to ADD and DISCARD.



- 4 If the target objects are detected correctly, press F1 ADD to add these images as part of the images to use in model learning. If there are multiple detection results and they include incorrect ones, they can be removed in a later step, so you may add them.
- 5 If there are no objects detected correctly, press F2 DISCARD to discard the images and the detection results.

No matter which of F1 ADD and F2 DISCARD you select, the live image display starts again, so you can perform detection again.

Change the scene by moving the object or objects within the field of view and repeat steps 1 to 5 to add a sufficient number of images and detection results. The more the images and detection results, the more accurate the learning results. It is desirable that the target objects be dispersed into the same positions as those when the production operation is performed. For a target object that has individual differences, it is preferable to snap images of multiple instances.

After adding sufficient images, press F4 NEXT > to go to the next step (Subsection 7.1.4.5 "Confirm Images and Results").

#### Hint


If you have not added or discarded any images, you cannot press F4 NEXT >. Add or discard images and return to the live image display before pressing F4 NEXT >.





### 7.1.4.5 Confirm Images and Results





The steps confirm the images and detection results to use in model learning are shown below.

The screen in this step consists of two screens, a list of images and a list of detection results. By moving between these two screens, confirm the images and the detection results and remove any incorrect detection results you may find.

In the image list screen, the images to use in model learning are displayed as thumbnails shown in the figure below.



For each image, detection results are plotted. Also, for each image, either a  or  icon is displayed.  indicates that all detection results of the image are selected.  indicates that some or all of the detection results of the image are deselected.

Tapping a  icon deselects all detection results of the image, and the icon changes to .  
Tapping a  icon selects all detection results of the image, and the icon changes to .

On this screen, the function keys below can be used.

### F1 PREV PAGE

Display the logged images on the previous page.

### F2 NEXT PAGE

Display the logged images on the next page.

### F6 CHECK ALL

Select all detection results of all images.


### F7 UNCHECK ALL

Deselect all detection results of all images.

### F8 FIND ALL





Discard the existing detection results and detect the target objects from all images again. This function key is displayed for "Learn again with the same images" only.



If you tap an image, the screen changes to a detection result list screen such as the one in the figure below, so that you can confirm the individual detection results in more detail.





In the upper half of the screen, the selected entire image is displayed, and in the lower half, the results of detection from the image are displayed in thumbnail format. The selected detection results are highlighted in both halves to indicate which detection results correspond to which parts of the image.

You can change the display size of the entire image displayed in the upper half with [Zoom] in the tool bar.

For each of the detection results displayed in the lower half, either a  or  icon is displayed.  indicates that the detection result is selected, and  indicates that the detection result is deselected.

Tapping a  icon deselects the detection result, and the icon changes to .

Tapping a  icon selects the detection result, and the icon changes to .

On this screen, the function keys below can be used.

### F1 PREV IMAGE

Go to the detection result list screen for the previous image.

### F2 NEXT IMAGE

Go to the detection result list screen for the next image.

### F5 RETURN

Return to the logged image list screen. From this screen, you cannot move directly to the next or previous step of the wizard. You must press this function key to return to the logged image list screen first.

### F6 CHECK ALL

Select all detection results of this image.


### F7 UNCHECK ALL


Deselect all detection results of this image.

**F8 FIND**


Discard the existing detection results of this image and detect the target objects again. This function key is displayed for "Learn again with the same images" only.

If you tap the thumbnail of a detection result, the detection result is highlighted in both the entire image and the thumbnail of the detection result.


If you find any incorrect detection result, tap the  icon of the detection result to remove the detection result.



Press F5 RETURN to return to the image list screen.




After confirming all the images and detection results, press F4 NEXT >. Then, model learning is started, using the added images and detection results.



Upon the completion of model learning, you automatically go to the next step (Subsection 7.1.4.6 "Remove Needless Features").

### 7.1.4.6 Remove Needless Features

The step to remove any features that are judged potentially needless through learning is shown below. The model pattern as a result of learning is displayed on the screen shown in the figure below.



On the image, each feature of the model pattern is displayed in a color. A feature whose need in detection is considered high is displayed in green, while a feature whose need is considered low (that is highly likely not necessary) is displayed in red. Any features whose need is less than the [Threshold] value are not displayed.

If you do not want to remove the needless features, select [Do not Remove].

If you want to remove the needless features, select [Remove Features below Threshold], and adjust the [Threshold] value in such a way that the features you want to remove are not displayed. The higher the value, the more features will be removed. If the needed features are no longer displayed, reduce the [Threshold] value.

**Hint**


After learning, you can mask any needless features on the model pattern manually later. It is recommended that you leave features unremoved except those that are clearly needless.

Press F4 NEXT > to go to the next step (Subsection 7.1.4.7 "Average Model Shape").

### 7.1.4.7 Average Model Shape

The step to average the shape of the model pattern is shown below.

The model pattern as a result of learning is displayed on the screen, shown in the figure below.






If you want to average the model shape, select [Adjust to Average Model].

If you do not want to average the model shape, select [Do not Adjust].

Press F4 NEXT > to go to the next step (Subsection 7.1.4.8 "Confirm Learning Model").

### 7.1.4.8 Confirm Learning Model

The step to confirm that the model pattern has been optimized through learning is shown below.




Press F4 FINISH to adopt the learning model pattern and return to the GPM Locator tool setting screen.



Press F5 CANCEL to discard the learning model pattern and return to the GPM Locator tool setting screen.

The optimization of the model pattern through model learning is now completed.

Finally, press F4 FIND to execute a test to confirm whether the model pattern runs as expected. If no problems are found, press the [SAVE] button to save the vision data.



### Hint

- 1 When vision data is saved, information about the images and detection results used in model learning is saved to the same device as that used for the vision log. Thus, this information will not be lost even after the controller is turned off.
- 2 If you find any problems with the learning model pattern, you can return the model pattern to the state before learning by unchecking [Enable] of Model Learning.

## 7.1.5 Overridable Parameters

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Score Threshold

Specify a number between 10 and 100.

### Contrast Threshold

Specify a number between 1 and 250.

### Elasticity

Specify a number between 1 and 5.

### DOF Angle

Enable/disable selection, minimum angle, maximum angle and nominal angle can be specified. Specify 0 for disable or 1 for enabled. Specify a number between -360 and 360 for the minimum, maximum and nominal angles.

## DOF Scale

Enable/disable selection, minimum scale, maximum scale and nominal scale can be specified. Specify 0 for disable or 1 for enabled. Specify a number between 25 and 400 for the minimum, maximum and nominal scales.

## DOF Aspect Ratio

Enable/disable selection, minimum aspect ratio, maximum aspect ratio and nominal aspect ratio can be specified. Specify 0 for disable or 1 for enabled. Specify a number between 50 and 100 for the minimum, maximum and nominal aspect ratios.

## 7.1.6 Setup Guidelines

Read these guidelines for a deeper understanding of how the GPM Locator tool works.

### 7.1.6.1 Overview and functions

This section provides an overview of the GPM Locator tool, describing what you can do and how you see objects with this tool.


#### What you can do with the GPM locator tool

The GPM Locator Tool offers image processing capabilities to process images captured by the camera, find the same pattern in an image as the pattern taught in advance, and output the position and orientation of the found pattern. The pattern taught in advance is called a model pattern, or simply a model.

As the position and orientation of the object placed within the camera view change, the position and orientation of the figure of that object captured through the camera also change accordingly. The GPM Locator Tool finds where the same pattern as the model pattern is in the image fed from the camera.

If the figure of the object in the image has same pattern as the model pattern, the Locator Tool can find it, regardless of differences of the following kinds:

- Linear movement: The position of the figure in the image is different than in the model pattern.
- Rotation: The apparent orientation of the figure in the image is different than in the model pattern.
- Expansion/reduction: The apparent size of the figure in the image is different than in the model pattern.



**Fig 7.1.6.1 (a) Pattern movement**

## What is the same pattern?

What does the GPM Locator Tool consider the “same pattern” as the model pattern? The GPM Locator Tool has two criteria to judge whether a pattern is the “same pattern” as the model pattern. When the pattern meets both of the criteria, the GPM Locator Tool regards it as the “same pattern”.

- The figure has the same geometry.
- The figure has the same dark/light polarity.

An understanding of what the GPM Locator Tool considers the same pattern helps you make the tool find eligible patterns with increased stability.

## Figure having the same geometry

First, we will discuss about a “figure having the same geometry”.

For example, suppose that you look at circular cylinders via a camera, as in Fig. 7.1.6.1(b). While the figures in Fig. 7.1.6.1(b) (i) and Fig. 7.1.6.1(b) (ii) differ in position in the image, they are considered to have the “same geometry” because both appear to be a perfect circle. The figure in Fig. 7.1.6.1(b) (iii), on the other hand, appears to be an ellipse in the image because the object is seen obliquely from the camera, whereas it is in fact a circular cylinder like the objects in Fig. 7.1.6.1(b) (i) and Fig. 7.1.6.1(b) (ii). Therefore, the tool considers the figure in the image in Fig. 7.1.6.1(b) (iii) to have a “different geometry” from those in Fig. 7.1.6.1(b) (i) and Fig. 7.1.6.1(b) (ii).




Fig 7.1.6.1 (b) When seen from the

Conversely, if the actual objects differ in geometry but their figures captured by the camera happen to be geometrically identical, the GPM Locator Tool judges them to have the “same geometry”.

## Image distortion


There is another factor to consider when determining whether the figure in the image is geometrically identical. It is “image distortion”.

No image captured via a camera is immune to distortion. Distortion occurs for a variety of reasons including distortion of the camera lens itself, lack of parallelism between the lens and the light receiving element surface, digitizing error, and improper lighting on the workpiece. Because of distortions resulting from these problems, for example, the figure of a square workpiece captured by the camera can be distorted in various ways, thus making the figure not exactly square. Also, when you snap an image of the same object several times, each resultant image might be distorted in a slightly different way due to a minor change in lighting or another factor.

One obstacle to the GPM Locator Tool finding the same pattern as the model pattern in the image is the “differences in distortion between the model pattern and the pattern in the image” stemming from these image distortions. The model pattern is distorted, and so is the pattern in the image. The problem is that the two models are distorted differently.

The GPM Locator Tool is designed to allow a “certain degree of geometric deviation” between two patterns. Fig. 7.1.6.1(c) shows a little exaggerated example where the dotted line represents the pattern taught as the model with the solid line representing the pattern found in the image. If the deviation between these two patterns is within the allowable range, the GPM Locator Tool judges them to be geometrically identical.

If there is any part where the deviation is greater than the allowable range, the GPM Locator Tool regards the part as “missing from the pattern in the image”, judging that its geometry is different only in that particular part.



**Fig 7.1.6.1(c) Geometric deviation**


Also, the cause of a circular cylinder being presented as an ellipse, as in Fig. 7.1.6.1(b), might be due to an image distortion occurring because the camera's optical axis is not perpendicular to the surface of the circular cylinder. Therefore, even when the object is slightly slanted, it is judged to have the same geometry if the resulting distortion is within the allowable range.

### Figure having the same dark/light polarity

Next, we will discuss about a “figure having the same dark/light polarity”.

Suppose you have two images as shown in Fig. 7.1.6.1(d) (i) and Fig.7.1.6.1(d) (ii). The figures in Fig. 7.1.6.1(d) (i) and Fig. 7.1.6.1(d) (ii) have the same geometry because both are squares of the same size. However, Fig. 7.1.6.1(d) (i) has a dark square on a light background, while Fig. 7.1.6.1(d) (ii) has a light square on a dark background. The difference between these two concerns “which is light, workpiece (square) or background”, i.e. the difference in dark/light polarity. If the patterns differ in dark/light polarity, the Locator Tool judges them different even when they are geometrically identical.


Therefore, if you teach a model pattern like the one in Fig. 7.1.6.1(d) (i), the tool cannot find a pattern like the one in Fig. 7.1.6.1(d) (b).



**Fig 7.1.6.1 (d) Dark/light polarity**

Next, suppose that you teach the pattern in Fig. 7.1.6.1(d) (i) as the model pattern and then obtain images with the patterns shown in Fig. 7.1.6.1(e). The image in Fig. 7.1.6.1(e) (i) has uneven brightness in the background, and the image in Fig. 7.1.6.1(e) (ii) has uneven brightness in the workpiece (square). The image in Fig. 7.1.6.1(e) (iii) has uneven brightness in both the background and the workpiece.

These three patterns all have the same dark/light polarity as Fig. 7.1.6.1(d) (i) in the upper half of the square and as Fig. 7.1.6.1(d) (ii) in the lower half of the square. This means that the dark/light polarity is the same as the model pattern only for half of the pattern. Therefore, the tool judges the patterns to be half identical and half different.



**Fig 7.1.6.1 (e) Dark/light polarity**

One thing to note is that “the human eye is quite insensible to dark/light polarity”. What are shown in Fig. 7.1.6.1(d) and Fig. 7.1.6.1(e) are mere examples where the dark/light polarity is very easy to discern. In most actual images, “telling which is lighter and which is darker” requires a considerable amount of attention. If the tool fails to find a pattern, it might be necessary to check whether the “dark/light polarity is in the reverse direction”.

### Missing or extra feature

Next, suppose that you teach the pattern in Fig. 7.1.6.1(f) (i) as the model pattern and then have an image captured by the camera with the pattern shown in Fig. 7.1.6.1(f) (ii). The pattern in Fig. 7.1.6.1(f) (b) does not contain a white circle, which is found in the model pattern in Fig. 7.1.6.1(f) (i).

If a feature found in the model pattern is missing from the pattern in the image, the Locator Tool judges that the pattern is different by as much as that missing feature. In this case, the pattern in Fig. 7.1.6.1(f) (ii) is considered to be different from the model pattern in Fig. 7.1.6.1(f) (i) in that “it is missing the white circle”.

Conversely, what happens if you teach the pattern in Fig. 7.1.6.1(f) (ii) as the model pattern and then have an image captured by the camera with the pattern shown in Fig. 7.1.6.1(f) (i)?

The GPM Locator Tool judges that the pattern in the image has the “same geometry”, even if it contains an extra feature not found in the model pattern. Therefore, the pattern in Fig. 7.1.6.1(f) (i) is considered to have the “same geometry” as the model pattern in Fig. 7.1.6.1(f) (ii).



**Fig 7.1.6.1 (f) Missing extra feature**

### Pattern similarity

We have discussed the criteria concerning a number of factors such as geometry, image distortion, dark/light polarity, and missing feature. However, not all these criteria need to be satisfied fully. It is

virtually impossible to eliminate the influence of the discussed factors completely. The GPM Locator Tool is designed to allow the influence of these factors to a certain degree. In other words, the tool is meant to find “similar patterns”, rather than “the same patterns”.

One measure of similarity is by evaluating how similar the pattern found in the image is to the model pattern. While this is generally called the “degree of similarity”, the Locator Tool refers to this value as a “score”. The score is a numerical value ranging from 0 to 100 points. If the pattern fully matches, it gets a score of 100 points. If it does not match at all, the score is 0. If the pattern in the image has any part that is “distorted because of the lens distortion”, that is “distorted due to parallax”, that has a “different dark/light polarity”, that is “missing a feature”, or that does not match for any other reason, the score is reduced from 100 points accordingly. If such parts account for 30% of the model pattern, the score is 70 points.

When you have the GPM Locator Tool find a matching pattern in an image, you specify a score threshold so that the tool “finds patterns whose score is higher than the specified threshold”.

### 7.1.6.2 Model pattern

---

The first thing you do when using the GPM Locator Tool is to teach the object you want the tool to find as a model pattern. This section provides the guidelines on teaching a model pattern.

#### Teaching a model pattern

Teach the geometry of the workpiece as seen via the camera as a model pattern. To teach a model pattern, read the image of the workpiece from the camera and enclose the part of the image you want to register as a model pattern within a rectangle. It is important to place the workpiece so that it comes to the center of the image. An image seen via the camera is subject to various kinds of distortion such as the distortion of the camera lens. Such distortions become minimal near the center of the image. When teaching a model pattern, therefore, make sure that the workpiece is placed so that it comes as near to the center of the image as possible.


#### Geometries whose position cannot be determined

There are some types of geometries whose position, orientation, or other attributes cannot be determined. If the position or orientation of the geometry taught as the model pattern cannot be determined, the GPM Locator Tool cannot find the pattern properly. Examples of such geometries are given below.

<1> Geometries whose position cannot be determined

With the geometries shown in Fig. 7.1.6.2(a) (i) and Fig. 7.1.6.2(a) (ii), the position cannot be determined in the direction parallel to the line. Avoid using these patterns as a model pattern unless “you do not mind which part of the pattern the tool finds as long as the tool finds the pattern”.

In these cases, the images captured by the camera look perfectly identical to the human eye, whereas the position found by the GPM Locator Tool differs for each pattern. This is because images are subject to distortion, as earlier described. Although humans see the pattern as a straight line, both the model pattern and the pattern in the image are in fact distorted, uneven curved lines. The tool searches for the position where the two uneven curved lines best match each other. Even if you snap multiple images consecutively with the workpiece fixed to the same place, the position where the unevenness matches varies for each image, since all the images are distorted in slightly different ways.




Care must be exercised as well when identical features are equally spaced, as shown in Fig. 7.1.6.2(a) (iii). For example, if you teach three of the five black circles as the model pattern, the tool cannot discern which three black circles to find. Therefore, you should avoid using such a geometry as the model pattern.

Even if you teach all the five black circles as the model pattern, a pattern gets a score as high as 80 points when it matches four of the black circles. This makes the found result unreliable when the score is lower than 90 points.

<2> Geometries whose orientation cannot be determined


The orientation of the circle shown in Fig. 7.1.6.2(b) (i) cannot be determined, because the orientation of the pattern in the image matches that of the model pattern no matter how the model pattern is rotated. In this case, specify that the orientation is to be ignored in the search.

Since the orientation of the rectangle shown in Fig. 7.1.6.2(b) (ii) perfectly matches at both 0 and 180 degrees, it is unknown which orientation the tool will find. In this case, limit the search range of orientation, as in -90 degrees to +90 degrees. The same is true with regular triangles and polygons.



<3> Geometries whose scale cannot be determined

As for a corner like the one shown in Fig. 7.1.6.2(c), the scale cannot be determined because the pattern in the image fully matches the model pattern no matter how many times its size is expanded. In this case, specify that the scale is to be ignored in the search.



**Masking the model pattern**

As described earlier in “Missing or extra feature”, if a feature found in the model pattern is missing from the pattern in the image, the GPM Locator Tool judges that the pattern is different by as much as that

missing feature. On the other hand, however, the tool ignores extra features. Therefore, if there is any extra feature that happens to exist in the image when the model pattern is taught, it is desirable not to include that feature in the model pattern.

The GPM Locator Tool allows you to mask a specific part of the image and to remove that part from the model pattern after the model pattern teaching operation. This process is called “masking the model pattern”. If the image taught as a model pattern includes any of the parts described below, mask those parts and remove them from the model pattern.

<1> Part where the distance from the camera differs

When you see an object through a camera, what is known as “parallax” occurs. Even when an object is moved linearly by the same amount in the actual space, the amount of travel in the image seen via the camera varies, if the distance from the camera to the object is different. This difference in the amount of travel is called parallax.

When you move an object having a certain height, the distance from the camera differs for the top and bottom of the object and the amount of travel seen via the camera varies due to parallax. This means that moving the object results in changes not only in position but also in geometry in the image.

For example, consider a glass like the one shown in Fig. 7.1.6.2(d) (i). If you place the glass so that it comes near the center of the image, the camera views the glass from right above and the resultant pattern is a concentric double circle as shown in Fig. 7.1.6.2(d) (ii). If you place the glass so that it comes to a corner of the image, however, the resultant pattern is an eccentric double circle due to the parallax effect as shown in Fig. 7.1.6.2(d) (iii). Since the patterns in Fig. 7.1.6.2(d) (ii) and Fig. 7.1.6.2(d) (iii) differ in geometry, the pattern in Fig. 7.1.6.2(d) (iii) cannot be found even if the pattern in Fig. 7.1.6.2(d) (ii) is taught as the model pattern.




Fig 7.1.6.2 (d) Effect of parallax

To avoid this problem, any part where the distance from the camera is different must be masked and removed from the model pattern. In the case of the glass, mask either the outer or inner circle.

As described earlier, the GPM Locator Tool allows distortion between the model pattern and the pattern in the image as long as the distortion is within the allowable range. If the difference in geometry caused by parallax is within the allowable range of distortion, the GPM Locator Tool can find the pattern. Also, widening the distance between the camera and the workpiece helps alleviate the effect of parallax.

<2> Part that looks differently for each workpiece

When you capture an image of a workpiece via the camera, the image sometimes might contain a feature, such as a blemish, that looks different for each workpiece or each time the position of the workpiece is changed. The GPM Locator Tool pays attention to such features as well when searching the image for a pattern identical to the taught model pattern. Therefore, removing these features from the model pattern helps the tool find matching patterns more accurately.



Mask the following parts to remove them from the model pattern.

- Blemish on the workpiece
- Unevenness on the workpiece surface (e.g. casting surface)
- Part that happens to appear aglow
- Shadow
- Hand-written letters and marks
- Label

<3> Part where dark/light polarity is irregular

When the position or orientation of an object is changed, the way the object is illuminated and how shadows are cast on it might change as well, thus altering the dark/light polarity of the figure in the image. As described earlier, the GPM Locator Tool considers a pattern different if its dark/light polarity is different.

When you snap images of actual workpieces, it is often the case that the dark/light polarity appears reversed in some parts of the pattern although the overall dark/light polarity of the pattern remains unchanged. These parts look different for each workpiece, as described in <2>, and removing them from the model pattern helps the tool find matching patterns more accurately.

### Other points to note

Basically, the more complex the geometry you teach as the model pattern is, the more stable the found result becomes. For example, a small circle is often difficult to be distinguished from a blemish. When the model pattern has a complex geometry, it is very unlikely that an unintended object happens to look like it.

Masking the model pattern excessively might draw you into the pitfall described above. If you mask too many parts of the model pattern, you can end up with a pattern having a very simple geometry, causing the tool to find an “unintended object” that happens to be included in the image. Or, the model pattern you teach might have a “geometry whose position or orientation cannot be determined”.

### 7.1.6.3 Found Pattern

---

This section explains about the pattern found by the Locator Tool.

#### Position of the found pattern

When the GPM Locator Tool finds a pattern identical to the model pattern in the image, it outputs the coordinates of the “model origin” of that found pattern as the “position of the pattern”.

You can set the position of the model origin anywhere you like. When you initially teach the model pattern, the model origin is positioned in the center of the rectangle you use for teaching the model pattern. No matter where you set the model origin, the probability of finding and the location accuracy of the GPM Locator Tool will not be affected.

If you change the position of the model origin, the tool outputs different coordinates even when it finds a pattern at the same position in the image. Changing the position of the model origin after setting the reference position makes it impossible to perform robot position offset normally. Note that, after you change the position of the model origin, you need to change the reference position and the taught robot position accordingly.

#### Orientation and scale of the found pattern

When the GPM Locator Tool finds a pattern identical to the model pattern in the image, it outputs the orientation and scale of the found pattern relative to the model pattern as “Orientation” and “Scale”.

The orientation of the found pattern indicates by how many degrees it is rotated with respect to the model pattern. The scale of the found pattern shows how many times it is expanded with respect to the model pattern.

### Score of the found pattern

The GPM Locator Tool represents how similar the pattern found in the image is to the model pattern, by using an evaluation value called score. The score is a numerical value ranging from 0 to 100 points. If the pattern fully matches, it gets a score of 100 points. If it does not match at all, the score is 0.

For example, a score of 70 points indicates that the pattern in the image is 30% different from the model pattern because it has parts that are “hidden beneath other objects”, that are “invisible due to halation”, that are “distorted because of the lens distortion”, that are “distorted due to parallax”, that have a “different dark/light polarity”, etc.

To judge whether proper values are obtained, repeat the find test while changing the position and orientation of the workpiece in the image. The desirable situation is where you constantly get a score of over 70 points, preferably 80 points or more.

If this is not the case, check the following:

- Whether the lens is dirty
- Whether the lens is in focus
- Whether the lens diaphragm is properly adjusted
- Whether the type of lighting is adequate
- Whether the brightness of lighting is properly adjusted
- Whether the points described in “Masking the model pattern” are followed

### Elasticity of the found pattern

The GPM Locator Tool represents how much the pattern found in the image is distorted with relation to the model pattern, by using an evaluation value called “elasticity”. The elasticity is 0 pixels if the found pattern fully matches the model pattern. The value will be 0.4 pixels if “some parts of the found pattern fully match and some parts are deviated by 1 pixel with an average deviation of 0.4 pixels”. The smaller the value is, the less distorted the found pattern is with relation to the model pattern.

To judge whether proper values are obtained, repeat the find test while changing the position and orientation of the workpiece in the image. The desirable situation is where you constantly get an elasticity value of below 1.0 pixel, preferably 0.5 pixels or less.

If this is not the case, check the following:


- Whether the lens is in focus
- Whether the lens diaphragm is properly adjusted
- Whether the type of lighting is adequate
- Whether the brightness of lighting is properly adjusted
- Whether the points described in “Masking the model pattern” are followed

### Contrast of the found pattern

In addition to score and elasticity, there is one more evaluation value that the GPM Locator Tool finds - “contrast”. This value represents “how clearly the pattern found in the image can be seen”. The value of contrast ranges from 1 to 255. The larger the value, the clearer the pattern.

Contrast is irrelevant to “whether the pattern is identical to the model pattern”. For example, take the ellipses shown in Fig. 7.1.6.3 (i) and Fig. 7.1.6.3 (ii). Since the ellipse in Fig. 7.1.6.3 (i) is seen clearly, it has a higher contrast value than the one in Fig. 7.1.6.3 (ii). Still, these ellipses get the same score

because their geometry and dark/light polarity are the same. However, if any part of the ellipse in Fig. 7.1.6.3 (ii) is invisible because of low contrast, the pattern's score is reduced as much.



**Fig 7.1.6.3 Contrast**

To judge whether proper values are obtained, repeat the find test while changing the position and orientation of the workpiece in the image. The desirable situation is where you constantly get a contrast value of 50 or higher. Also, the contrast of an image widely varies depending on the weather condition and the time of the day. Make sure that contrast values of 50 or higher are obtained in different time zones of the day.

If this is not the case, check the following:

- Whether the lens is dirty
- Whether the lens is in focus
- Whether the lens diaphragm is properly adjusted
- Whether the type of lighting is adequate
- Whether the brightness of lighting is properly adjusted
- Whether ambient light is present

### 7.1.6.4 Location parameters

This section provides the guidelines on adjusting the parameters of the GPM Locator Tool.

#### Search Window

Specify the range of the area of the image captured from the camera that is searched for the pattern. The default value is the entire image.

The size of the search window is determined based on the application that uses the GPM Locator Tool. For example, if the workpiece is likely to appear anywhere in the image, select the entire image. If the workpiece is considered to appear at almost the same position in every shot, the search window can be narrowed.

The narrower the search window is, the faster the location process runs.

If you choose a type of lens that offers a wider camera view, you can narrow the search window. This approach is not recommended, however, since it will degrade the location accuracy. Determine the scale of the camera view according to the amount of deviation of the found workpiece, and then specify the size of the search window in the image based on that scale.

#### Run-Time Mask

You can set masks within the range that is specified as the search window.

Use this function when you want to specify a circular or other non-rectangular geometry as the search range.

## Orientation range

Choose whether to ignore orientation in the search.

- <1> Ignore orientation in the search
- <2> Do an orientation search within the range specified by the upper and lower limits

For example, suppose that you teach the geometry shown in Fig. 7.1.6.4(a) (i) and that the image captured by the camera shows the workpiece having the same geometry but rotated at 5 degrees.

If you specify <1>, orientation is ignored in the search. The tool pays attention only to the orientation specified by the reference value and finds those patterns that are not rotated like the one shown in Fig. 7.1.6.4(a) (ii). Any deviation in orientation is regarded as geometrical distortion, and the score is reduced as much.

If you specify <2>, an orientation search is done within the range specified by the upper and lower limits. Therefore, a pattern like the one shown in Fig. 7.1.6.4(a) (iii) can also be found as a fully matching pattern.

In the case of <2>, care must be taken because a pattern is not found if its orientation is outside the orientation range specified by the upper and lower limits, regardless of how slightly. For example, when you have taught a regular triangle as the model pattern, the tool will mathematically be able to find any triangle if you specify the orientation range as from  $-60$  degrees to  $+60$  degrees. In actuality, however, the orientation of some triangles might not fit into this range, like  $-60.3$  degrees and  $+60.2$  degrees. To avoid this problem, set the orientation range with small margins, as from  $-63$  degrees to  $+63$  degrees.

The time the location process takes is shorter in the case of <1> than <2>. If you specify <2>, the location process takes less time when the orientation range is narrower.



(i) Model pattern



(ii) Reference orientation  $0^\circ$



(iii) Orientation range  $\pm 180^\circ$

Fig 7.1.6.4 (a) Orientation range

## Scale range

Choose whether to ignore scale in the search.


- <1> Ignore scale in the search
- <2> Do a scale search within the range specified by the upper and lower limits

For example, suppose that you teach the geometry shown in Fig. 7.1.6.4(b) (i) and that the image captured by the camera shows the workpiece having the same geometry but expanded by 3%.

If you specify <1>, scale is ignored in the search. The tool pays attention only to the scale specified by the reference value and finds those patterns that are not expanded like the one shown in Fig. 7.1.6.4(b) (ii). Any deviation in scale is regarded as geometrical distortion, and the score is reduced as much.

If you specify <2>, a scale search is done within the range specified by the upper and lower limits. Therefore, a pattern like the one shown in Fig. 7.1.6.4(b) (iii) can also be found as a fully matching pattern. In the case of <2>, care must be taken because a pattern is not found if its scale is outside the range specified by the upper and lower limits, regardless of how slightly.

The time the location process takes is shorter in the case of <1> than <2>. If you specify <2>, the location process takes less time when the scale range is narrower.



### Note on the scale

A change in the scale, or a change in the size of the figure in the image captured by the camera, means that “the distance between the camera and the workpiece has changed”. As described with relation to parallax, if the distance between the camera and the workpiece changes, the actual travel amount of the object becomes different even if the apparent travel amount in the image remains unchanged. Therefore, a change in the distance between the camera and the workpiece makes the tool unable to calculate the actual travel amount of the object correctly from the travel amount of the object in the image. This can impede the accurate offset of the robot position.

If the apparent scale has changed even though the distance between the camera and the workpiece has not changed, you might have altered the lens zoom or focus. In this case, by letting the GPM Locator Tool do a scale search as well, you can have the location process itself accomplished. Doing so, however, makes the tool unable to calculate the actual travel amount of the object correctly from the travel amount of the object in the image, thereby impeding the accurate offset of the robot position.

When using the scale search, make sure that not only the GPM Locator Tool but also the entire application, including robot position offset, are prepared for cases when patterns having different scales are found.

### Score threshold

Specify the score threshold for a pattern to be found. A pattern in the image is not found if its score is lower than the specified threshold. The default value is 70 points.

To determine the threshold, repeat the find test while changing the position and orientation of the workpiece in the image. Identify the worst score, and set the value obtained by subtracting 5 to 10 points from that worst score.

Lowering the score threshold forces the GPM Locator Tool to examine many parts of the image where a pattern can potentially be found, thus resulting in a longer location process. Conversely, raising the score threshold lets the tool narrow down the parts to examine, leading to a shorter location time.

If you need to set the score threshold to lower than 60, the lens setup or lighting is often inadequate. Before setting a low threshold, check the following:

- Whether the lens is dirty
- Whether the lens is in focus
- Whether the lens diaphragm is properly adjusted
- Whether the type of lighting is adequate
- Whether the brightness of lighting is properly adjusted
- Whether the points described in “Masking the model pattern” are followed
- Whether the lens setup has not been changed since teaching the model pattern
- Whether the distance between the camera and the workpiece has not been changed since teaching the model pattern

## Contrast threshold

Specify the contrast threshold for a pattern to be found. A pattern in the image is not found if its average contrast is lower than the specified threshold. The specifiable contrast threshold value range is 10 to 255. The default value is 50.

To determine the threshold, repeat the find test while changing the position and orientation of the workpiece in the image. Identify the lowest contrast, and set the value obtained by subtracting 10 or so from that lowest contrast. The contrast widely varies depending on the time of the day, the weather conditions, and so on. Conduct tests in different time zones on different days to confirm the validity of the threshold.

A higher contrast threshold leads to a shorter location process.

If you need to set the contrast threshold to lower than 20, the lens setup or lighting is often inadequate. Before setting a low threshold, check the following:

- Whether the lens is dirty
- Whether the lens is in focus
- Whether the lens diaphragm is properly adjusted
- Whether the type of lighting is adequate
- Whether the brightness of lighting is properly adjusted
- Whether the points described in “Masking the model pattern” are followed

## Allowable elasticity

Specify the upper limit of elasticity with relation to the model pattern for a pattern to be found. The allowable elasticity must be specified in pixels. The default value is 1.5 pixels.

This default value rarely needs to be changed. It is not recommended to set a large value for the allowable elasticity, except in the case of a “bag-like workpiece whose geometry is subject to change”.

What differs between when a small value is set for the allowable elasticity and when a large value is set is explained below, using a rather extreme example. Suppose that you have taught a circle, like the one shown in Fig. 7.1.6.4(c) (i), as the model pattern, and you have a pentagon in the image, as shown in Fig. 7.1.6.4(c) (ii). When a small value is set for the allowable elasticity, the pattern in Fig. 7.1.6.4(c) (ii) is not found because its geometry is judged different. When a large value is set for the allowable elasticity, however, even the pattern in Fig. 7.1.6.4(c) (iii) is considered to have the same geometry and is found.




Fig 7.1.6.4 (c) Allowable elasticity range

When a large value is set for the allowable elasticity, the GPM Locator Tool needs to take many distorted geometries into consideration and takes longer to find a pattern. Conversely, setting a small value leads to a shorter location time.

When a large value is set for the allowable elasticity, it appears that patterns can be found with high scores. However, this setting is often prone to incorrect location or failure to find a matching pattern. This can also be inferred from the example in Fig. 7.1.6.4(c) (iii). Keep in mind that setting a large value for the allowable elasticity can generally result in frequent incorrect locations.

## Using an emphasis area

After teaching a model pattern, you can specify that attention is to be paid to a specific part of the model pattern. Such a part is called an emphasis area. In the cases described below, specifying an emphasis area enables stable pattern location.

<1> When the position cannot be determined without paying attention to a small part

The position and orientation of both of the patterns shown in Fig. 7.1.6.4(d) can be uniquely determined. Without the parts enclosed within the dotted-line boxes, however, they will end up being “geometries whose position or orientation cannot be determined”. What is distinctive of these parts enclosed within the dotted-line boxes is that they are relatively small in comparison with the entire model pattern.

In such cases, the tool often finds the orientation or position incorrectly, because the pattern as a whole appears to match well, even though the part enclosed within the dotted-line box cannot be seen.




Fig 7.1.6.4 (d) Emphasis area

Humans unconsciously pay attention to these small parts, while the GPM Locator Tool needs to be taught to do so. Such small parts that require special attention are called “emphasis areas”. Teaching emphasis areas to the GPM Locator Tool makes it able to find position and orientation more accurately.

If the part specified as an emphasis area cannot be seen in the image, the pattern is not found, because the tool cannot verify that the correct pattern is found.

<2> When an incorrect pattern is found unless attention is paid to a small part

Suppose that you have two patterns of Figs. 7.1.6.4(e) (i) and (ii) mixed in the image and want the tool to find only the pattern of Fig. 7.1.6.4(e) (ii). You teach the pattern of Fig. 7.1.6.4(e) (ii) as the model pattern. However, the pattern of Fig. 7.1.6.4(e) (i) has basically the same geometry, except for lack of the white circle, and thus gets a score of 90 points or higher, making it difficult for the tool to find only the pattern of Fig. 7.1.6.4(e) (ii). In such a case, specify the white circle, which is contained only in the pattern of Fig. 7.1.6.4(e) (ii), as an emphasis area. Doing so allows the tool to find only the pattern of Fig. 7.1.6.4(e) (ii) having the white circle more reliably.

If the part specified as an emphasis area cannot be seen in the image, the pattern is not found, because the tool cannot verify that the correct pattern is found.

Conversely, if you want only the pattern of Fig. 7.1.6.4(e) (i) to be found, it is impossible for the Locator Tool alone to make this discrimination. In that case, you can use a sub-tool such as a Blob tool to detect the white circle along with a conditional execution tool to reject the found pattern if the white circle is present.



Fig 7.1.6.4 (e) Emphasis area

### Emphasis area threshold

In addition to the score for the entire model pattern, specify a threshold indicating how much of the emphasis area is to be matched for a pattern to be found. The default value is 70 points.

As with the “score threshold”, it is not recommended to set a small value for this threshold (the value should be at least 50 points). Setting too small a value makes the use of an emphasis area meaningless.

### Allowing the position deviation of the emphasis area

When you have an emphasis area to be used for location, you can specify that the tool is to allow an emphasis area even if its position is deviated by two or three pixels with respect to the position of the entire model pattern.

For example, suppose that you teach the pattern in Fig. 7.1.6.4(f) (i) as the model pattern and specify the white triangle as an emphasis area. Without the triangle, the tool can only search for the pattern as a rectangle at  $\pm 90$  degrees. With the triangle, however, the tool can do the search using  $\pm 180$  degrees. In other words, the triangle is used to distinguish between 0 and 180 degrees.



Fig 7.1.6.4 (f) Floating of the emphasis area

To make the situation complicated, however, the triangle is a mark on the label affixed on the cardboard package. Assume that the label is put at the same position on most packages, while it is out of position on some. In the latter case, the emphasis area in the model pattern does not match the triangle in the image, as shown by the dotted line in Fig. 7.1.6.4(f) (ii), and the tool fails to find the pattern because it considers that the emphasis area does not match. By teaching the tool to allow the position deviation of the emphasis area, you can have a pattern found even if a figure identical to the emphasis area is deviated by two to three pixels.


The use of this function causes the tool to take longer to find a pattern. Depending on the nature of the image (particularly complex images with much noise), incorrect location can occur. Before using this function, thoroughly test its effectiveness.

### Area overlap

If the patterns found in an image overlap one another at more than a specified ratio, the GPM Locator Tool leaves only the pattern having the highest score and deletes the others.

For example, suppose that you teach a regular triangle, like the one shown in Fig. 7.1.6.4(g) (i), as the model pattern and specify the orientation range as from  $-180$  degrees to  $+180$  degrees. The GPM Locator Tool recognizes that a pattern matches at three different orientations, as shown in Fig. 7.1.6.4(f) (ii). Since these three patterns overlap one another, however, the tool leaves only one pattern having the highest score, ignoring the others.





**Fig 7.1.6.4 (g) Overlap restriction**

Whether two patterns overlap is determined by whether the area where the patterns' rectangular frames overlap is larger than the ratio specified for overlap restriction. If the ratio of the overlapping area is larger than the specified value, the patterns are judged to overlap. If you specify 100% for overlap restriction, the tool will not delete overlapping patterns unless they fully overlap one another (i.e. they have completely the same geometry).

### Displaying almost found

You can specify that the GPM Locator Tool is to display those patterns that are almost found that barely failed to be found due to the set threshold or range. This function is available only for the test execution of the GPM Locator Tool.


Enabling this function lets you know that there are patterns that failed to be found for the reasons listed below, which helps you adjust the location parameters.

- Pattern whose score is slightly lower than the threshold
- Pattern whose contrast is slightly lower than the threshold
- Pattern whose emphasis area is slightly lower than the threshold
- Pattern whose orientation is slightly outside the range
- Pattern whose scale is slightly outside the range

Note that this function does not guarantee that the tool will display all the patterns “whose score is a certain percentage lower than the threshold” or on any other similar principles. The function is simply intended to let the tool display patterns that it happens to find that do not satisfy the preset conditions but match the criteria listed above during the course of searching for patterns that meet the specified threshold or range.

## 7.2 CURVED SURFACE LOCATOR TOOL

The curved surface locator tool is an image processing tool using gradation (change from light to dark or vice versa). It checks a camera-captured image for the same pattern as a model pattern taught in advance and outputs its location. If you select the curved surface locator tool in the tree view of the setup page for the vision process, a screen like the one shown below appears.



### Input Image

Select the image which is used for training model and detection. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this Curved Surface Locator Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

### 7.2.1 Setting up a Model


Teach the model pattern of the workpiece you want to find.

#### Teaching the model pattern

Teach the model pattern as follows.


- 1 Press F2 LIVE to change to the live image display.
- 2 Place the workpiece near the center of the camera view.
- 3 Press F2 STOP and then press F3 SNAP to snap the image of the workpiece.
- 4 Select [Image + Image Feature] in [Image Display Mode], and adjust the value in [Contrast Threshold] for execution (below [Score Threshold]) to determine the contrast threshold appropriate for the model.
- 5 Enter the determined threshold in [Next] for [Contrast Threshold] for model teaching (above the [Teach Pattern] button), and reset [Contrast Threshold] for execution (below [Score Threshold]) to its original value.
- 6 Tap the [Teach] button.

- 7 Enclose the workpiece within the red rectangle that appears, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.



### Training Stability

The evaluation results for items [Location], [Orientation], and [Scale] of the taught model are displayed as one of the following three levels.




- Good: Can be found stably.
- Poor: Cannot be found very stably.
- None: Cannot be found.

### Training Mask


If the taught model pattern has any unnecessary items in the background, any unwanted or incorrect features not found in all other parts, or any blemishes, you can remove it from the pattern by filling that part with the color of red.



To edit a training mask, tap the [Edit] button on the [Training Mask] line. When an enlarged view of the model pattern appears on the image display control, fill the unnecessary parts of the model pattern with

the color of red. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.



## Model origin

The model origin is the point that numerically represents the location of the found pattern. The coordinates (Row, Column) of the location of the found pattern indicate the location of the model origin. When the found result is displayed on the image,  appears at the model origin.

To move the model origin manually, tap the [Set Org] button. An enlarged view of the model pattern appears on the image display control, and  appears at the current position of the model origin. Move the  with the mouse to move the model origin. For detailed information about the operation method, see Subsection 3.7.8, “Setting Points”.

## 7.2.2 Adjusting the Location Parameters

Adjust the location parameters.

### Model ID

When you want to have taught two or more curved surface locator tools and want to identify which tool the found workpiece corresponds to, you assign a distinct model ID to each tool. The model ID of the found model pattern is reported to the robot controller along with offset data. This enables the robot program to identify the type of the found model.

### Score Threshold

The accuracy of the found result is expressed by a score, with the highest score being 100. The target object is successfully found if its score is equal to or higher than this threshold value. If the score is lower, the target object is not found. Set a value between 10 and 100. The default value is 50. Setting a small value might lead to an inaccurate location.

### Contrast Threshold

Specify the contrast threshold for the search. The default value is 10. If you set a small value, the tool will be able to find the target in obscure images as well but take longer to complete the location process. The minimum value is 1. If the tool is prone to inadequately find blemishes and other unwanted edges with low contrast, try setting a larger value. Those image features whose contrast is lower than the threshold are ignored. Selecting the [Image+Image Feature] in [Image Display Mode] lets you check the image features extracted based on the current threshold.

## Area Overlap

If the ratio of overlap of the found objects is higher than the ratio specified here, then the found result for the workpiece with the lower score is deleted, leaving only the one with the higher score. The ratio of overlap is determined by the area where the models' external rectangular frames overlap. If you specify 100% as the limit value, the found results will not be deleted even if the workpieces overlap.

## Search Window

Specify the range of the area of the image to be searched. The smaller the search window is, the faster the location process runs. The default value is the entire image. To change the search window, tap the [Set] button. When a rectangle appears on the image, adjust its geometry, as when teaching a model. For detailed information about the operation method, see Subsection 3.7.9, "Window Setup".

## Run-Time Mask

Specify an area of the search window that you do not want processed, as an arbitrary geometry. Use this function when you want to specify a search window of an arbitrary geometry, such as a circle or donut-shaped window. The filled area will be masked in the rectangle specified as the search window and will not be subject to the image processing. To change the run-time mask, tap the [Edit] button. For detailed information about the operation method, see Subsection 3.7.14, "Editing Masks".

## Degree of Freedom - Orientation

Specify the range of orientation subject to be searched. The tool searches for a model rotated in the range specified by [Minimum] and [Maximum], with the orientation of the taught model being 0 degrees. The specifiable value range is from -360 to +360 degrees for both [Minimum] and [Maximum]. The narrower the orientation range is, the faster the search process ends. If a range wider than 360 degrees is specified, the range is automatically corrected to 360 degrees when the vision process runs.

If you uncheck this box, the orientation is ignored and the tool searches only for a model having the orientation specified in [Nominal].

By default, the orientation search is enabled and the range is from -180 to +180 degrees.

## Degree of Freedom - Scale

Specify the range of scale to be searched. With the size of the taught model being 100%, the tool searches for a model expanded or reduced by the ratio specified in [Minimum] and [Maximum]. The specifiable value range is from 30% to 160% for both [Minimum] and [Maximum]. The narrower the size range is, the faster the search process ends.

If you uncheck this box, the scale is ignored and the tool searches only for a model having the scale specified in [Nominal].

By default, the scale search is disabled.

## Time-out

If the location process takes longer than the time specified here, the tool ends the process without finding all of the workpieces.

## Result Plotting Mode

Select how the found results are to be displayed on the image after the process is run.

### Plot Everything

The origin, features, and rectangle of the model will be displayed.

**Plot Edges**

Only the origin and features of the model will be displayed.

**Plot Bounding Box**

Only the origin and rectangle of the model will be displayed.

**Plot Only Origin**

Only the origin of the model will be displayed.

**Plot Nothing**

Nothing will be displayed.

**Image Display Mode**

Select the image display mode for the setup page.

**Image**

Only the camera image will be displayed.

**Image+Results**

The camera image and found results will be displayed.

**Image+Gradiations**

The camera image and features of the image will be displayed.

**Pattern**

The taught model pattern will be displayed.

**Pattern+T.Mask**


The taught model pattern, with an area overlaid that is masked as the emphasis area, will be displayed.

**Show Almost Found**

If there is any workpiece that failed to be found because it fell just short of meeting the score, contrast, orientation, scale, and/or other conditions, its test result is displayed. The result appears in a red rectangle on the image.

## 7.2.3 Running a Test

Press F4 FIND to run a test and see if the tool can find workpieces properly.



### Found

The number of found workpieces is displayed.

### Almost Found

The number of workpieces that failed to be found because they were slightly outside the specified range is displayed. "0" is displayed if the [Show Almost Found] check box is not checked.

### Time to Find

The time the location process took is displayed in milliseconds.

### Found Results table

The following values are displayed.

#### Row, Column

Coordinates of the model origin of the found pattern (units: pixels).

#### Angle

Orientation of the found pattern (units: degrees). This is displayed only when the check box for the orientation search is checked.

#### Scale

Scale of the found pattern (units: %). This is displayed only when the check box for the scale search is checked.

#### Score

Score of the found pattern.

---

## 7.2.4 Overridable Parameters

---

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Score Threshold

Specify a number between 10 and 100.

### Contrast Threshold

Specify a number between 1 and 250.

### DOF Angle

Enable/disable selection, minimum angle, maximum angle and nominal angle can be specified. Specify 0 for disable or 1 for enabled. Specify a number between –360 and 360 for the minimum, maximum and nominal angles.

### DOF Scale

Enable/disable selection, minimum scale, maximum scale and nominal scale can be specified. Specify 0 for disable or 1 for enabled. Specify a number between 30 and 160 for the minimum, maximum and nominal scales.

---

## 7.2.5 Setup Guidelines

---

Read these guidelines for a deeper understanding of how the curved surface locator tool works.

---

### 7.2.5.1 Overview and functions

---

This subsection provides an overview of the curved surface locator tool, describing what you can do and how you see objects with this tool.

#### What you can do with the curved surface locator tool


The curved surface locator tool offers image processing capabilities to process images captured by the camera, find the same pattern in an image as the pattern taught in advance, and output the position and orientation of the found pattern. The pattern taught in advance is called a model pattern, or simply a model.

As the position and orientation of the object placed within the camera view changes, the position and orientation of the figure of that object captured through the camera also changes accordingly. The curved surface locator tool finds where the same pattern as the model pattern is in the image fed from the camera.

If the figure of the object in the image has the same pattern as the model pattern, the curved surface locator tool can find it, regardless of differences of the following kinds:

- Linear movement: The position of the figure in the image is different than in the model pattern.
- Rotation: The apparent orientation of the figure in the image is different than in the model pattern.
- Expansion/Reduction: The apparent size of the figure in the image is different than in the model pattern.





**What is the same pattern?**

What does the curved surface locator tool consider the “same pattern” as the model pattern? The curved surface locator tool has the following two criteria to judge whether a pattern is the “same pattern” as the model pattern. When the pattern meets both of the criteria, the curved surface locator tool regards it as the “same pattern”.


- The figure has the same geometry of distribution of gradation.
- The figure has the same orientation of gradation.

An understanding of what the curved surface locator tool considers the same pattern helps you make the tool find eligible patterns with increased stability.


**Figure having the same geometry of distribution of gradation**

First, we will discuss about a “figure having the same geometry of distribution of gradation”.

For example, when you look at a circular cylinder via a camera with coaxial lighting as shown in the left figure below, you can see light/dark distribution as shown in the center figure below. The curved surface locator tool focuses on the part where the tone changes from light to dark or vice versa, that is, gradation. In the right figure below, the hatched area indicates the distribution of gradation.



In the figure below, the three left figures have the same geometry of distribution of gradation, though they have different rotation angles and scales, and the rightmost figure has a different geometry. Whether figures have the same geometry of distribution of gradation depends on whether their original objects have the same geometry.




Conversely, if the original objects differ in geometry but the distributions of gradation in their figures captured by the camera happen to be geometrically identical, the curved surface locator tool judges them to have the same geometry.

### Figure having the same orientation of gradation

Next, we will discuss about a “figure having the same orientation of gradation”.


Suppose you have an image as shown in the figure below. Two circular cylinders are placed side by side and you can see distributions of gradation around the center of each circular cylinder and the valley between the circular cylinders.




In the figure below, these distributions of gradation are indicated with hatched areas. As far as you focus on the geometry, the three distributions of gradation are similar.



When you focus on the orientation of gradation, however, you will not say that they are similar. In the figure below, the orientation of gradation from light to dark is indicated with an arrow ( $\rightarrow$ ). While in the right and left gradation areas, arrows are directed from within outward, in the center gradation area, they are directed inwards. Thus, when you focus on the orientation of gradation, the right and left gradation areas completely differ from the center gradation area. If the patterns differ in the orientation of gradation, the curved surface locator tool judges them different even when their distributions of gradation are geometrically identical.




In the setup page of the curved surface locator tool, a total of eight colors, magenta, cyan, green, yellow, and colors between them, are used to make the orientation of gradation easy to check.



**Missing or extra gradation area**

Suppose that you have the right and left gradation images in the figure below. If you teach the left gradation image as the model pattern and make the curved surface locator tool compare it with the right gradation image, the tool judges that the right pattern is different from the model pattern because the right pattern does not have many gradation areas in the model pattern. Conversely, if you teach the right gradation image as the model pattern and make the tool compare it with the left gradation image, the tool judges that the left pattern is the same as the model pattern because the left pattern have all gradation areas in the model pattern. The curved surface locator tool does not care about extra gradation areas.



**Pattern similarity**

We have discussed the criteria concerning the geometry of distribution, orientation, and missing and extra areas in regard to gradation in patterns. However, not all these criteria need to be satisfied fully. It is virtually impossible to eliminate the difference between patterns. The curved surface locator tool is designed to allow the difference between patterns to a certain degree. In other words, the tool is meant to find “similar patterns”, rather than “the same patterns”.


One measure of similarity is by evaluating how similar the pattern found in the image is to the model pattern. While this is generally called the degree of similarity, the curved surface locator tool refers to this value as a “score”. The score is a numerical value ranging from 0 to 100 points. If the pattern fully matches, it gets a score of 100 points. If it does not match at all, the score is 0. If the pattern in the image has any part that is “distorted because of the lens distortion”, that is “distorted due to parallax”,

that has a “different dark/light polarity”, that is “missing a feature”, or that does not match for any other reason, the score is reduced from 100 points accordingly. If such parts account for 30% of the model pattern, the score is 70 points.

When you have the curved surface locator tool find a matching pattern in an image, you specify a score threshold so that the tool “finds patterns whose score is higher than the specified threshold”.

### 7.2.5.2 Lighting environment

The lighting environment is important for the curved surface locator tool because the tool uses gradation generated by light on the surface of an object. It will be ideal if colored coaxial lighting and a band-pass filter which transmits only that color are used. Coaxial lighting enables the lighting and view directions to match wherever the object is placed. The combination of colored lighting and a band-pass filter enables the influence of the ambient light to be eliminated as much as possible.



### 7.2.5.3 Model pattern

The first thing you do when using the curved surface locator tool is to teach the object you want the tool to find as a model pattern. This subsection provides the guidelines on teaching a model pattern.

#### Teaching a model pattern

Teach the geometry of the workpiece as seen via the camera as a model pattern. To teach a model pattern, snap the image of the workpiece from the camera and train the part of the image you want to register as a model pattern within the rectangle. It is important to place the workpiece near the center of the image. An image seen via the camera is subject to various kinds of distortion such as the distortion of the camera lens. Such distortions become minimal near the center of the image. When teaching a model pattern, therefore, make sure that the workpiece is placed so that it comes as near to the center of the image as possible.

#### Masking the model pattern


As described earlier in “Missing or extra gradation area”, if a gradation area found in the model pattern is missing from the pattern in the image, the curved surface locator tool judges that the pattern is different by as much as that missing gradation area. On the other hand, however, the tool ignores extra gradation areas. Therefore, if there is any extra feature that happens to exist in the image when the model pattern is taught, it is desirable not to include that feature in the model pattern.

The curved surface locator tool allows you to mask a specific part of the image and to remove that part from the model pattern after the model pattern teaching operation. This process is called “masking the model pattern”. If the image taught as a model pattern includes any of the parts described below, mask those parts and remove them from the model pattern.


<1> Part where the orientation of gradation is irregular

When the position, orientation, or background of an object is changed, the orientation of gradation in the figure in the image might change as well. As described earlier, the curved surface locator tool considers a pattern different if its orientation of gradation is different. Therefore, masking the parts where the orientation of gradation is irregular and removing them from the model pattern helps the tool find matching patterns more accurately.


A typical example can be seen in the bulk loading state, where the brightness of the background of an object remarkably changes. For example, the background color of the left object is white and that of the right object is black in the figure below.



Then, the orientation of gradation along the periphery of the left object is opposite to that along the periphery of the right object as shown in the figure below. Therefore, if the periphery of the object is included in the model pattern, the tool will find matching patterns less accurately.



For this reason, mask the gradation area in the periphery of the object when teaching the model pattern, and only the gradation area at the center of the object that is independent of the background is left, which helps the tool find matching patterns accurately.



<2> Part that looks differently for each workpiece

When you capture an image of a workpiece via the camera, the image sometimes might contain a feature, such as a blemish, that looks different for each workpiece or each time the position of the workpiece is


changed. The curved surface locator tool pays attention to such features as well when searching the image for a pattern identical to the taught model pattern. Therefore, removing these features from the model pattern helps the tool find matching patterns more accurately.

Mask the following parts to remove them from the model pattern.

- Blemishes on the workpiece
- Areas that appear illuminated
- Shadows
- Hand-written letters and marks
- Labels

## 7.3 BLOB LOCATOR TOOL

The blob locator tool performs image processing that searches a binarized image for a region (hereinafter called a “blob”) that has the same features, such as area and perimeter, as the specified model. If you select the blob locator tool in the tree view of the setup page for the vision process, a screen like the one shown below appears.



### Input Image

Select the image which is used for training model and detection. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this Blob Locator Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

### 7.3.1 Image Binarization

The blob locator tool converts an input gray-scale image into a binarized black-and-white image before performing image processing. First, set the conditions for the binarization of an image.

#### Threshold Mode

Select the threshold mode in two dropdown boxes. For the left dropdown box, select one of the followings:

**Fixed**

Binarize the image using the specified threshold set in [Threshold value] as it is.

**Auto**

Calculate the threshold automatically for an individual image as brightness changes based on the threshold value specified for the image used for training.

For the right dropdown box, select one of the followings:





**Single**

Binarize the image using a single threshold value. Pixels darker than the threshold become black, and pixels brighter than the threshold become white.





**Dual**

Binarize the image using two (lower and upper) threshold values. Pixels darker than the lower threshold and pixels brighter than the upper threshold become black, and pixels which are brighter than the lower threshold and darker than the upper threshold become white.





**Threshold**

This item is the threshold value for the Single mode. Set the threshold using an integer in the range of 0 to 255. Enter a new value in the field, or change the existing value using     button, so that there is a clear black-and-white distinction between the object and the background.

**Lower Threshold**

This item is the lower threshold value for the Dual mode. Set the threshold for binarization using an integer in the range of 0 to [Upper Threshold]. Enter a new value in the field, or change the existing value using     button, so that there is a clear black-and-white distinction between the object and the background.

**Upper Threshold**

This item is the upper threshold value for the Dual mode. Set the threshold for binarization using an integer in the range of [Lower Threshold] to 255. Enter a new value in the field, or change the existing value using     button, so that there is a clear black-and-white distinction between the object and the background.

**Morphology Operator**

Select the filter to be applied to the binarized image from the options listed below, and specify the filter size in the text box on the right.

**None**

Do not perform morphing.

**Erode**

Erode the black area. Helps reduce the black pixel noise.

**Dilate**

Dilate the black area. Helps reduce the white pixel noise.

**Open**

Erode the black area and then dilate it. This will connect white blobs that are close to touching or disconnect black blobs that are slightly touching.

**Close**

Dilate the white area then erode it. This will connect black blobs that are close to touching or disconnect white blobs that are slightly touching.

## 7.3.2 Teaching a Model

Teach the workpiece to be found as the model.

**Polarity**

Select the color of the blob to be found from the following:

**White on Black**

Find a white blob.


**Black on White**

Find a black blob.

**Train Model**

Teach the model as follows.

- 1 Press F2 LIVE to change to the live image display.
- 2 Place the workpiece near the center of the camera view.
- 3 Press F2 STOP and then press F3 SNAP to snap the image of the workpiece.
- 4 Set Polarity to [Black on White].
- 5 Tap the [Teach] button.
- 6 Enclose the workpiece within the displayed red rectangle, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.





### Trained model info.

The feature information of the trained model is displayed. Together with the image enclosed by a rectangle when training the model, the feature information of the trained blob is displayed.

## 7.3.3 Adjusting the Location Parameters

---

Adjust the location parameters.

### Model ID

If you want to train more than one blob locator tool and identify which blob locator tool has found the workpiece, set a different model ID to each blob locator tool. Since the model ID of the blob locator tool that has found the workpiece is sent to a vision register along with the offset data, the robot program can identify the model ID of the found workpiece.

### Use Computed RT Mask

This item is available only when this blob locator tool is a child tool of another blob locator tool. When this check box is checked, a blob found by the parent blob locator tool is used as the search window and the runtime mask of this blob locator tool. Usually it is checked off.

### Search Window

Specify the range of the area of the image to be searched. The narrower the range is, the faster the location process ends. The default value is the entire image. To change the search window, tap the [Set] button. When a rectangle appears on the image, adjust its geometry, as when teaching a model. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.

### Runtime Mask

Specify an area of the search window that you do not want processed, as an arbitrary geometry. Use this function when you want to specify a search window of an arbitrary geometry, such as a circle- or donut-shaped window. The filled area will be masked in the rectangle specified as the search window and will not be subject to the image processing. To change the run-time mask, tap the [Edit] button. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.

### Calculate Angle

Specify whether to calculate the orientation of the found blob. If you check this box, the orientation of the blob will be calculated. The blob locator tool can recognize orientation in the range from  $-90$  to  $+90$  degrees.

If you uncheck this box, the long axis length, short axis length, and elongation of the found blob will not be calculated.

### Angle Calc. Method

Specify the angle calculation method from the following:

#### Axis of Inertia

The axis of inertia of the found blob is calculated, and the direction of the axis is used as the angle of the found blob.

#### Minimum Rectangle

The minimum rectangle that circumscribes the found blob is calculated, and the direction of the rectangle is used as the angle of the found blob.

## Find if Touching Win.

The blob locator tool outputs the center of mass of the blob as the found location. If the blob is in contact with the search window, it is impossible to know how much of the blob extends out of the search window, in which case the center of mass cannot be calculated accurately. By default, therefore, the blob locator tool ignores any blob touching the search window. However, checking this box causes the tool to find blobs touching the search window as well. Use this function when you want to measure the area of the black region in the image, rather than finding the location of a blob.



### CAUTION

Uncheck this box if you want to find the location of a workpiece using the blob locator tool. By default, the box is not checked.

## DOF – Area

Specify the range of area values for judging the blob to match the model. If the area of the found blob is within the range specified by [minimum] and [Maximum], the location succeeds. If you uncheck the box, the area will not be checked.

## DOF – Perimeter

Specify the range of perimeter values for judging the blob to match the model. If the perimeter of the found blob is within the range specified by [Minimum] and [Maximum], the location succeeds. If you uncheck the box, the perimeter will not be checked.

## DOF – Circularity

The degree of circularity is calculated by dividing the  $4\pi$  area by square of perimeter and represents how closely the found blob resembles a circle. If the blob is a perfect circle, this value is 1.0. The more complex the blob becomes in geometry, the smaller the value becomes.

Specify the range of degrees of circularity for judging the blob to match the model. If the degree of circularity of the found blob is within the range specified by [Minimum] and [Maximum], the location succeeds. If you uncheck the box, the degree of circularity will not be checked.

## DOF – Semi Major

Specify the range of semi-major axis length values for judging the blob to match the model. If the semi-major axis length of the found blob is within the range specified by [Minimum] and [Maximum], the location succeeds. If you uncheck the box, the semi-major axis length will not be checked. When the minimum rectangle is selected in the Angle Calc Method, the semi-major axis length means the radius of the minimum rectangle.

## DOF – Semi Minor

Specify the range of semi-minor axis length values for judging the blob to match the model. If the semi-minor axis length of the found blob is within the range specified by [Minimum] and [Maximum], the location succeeds. If you uncheck the box, the semi-minor axis length will not be checked. When the minimum rectangle is selected in the Angle Calc Method, the semi-minor axis length means the radius of the minimum rectangle.

## DOF – Elongation

Elongation is calculated by dividing the semi-major axis length by the semi-minor axis length and represents how slender the found blob is. The longer the blob is, the larger the value becomes. Specify the range of elongation values for judging the blob to match the model. If the elongation of the found blob is within the range specified by [Minimum] and [Maximum], the location succeeds. If you uncheck the box, the elongation will not be checked.

## Display Mode

Select how the found result is to be displayed on the image after the process is run.

**Found Position**

Only the center of mass of the blob will be displayed.

**Contour**

Only the contour of the blob will be displayed.

**All**

Both the center of mass and contour of the blob will be displayed.

**Image Display Mode**

Select the image display mode for the setup page.

**Grayscale Image**

The camera image will be displayed as it is.

**Grayscale Im. + Results**

The camera image and found results will be displayed.

**Grayscale + Threshold**

The camera image and masks are displayed. The white areas of binarized image are displayed as green masks.

**Binary Image**

The camera image will be binarized when displayed.

**Binary Image + Results**

The camera image and found results will be binarized when displayed.

**Model Image**


The taught model pattern will be displayed.

**Convert to mm**

Usually this item is not displayed. If you load a vision process trained on an older version of iRVision on which the blob locator tool had not supported the millimeter conversion, the vision process has been included a blob locator tool, and [Measurements in mm] of the vision process has been enabled, this item is displayed. In that case, the measurements of blob locator tool aren't converted to millimeters by default. Check this item if you want to configure the blob locator tool to convert the measurements to millimeters.

## 7.3.4 Running a Test

Press F4 FIND to run a test and see if the tool can find blobs properly.



### Found

The number of found blobs is displayed.

### Time to Find

The time the location process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

#### Row, Column

Coordinate values of the center of mass of the found blob (units: pixels).

#### Score

Score of the found blob.

#### Angle

Orientation of the found blob. This is displayed only when the [Calculate Angle] check box is checked.

#### Area

Area of the found blob. By default, it is in pixels. When [Measurements in mm] is enabled in the parent vision process, it is converted to millimeters.

#### Perimeter

Perimeter of the found blob. By default, it is in pixels. When [Measurements in mm] is enabled in the parent vision process, it is converted to millimeters.

#### Circularity

Degree of circularity of the found blob.

**Semi-major**

Long axis length of the found blob. By default, it is in pixels. When [Measurements in mm] is enabled in the parent vision process, it is converted to millimeters.

**Semi-minor**

Short axis length of the found blob. By default, it is in pixels. When [Measurements in mm] is enabled in the parent vision process, it is converted to millimeters.

**Elongation**

Elongation of the found blob.

**NOTE**

- 1 If the tool fails to find the object, run the find test with all the search range boxes unchecked. This slows down the process but it can identify which item causes the location to fail. With the DOF parameters unchecked, all the blobs in the image are found. Adjust the parameters to an appropriate range until only the desired blobs are detected.
- 2 When [Measurements in mm] is enabled in the parent vision process, Area, Perimeter, Semi-major and Semi-minor are converted to millimeters. Semi-major and Semi-minor can be converted accurately. Area and Perimeter are approximate values calculated by using the average scale.
- 3 When you enable/disable [Measurements in mm] after teaching the model blob, you need to reteach the model blob.

**7.3.5 Overridable Parameters**

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

**Area**

Enable/disable selection for area checking, minimum area and maximum area can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number equal to or larger than 0 for minimum and maximum area.

**Perimeter**

Enable/disable selection for perimeter checking, minimum perimeter and maximum perimeter can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number equal to or larger than 0 for minimum and maximum perimeter.

**Circularity**

Enable/disable selection for circularity checking, minimum circularity and maximum circularity can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number between 0 and 1 for minimum and maximum circularity.

**Semi Major**

Enable/disable selection for semi-major axis length checking, minimum semi-major axis length and maximum semi-major axis length can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number equal to or larger than 0 for minimum and maximum semi-major axis length.

## Semi Minor


Enable/disable selection for semi-minor axis length checking, minimum semi-minor axis length and maximum semi-minor axis length can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number equal to or larger than 0 for minimum and maximum semi-minor axis length.

## Elongation

Enable/disable selection for elongation checking, minimum elongation and maximum elongation can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number equal to or larger than 0 for minimum and maximum elongation.

# 7.4 LINE LOCATOR TOOL

Line Locator Tool is an image processing tool that finds a line segment with the length taught in advance within a camera-captured image, and outputs the position and direction of the line. If you select a line locator tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.



## Input Image

Select the image which is used for training model and detection. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this Line Locator Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

## 7.4.1 Setting up a Model

Teach the type and the length of the line segment to find. Unlike a GPM Locator Tool, features in an image are not taught as a model.

## Line Type

Select the type of line segment to find.

### Single

A bordering line between a dark region and a light region is detected. A 0-degree model is generated as a vertical straight line with a dark region on the left and a light region on the right of the line.

### Double (Step)

Two parallel lines are considered as a single thick line through the center of the two lines.

A 0-degree model is generated as a vertical straight line with the line having brightness between the brightness of the left and right regions, where the left region is darker and the right region is lighter than the line.

### Double (Dark)


Two parallel lines are considered as a single thick line through the center of the two lines.

A straight dark line is found with this line type. A 0-degree model is generated as a vertical straight line with the line having brightness darker than the brightness of the left and right regions.

### Double (Light)

Two parallel lines are considered as a single thick line through the center of the two lines.

A straight light line is found with this line type. A 0-degree model is generated as a vertical straight line with the line having brightness lighter than the brightness of the left and right regions.




## Teaching the model line length

Teach the model line length as follows.

- 1 Press F2 LIVE to change to the live image display.
- 2 Place the workpiece near the center of the camera view.
- 3 Press F2 STOP and then F3 SNAP to snap the image of the workpiece.
- 4 Tap the [Train] button.
- 5 Enclose the workpiece within the red rectangle that appears, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.12, “Single Line Setup” and 3.7.13, “Double Line Setup” .

The length of the rectangular window in the direction perpendicular to the rotation handle will be the length of the line taught as the model pattern.



### Line Width

When one of the double line types is selected as the [Line Type], the width of a line to be found is specified in pixels. Set a value between 1 and 50.

### Adjust Width

When one of the double line types is selected as the [Line Type], the line width is automatically adjusted to the found line width by tapping the [Adjust] button.

#### NOTE

- 1 The line width is automatically adjusted by finding the line internally. Specify a width close to the actual width in [Line Width] before executing.
- 2 The model origin is automatically set at the center of the trained line segment, and it cannot be changed. The coordinate values (Row, Column) of the found result indicate the location of the model origin. When the found result is displayed on the image, a + mark appears at the model origin.

## 7.4.2 Adjusting the Location Parameters

Adjust the location parameters.

### Model ID

When you have taught two or more GPM Locator tools and want to identify which tool was used to detect the workpiece, assign a distinct model ID to each tool. The model ID of the tool, which found the workpieces, is reported to the robot controller along with offset data. This enables the robot program to identify the type of the found workpieces.

### Score Threshold

The accuracy of the found result is expressed by a score, with the highest score being 100. The target line is successfully found if its score is equal to or higher than this threshold value. If the score is lower, the target line is not found. Set a value between 10 and 100. The default value is 70. Setting a small value might lead to inaccurate location.

### Contrast Threshold

Specify the contrast threshold for the search. Set a value between 1 and 200. The default value is 50. If you set a small value, the tool will be able to find the target in obscure images as well but take longer to



complete the location process. If the tool is prone to inadequately find blemishes and other unwanted edges with low contrast, try setting a larger value. Those image features whose contrast is lower than the threshold are ignored. Selecting the [Pattern] in [Image Display Mode] lets you check the image features extracted based on the current threshold.

### **Area Overlap**

If the ratio of overlap of the found lines is higher than the ratio specified here, then the found result for the line with the lower score is deleted, leaving only the one with the higher score. The ratio of overlap is determined by the area where the models' external rectangular frames overlap. Set a value between 10 and 100. The default value is 75. If you specify 100% as the limit value, the found results will not be deleted even if the lines overlap.

### **Elasticity**

Specify a pixel value to indicate how much the pattern in the image is allowed to be deviated (distorted) in geometry from the taught model. Set a value between 0.1 and 5.0. The default value is 1.5. Setting a large value enables the tool to find the target in images that are greatly deviated in geometry. However, the larger the value is, the more likely inaccurate location becomes.

### **Search Window**

Specify the range of the area of the image to be searched. The narrower the range is, the faster the location process ends. When the model is taught by tapping the [Train] button, the search window is automatically set to the length of the line with the width of 100 pixels, with the center of the window at the model origin of the line. To change the search window, tap the [Set] button. When a rectangle appears on the image, adjust its geometry, as when teaching a model. For detailed information about the operation method, see Subsection 3.7.9, "Setting a Window".

### **Orientation**

Specify the range of orientation subject to be searched. The tool searches for a model rotated in the range specified by [Minimum] and [Maximum], with the orientation of the taught model (vertical line in the image) being 0 degrees. The specifiable value range is from -360 to +360 degrees for both [Minimum] and [Maximum]. The narrower the orientation range is, the faster the search process ends. If a range wider than 360 degrees is specified, the range is automatically corrected to 360 degrees when the vision process runs.

If you uncheck this box, the orientation is ignored and the tool searches only for a model having the orientation specified in [Nominal].

By default, the orientation search is enabled and the range is from -180 to +180 degrees.

### **Result Plotting Mode**

Select how the found results are to be displayed on the image after the process is run.

#### **Line**

The found line will be displayed.

#### **Line and Model Origin**

The line and the origin will be displayed.

#### **Edges**

Matched edges will be displayed in green and mismatched edges will be displayed in red.

**Edges and Model Origin**

The edges and the origin will be displayed.

**Image Display Mode**

Select the image display mode for the Setup Page.

**Image**

Only the camera image will be displayed.

**Image+Edges**

The camera image and the features within the search window will be displayed.

When the search window is not taught, the image and the features within the image will be displayed.

**Image+Results**

The camera image and the found results will be displayed.

**Show Almost Found**

If there is any line that failed to be found because it fell just short of meeting the score, contrast, orientation, and/or other conditions, its test result is displayed. The result appears in a red rectangle on the image.

**Part of Interest**

When the line locator tool is a child tool of another locator tool, and if the parent locator tool finds multiple found results, the result to display on the image display can be selected. If the parent locator tool has only one found result, or if the parent tool is not a locator tool, then this item is not shown.

**All**


The results of all parent tool results and the corresponding line locator tool results are displayed. This option is selected by default.

**Pn**

Parent locator tool results in the image display are labeled with a "P" followed by an index number. The "n" represents the index number, and this option is added for how many ever parent results are found. When the parent locator tool finds multiple results, selecting this option will only display the corresponding parent result and the locator tool results based on the parent result.

## 7.4.3 Running a Test

Press F4 FIND to run a test and see if the tool can find lines properly.



### Time to Find

The time the location process took is displayed in milliseconds.

### Num Found

The number of found lines is displayed.

### Num Almost Found

The number of lines that failed to be found because they were slightly outside the specified range is displayed. "0" is displayed if the [Show Almost Found] check box is not checked.

### Found Result Table

The following values are displayed.

#### Row(V), Column(H)

Coordinate values of the model origin of the found line (units: pixels).

#### Score

Score of the found line.

#### Contrast

Contrast of the found line.

#### Fit Error

Deviation of the found line from the model line (units: pixels).

#### Angle

Orientation of the found line (units: degrees). This is displayed only when the box for the orientation search is checked.

---

## 7.4.4 Overridable Parameters

---

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Score Threshold

Specify a number between 10 and 100.

### Contrast Threshold

Specify a number between 1 and 250.

### Elasticity

Specify a number between 1 and 5.

### DOF Angle

Enable/disable selection, minimum angle, maximum angle and nominal angle can be specified. Specify 0 for disable or 1 for enabled. Specify a number between -360 and 360 for the minimum, maximum and nominal angles.

---

## 7.4.5 Guideline

---

Read these guidelines for a deeper understanding of how a line locator tool works.

### What you can do with the line locator tool

The Line Locator Tool offers image processing capabilities to process images captured by the camera, find the line in an image as the pattern and length taught in advance (or longer), and output the position and orientation of the found line. The pattern taught in advance is called a model pattern, or simply a model. Unlike a GPM Locator Tool which generates a model pattern based on the object captured in the image, the Line Locator Tool generates and stores a model pattern internally based on the specified line type and length.

A found line is not of a finite length, but rather a segment with an infinite length in the direction of the found orientation. This feature can be utilized in such applications where the intersection of two lines or the angle formed by two lines is to be found.

### Line locator tool result


The result of a line locator tool is the position of the model origin (Vt, Hz) and the orientation of the line. However, the position of the model origin can vary along the length of the line.

The position information output by a line locator tool has a different meaning from the position information output by GPM locator tools. Where as a GPM locator tool outputs the position as a “point” in the image, the line locator tool outputs the position as a “line,” and *iRVision* differentiates them as two types of positions.

In essence, a “line” does not have definite position information. For practical purposes, the “line” position can be used to calculate the offset, or to dynamically shift the search window of a child tool. However, keep in mind that the position of a line is indeterminable and could be anywhere on a given line.

## 7.5 COMBINATION LOCATOR TOOL

Combination Locator Tool is a locator tool that customizes the output results by combining the results of multiple locator tools. This locator tool collaborates with the child locator tools to function as a single locator tool. The child locator tools do all the image processing, and the combination locator tool simply outputs the customized results. If you select the combination locator tool in the tree view of the setup page for the vision process, a screen like the one shown below appears.




### 7.5.1 Setup

Setup the combination locator tool.

#### Adding child tools

When a combination locator tool is created, two line locator tools and a position calculation tool are added by default as its child tools. The output results can be customized by changing the combinations of child tools.

The following tree view is used when the [Line Locator 1] and [Line Locator 2] detect lines and [Position Calculation 1] calculates the intersection of the lines and [Combination Locator Tool 1] outputs the result of the calculation.




#### Locator 1

Select which child position calculation tool results to output as the result of the combination locator results. The found result of Locator 1 is output in that order. The results of other child tools that are not selected are not output.

For detail information of the Line Locator Tool and the Position Calculation Tool, please refer to Subsection 7.4 “Line Locator Tool” and 7.24 “Position Calculation Tool”.

## 7.5.2 Running a Test

Press F4 FIND to run a test and see if the tool can output the result of the selected position locator tool properly.



### Time to Find

The time the location process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

#### Locator

Name of the locator tool that output the result.

#### Row, Column

Coordinate values of the model origin of the found pattern (units: pixels).

#### Angle

Orientation of the found pattern (units: degrees).

#### Scale

Scale of the found pattern (units: %).

If the selected command tool result does not have the size parameter, 100 is displayed.

#### Aspect Ratio

Aspect ratio of the found pattern (units: %).


If the selected command tool result does not have the aspect ratio parameter, 100 is displayed.

## 7.5.3 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.6 EDGE PAIR LOCATOR TOOL

The edge pair locator tool finds two parallel lines (edge pair) that are the same as the trained model pattern from an image and outputs the center position of the edge pair and the distance between the edges. It is mainly used for length measurement. If you select the edge pair locator tool in the tree view of the setup page for the vision process, a page like the one shown below appears.



### Input Image


Select the image which is used for training model and detection. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this Edge Pair Locator Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

### 7.6.1 Setting the Search Window

Set the area to be searched for an edge pair.


#### Search Area

Specify the range of the area of the image to be measured. The shorter the measurement area is in height, the more accurately the position of the edges is found. To change the measurement area, tap the [Set] button. When a red rectangle appears on the image, enclose the area containing the edge pair to find with the displayed rectangle, and press F4 OK. The rectangle should be placed so that the centerline that indicates the rotation angle of the rectangle is parallel to the length to measure, as shown below. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.



## 7.6.2 Teaching a Model

Teach the edge pair to be found as the model. The procedure for teaching the model is as follows.



- 1 Tap the [Train] button.
- 2 The edge found in the measurement area is displayed in the window. First, move the left tip of the red line to the left edge of the edge pair used as the model.
- 3 Next, move the right tip of the red line to the right edge of the edge pair used as the model, and then press F4 OK.

When the model teaching process is completed, the information on the taught model is displayed.

### Model Image

The edge pair to be found and the distance between the paired edges are displayed. The polarity of the edges to be found (from white to black or black to white) can be seen.

### Standard Length

It is the distance between edges of the model edge pair. At runtime, if two or more edge pair candidates are found in the search window and they overlap each other, priority is given to the edge pair whose distance between edges is closest to the standard length.

### Left/Right Edge Contrast

It is the contrast of edges of the model edge pair. At runtime, if two or more edge pair candidates are found in the search window and they overlap each other, priority is given to the edge pair whose contrast is closest to that of the model edge pair.

## 7.6.3 Adjusting the Location Parameters

Adjust the location parameters.

### Model ID

When you want to have taught two or more edge locator tools and want to identify which tool the found workpiece corresponds to, you assign a distinct model ID to each tool. The model ID of the found model pattern is reported to the robot controller along with offset data. This enables the robot program to identify the type of the found model.



## Contrast Threshold

Specify the contrast threshold for the search. The default value is 30. If you set a small value, the tool will be able to find the edges with less contrast but it will take longer to complete the location process. The minimum value is 1. If the contrast is set too low false edges may be found, if this is the case raise contrast threshold. The edges whose contrast is lower than the threshold are ignored.

## Maximum Length to Search

Specify the maximum inter-edge distance of the edge pair to be found. When a model edge pair is taught, a value that is 105% of the standard length is input as the default value.

## Minimum Length to Search

Specify the minimum inter-edge distance of the edge pair to be found. When a model edge pair is taught, a value that is 95% of the standard length is input as the default value.

## Result Plotting Mode

Select the image display mode for the Setup Page.

### Edge

The search area, the measured edge pair distance (green arrow), and the center position of the found edge pair are displayed.

### Edges + Arrow

The scan direction (blue arrow), the measured edge pair distance (green arrow), and the center position of the found edge pair are displayed.

### Edges + Proj. + Grad.

In addition to the information presented in the Edge mode, graphs are displayed that show changes in contrast and gradient of the search area.

### Edges + Proj. + Grad.+ Arrow

In addition to the information presented in the Edges + Arrow mode, graphs are displayed that show changes in contrast and gradient of the search area.

## Result Show Mode

Select the mode for displaying the result on the setup window.

### Found Results

Of the found edge pairs, the one to be output as the found result is displayed.

### All Edge Pairs


All the edge pairs whose polarity (from white to black or black to white) matches that of the model edge pair are displayed, irrespective of the length.

## Result to Display

If the edge pair locator tool is inserted as a child tool of a locator tool, and if the parent locator tool outputs multiple found results, you can display the result corresponding to a specific found result of the parent tool by selecting a result number. Selecting [All] displays the results for all the found results of the parent locator tool.

## 7.6.4 Running a Test

Press F4 FIND to run a test and see if the tool can find workpieces properly.



### Time to Find

The time the location process took is displayed in milliseconds. This only represents the time it took to process the image and does not include the time it took to snap it.

### Found result table - Found Results

For the edge pair locator tool, the items displayed in the found result table differ depending on the item selected in [Result Show Mode]. When [Found Results] is selected, the found edge pair to be output as the found result is displayed.

### Row(V), Column(H)

Coordinates of the center of mass of the found edge pair (unit: pixel).

### Score

Score of the found edge pair.

### Angle

Rotation angle of the measurement area at the time when the location process is executed, relative to the measurement area at the time of setup.

### Length

Inter-edge distance of the found edge pair (unit: pixel).

### Contrast

Average contract of the found edge pair.

### Edge 1 Row

Vertical-direction coordinate of the left edge of the found edge pair (unit: pixel).

### Edge 1 Col

Horizontal-direction coordinate of the left edge of the found edge pair (unit: pixel).

**Edge 2 Row**

Vertical-direction coordinate of the right edge of the found edge pair (unit: pixel).

**Edge 2 Col**

Horizontal-direction coordinate of the right edge of the found edge pair (unit: pixel).

**Found result table - All Edge Pairs**

If you select [All Edge Pairs], all the edge pairs whose polarity (from white to black or black to white) matches that of the model are displayed, irrespective of the length.

**Length**

Distance between found edge pairs (unit: pixel).

**Contrast 1**

Average contrast of the left edge of the found edge pair.

**Contrast 2**

Average contrast of the right edge of the found edge pair.

---

**7.6.5 Overridable Parameters**

---

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 "VISION OVERRIDE" and 9.2.2.8 "OVERRIDE" for details.

**Contrast Threshold**

Specify a number between 1 and 250.


---

**7.7 HISTOGRAM TOOL**

---

The histogram tool measures the brightness of an image. When the histogram tool is located below a locator tool, such as the GPM Locator Tool, in the tree view, the measurement window of the histogram tool moves dynamically according to the found result of the parent locator tool.

If you select the histogram tool in the tree view of the setup page for the vision process, a screen like the one shown below appears.



## Input Image

Select the image which is used for training area to measure brightness. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this Histogram Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

## 7.7.1 Setting the Measurement Area

### Use Computed RT Mask

This item is available only when this histogram tool is a child tool of a blob locator tool. When this check box is checked, a blob found by the parent blob locator tool is used as the measurement area and the runtime mask of this histogram locator tool. Usually it is unchecked.


### Area to measure brightness

Set the area whose brightness is to be measured, as follows.

- 1 Press F2 LIVE to change to the live image display.
- 2 Place the workpiece near the center of the camera view.
- 3 Press F2 STOP and then press F3 SNAP to snap the image of the workpiece.
- 4 Tap the [Set] button for [Area to measure brightness].

The parent locator tool runs automatically, and a red + mark appears on the found object. If the location fails, an alarm message to that effect is displayed and the measurement area setting is stopped.

- 5 Select the area to measure, using the displayed red rectangle, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.



The values shown in [Reference Position] indicate the position of the object that the parent locator tool found when the measurement area was specified.

### Run-Time Mask

Specify an area of the measurement window that you do not want processed as an arbitrary geometry. The filled area will be masked in the rectangle specified as the measurement window and will not be subject to the image processing. To change the run-time mask, tap the [Edit] button. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.

### Filter Type

Before measuring a histogram, you can apply a filter to the image.

#### None

Do not use a filter.

#### Blur

Apply a filter to blur the image. Blurring an image obscures brightness differences in the image, thus helping alleviate the effect of noise.

### Times

Specify the number of times the filter is to be applied. Currently, this item is available only when [Blur] is set in [Filter Type]. The larger the number, the stronger the blurring effect. The specifiable value range is 1 to 10.

### Range of Interest

Specify the brightness range of interest from 0 (dark) to 255 (bright). [Within Range (%)], described later, indicates the percentage of pixels within the specified brightness range.

### Image Display Mode

Select the type of image to be displayed in the image display frame from the following two types:

#### Original Image


Display the image as it is captured by the camera.

## Filtered Image

Display the image resulting from applying a specified filter to the original image.

## 7.7.2 Running a Test

Run a measurement test to see if the tool can find brightness properly.



### Time to Find

The time the histogram measurement took is displayed in milliseconds.

### Measurement Result Table

The following values are displayed.

#### Pixels

Total number of pixels in the measured area.

#### Max.

Brightness of the brightest pixel in the measured area.

#### Min.

Brightness of the darkest pixel in the measured area.

#### Median

Median of the brightness of the measured area.

#### Mode

Most common brightness of pixels in the measured area.

#### Mean

Mean brightness of the measured area.

#### Std. Dev.

Standard deviation in brightness of the measured area.

### In Range (%)

Ratio of the number of pixels within the brightness range specified in [Range of Interest] to the total number of pixels in the area whose brightness has been measured.

### Out of Range (%)


Ratio of the number of pixels outside the brightness range specified in [Range of Interest] to the total number of pixels in the area whose brightness has been measured.

## 7.7.3 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.8 EDGE HISTOGRAM TOOL

The edge histogram tool measures the changes (gradients) in brightness of an image. When the edge histogram tool is located below a locator tool, such as the GPM locator tool, in the tree view, the measurement window of the edge histogram tool shifts according to the found result of the parent locator tool. If you select the edge histogram tool in the tree view of the setup page for the vision process, a screen like the one shown below appears.



### Input Image

Select the image which is used for training area to measure brightness. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this Edge Histogram Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

## 7.8.1 Setting the Measurement Area


### Use Computed RT Mask

This item is available only when this edge histogram tool is a child tool of a blob locator tool. When this check box is checked, a blob found by the parent blob locator tool is used as the measurement area and the runtime mask of this edge histogram locator tool. Usually it is checked off.

### Measurement Area

Set the area whose gradients are to be measured, as follows.

- 1 Press F2 LIVE to change to the live image display.
- 2 Place the workpiece near the center of the camera view.
- 3 Press F2 STOP and then press F3 SNAP to snap the image of the workpiece.
- 4 Tap the [Set] button for [Measurement area].
- 5 The parent locator tool runs automatically, and a red + mark appears on the found object.  
If the location fails, an alarm message to that effect is displayed and the measurement area setting is stopped.
- 6 Enclose the workpiece within the red rectangle that appears, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, "Window Setup".



The values shown in [Reference position] indicate the position of the object that the parent locator tool found when the measurement area was specified.

### Run-Time Mask

Specify an area of the measurement window that you do not want measured by the edge histogram. The masked area of the measurement window will not be subject to the image processing of the edge histogram. To change the run-time mask, tap the [Edit] button. For detailed information about the operation method, see Subsection 3.7.14, "Editing Masks".


### Mode

A gradient has two elements - contrast and direction. Of these, specify the element whose distribution is to be measured.




## Contrast

The distribution of gradient contrasts is measured. A gradient contrast is represented by a value from 0 (weak) to 255 (strong). As shown in the example of the “gradient contrast image” in the following figure, the value becomes larger at a place where there is a greater contrast between brightness and darkness.



## Direction

The distribution of gradient directions is measured. A gradient direction is represented by a value from 0 to 255. Numbers become larger as they go counterclockwise on the screen. Which direction is represented by each individual value is set in [Center of histogram means].



## Image Preprocessing

As the preprocessing before gradient distribution measurement, a filter can be applied to the image. This suppresses the disturbance of the gradient distribution due to fine noise. The following three settings are available:

### None

Measure the gradient distribution with the original image without preprocessing.

### Gaussian

Apply a Gaussian filter as the preprocessing. This makes it easier to save the original gradient distribution than with [Blur]. This setting is recommended when measuring a workpiece for which the original gradient distribution is relatively stable.

### Blur

Apply a blurring filter to the image as the preprocessing. This produces a greater effect in averaging the original gradient distribution than does [Gaussian]. This setting is recommended in

the case of an image of a casting surface or other similar material where there are many gradients that do not faithfully represent the nature of the workpiece.

### Times


Specify the number of times the filter is to be applied as the preprocessing. Applying the filter more times produces a greater noise reduction effect but leads to a reduced gradient contrast. The specifiable value range is 1 to 10.

### Range of Interest

Specify the contrast or direction range of interest in 256 steps from 0 to 255. [Within Range(%)], described later, indicates the percentage of pixels within the specified brightness range.


### Dir. at Middle Value

This field is valid only when [Direction] is selected for [Mode]. In the direction image, directions of the gradient distribution are represented with grayscale values from 0 to 255. This item is used to specify which gradient direction is assigned to which grayscale value. For example, when [Upward] is specified, the gradient direction with waning brightness toward the top of the image is assigned to 128, which is the middle value, and plotted at the center of the histogram. Select the direction that best represents the characteristics of the range to be measured. For your reference, the result of the histogram chart when each option is selected is described for the image shown below. Since majority of the gradient direction in the area enclosed by the red rectangle is right-to-left (leftward), the peak is plotted at the center of the histogram chart when [Leftward] is selected.




### Upward

The gradient direction with waning brightness toward the top of the image (upward) is plotted at the grayscale value of 128. The grayscale value of 64 represents the rightward gradients, and the grayscale value of 192 represents the leftward gradients. The grayscale values 0 and 255 represent downward gradients.




### Leftward

The gradient direction with waning brightness toward the left of the image (leftward) is plotted at the grayscale value of 128. The grayscale value of 64 represents the upward gradients, and the grayscale value of 192 represents the downward gradients. The grayscale values 0 and 255 represent rightward gradients.




### Downward

The gradient direction with waning brightness toward the down of the image (downward) is plotted at the grayscale value of 128. The grayscale value of 64 represents the leftward gradients, and the grayscale value of 192 represents the rightward gradients. The grayscale values 0 and 255 represent upward gradients.



## Rightward

The gradient direction with waning brightness toward the right of the image (rightward) is plotted at the grayscale value of 128. The grayscale value of 64 represents the downward gradients, and the grayscale value of 192 represents the upward gradients. The grayscale values 0 and 255 represent leftward gradients.



## Minimum Contrast

This item is valid only when [Direction] is set for [Mode]. Pixels whose gradient contrast is lower than this value are not used for gradient direction measurement. The default value is 10, which may be adjusted as necessary.

## Image Display Mode

Select the type of image to be displayed in the image display frame from the following three types:

### Original Image

Display the image as it is captured by the camera.

### Edge Image


Display the image whose gradient distribution is to be measured actually. The image to be displayed differs depending on the setting of [Mode]. For information about the image to be displayed, see the description of [Mode] given earlier.

### Preprocessed Image

Display the image to which the specified filter has been applied as the preprocessing.

## 7.8.2 Running a Test

Press F4 FIND to run a measurement test and see if the tool can measure the gradient distribution properly.



### Time to Find

The time the gradient distribution measurement took is displayed in milliseconds.

### Measurement Result Table

The following values are displayed.

#### Pixels

Total number of pixels in the area in which the gradient distribution measurement was made. The unit is the pixel. Note that pixels whose contrast is lower than the minimum contrast are excluded from the gradient distribution measurement and not included in the total number.

#### Max.

Maximum value in the gradient distribution measurement area.

#### Min.

Minimum value in the gradient distribution measurement area.

#### Median

Median value in the gradient distribution measurement area.

#### Mode

Value found the most number of times in the gradient distribution measurement area.

#### Mean

Mean value in the gradient distribution measurement area.

#### Std. Dev.

Standard deviation of the values in the gradient distribution measurement area.


**In Range (%)**

Ratio of the number of pixels within the range specified in [Range of Interest] to the total number of pixels in the gradient distribution measurement area.


**Out of Range (%)**

Ratio of the number of pixels outside the range specified in [Range of Interest] to the total number of pixels in the gradient distribution measurement area.

Shown below is an example of the test run using [Direction]. Since the found results of the parent tool are reflected on the direction calculation, there is no significant change in the histogram, even if the workpiece is rotated.



On the other hand, if there is any other object in the measurement area, the histogram changes as shown below. Paying attention to this change helps identify the overlap or other condition of the workpieces.



### 7.8.3 Overridable Parameters


---

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.9 CONDITIONAL EXECUTION TOOL

The conditional execution tool evaluates the result of the histogram or other tool based on specified conditions and, only if the conditions are met, executes the specified processing.

If you select the conditional execution tool in the tree view of the setup page for the vision process, a screen like the one shown below appears.



### 7.9.1 Setting the Parameters

Set the conditions to evaluate and the processing to be performed when the conditions are met.

#### Measurements

In [Measurements], select the value or values to be evaluated with conditional statements. Up to five values can be specified.

- 1 From the drop-down box on the left, select a tool. The parent tool or preceding command tools that are at the same level as this tool can be selected.
- 2 From the drop-down box on the right, select a measurement value.

#### Conditions

In [Conditions], specify the conditional statement or statements. Up to five conditions can be specified.

- 1 Check the box.
- 2 From the drop-down box on the left, select a value.
- 3 From the drop-down box in the middle, select an operator for evaluation.
- 4 From the drop-down box on the right, select [Const] or a [Value X].
- 5 If you select [Const], enter a constant in the text box to the right.

#### Action

Select the action to be performed when all the specified conditions are met.

In the first dropdown box, select the logic to perform the action.

#### When all conditions are true,

Performs the specified action when all conditions met.

**When at least one condition is true,**

Perform the specified action when at least one condition met.

**When all conditions are false,**

Performs the specified action when all conditions does not met.

**When at least one condition is false,**

Performs the specified action when at least one condition not met.

In the next dropdown box, select an action to perform.

**Invalidate this result**

Invalidate this position.

**Add the following value to model ID:**

Add the specified value to the model ID.

**Change the found angle by this many degrees:**

Add the specified value in degrees to the found angle.

**When undetermined**

In [When undetermined], specify the action to be taken when whether the conditions are met cannot be determined. This can happen when there is no measurement value to evaluate - e.g., when the locator tool specified in [Value1] has failed to find the workpiece. Select one of the following options to specify the action to be taken:

**Invalidate this result.**

Invalidate this position.


**Add the following value to model ID:**

Add the specified value to the model ID.



## 7.9.2 Running a Test

Press F4 FIND to run a test and see if the tool can evaluate the conditions properly.



### Result

In [Result], [TRUE] is displayed if all of the specified conditions are met and [FALSE] is displayed if any of the specified conditions are not met.

### Execution Result Table

The measurement values for [Value 1] to [Value 5] and the PASS/FAIL evaluation results for [Condition 1] to [Condition 5] are displayed.

## 7.9.3 Overridable Parameters


This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Const 1 ~ 5

Specify a number between -9999.999 and 9999.999.


## 7.10 MULTI-LOCATOR TOOL

The Multi-locator tool changes the locator tool to be executed, according to the value set in a robot register. If you select the Multi-locator tool in the tree view of the setup page of the vision process, a screen like the one shown below appears.



### 7.10.1 Adding Child Tools

Add locator tools you want to use according to the value of the register as child tools of the Multi-locator tool. In the figure below, GPM Locator Tool 1 is executed when the register value is 1; GPM Locator Tool 2 is executed when it is 2.



#### CAUTION

The Multi-locator tool cannot contain different types of locator tool. For example, you cannot mix a blob locator tool to a GPM Locator Tool under the multi-locator tool.

### 7.10.2 Setting the Register

Specify the register you want to use to change the locator tool.

#### Tool Index Register

Specify the number of the register you want to use to change the tool.

#### Register Value


The value currently set in the register specified in [Location Tool Index Register] is displayed. When the value is changed, the value of the register of the robot controller is also updated automatically. This function is useful when you change the locator tool and run a test.

## Register Comment

The comment currently set for the register specified in [Location Tool Index Register] is displayed.

## 7.10.3 Running a Test

Press F4 FIND to run a test and see if the tool can find workpieces properly.



## Found

The number of found workpieces is displayed.

## Time to Find

The time the location process took is displayed in milliseconds.

## Found Results table


The items displayed differ depending on the tools set as child tools of the Multi-locator tool. For the explanation of each measured value, see the pages describing the set child tools.

## 7.10.4 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.11 MULTI-WINDOW TOOL

The multi-window tool changes the search window to be used, according to the value set in a robot register. If you select the multi-window tool in the tree view of the setup page of the vision process, a screen like the one shown below appears.



### 7.11.1 Setting the Register

Specify the register you want to use to change the window.

#### Window Index Register

Specify the number of the register you want to use to change the window.

#### Register Value

The value currently set in the specified register is displayed. When the value is changed, the value of the register of the robot controller is also updated automatically. This function is useful when you change the window and run a test.

#### Register Comment

The comment currently set for the specified register is displayed.


#### Add Index to M. ID

Specify whether to add the value of the specified register to the model ID. When this check box is checked, the value of the specified register is added to the model ID.

## 7.11.2 Setting a Window

Create a new window, and delete or change a window.


### Creating a new window

Tap  button. A new window is created.


### Deleting a window

Tap  button. The window is deleted.

### Moving up

Tap  button. You can change the window.

### Moving down

Tap  button. You can change the window.

### Search Window


Specify the range of the area of the image to be searched. The default value is the entire image. To change the search window, tap the [Set] button. When a rectangle appears on the image, change the search window. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.

### Run-Time Mask

Specify an area of the search window that you do not want processed, as an arbitrary geometry. Use this function when you want to specify a search window of an arbitrary geometry, such as a circle or donut-shaped window. The filled area will be masked in the rectangle specified as the search window and will not be subject to the image processing. To change the run-time mask, tap the [Edit] button. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.

## 7.11.3 Running a Test

Press F4 FIND to run a test and see if the tool can find workpieces properly.



## Found

The number of found workpieces is displayed.

## Time to Find

The time the location process took is displayed in milliseconds.

## Found Results table


The items displayed differ depending on the tools set as child tools of the multi-window tool. For the explanation of each measured value, see the pages describing the set child tools.

## 7.11.4 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.12 POSITION ADJUSTMENT TOOL

The position adjustment tool fine-adjusts the position found by the parent locator tool using the found result of its child locator tools. If it is difficult to find the position or angle accurately for the entire workpiece, find the entire workpiece using the parent locator tool, then find some parts with which positioning can be made easy, such as holes, using its child locator tools, and modify the entire found position for more accurate offset data. If you select the position adjustment tool in the tree view of the setup page of the vision process, a screen like the one shown below appears.



### 7.12.1 Setting Parameters


Set the parameters.

#### Adjust Mode

Specify the value(s) to be adjusted.

#### Position


Found position (Row and Column) of the parent locator tool are adjusted.



Found position (Row and Column) of the parent locator tool is adjusted so that the relative position of the parent locator tool's result and the child locator tool's results becomes the same as the one trained as the reference position. The adjustment of Row is positive when adjusted to the underside, and the adjustment of Column is positive when adjusted to the right.

**Angle**


Found angle found of the parent locator tool is adjusted.



Found angle of the parent locator tool is adjusted so that the relative position of the parent locator tool's result and the child locator tool's results becomes the same as the one trained as the reference position. The adjusted angle is positive when adjusted counterclockwise.

**Position and Angle**

Found position (Row and Column) and found angle of the parent locator tool is adjusted.



Found position (Row and Column) and found angle of the parent locator tool are adjusted so that the relative position of the parent locator tool's result and the child locator tool's result becomes the same as the one trained as the reference position. The adjustment of Row is positive when adjusted to the underside, and the adjustment of Column is positive when adjusted to the right. The adjusted angle is positive when adjusted counterclockwise.



#### CAUTION

To adjust both the position and orientation, at least two child locator tools must be specified. If only one child locator tool is set, either the position or orientation can be adjusted only.

### Selecting tools

Up to five tools can be specified. Preceding locator tools that are at the same level as this tool can be selected. Select a tool you want to use the position adjustment of the parent locator tool from the drop-down list.

### Setting the Reference Position

- 1 Press F2 LIVE to change to the live image display.
- 2 Place the workpiece at a position where the parent and child locator tools can find it.
- 3 Press F2 STOP and then press F3 SNAP to snap the image of the workpiece.
- 4 Tap the [Set] button.
- 5 The parent and child locator tools find the workpiece and the position found by each tool is set as the reference position.


### Fit Error Limit

This is the threshold for the combine error (units: pixels) between the point found when the reference position is set and the point found when the detection process is executed actually. If the combine error exceeds this threshold, the workpiece is not found. When this check box is unchecked, the combine error is not checked.



## 7.12.2 Running a Test

Press F4 FIND to run a test and see if the tool can adjust the position properly.



### Found

The number of found workpieces is displayed.

### Time to Find

The time the location and position adjustment amount calculation processes took is displayed in milliseconds.

### Found result table

The following values are displayed.

#### Row

Adjustment amount in the virtual direction in the window (units: pixels).

#### Column

Adjustment amount in the horizontal direction in the window (units: pixels).

#### Angle

Adjustment amount in the rotation direction (units: degrees).

#### Scale

Adjustment amount for the scale (units: %).

#### Aspect

Adjustment amount for the aspect ratio (units: %).

#### Skew

Adjustment amount for the direction for the aspect ratio (units: degrees).

#### Fit Error

The combine error between the point found when the reference position (units: pixels).

## 7.12.3 Overridable Parameters


This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.13 MEASUREMENT OUTPUT TOOL

The measurement output tool outputs the measurement values of histogram tools and other tools together with offset data to a vision register.


When offset data measured by a vision process is obtained using the GET\_OFFSET command described in Section 9.2, "PROGRAM COMMANDS", the measurement values specified here are stored in a vision register together with offset data. You can copy the obtained measurement values into a robot register to be used in a robot program.

If you select the measurement output tool in the tree view of the setup page of the vision process, a screen like the one shown below appears.




### 7.13.1 Setting the Measurement Values

Select values you want to set in a vision register in [Measurements].  
Up to 10 values can be specified.



- 1 From the drop-down box on the left, select a tool. The parent tool or preceding command tools that are at the same level as this tool can be selected.
- 2 From the drop-down box on the right, select a measurement value.

For a vision process such as “2D multi-view vision process” or “3D multi-view vision process” that has two or more camera views, you can set a measurement output tool for each camera view as shown in the figure below.




In this case, the values from Measurement Output Tool 1 and Measurement Output Tool 2 are output to the vision register. For example, when [Value 1] to [Value 5] are specified in the Measurement Output Tool 1 and [Value 6] to [Value 10] are specified in the Measurement Output Tool 2, the measurement values specified in the Measurement Output Tool 1 are written to measurement values 1 to 5 in the vision register and measurement values specified in the Measurement Output Tool 2 are written to measurement values 6 to 10 in the vision register.

**CAUTION**  
 If the same measurement values are specified the Measurement Output Tool 1 and the Measurement Output Tool 2, the values from camera view 1 are written to the vision register.

### 7.13.2 Running a Test

Press F4 FIND to run a test and see if the tool can output measurement values properly.



**Found**

The number of found workpieces is displayed.

**Time to Find**


The time the location process took is displayed in milliseconds.

## 7.13.3 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.14 3DL PLANE COMMAND TOOL

The 3DL plane command tool measures the position and posture of the workpiece by illuminating the planar section of the workpiece with a laser with a 3D laser sensor. If you select [3DL Plane Command Tool] in the tree view, a screen like the one shown below appears.




### 7.14.1 Setting the Measurement Area

Set the area subject to laser measurement, as follows.

#### **CAUTION**

If the GPM Locator Tool resides in the same program, teach the GPM Locator Tool before teaching the measurement area. If the model origin of the GPM Locator Tool is changed or the model is re-taught, the measurement area of the plane measurement tool needs to be set again.


- 1 Press F6 LASER ON to turn on the laser.
- 2 Press F2 LIVE to display the live image of the camera.
- 3 Jog the robot so that the plane of the workpiece to be measured is at the center of the image. You can make positioning easier to do by tapping the  button, which displays the center line of the window.
- 4 Adjust the distance between the 3D laser sensor and workpiece so that the laser intersection point comes around the center of the plane. In this case, the distance between the 3D laser sensor camera and workpiece plane is about 400 mm.
- 5 Press F2 STOP to stop live. Press F6 LASER OFF to turn off the laser. Press F3 to snap the image.
- 6 Tap the [Train] button.
- 7 Enclose the workpiece to be taught within the displayed red rectangle, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, "Window Setup".

## Laser ID

[Laser ID] can be set to identify which final result corresponds to which 3DL plane command tool when more than one 3DL plane command tool has been added to the vision process. Normally, the initial value is fine when there is only one plane measurement.

## 2D-3D Gap

In [2D-3D Gap], enter the difference in height relative to the laser plane, if there is a height gap between the plane for which the model of the GPM Locator Tool is taught and the plane to be measured with the laser. This will be a positive value if the model plane is nearer to the camera than the laser plane.



## Search Narrow Area

If the plane area to be measured is small and the available points are few, enable [Search Narrow Area], which lets you increase the number of points to be used for the measurement. Note that this increases the processing time as well. Therefore, enable this item only when necessary.

## Window Mask

If there is an uneven portion on the plane to be illuminated with the laser in the measurement area, or if there is a region you want to remove from the measurement area, set a mask. To create a mask in the measurement area, tap the [Edit] button. Even when you have edited a mask, the tool will ignore the mask if you uncheck the [Enable] box. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.

## 7.14.2 Adjusting the Location Parameters

Attempts to adjust the laser point location parameters should be confined to those cases where adjusting the laser measurement settings never yields accurate found results. Forcing the tool to find laser points or changing the values inadvertently might result in inaccurate calculation of the detection position.



### CAUTION

Before changing the location parameters, check that the laser measurement exposure time in the vision process has been adjusted so that an image is captured adequately.

## Min. Num. Laser Points

If the number of effective points found in the measurement area, excluding the mask area, is below this threshold, the measurement result is invalid. If the laser point found result varies because of a small measurement area or change in image brightness, lowering the minimum number of laser points might make location possible. Note that, because the inclination of the workpiece plane is calculated from the found points, measurement accuracy can degrade as the number of points decreases.

The number of effective laser points to be found is dependent on the [Min. Laser Contrast] and [Max. Laser Fit Error] shown below.

### **Min. Laser Contrast**

This is the threshold for finding points of the laser applied to the measurement area, excluding the mask area.

### **Max. Line Fit Error**

When a straight line is formed by points of the laser applied to the measurement area, excluding the mask area, each point is regarded as an effective point as long as its deviation from the straight line is within this margin of error expressed in pixels. When the plane to be measured is textured, as in a casting surface, increasing this value slightly might allow the tool to find more effective points. Note that setting too large a value might degrade accuracy.

### **Max. Lines Distance**

Theoretically, the straight line formed by laser points calculated from each laser slit intersects at the intersection point of the laser applied to the workpiece plane. In actuality, however, the distance between the two lines rarely becomes 0 because of calibration error or measurement error. The maximum LL distance is threshold for the length of common perpendicular of the two straight lines. The initial value is set to 3.0 mm. If the need arises to set a distance longer than this, the 3D laser sensor might not have been calibrated properly. Although the maximum LL distance can be increased on a temporary basis as long as the position offset of the robot is within the required accuracy range, it is recommended to perform automatic re-calibration as appropriate.

### **Find Mode**

In the case that some laser lines are detected from each laser slit, select the combination of laser lines used for the measurement. The upper drop-down list has two options.

#### **Use Best Lines**

The detected laser lines including the most laser points are selected for each laser slit. The measurement uses the combination of the selected laser lines.

#### **Use All Lines**

All the detected laser lines are selected in order for each laser slit. The measurement uses all the combinations of the different laser slits' laser lines.

When "Use All Lines" is selected, the lower drop-down list is enabled. It has two options.

#### **Find First**

The measurement uses the combinations of the laser lines selected in descending order of the number of laser points. When the distance between the combined laser lines becomes less than the maximum lines distance at first, the plane measured by the combined laser lines is output and the measurement is terminated.

#### **Find Best**

The plane measured by the combined laser lines whose distance is the smallest is output.

### **Laser Plotting Mode**

Select how the laser label is to be displayed on the image when the process is run.

#### **Plot CW Mode**

The laser label is displayed clockwise.

**Plot CCW Mode**

The laser label is displayed counterclockwise.

**Plot Nothing**

The laser label is not displayed.

**Image Display Mode**

Select how the found results are to be displayed on the image after the test is run.

**2D Image**

The camera-captured image is displayed.

**Laser Slit Image 1**


The image of laser slit 1 is displayed.

**Laser Slit Image 2**

The image of laser slit 2 is displayed.

**7.14.3 Running a Test**

Press F4 FIND to run a test and see if the tool can find workpieces properly.



**Found**

If the result is successfully calculated, 1 is displayed. If the tool fails to find the workpiece, 0 is displayed.

**Time to Find**

The time the location process took is displayed in milliseconds.

**Found Result Table**

The following values are displayed.

**X,Y,Z,W,P,R**

Coordinate values of the found plane.

**Model ID**

Model ID of the found GPM Locator Tool.

**Score**

Score of the found GPM Locator Tool.

**Laser ID**

Measurement number of the found plane.

**Laser 1 Points**

Number of found laser 1 points.

**Laser 2 Points**

Number of found laser 2 points.

**Laser 1 Fit Err**

Straight-line approximation error of laser 1 (units: pixels).

**Laser 2 Fit Err**

Straight-line approximation error of laser 2 (units: pixels).

**Laser Distance**

Straight-line distance between found laser 1 and laser 2 (units: mm).

## 7.14.4 Overridable Parameters


---

This command tool has no overridable parameters that can be overridden with Vision Override.



## 7.15 3DL DISPL COMMAND TOOL

The 3DL displ. command tool measures the distance to the workpiece by illuminating the workpiece with a laser with a 3D laser sensor. If you select [3DL Displ. Command Tool] in the tree view, a screen like the one shown below appears.




### 7.15.1 Setting the Measurement Area

Set the area subject to laser measurement, as follows.

#### **CAUTION**

If the GPM Locator Tool resides in the same program, teach the GPM Locator Tool before teaching the measurement area. If the model origin of the GPM Locator Tool is changed or the model is re-taught, the measurement area of the plane measurement tool needs to be set again.

- 1 Press F6 LASER ON to turn on the laser.
- 2 Press F2 LIVE to display the live image of the camera.
- 3 Jog the robot so that the plane of the workpiece to be measured comes at the center of the image. You can make positioning easier to do by tapping the  button, which displays the center line of the window.
- 4 Adjust the distance between the 3D laser sensor and workpiece so that the laser intersection point comes at the center of the plane. In this case, the distance between the 3D laser sensor camera and workpiece plane is about 400 mm.
- 5 Press F2 STOP to stop live. Press F6 LASER OFF to turn off the laser. Press F3 SNAP to snap the image of the workpiece.
- 6 Tap the [Train] button.
- 7 Enclose the workpiece to be taught within the displayed red rectangle, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, "Window Setup".

#### Laser ID

[Laser ID] can be set to identify which final result corresponds to which 3DL laser displacement tool when more than one 3DL displ. command tool has been added to the vision process. Normally, the initial value is fine when there is only one plane measurement.

## Search Narrow Area

If the plane area to be measured is small and the available points are few, enable [Search Narrow Area], which lets you increase the number of points to be used for the measurement. Note that this increases the processing time as well. Therefore, enable this item only when necessary.

## Window Mask

If there is an uneven portion on the plane to be illuminated with the laser in the measurement area, or if there is a region you want to remove from the measurement area, set a mask. To create a mask in the measurement area, tap the [Edit] button. Even when you have edited a mask, the tool will ignore the mask if you uncheck the [Enable] box. For detailed information about the operation method, see Subsection 3.7.9, "Edit Masks".

## 7.15.2 Adjusting the Location Parameters

Attempts to adjust the laser point location parameters should be confined to those cases where adjusting the laser measurement settings never yields accurate found results. Forcing the tool to find laser points or changing the values inadvertently might result in inaccurate calculation of the detection position.



### CAUTION

Before changing the location parameters, check that the laser measurement exposure time in the vision process has been adjusted so that an image is captured adequately.

## Min. Num. Laser Points

If the number of effective points found in the measurement area, excluding the mask area, is below this threshold, the measurement result is invalid. If the laser point found result varies because of a small measurement area or change in image brightness, lowering the minimum number of laser points might make location possible. Note that, because the inclination of the workpiece plane is calculated from the found points, measurement accuracy can degrade as the number of points decreases.

The number of effective laser points to be found is dependent on the [Min. Laser Contrast] described below.

## Min. Laser Contrast

This is the threshold for finding points of the laser applied to the measurement area, excluding the mask area.

## Z Range

This is the range of Z-direction points to be used for calculation from the average value of laser points. Set this to a value between 0 and 200.

## Z Deviation

This is the deviation range of Z-direction points with respect to the average. Set this a value between 0 and 5.

## Laser Plotting Mode

Select how the laser label is to be displayed on the image when the process is run.

### Plot CW Mode

The laser label is displayed clockwise.

**Plot CCW Mode**

The laser label is displayed counterclockwise.

**Plot Nothing**

The laser label is not displayed.

**Image Display Mode**

Select how the found results are to be displayed on the image after the test is run.

**2D Image**

The camera-captured image is displayed.

**Laser Slit Image 1**


The image of laser slit 1 is displayed.

**Laser Slit Image 2**

The image of laser slit 2 is displayed.

**7.15.3 Running a Test**

Press F4 FIND to run a test and see if the tool can find workpieces properly.



**Found**

If the result is successfully calculated, 1 is displayed. If the tool fails to find the workpiece, 0 is displayed.

**Time to Find**

The time the location process took is displayed in milliseconds.

**Found Result Table**

The following values are displayed.

**X,Y,Z,W,P,R**

Coordinate values of the found plane. (W and P are always zero.)

**Model ID**

Model ID of the found GPM Locator Tool.

**Score**

Score of the found GPM Locator Tool.

**Laser ID**

Measurement number of the found plane.

**Laser 1 Points**

Number of found laser 1 points.

**Laser 2 Points**


Number of found laser 2 points.

## 7.15.4 Overridable Parameters


This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.16 3DL CYLINDER TOOL

The 3DL cylinder tool measures the surface of a cylinder workpiece, like the one shown below, using a 3D laser sensor, in order to estimate the central axis of the workpiece.



If you select [3DL Cylinder Command Tool] in the tree view, a screen like the one shown below appears.




## 7.16.1 Setting the Measurement Area

Set the area subject to laser measurement, as follows.

### CAUTION


If the GPM locator tool or curved surface locator tool resides in the same program, teach the GPM locator tool or curved surface locator tool before setting this measurement area. If the model origin of the GPM locator tool or curved surface locator tool is changed or the model is re-taught, the measurement area of the cylinder measurement tool needs to be set again.

- 1 Press F6 LASER ON to turn on the laser.
- 2 Press F2 LIVE to display the live image of the camera.
- 3 Jog the robot so that the cylinder to be measured is at the center of the image.  
You can make positioning easier to do by tapping the  button, which displays the center line of the window.
- 4 Adjust the distance between the 3D laser sensor and cylinder so that the laser intersection point comes around the center of the plane. In this case, the distance between the 3D laser sensor camera and workpiece plane is about 400 mm or 600 mm, depending on how laser and camera portion of the 3DL sensor are connected.
- 5 Press F2 STOP to stop live. Press F6 LASER OFF to turn off the laser. Press F3 SNAP to snap the image of the workpiece.
- 6 Tap the [Train] button.
- 7 Enclose the workpiece to be taught within the displayed red rectangle, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.  
If there is a laser image, the laser is displayed on the workpiece surface. Set the window to enclose the laser.

### Train Cylinder Dir.

After training the window, teach a cylinder direction with 2 line segments.

- 1 Tap the [No.1] in [Train Cylinder Dir].
- 2 Set one line segment along one end of the curved surface of the cylinder.
- 3 Tap the [No.2] in [Train Cylinder Dir].
- 4 Set the other line segment along the other end of the curved surface as well. The orientations of the two lines must be roughly the same and angle at less than 30 degrees.  
For the operation method of setting one line segment, see Subsection 3.7.12, “Single Line Setup” .



### Cylinder Diameter

Set the diameter of the part where the cylinder direction has been taught. This value must be between 10 mm and 200 mm.

### Laser ID

When more than one cylinder tool is added to the process, [Laser ID] can be set to identify which cylinder tool corresponds to the final result. Normally, when the process uses one cylinder tool, the default value may be used as is.

## Window Mask

If the model data has any unnecessary region (e.g., a region that does not belong to the cylinder or a region with irregularities), masking that region enables stable measurement. To create a mask in the measurement area, tap the [Edit] button. Even when you have edited a mask, the tool will ignore the mask if you uncheck the [Enable] check box. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.

## 7.16.2 Adjusting the Location Parameters

---

Attempts to adjust the laser point location parameters should be confined to those cases where adjusting the laser measurement settings never yields accurate found results. Forcing the tool to find laser points or changing the values inadvertently might result in inaccurate calculation of the detection position.

### CAUTION

Before changing the location parameters, check that the laser measurement exposure time in the vision process has been adjusted so that an image is captured adequately.

### Min. Num Laser Points 1

If the min. number laser points 1 found in the measurement area, excluding the mask area, is below this threshold, the measurement result is invalid. Set this to a value between 2 and 480.

### Min. Num Laser Points 2

If the min. number laser points 2 found in the measurement area, excluding the mask area, is below this threshold, the measurement result is invalid. Set this to a value between 2 and 480.

### Laser 1 Contrast

This is the threshold for finding points of the laser 1 applied to the measurement area, excluding the mask area. Set this to a value between 0 and 255.

### Laser 2 Contrast

This is the threshold for finding points of the laser 1 applied to the measurement area, excluding the mask area. Set this to a value between 0 and 255.

### Max Fit Error

When a cylinder surface is formed by laser points applied to the measurement area, excluding the mask area, each of these points is regarded as valid if the point's error from the cylinder surface is below this threshold. Set this to a value between 0 and 10 mm. The maximum value may change depending on the cylinder diameter.

### Laser Plotting Mode

Select how the laser label is to be displayed on the image when the process is run.

#### Plot CW mode

The laser label is displayed clockwise.

#### Plot CCW mode

The laser label is displayed counterclockwise.

**Plot nothing**

The laser label is not displayed.

**Image Display Mode**

Select the mode for displaying the found results on the window when running a test.

**2D Image**

The camera-captured 2D image and the found results will be displayed.

**Laser Slit Image 1**


Laser slit image 1 will be displayed.

**Laser Slit Image 2**

Laser slit image 2 will be displayed.

**7.16.3 Running a Test**

Press F4 FIND to run a test and see if the tool can find the workpiece properly.



**Found**

If the result is successfully calculated, 1 is displayed. If the tool fails to find the workpiece, 0 is displayed.

**Time to Find**

The time the location process took is displayed in milliseconds.

**Found Result Table**

The following values are displayed.

**X, Y, Z**

X, Y, and Z direction positions of the model origin of the found target in the user frame specified for output during the camera calibration (unit: mm).

**W, P, R**

W, P, and R direction postures of the found cylinder in the user frame specified for output (unit: degree).

**Model ID**

Model ID of the found curved surface locator tool or GPM locator tool model.

**Score**

This indicates how well the features of the found target match those of the taught curved surface locator tool or GPM locator tool model. If they completely match, 100 is displayed.

**Laser ID**

Laser ID of the cylinder tool used for the measurement.

**Laser1 Points**

Number of valid laser 1 points found in the measurement area.

**Laser2 Points**

Number of valid laser 2 points found in the measurement area.

**Laser1 Fit Err**

Average error between valid laser 1 points and the generated cylinder surface (unit: pixel).

**Laser2 Fit Err**

Average error between valid laser 2 points and the generated cylinder surface (unit: pixel).

---

**7.16.4 Overridable Parameters**


---

This command tool has no overridable parameters that can be overridden with Vision Override.



# 7.17 EVALUATION TOOL

The evaluation tool determines whether a workpiece has passed or failed the inspection, by evaluating one or more conditional expressions. You can write more than one conditional expression and have the tool evaluate those multiple conditional expressions in a comprehensive fashion. The tool is available only with the single-view inspection vision process. If you select the evaluation tool in the tree view of the setup page of the single view inspection vision process, a screen like the one shown below appears.




## 7.17.1 Setting the Parameters

Set the measured values and conditional expressions to be evaluated, as well as the [Pass When] condition for making overall judgment based on the results of the individual conditional expressions.

### Value 1 to 10

Tapping the [Variable] tab displays a screen like the one shown below. Select a value to be evaluated with a conditional expression. Up to 10 values can be specified.



- 1 From the drop-down box on the left, select a command tool. The parent tool or preceding command tools that are at the same level as this tool can be selected.
- 2 From the drop-down box on the right, select a measurement value to be evaluated.

### Condition 1 to 10

Tapping the [Condition] tab displays a screen like the one shown below.

Set a conditional expression. Up to 10 conditional expressions can be specified.

Condition				Variable	
C1	<input checked="" type="checkbox"/>	V1	>	Const.	53.000
C2	<input checked="" type="checkbox"/>	V1	<	Const.	54.000
C3	<input type="checkbox"/>		>	Const.	
C4	<input type="checkbox"/>		>	Const.	
C5	<input type="checkbox"/>		>	Const.	
C6	<input type="checkbox"/>		>	Const.	
C7	<input type="checkbox"/>		>	Const.	
C8	<input type="checkbox"/>		>	Const.	
C9	<input type="checkbox"/>		>	Const.	
C10	<input type="checkbox"/>		>	Const.	

- 1 Enable the condition by tapping the check box.
- 2 From the leftmost drop-down list, select the value to be evaluated, from the following:
  - Variable 1 to Variable 10
  - Result of a conditional expression preceding this conditional expression
- 3 From the second drop-down list, select the logical expression to be used for evaluation. The available items are described later.
- 4 From the third drop-down list, select the value to be compared for evaluation, from the following:
  - Const
  - Variable 1 to Variable 10
  - Result of a conditional expression preceding this conditional expression
- 5 If you select [Const] in step 4, enter a constant value in the text box on the right side.

### Logical expression for evaluation

As a logical expression to be specified in a conditional expression, one of the following can be selected. The available options differ depending on the type of evaluation.

=

The expression is “true” if the evaluation target value is equal to the comparison value; otherwise, it is “false”.

>

The expression is “true” if the evaluation target value is larger than the comparison value; otherwise, it is “false”.

>=

The expression is “true” if the evaluation target value is larger than or equal to the comparison value; otherwise, it is “false”.

<

The expression is “true” if the evaluation target value is smaller than the comparison value; otherwise, it is “false”.

<=

The expression is “true” if the evaluation target value is smaller than or equal to the comparison value; otherwise, it is “false”.

**<>**

The expression is “true” if the evaluation target value is not equal to the comparison value; otherwise, it is “false”.

**IN**

The expression is “true” if the evaluation target value is within the range defined by two comparison values; otherwise, it is “false”.

**OUT**

The expression is “true” if the evaluation target value is outside the range defined by two comparison values; otherwise, it is “false”.

**AND**

The expression is “true” if both the evaluation target value and the comparison value are “true”; otherwise, it is “false”.

**OR**

The expression is “true” if either the evaluation target value or the comparison value is “true”; otherwise, it is “false”.

**XOR**

The expression is “true” if both the evaluation target value and the comparison value are “true” or “false”; otherwise, it is “false”.

**Pass When**

Set a condition for making overall judgment as to whether the workpiece has passed or failed the inspection, based on the evaluation results of the individual conditional expressions.

Pass When:	All True ▾
------------	------------

Select one of the following:

**All True**

The workpiece is judged to have “passed” if all the specified conditional expressions are “true” or to have “failed” if any of the specified conditional expressions are “false”. [Undetermined] is displayed if there are no “false” conditions and there is at least one condition that cannot be evaluated. Typically a condition cannot be evaluated if the locator tool does not find a workpiece.

**At Least One True**

The workpiece is judged to have “passed” if any of the specified conditional expressions is “true” or to have “failed” if all the specified conditional expressions are “false”. [Undetermined] is displayed if there are no “true” conditions and there is at least one condition that cannot be evaluated. Typically a condition cannot be evaluated if the locator tool does not find a workpiece.

**All False**

The workpiece is judged to have “passed” if all the specified conditional expressions are “false” or to have “failed” if any of the specified conditional expressions is “true”. [Undetermined] is displayed if there are no “true” conditions and there is at least one condition that cannot be evaluated. Typically a condition cannot be evaluated if the locator tool does not find a workpiece.

### At Least One False


The workpiece is judged to have “passed” if any of the specified conditional expressions is “false” or to have “failed” if all the specified conditional expressions are “true”. [Undetermined] is displayed if there are no “false” conditions and there is at least one condition that cannot be evaluated. Typically a condition cannot be evaluated if the locator tool does not find a workpiece.

### Last Condition True

The workpiece is judged to have “passed” if the last expression of the specified conditional expressions is “true” or to have “failed” if that expression is “false”. [Undetermined] is displayed if the conditional expression cannot be evaluated.

## 7.17.2 Running a Test

Press F4 FIND to run a test and see if the tool can perform evaluation properly.



### Time to Find

The time the evaluation took is displayed in milliseconds.

### Verdict

The overall evaluation result of the evaluation tool is displayed.

### Found Result Table

The Found Result Table is displayed by selecting a result of the Verdict view. The number of each conditional expression evaluated and the associated evaluation logical expression, evaluation target value, comparison value, and evaluation result are displayed.

### Cond. No

Number of the conditional expression.

### Condition

Conditional expression that is set.

### Value

Evaluation target value evaluated with the conditional expression.

## Cond. Result


Evaluation result of the conditional expression.

## 7.17.3 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.18 SURFACE FLAW INSPECTION TOOL

Surface Flaw Inspection tool finds defects on the planer surface of a target object. First, regions that seem suspicious are extracted by searching within the specified search window. Then, the measurements of potential flaws such as individual flaw area and length, as well as the number of found flaws and the ratio of total flaw area to the search window area, are evaluated. This tool is only available with Single-view Inspection vision process. If you select a surface flaw inspection tool in the tree view of the setup page for a vision process, a setup page like the one shown below appears.



### Input Image

Select the image which is used for training area to inspection. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this Surface Flaw Inspection Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

### 7.18.1 Adjusting the Search Parameters

Adjust the parameters for finding flaws from the image.

#### Search Window

Specify the region of the image to be inspected. The narrower the region is, the faster the inspection process ends. Set the search window as follows.

- 1 Press F2 LIVE to change to the live image display.

- 2 Place a workpiece near the center of the camera view.
- 3 Press F2 STOP and then press F3 SNAP to snap the image of the workpiece.
- 4 Tap the [Set] button.
- 5 Enclose the inspection region within the red rectangle that appears, and press F4 OK.

For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.

## Run-Time Mask

Specify an area of the search window that you do not want to inspect, with an arbitrary geometry. Use this function when you want to specify a search window of an arbitrary geometry, such as a circle- or donut-shaped window. The filled area will be masked in the rectangle specified as the search window and will not be subject to inspection. To change the run-time mask, tap the [Edit] button. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.

## Flaw Color

Select the color of the flaw to be found from the following options:

### White

Finds white flaws.

### Black

Finds black flaws.

## Contrast Threshold

Specify how clearly the contour is perceivable in order to be considered as a flaw. If the average contrast of the contour of the found region is below this threshold, then the region will not be considered as a flaw. Faint flaws can be detected when a lower threshold value is specified, but some flaws may be recognized larger and the contour fuzzier. On the other hand, faint flaw are not found when a higher threshold value is specified, and only apparent flaws are found. The default value is 10, and the specifiable range is from 1 to 200.

## Magnitude Range

Specify the range of pseudo-depth of individual flaw to be found. The magnitude is determined as the difference between the darkest gray within the found flaw region and the gray of the contour. The default values are 10 for minimum and 200 for maximum, and the specifiable value range is from 1 to 255.

## Search Limit

The search limit is used to adjust the extent of the individual flaw contour. This parameter is normally left at [Standard].

### Min

The flaws tend to be recognized in smaller segments.

### Low

The flaws tend to be recognized in segments.

### Standard

Standard setting is used to find flaws.

### High

The flaws tend to be recognized in masses.

**Max**

The flaws tend to be recognized in larger masses.

## 7.18.2 Image Preprocessing

---

Surface Flaw Inspection command tool has its own image preprocessing in order to generate an image suitable for inspection. There are two types of preprocessing available, and both are applied to the pixels within the search window. Multiple preprocessing can be specified, and they are applied in a pre-determined order.

### 7.18.2.1 Background removal

---

Background Removal is a function that removes features that seems to be a part of the background. This preprocessing is applied before other preprocessing.

**Method**

Select the method of background removal from the following options:

**Not Used**

Background removal is not applied.

**Static**

By registering a flawless image as the master image, features identical to the master image are removed as the background from the image to be inspected. This method has the effect of removing features that appear the same in all images such as, the shape of the inspected object. The processed image will be the difference of the registered master image and the captured image. Be advised that not all background features are removed, due to individual variability of objects, lens disparity, or lighting conditions.

**Dynamic**

An image representing the background features (a pseudo-master image) is dynamically generated from the captured image, and is used as the master image for background removal. This method has the effect of removing minor undulation of the image when there are no abrupt changes in the grayscale level of the pixels. The processed image will be the difference of the pseudo-master image and the captured image.

**Shading**

The gradual grayscale changes in the image due to uneven lighting is removed. It is essential for inspection to have the image area evenly lit, and this method has the effect of generating an image as if the lighting is constant across the entire pixels. A master image, captured by showing a flat surface such as a sheet of paper, needs to be registered to calculate the coefficients for adjustment. If there are grayscale changes not associated with the lighting non-uniformity, this method may not work properly.

**Train Master**

Registers an image as a master image. A master image needs to be registered when the background removal method is either "Static" or "Shading."

When a master image is already registered, the text on the button becomes [Append Master]. When the [Append Master] button is tapped, the captured image and the registered master image are integrated to generate a new master image. By appending multiple images and registering the integrated image as the master image, the S/N ratio of the master image can be improved.

## Clear Master

Clears the registered master image. The button is disabled when a master image is not registered.

## Dynamic Size

Specify the unit size for processing the image. Dynamic size is a parameter used to generate a pseudo-master image in the dynamic background removal method. This parameter is only enabled when the method is “Dynamic.” The default value is 7, and the specifiable value range is from 1 to 10.

## Num Images

The number of images used to generate the master image is displayed.

## Runtime Mask

Specify an area of the shading background removal master image with an arbitrary geometry. The masked pixels will not be included in calculating the coefficients for adjusting the lighting non-uniformity. Use this function when there are grayscale changes not associated with the lighting non-uniformity in the master image. To change the run-time mask, tap the [Edit] button. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.

## Image Display Mode

Select the mode to display an image in the background removal setup from the following options:

### Original

Displays the image as it is captured by the camera.

### Master

Displays the registered master image. A pseudo-master image is displayed when the background removal method is “Dynamic.”

### Background Removed

Displays the background removed image.

## F4 OK

Returns to the Surface Flaw Inspection setup after saving the changes.

## F5 Cancel

Returns to the Surface Flaw Inspection setup discarding all changes.

## 7.18.2.2 Filters

---

Multiple filters can be applied to the image prior to the inspection. Filters are applied in the order of [Filter Type 1] and [Filter Type 2], after applying the background removal.

### Filter Types

#### None

Does not use a filter.

#### Blur

Applies a filter to blur the image. Blurring an image obscures brightness differences in the image, thus helping alleviate the effect of noise.



**Sharpen**

Applies a filter to sharpen the image.

**Blur & Sharpen**

Applies a blur filter followed by a sharpen filter.

**Sharpen & Blur**

Applies a sharpen filter followed by a blur filter.

**Erode**

Erodes the black area. Helps reduce the black pixel noise.

**Dilate**

Dilates the black area. Helps reduce the white pixel noise.

**Open**

Erodes the black area and then dilates it. This will connect white regions that are close to touching or disconnect black regions that are slightly touching.

**Close**

Dilates the white area then erodes it. This will connect black regions that are close to touching or disconnect white regions that are slightly touching.

**Times**

Specify the number of times the selected filter is to be applied. The larger the number is, the stronger the filter effect becomes. The default value is 1, and the specifiable value range is from 1 to 20.

---

**7.18.3 Adjusting the Range Parameters**

---

The found regions based on the specified flaw color are examined using the following measurements, to determine whether each region should be considered as a flaw. Each measurement has “Enabled”, “Min”, and “Max” to change the acceptable range. Measurements without a check in the “Enabled” checkbox will not be used to evaluate whether the found regions are flaw or not.

**Calculate the Angle**

When this checkbox is checked, a rectangle circumscribing the flaw is calculated, and its length, width, angle, and elongation are calculated as measurements. The rectangle is formed such that the longer sides are parallel to the major axis of the flaw. The inspection process will take longer when this feature is enabled. Use this feature only when you want to judge the flaws based on length, width, angle, and/or elongation.

**Area**

Specify the range of area values (in pixels) for judging the found region as a flaw. The default values are 10 for minimum and 10000 for maximum, and the specifiable value range is from 1 to 1000000.

**Perimeter**

Specify the range of perimeter values (in pixels) for judging the found region as a flaw. The default values are 10 for minimum and 500 for maximum, and the specifiable value range is from 1 to 8200.

## Circularity

Specify the range of circularity values for judging the found region as a flaw. Circularity represents how closely the found flaw resembles a circle. If the flaw is a perfect circle, this value is 1.0. The more complex the flaw contour becomes in geometry, the smaller the value becomes. The default values are 0.0 for minimum and 1.0 for maximum, and the specifiable value range is from 0.0 to 1.0.

## Length

Specify the range of length values (in pixels) for judging the found region as a flaw. The length is calculated as the length of a rectangle circumscribing the flaw, with its sides parallel to the major axis of the flaw. The default values are 20.0 for minimum and 400.0 for maximum, and the specifiable value range is from 1.0 to 50000.0.

## Width

Specify the range of width values (in pixels) for judging the found region as a flaw. The width is calculated as the width of a rectangle circumscribing the flaw, with its sides parallel to the major axis of the flaw. The default values are 20.0 for minimum and 400.0 for maximum, and the specifiable value range is from 1.0 to 50000.0.

## Angle

Specify the range of angle values (in degrees) for judging the found region as a flaw. The angle is calculated as the angle of the major axis of the rectangle circumscribing the flaw. A flaw with an angle of 0 degrees has its major axis vertical with respect to the image. The default values are -180.0 for minimum and 180.0 for maximum, and the specifiable value range is from -180.0 to 180.0.

## Elongation

Specify the range of elongation values for judging the found region as a flaw. Elongation is calculated by dividing the length by the width, and represents how slender the found flaw is. The longer the flaw is, the larger the value becomes. The default values are 1.0 for minimum and 800.0 for maximum, and the specifiable value range is from 1.0 to 50000.0.

## 7.18.4 Display Modes

---

### Plot Mode

Select the mode to plot results from the following options:

#### Position

Only the center of mass of each flaw will be plotted.

#### Contour

Only the contour of each flaw will be plotted.

#### Position & Contour

The center of mass and the contour of each flaw will be plotted.

#### Position & Bound Box

The center of mass and the box circumscribing each flaw will be plotted.

#### All

The center of mass, the contour, and the box circumscribing each flaw will be plotted.

### Image Display Mode

Select the image to display from the following options:

#### Original

Displays the image as it is captured by the camera.

#### Original + Results

Displays the image as it is captured by the camera, and the results if any.

#### Master

Displays the registered master image. A pseudo-master image is displayed when the background removal method is “Dynamic.”

#### Background Removed

Displays the background removed image.

#### Filtered


Displays an image with both background removal and filters applied, if any.

#### Filtered + Results

Displays an image with both background removal and filters applied, and the results if any.

## 7.18.5 Running a Test

Press F4 FIND to run a test and see if the tool can find flaws properly.



#### Num Found

The number of found flaws is displayed.

#### Total Area

The total area of found flaws is displayed.

#### Flaw Ratio

The ratio of Total Area and the search window area is displayed.

**Inspect Ratio**

The ratio of the area inspected and the area supposed to be inspected is displayed.

**Process Time**

The time the inspection took is displayed in milliseconds.

**Found Result Table****Row, Column**

Coordinate values of the center of mass of the found flaw (units: pixels).

**Contrast**

Average contrast value of the flaw contour pixels.

**Magnitude**

Magnitude (pseudo-depth) of the found flaw.

**Area**

Area of the found flaw (units: pixels).

**Perimeter**

Perimeter of the found flaw (units: pixels).

**Circularity**

Degree of circularity of the found flaw.

**Length**

Length of the found flaw (units: pixels). This is displayed only when the checkbox for “Calculate the Angle” is checked.

**Width**

Width of the found flaw (units: pixels). This is displayed only when the checkbox for “Calculate the Angle” is checked.

**Angle**

Orientation of the found flaw (units: degrees). This is displayed only when the checkbox for “Calculate the Angle” is checked.

**Elongation**

Elongation of the found flaw. This is displayed only when the checkbox for “Calculate the Angle” is checked.

---

**7.18.6 Overridable Parameters**

---

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

**Flaw Color**

Specify 1 for black flaw or 0 for white flaw.

**Contrast Threshold**

Specify a number between 1 and 250.

**Magnitude Range**

Minimum magnitude and maximum magnitude can be specified. Specify a number between 1 and 250.

**Search Limit**

Specify 1 for “Min”, 2 for “Low”, 4 for “Standard”, 8 for “High”, or 16 for “Max”.

**Area**

Enable/disable selection for area checking, minimum area and maximum area can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number equal to or larger than 0 for minimum and maximum area.

**Perimeter**

Enable/disable selection for perimeter checking, minimum perimeter and maximum perimeter can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number equal to or larger than 0 for minimum and maximum perimeter.

**Circularity**

Enable/disable selection for circularity checking, minimum circularity and maximum circularity can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number between 0 and 1 for minimum and maximum circularity.

**Semi Major**

Enable/disable selection for semi-major axis length checking, minimum semi-major axis length and maximum semi-major axis length can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number equal to or larger than 0 for minimum and maximum semi-major axis length.

**Semi Minor**

Enable/disable selection for semi-minor axis length checking, minimum semi-minor axis length and maximum semi-minor axis length can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number equal to or larger than 0 for minimum and maximum semi-minor axis length.

**Angle**


Enable/disable selection for angle checking, minimum angle and maximum angle can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number between -180 and 180 for minimum and maximum angle.

**Elongation**

Enable/disable selection for elongation checking, minimum elongation and maximum elongation can be specified. Specify 0 for disabling checking or 1 for enabling. Specify a number equal to or larger than 0 for minimum and maximum elongation.

## 7.19 BEAD INSPECTION TOOL

Bead Inspection Tool provides a function to inspect a bead-formed object, such as sealant and adhesive. Bead Inspection Tool generates many inspection points along a specified inspection line on an image. The inspection line can be specified as a polygon, a circle or an arc. Inspection is performed by predefined child tools for each inspection point. You only need to train the center line of the bead and inspection interval. This tool is only available with the Single-view Inspection vision process. If you select a bead inspection tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.



### Input Image

Select the image which is used for training model and detection. When the vision process has an Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this bead inspection tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

### 7.19.1 Setting up an Inspection Line


Teach the inspection line so the inspection line runs through the center line of the bead you want to inspect.

#### Teach Method

Select a type of the inspection line from the following options.


##### Polygon

Teach the inspection line as a polygonal line that connects multiple vertices. In the case of the following figure, the starting point of the inspection line is vertex1 and the ending point of the inspection line is vertex3.




## Circle

Teach the inspection line as a circle that passig through three vertices. The starting point of the inspection line is the bottom point of the circle.



## Arc

Teach the inspection line as an arc that passes through three vertices. The starting point of the inspection line is vertex1 and the ending point of the inspection line is vertex3.



## Selected Vertex



Select a vertex of the inspection line to edit. Specify an index number of the vertex that you want to edit. A polygon is composed of two or more vertices. A circle and an arc are composed of three vertices.

### Hint

When the bead cannot be depicted with a single shape of inspection line, use multiple Bead Inspection Tools.

## Teaching Inspection Line

Teach the inspection line as follows:

- 1 Select a type of the inspection line for the [Teach Method] dropdown box.
- 2 Tap the [Teach] button to start teaching the inspection line. The label on the button becomes [End].
- 3 Select the vertex you would like to adjust by tapping   button on the right of the [Selected Vertex] textbox or entering a value in the [Selected Vertex] textbox.
- 4 Tap the [Move], [Add] or [Delete] button.  
Tapping the [Move] button displays a red crosshair cursor at the current position of the selected vertex on the image. Move the red crosshair cursor to the position you would like to move the vertex to.

Tapping the [Add] button displays a red crosshair cursor at the midpoint of the selected vertex and the next vertex on the image. When the last vertex is selected, the red crosshair cursor is displayed at the center of the image. Move the red crosshair cursor to the position you would like to add the new vertex.

Tapping the [Delete] button deletes the selected vertex.

For the detailed information about the operation method of the red crosshair cursor, see Subsection 3.7.8 “Setting Points”.

- 5 Press F4 OK or F5 CANCEL to finish editing the selected vertex.
- 6 Repeat the step 3 to 5 so that the inspection line runs along the center line of the bead you would like to inspect.
- 7 Tap the [End] button to finish editing the inspection line.

## 7.19.2 Adjusting Parameters

Adjust the following parameters.

### Inspection Interval


Specify the interval of the inspection points to be generated. A value between 1 and 100 can be specified. The unit is pixels.

#### **⚠ CAUTION**

Inspection points are not always generated exactly at the specified inspection interval. If the taught inspection line cannot be divided equally at the specified inspection interval, inspection points are generated by automatically fine-tuning the inspection interval so that the inspection line can be divided equally.

### Model ID

When you have taught two or more Bead Inspection Tools and want to identify which tool was used to generate the inspection point, assign a distinct model ID to each tool. It is useful when you want to count results of some Bead Inspection Tools. For example, assume a vision process has four Bead Inspection Tools “A”, “B”, “C” and “D”, the model ID of “A” is set to 1, and the model ID of “B”, “C” and “D” is set to 2. Then you can count number of passed/failed inspection points from Bead Inspection Tool “B”, “C” and “D” (namely excluding “A”) by configuring a Count Tool to count results with model ID set to 2.





## Parent Tool Ref. Pos.

It is the reference position to be used for dynamic window shifting. This section displays the position of the workpiece found by the parent locator tool when the inspection line is taught.

## Plot Mode

Select how the results are displayed after the process is run from the following options.

### Plot Inspection Point

The inspection points will be displayed.

### Not Plot Inspection Point

Nothing will be displayed.

## Image Display Mode

Select the image display mode for the setup page from the following options.

### Image

The camera image will be displayed as is.

### Insp, Line

The camera image and the generated inspection line will be displayed.

### Insp, Line + Vertex

The camera image, the generated inspection line and the vertices will be displayed.

### Insp, Line + Vertex + Index

The camera image, the generated inspection line, the vertices and the vertex indices will be displayed.

## 7.19.3 Running a Test

Press F4 FIND to run a test and see if the tool can generate inspection points properly.

The screenshot shows the IRVision Setup Main - CTBI interface. At the top, there are status indicators: Busy, Teach, Hold, Fault, Run, I/O, Prod, Done, JOB LINE 0, T2, ABORTED, JOINT, and 5%. The main window is titled 'IRVision Setup Main - CTBI' and contains a 'Bead Inspection Tool 1' configuration panel. The 'Image' tab is selected, showing a zoomed-in view of a bead with a green inspection line and vertices labeled 1 through 6. The 'Results' section at the bottom displays a table of inspection data.

#	Vt	Hz	Angle
1	248.0	28.0	-0.8
2	248.8	82.8	-0.8
3	249.6	137.6	-0.8
4	250.0	192.4	0.0

## Time to Test

The time the bead inspection tool took is displayed in milliseconds.

## Found Results Table

The following values are displayed.

### Vt, Hz

Coordinate values of the generated inspection point (units: pixels).

### Angle

Orientation of the generated inspection point (units: degrees).

## 7.19.4 Overridable Parameters

---

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Inspection Interval

Specify the interval of inspection points. A number between 1 and 100 can be specified. The unit is pixels.

## 7.19.5 Available Child Tools


---

Bead Inspection Tool can have the following command tools as its child. For details of individual command tools, refer to the Subsection 7 “Command Tool”. For examples of application, refer to “R-30iB/R-30iB Mate CONTROLLER *iR*Vision Inspection Application OPERATOR’S MANUAL”.

- GPM Locator Tool
- Blob Locator Tool
- Edge Pair Locator Tool
- Line Locator Tool
- Histogram Tool
- Edge Histogram Tool
- Count Tool
- Arithmetic Tool
- Geometric Tool
- Statistic Calculation Tool
- Position Calculation Tool

## 7.20 COUNT TOOL

The count tool counts the number of targets found by locator tools that are at the same level as the count tool. In addition, it can also count the number of found targets having a specific model ID. The conditional execution tool can use the count result for evaluation, and the measurement output tool can write the count result to a vision register. If you select the count tool in the tree view of the setup page of the vision process, a screen like the one shown below appears.



### 7.20.1 Setting the Parameters

Specify the target to count.

#### Locator Tool


Specify this item when you want to count the number of targets found by a specific locator tool. If you check the box and select a locator tool name, the count tool counts the number of targets found by that specified locator tool. If you leave the box unchecked, the count tool counts the total number of targets found by all the locator tools preceding the count tool that are at the same level as the count tool.

#### Model ID

Specify this item when you want to count the number of found results having a specific model ID. If you check the box and specify a model ID, the count tool counts the number of found results having that specified model ID. If you leave the box unchecked, the count tool counts the total number of found results, irrespective of the model ID. If you check both the [Locator Tool] and [Model ID] boxes, the count tool counts the number of targets found by the specified locator tool that have the specified model ID.

## 7.20.2 Running a Test

Press F4 FIND to run a test and see if the count tool operates properly.



### Time to Find

The time the count tool process took is displayed in milliseconds.

### Measurement Result Table

The following values are displayed.

#### Num. Found

Number of targets found.

#### Num. Passed

Number of targets that the evaluation tool judged to have passed. This is shown only for a single-view inspection vision process.

#### Num. Failed


Number of targets that the evaluation tool judged to have failed. This is shown only for a single-view inspection vision process.

## 7.20.3 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.21 ARITHMETIC CALCULATION TOOL

The arithmetic calculation tool performs four arithmetic operations for specified measured values. For example, it can calculate the difference between the mean brightness values measured by two histogram tools. The conditional execution tool can use the calculation result for evaluation, and the measurement output tool can write the calculation result to a vision register. If you select the arithmetic calculation tool in the tree view of the setup page of the vision process, a screen like the one shown below appears.



### 7.21.1 Setting the Parameters

Set what the tool is to calculate.

#### Operation

Set what kind of calculation is to be performed, by using [Value 1] and [Value 2].

One of the following can be selected:

- Value 1 + Value 2
- Value 1 – Value 2
- Value 1 × Value 2
- Value 1 ÷ Value 2
- Value 1 Mod Value 2


The operator Mod calculates the residue. Value 1 Mod Value 2 calculates the residue of Value 1 divided by Value 2. The residue can be a decimal fraction. When Value 1 is a negative value, the result of a calculation is also a negative value. The sign of the Value 2 is ignored.

#### Value 1, Value 2

Set the values to be used for the calculation. The measured values of the parent tool, the measured values of preceding command tools that are at the same level as this tool or constants can be selected. In the first drop-down box, select a command tool name or [Constant]. If you select a command tool name, then go to the next drop-down box and select the measured value to be used for the calculation. If you select [Constant], enter a constant value in the text box.

## 7.21.2 Running a Test

Press F4 FIND to run a test and see if the arithmetic calculation tool operates properly.



### Time to Find

The time the arithmetic calculation tool process took is displayed in milliseconds.

### Measurement Result Table

The following values are displayed.

### Value 1, Value 2

The values used for the calculation are displayed.

### Result


The result of the calculation is displayed.

## 7.21.3 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.22 GEOMETRIC CALCULATION TOOL

The geometric calculation tool performs a geometric calculation using the positions found by specified locator tools. For example, it can calculate the distance between the holes found by two locator tools. The conditional execution tool can use the calculation result for evaluation, and the measurement output tool can write the calculation result to a vision register. If you select the geometric calculation tool in the tree view of the setup page of the vision process, a screen like the one shown below appears.



### 7.22.1 Setting the Parameters


Set what the tool is to calculate.

#### Operation

Select the geometric calculation to be performed. One of the following can be selected:

#### Distance


Considering the points found by [Locator 1] and [Locator 2] as the input point 1 and 2 individually, the geometric calculation tool calculates the distance between the two points.



The resulting value is in pixels by default, but in millimeters if its parent vision process is configured to make millimeter conversion.

### 3-Point Angle

Considering the points found by [Locator 1], [Locator 2] and [Locator 3] as the input point 1, 2 and 3 individually, the geometric calculation tool calculates the angle generated by the three points, as shown in the figure below.



The resulting value is in degrees. When the input point 3 is on the right of the line passing from the input point 1 to the input point 2, the resulting value is a positive value. Otherwise, it is a negative value.

### Locator 1...3

Select the locator tools that will detect the positions to be used for the calculation. The parent tool or preceding locator tools that are at the same level as this tool can be selected. If you select [Distance] for [Operation], select [Locator 1] and [Locator 2]. If you select [3-Point Angle], select [Locator 1] to [Locator 3].

## 7.22.2 Running a Test

Press F4 FIND to run a test and see if the geometric calculation tool operates properly.

#	Locator 1	Locator 2	Calculation Result (pix)
1	(214.6, 164.4)	(213.8, 492.3)	327.9



## Time to Find

The time the geometric calculation tool process took is displayed in milliseconds.

## Measurement Result Table

The following values are displayed.

### Locator 1~3

The positions used for the calculation are displayed. The unit is the pixel.

### Calculation Result


The values used for the calculation are displayed.

## 7.22.3 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.23 STATISTIC CALCULATION TOOL

The statistic calculation tool performs a statistic calculation for the measured values of targets found by a specified locator tool. For example, when the blob locator tool has found five blobs, it can calculate the average area or standard deviation of the five blobs. The conditional execution tool can use the calculation result for evaluation, and the measurement output tool can write the calculation result to a vision register. If you select the statistic calculation tool in the tree view of the setup page of the vision process, a screen like the one shown below appears.



### 7.23.1 Setting the Parameters

Set what the tool is to calculate.

#### Locator


Select the name of the locator tool from which to obtain measured values. Only a locator at the same level and above the statistical calculation tool can be selected.

## Measurement

Select the measured value for which the statistic calculation is to be performed.

### 7.23.2 Running a Test

Press F4 FIND to run a test and see if the statistic calculation tool operates properly.



#### Time to Find

The time the statistic calculation tool process took is displayed in milliseconds.

#### Measurement Result Table

The following values are displayed.

##### Maximum

Maximum value of the selected measured values.

##### Minimum

Minimum value of the selected measured values.

##### Mean

Mean value of the selected measured values.

##### Std. Dev.

Standard deviation of the selected measured values.

##### Total

Total of the selected measured values.

##### Num. Found


Number of targets found.

## 7.23.3 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.24 POSITION CALCULATION TOOL

The position calculation tool calculates a new position from other found positions. For example, it can calculate the intersection of two lines found by two line locator tools, the foot of perpendicular from a hole found by a GPM locator tool to a line found by a line locator tool, and so on. If you select the position calculation tool in the tree view of the setup page of the vision process, a setup page like the one shown below appears.



### 7.24.1 Setting the Parameters

Set the parameters.

#### Model ID


When you have taught two or more position calculation tools and want to identify which tool was used to calculate the position, assign a distinct model ID to each tool. The model ID of the tool, which calculated the positions, is reported to the robot controller along with offset data. This enables a robot program to identify the type of the calculated position.

#### Calculation Mode

Select a position calculation to be performed. According to the calculation mode that you select, locator tools that you can select at drop-down boxes of [Locator 1~3] is determined. Results of some locator tools are treated as a “point”, and some are as a “line”.

#### Intersect. of two lines


An intersection of two lines is calculated from two input lines.



The result position is the intersection of two input lines, and the result angle is the bisector direction of the angle between two input lines. In addition, the angle between two lines is calculated as its measurement value. The unit of the measurement value is degree. If [Intersect. of two lines] is selected for [Calculation Mode], “(Line)” is displayed at the right of drop-down boxes of [Locator 1~2]. You can select locator tools that output “Line” at the drop-down boxes of [Locator 1~2]. The result of a position calculation tool that is configured to calculate [Intersect. of two lines] is treated as a “Point”, and you can use it as an input to another position calculation tool.

### Midpoint of two points


A middle point of two points is calculated from two input points.



The result position is the middle point of two points, and the result angle is the direction from the input point 1 to the input point 2. In addition, the distance between two input points is calculated as its measurement value. The measurement value is in pixels by default, but in millimeters if its parent vision process is configured to make millimeter conversion. If [Midpoint of two points] is selected for [Calculation Mode], “(Point)” is displayed at the right of drop-down boxes of [Locator 1~2]. You can select locator tools that output “Point” at the drop-down boxes of [Locator 1~2]. The result of a position calculation tool that is configured to calculate [Midpoint of two points] is treated as a “Point”, and you can use it as an input to another position calculation tool.

### Center of circle


A center of a circle that passes through three input points is calculated from three input points.



The result position is the center of the circle, and the result angle is always zero. In addition, the diameter of the circle that passes through three input points is calculated as its measurement value. The measurement value is in pixels by default, but in millimeters if its parent vision process is configured to make millimeter conversion. If [Center of circle] is selected for [Calculation Mode], “(Point)” is displayed at the right of drop-down boxes of [Locator 1~3]. You can select locator tools that output “Point” at the drop-down boxes of [Locator 1~3]. The result of a position calculation tool that is configured to calculate [Center of circle] is treated as a “Point”, and you can use it as an input to another position calculation tool.

### Foot of a perpendicular


A foot of perpendicular which drops down from a point to a line is calculated from an input point and an input line.



The result position is the foot of perpendicular which drops down from the input point to the input line, and the result angle is the direction from the foot to the input point. In addition, the perpendicular distance from the input point to the input line is calculated as its measurement value. The measurement value is in pixels by default, but in millimeters if its parent vision process is configured to make millimeter conversion. If [Foot of a perpendicular] is selected for [Calculation Mode], “(Point)” is displayed at the right of the drop-down list of [Locator 1], and “(Line)” is displayed at the right of the drop-down list of [Locator 2]. You can select a locator tool that outputs a “Point” at the drop-down list of [Locator 1], and a locator tool that outputs a “Line” at the drop-down list of [Locator 2]. The result of a position calculation tool that is configured to calculate [Foot of a perpendicular] is treated as a “Point”, and you can use it as an input to another position calculation tool.

### Perpendicular line

A line which passes through a point and is perpendicular to a line is calculated from an input point and an input line.




The input point is used as a point on the line. The result angle is the direction from the foot to the input point. In addition, the perpendicular distance from the input point to the input line is calculated as its measurement value. The measurement value is in pixels by default, but in

millimeters if its parent vision process is configured to make millimeter conversion. If [Perpendicular line] is selected for [Calculation Mode], “(Point)” is displayed at the right of the drop-down list of [Locator 1], and “(Line)” is displayed at the right of the drop-down list of [Locator 2]. You can select a locator tool that outputs a “Point” at the drop-down list of [Locator 1], and a locator tool that outputs a “Line” at the drop-down list of [Locator 2]. The result of a position calculation tool that is configured to calculate [Perpendicular line] is treated as a “Line”, and you can use it as an input to another position calculation tool.

### Parallel line


A line that passes through a point and is parallel to a line is calculated from an input point and an input line.



The input point is used as a point on the line. The result angle is the same direction as the direction of the input line. In addition, perpendicular distance from the input point to the input line is calculated as its measurement value. The measurement value is in pixels by default, but in millimeters if its parent vision process is configured to make millimeter conversion. If [Parallel line] is selected for [Calculation Mode], “(Point)” is displayed at the right of the drop-down list of [Locator 1], and “(Line)” is displayed at the right of the drop-down list of [Locator 2]. You can select a locator tool that outputs a “Point” at the drop-down list of [Locator 1], and a locator tool that outputs a “Line” at the drop-down list of [Locator 2]. The result of a position calculation tool that is configured to calculate [Parallel line] is treated as a “Line”, and you can use it as an input to another position calculation tool.

### Line through two points

A line that passes through two points is calculated from two input points.



The middle point of two input points is used as a point on the line. The result angle is the direction from the input point 1 to the input point 2. In addition, the distance between two points is calculated as its measurement value. The measurement value is in pixels by default, but in millimeters if its parent vision process is configured to make millimeter conversion. If [Line through two points] is selected for [Calculation Mode], “(Point)” is displayed at the right of the


drop-down boxes of [Locator 1~2]. You can select locator tools which output “Point” at the drop-down boxes of [Locator 1~2]. The result of a position calculation tool that is configured to calculate [Line through two points] is treated as a “Line”, and you can use it as an input to another position calculation tool.

### Locator 1~3

Select locator tools that output positions to be used as inputs to position calculation tool. Its parent locator tool or preceding sibling locator tools can be selected. If [center of circle] is selected for [Calculation Mode], select [Locator 1~3]. If you select the other options for [Calculation Mode], select [Locator 1~2].

## 7.24.2 Running a Test

Press F4 FIND to run a test and see if the position calculation tool operates properly.



### Time to Find

The time the position calculation tool process took is displayed in milliseconds.

### Measurement Result Table

The following values are displayed.

### Locator 1~3

The input positions and angles to the position calculation tool are displayed. Only when [center of circle] is selected for [Calculation mode], the column of [Locator 3] is displayed. The positions are in pixels, and the angle is in degrees.

### Result Pose

The calculated position and angle are displayed. The position is in pixels, and the angle is in degrees.

### Score

The average score of command tools which was used by position calculation are displayed.

### Measurement Value

The resulting measurement value is displayed. The column header depends on the calculation mode.

- Intersect. of two lines : Angle
- Midpoint of two points : Distance
- Center of circle : Diameter
- Foot of a perpendicular : Perpendicular Distance
- Perpendicular line : Perpendicular Distance
- Parallel line : Perpendicular Distance
- Line through two points : Distance

### Popup alarm at running a test

Depending on the input positions, calculation may fail. If failed at production runtime the position calculation just does not output results. On the other hand, the reason why the position calculation failed is displayed when running a test.

#### Input poses are too near

It is displayed when the distance between two input points or the distance between an input point and an input line is less than 1 pixel.

#### Input lines are parallel

It is displayed when [Intersect. of two lines] is selected for [Calculation Mode] and the angle between two input lines is less than 1 degree.

#### Relation of input points is inappropriate

It is displayed when [Center of circle] is selected for [Calculation Mode] and one of the interior angles of three input points is less than 1 degree.

#### Result pose is out of image


It is displayed when the result position is out of image.

## 7.24.3 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.


## 7.25 WINDOW SHIFT TOOL

The window shift tool dynamically shifts the windows of locator tools or measurement tools based on the result of a locator tool or another vision process. For example, when you use an application that retrieves workpieces from a container or rack, you may set the tool to shift the search window of the locator tool based on the position of the container or rack, thereby preventing objects outside the container or rack from being found inadvertently. Place the window shift tool directly below the vision process. The windows of the locator tools and measurement tools that are at the same level as the window shift tool and that are inserted below the window shift tool are shifted according to the window shift tool settings.





If you select the window shift tool in the tree view of the setup page of the vision process, a screen like the one shown below appears.



## 7.25.1 Setting the Parameters

Set the parameters.

### Mode

Select the window shift mode from the following:

#### Locator Tool

A locator tool is placed as a child tool of the window shift tool, which in turn shifts windows based on the found results of that locator tool. Use this mode when the locator tool can find the container and the workpieces in the same field of view.

#### Other VP Result

The tool shifts windows based on the found results of another vision process that are stored in a vision register. Use this mode when you want to use different exposure times when finding the container then when finding the workpieces in it. A vision process for finding the workpieces and for the container needs to be prepared separately. In cases where the position of the container changes only when it is replaced, rather than every time a workpiece is found, you can reduce the cycle time by having the system run the vision process for finding the container only when the container is replaced.


#### IA Result

In the bin picking system that performs the detection of workpiece using a camera fixed on the camera mount and performs 3D measurements using a 3D Laser Vision Sensor installed in the wrist of a robot, if the interference avoidance function is used to obtain the position to perform the 3D measurement, the obtained position will differ from the original one and the search window will be displaced by as much as that difference, resulting in the 3D measurement failing to find the workpiece. In that case, the search window can be shifted according to the avoidance amount by using the interference avoidance result. This function is available only when the window shift tool is set as a child tool of the 3DL Single-View Vision Process or 3DL Curved Surface Single Vision Process.

The parameters other than [Mode] depend on the mode you select.

### 7.25.1.1 Shifting windows based on a locator tool's results

When windows are shifted based on the found results of a locator tool, the only parameter to set is the [Mode], which is set to "locator tool". Insert a locator tool as a child tool of the window shift tool, and teach a model pattern of the child locator tool.



#### Setting the Reference Position

Once you teach a command tool that is at the same level and below the window shift tool, the child locator tool of the window shift tool automatically runs. The position found by the child locator tool of the window shift tool is automatically saved as the reference position for shifting the window of the taught command tool. The saved window shift reference position is displayed as follows (shown below is an example of the GPM locator tool).

Parent Tool Ref. Pos.: (251.5, 145.5) 0.0° 100.0%

### 7.25.1.2 Shifting windows based on another vision process' results

When shifting windows based on another vision process' results, make the settings as follows.

#### Vision Register Number

Specify the number of the vision register that stores the vision process results to be used for shifting windows. Make sure that the vision processes for finding the container and the workpieces are calibrated to the same [Application User Frame]. Please set the reference position when the offset value in the vision register specified here is zero.

#### Reference Z

Set the Z value of found position set in the vision register specified at [Vision Register Number].


#### Change Search Window Size

If [Depalletizing Vision Process] or [Bin-Pick Search Vis. Process] are selected as the vision process that uses the window shift tool, the size of the search window can be expanded or reduced according to the height of the workpiece to be found. If one of these vision processes is used, the setting window of the window shift tool has the following two additional parameters:

Change Search Window Size:

Work Height: R

To expand or reduce the size of the search window, check the [Change Search Window Size] box and specify the number of the register storing the workpiece height information in [Work Height]. The window shift tool fetches the value in the register during execution, and changes the size of the search window according to the value.




### ⚠ CAUTION

The function of [Change Search Window Size] is useful when the height of workpieces is known and independent of the height of container or rack that the vision process for window shift tool finds. If the height of workpieces is dependent on that of container or rack, search window size will change correctly without the check on [Change Search Window Size]

## Setting the Reference Position

Once you teach a command tool that is at the same level and below, the window shift tool automatically runs. The window shift tool obtains information from the specified vision register and relevant register and generates position data for window shifting. The position data generated by the window shift tool is saved as the window shift reference position for the locator tool detecting the model.



The saved window shift reference position is displayed as follows (shown below is an example of the GPM locator tool).

Parent Tool Ref. Pos.: (0.0, -0.0) 0.0° 100.0%

### ⚠ CAUTION

- 1 The window shift tool reads the values that are set in the vision register at the time of access. If the values stored in the vision register do not match the actual position of the container, the tool cannot shift the window properly. Run the vision process for finding the container to make sure that the latest information about the container position is saved in the vision register.
- 2 With vision processes that do not use Application User Frame, the "Other VP Result" mode cannot be used. For example, Single View Inspection Vision Process cannot use a Window Shift Tool when its Mode is Other VR Result since it does not use an application frame

## Window Center

Set the center position of the search window on the command tool that is at the same level and below.

### 7.25.1.3 Shifting windows based on interference avoidance results

When shifting windows based on interference avoidance function result, make the settings as follows.

#### IA Position

Set the index number of the position register in which the avoidance position is set that has been calculated by the interference avoidance function for a measurement position.

#### IA Offset

Set the index number of the position register in which the tool offset value is set that has been calculated by the interference avoidance function for a measurement position.

#### Utool frame

Select the number of the tool frame used for interference avoidance calculation for a measurement position.

#### Ref. Vision Result

Set the index number of the vision register in which a vision result found by a fixed camera is set.

### Setting the Reference Position

After setting the window shift tool described above, set the reference position for shifting windows. The setup of the reference position for shifting windows is automatically done by each locator tool that is below the window shift tool in the same level during model teaching. When a model pattern is taught, the window shift tool is automatically executed and retrieves values from the specified position register and vision register to generate position data. The position data is recoded by each locator tool as the reference position for shifting windows.

#### CAUTION

When the reference position is set (the locator tool model is taught), the reference position is calculated using the avoidance amount set in the position register. For example, if an avoidance amount requiring a +30-degree rotation from the taught position is set as the result of interference avoidance calculation when the reference position is set, and if an avoidance amount requiring a +40-degree rotation is calculated during the normal operation, the calculated shift amount will require a +10-degree rotation. It is important to check that the search window has been placed at the proper position based on the result of interference avoidance calculation before setting the reference position. The easiest way is to teach the search window at a measurement position that does not require interference avoidance and then set the reference position.

### 7.25.2 Running a Test


The window shift tool setup page does not offer the capability to run a test. To check whether the search window is shifted properly, run a test using the setup page of a locator tool that is inserted below the window shift tool.

## 7.25.3 Overridable Parameters


This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.26 IMAGE PREPROCESS TOOL

The image preprocess tool has the color extraction tool and the image filter tool which are described below as a child tool and has its place as the container of the command tool of the image processing. You can treat the image which is processed by the color extraction tool and the image filter tool which are the child tool of the image preprocess tool as the input image of the command tool which is used for a detection and an inspection. Only one image preprocess tool can be inserted just below the vision process, as follows.



If you select the image preprocess tool in the tree view of the setup page of the vision process, a setup page like the one shown below appears.



### 7.26.1 Setting the Parameters

This command tool does not have any settings. Add the image filter tool and the color extraction tool as child tools.

### 7.26.2 Running a Test


The image preprocess tool setup page does not offer the capability to run a test.

### 7.26.3 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.27 IMAGE FILTER TOOL


Image Filter Tool executes image processing (e.g., Blur and Sharpen and so on) with respect to the image which is acquired by the camera. Image Filter Tool can be inserted only under Image Preprocess Tool. As shown in the following image, by adding several Image Filter Tools, several different filtered images can be used in each command tool.



To use the result image created by Image Filter Tool in a command tool, open the setup page of the command tool and then select the name of Image Filter Tool in the drop-down box of [Input Image].

Input Image:

When you select Image Filter Tool in the tree view of the setup page of the vision process, a setup page like the one shown below appears.



### NOTE

Some command tools such as Histogram Tool, 2D Barcode Tool, and Surface Flaw Inspection Tool have their own local filter functions that can be used instead of Image Filter Tool.

### 7.27.1 Setting the Parameters

#### Input Image

Select the image to be filtered. The available options in the drop-down list are listed below.

#### Camera Image

The input image comes from the camera.

## Image Register N

The input image comes from the specified image register. An image can be stored in an image register by executing Image Filter Tool with [Save Result Image] being enabled, or by calling IRVSNAP from a TP program. When no image registers have been allocated, this option will not appear.

## Tool Name

The input image comes from the selected tool. The available tool is Flat Field Tool, Image Filter Tool, Image Arithmetic Tool, Color Extraction Tool, or Color Component Tool at the same level as this tool.

## Filter list

You can configure up to 10 image filters to run one after another.

## Enable

The enabled filters will run in sequence. It is OK to have disabled filters in-between enabled filters.

## Filters

Select the filter type. For the details of each filter, refer to 7.27.4 “Filters”.

## Size / # of Iterations

Set the filter size or the number of the iterations about the selected filter. For the details, refer to 7.27.4 “Filters”.

## Run in Search Window

By default, Image Filter Tool processes the entire image. But if this item is checked, Image Filter Tool processes only inside the search window of the command tools which use the result image. According to the number of found, processing only inside the search window may reduce the processing time of Image Filter Tool.

Note that Image Filter Tool processes inside the search window only in the following cases. In the other cases, Image Filter Tool processes the entire image even if the item is checked.

- When executing the vision process from a TP program
- When running a test on the setup page

## Save Result Image

If this item is checked, the result image is stored in the selected image register. When there is no image register, an error message is displayed. For details of the image register, refer to 9.4.1 “IRVSNAP, IRVFIND”.


## Image Display Mode

Select the image display mode from the following choices:

- Input Image
- Result Image


## Command Tools Using This Result Image

The name of command tools which use the result image of this Image Filter Tool is displayed. When this Image Filter Tool is changed, verify that these command tools still operate as intended.



## 7.27.2 Running a Test

Press F4 FIND to run a test and see if Image Filter Tool operates properly.



### Time to Find

The processing time of Image Filter Tool took is displayed in milliseconds.

## 7.27.3 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.27.4 Filters

This section shows examples of how to use each type of filter.


### Blur

Blur filter can be used to smooth out fine surface texture or image noise. Blur filter is very similar to Gaussian Blur filter. Blur filter is suitable to process the whole image, and Gaussian Blur filter is suitable to remove the noise of the image.


### Filter Size

As the filter size of Blur filter becomes larger, the image is blurred stronger.





Input Image



Result Image (Blur with N=3)

### Sharpen


Sharpen filter can be used to enhance the contrast of the edges in the image. As a filter similar to Sharpen filter, you can use Gaussian Sharpen filter. When you give priority to processing time, Sharpen filter is suitable. And when you want to use the filter many times, Gaussian Sharpen filter is suitable

### Filter Size

As the filter size of Sharpen filter becomes larger, the outlines become sharper.



Input Image



Result Image (Sharpen with N=1)

## Erode

Erode filter can be used to expand the light areas and shrink the dark areas in the image.

### Number of Iterations

As the number of the iterations of Erode filter becomes larger, the dark areas in the image become smaller.

In the example below, Erode filter expands the white circles in Data Matrix code, so that the Data Matrix code can be read easily.



Input Result



Result Image (Erode with N=2)


### Dilate

Dilate filter is used to expand the dark areas and shrink the light areas in the image.

#### Number of Iterations

As the number of the iterations of Dilate filter becomes larger, the dark areas in the image become larger.

In the example below, Dilate filter expands all of the black circles, so that Data Matrix code can be read easily.



Input Image



Result Image (Dilate with N=2)


## Open

Open filter performs Dilate filter after Erode filter. Open filter can erase the small dark area.


### Number of Iterations

As the number of the iterations of Open filter becomes larger, the larger dark areas in the image can be erased.

In the example below, Open filter erases thin dark lines.



Input Result



Result Image (Open with N=2)


## Close

Close filter performs Dilate filter after Erode filter. Close filter can be used to erase light areas.

### Number of Iterations

As the number of the iterations of Close filter becomes larger, the larger light areas in the image can be erased.

In the example below, Close filter connects the black circles and fills in their light centers.



Input Image




Result Image (Close with N=2)

## Top Hat


Top Hat filter can be used to extract thin light lines and the small light holes of the image. In the example below, Top Hat filter extract thin white lines.

### Filter Size

As the filter size of Top Hat filter becomes larger, the bolder white lines in the image can be extracted.



Input Image



Result Image (Top Hat with N=2)


## Bottom Hat

Bottom Hat filter is used to extract thin dark lines and small dark holes.


### Filter Size

As the filter size of Bottom Hat filter becomes bigger, the bolder dark lines can be extracted.

In the example below, Bottom Hat filter extracts small dark holes.



Input Image



Result Image (Bottom Hat with N=3)

## Edge Magnitude


Edge Magnitude filter is used to output the image that shows difference from the results of Erode filter and Dilate filter. Edge Magnitude filter can be used to extract highlight edges of the image.

### Number of Iterations

As the number of the iterations of Edge Magnitude filter becomes larger, the highlight edges become bolder.



Input Image




Result Image (Edge Magnitude with N=2)

## Median

Median filter output featured pixels and its neighborhood. Median filter can be used to remove image “salt and pepper” noise without affecting the edges in the image.


### Filter Size

As the filter size of Medial filter becomes bigger, noises can be removed strongly.



Input Image






**Result Image (Median with N=3)**

## **Gaussian Blur**


Gaussian Blur filter can be used to smooth out the fine surface texture or the image noise. Gaussian Blur filter is very similar to Blur filter. Blur filter is suitable to process the whole image, and Gaussian Blur filter is suitable to remove the noise of the image.

### **Filter Size**

As the filter size of Gaussian Blur filter becomes bigger, the image can be blurred strongly.



**Input Image**



**Result Image (Gaussian Blur with N=3)**

## **Gaussian Sharpen**

Gaussian Sharpen filter is used to emphasize the highlight edges by increasing the contrast of the input image. When you give priority to processing time, Sharpen filter is suitable. And when you want to use the filter many times, Gaussian Sharpen filter is suitable.

**Filter Size**

As the filter size of Gaussian Sharpen filter becomes larger, the highlight edges are more emphasis.



Input Image



Result Image (Gaussian Sharpen with N=2)

**Gaussian High Pass**


Gaussian High Pass filter is used to extract a high frequency component of the image.

**Filter Size**

As the filter size of Gaussian High Pass filter becomes larger, lower frequency component is erased and high frequency component is left.



Input Image



**Result Image (Gaussian High Pass with N=3)**


## Vertical Gradient

Vertical Gradient filter can be used to highlight horizontal edges and texture in the image.


### Filter Size

As the filter size of Vertical Gradient filter becomes larger, the smaller shade can be neglected and the bigger shade can be extracted.

In the example below, it extracts horizontal processing marks.



**Input Image**



**Result Image (Vertical Gradient with N=1)**


## Horizontal Gradient

Horizontal Gradient filter can be used to highlight vertical edges and texture in the image.


### Filter Size

As the filter size of Horizontal Gradient filter becomes larger, the smaller shade can be neglected and the bigger shade can be extracted.

In the example below, it extracts the vertical processing marks.



Input Image




Result Image (Horizontal Gradient with N=1)

### Gradient Magnitude

Gradient Magnitude filter is used to output the magnitude of the shade gradient in images. Gradient Magnitude filter cannot designate the filter size or the number of the iterations.




Input Image




**Result Image (Gradient Magnitude)**

## Gradient Direction

Gradient Direction filter is used to output the direction of the shade gradient in images. Direction of the shade gradient that becomes dark as it goes down (downward) is assigned to 128. Shade gradient number 64 means left, and 192 means right. Upward shade gradient is assigned to near 0 and near 255. Gradient Direction filter cannot designate the filter size or the number of the iterations.



**Input Image**



**Result Image (Gradient Direction)**

## Negative

Negative filter can be used to reverse the light and shade to make dark areas bright and bright areas dark of Input Image. Negative filter cannot designate the filter size or the number of the iterations.



Input Image



Result Image (Negative)

## Contrast Equalization

Contrast Equalization filter adjusts the brightness of the entire image to certain value to make entirely dark image bright and bright image dark. Because the brightness gets a certain value, it can easily configure the threshold of the command tools. Contrast Equalization filter cannot designate the filter size or the number of the iterations.




Input Image



Result Image (Contrast Equalization)

## 7.28 COLOR EXTRACTION TOOL


Color Extraction Tool creates the color extracted image from a color image on the basis of the color extraction parameters. This tool can be inserted only under Image Preprocess Tool. And, in the case of the camera which is set up in the vision process or camera view is the color camera, this tool can be used. By adding several Color Extraction Tools as follows, Color Extraction Tools create the color extracted images based on different color extraction parameters and each command tool can use a different color extracted image.



To use the result image created by Color Extraction Tool in a command tool, open the setup page of the command tool and then select the name of Color Extraction Tool in the drop-down box of the [Input Image].

Input Image:

If you select Color Extraction Tool in the tree view of the setup page of the vision process, a setup page like the one shown below appears.



## 7.28.1 Setting the Parameters

### Base Color

Tap the [Set] button and enclose the area of the color to be extracted with the rectangle. When the base color is trained, it is displayed on the left side of the [Set] button.

### Mask

When the rectangle specified for Base Color contains other colors than the one to be extracted, tap the [Edit] button to mask the unexpected colors. When the [Enable] check box is unchecked, the mask is ignored.

### Base Color Components

Red, Green, and Blue (RGB) components and Hue, Saturation, and Intensity (HSI) components of the base color are displayed. They can be individually adjusted. RGB components have the range of 0-255. Hue is an angle from 0° to 360°. 0° is red, 120° is green, and 240° is blue. Saturation has the ranges from 0% to 100%. Intensity has the ranges from 0 to 255.

### Adjustment

Adjust the color extraction ranges (the position and size of white ellipses which are displayed on the histogram images).

### Intensity

Adjust the intensity range of the color extraction. The center position and radius of the ellipse can be adjusted along the intensity axis (the magenta axis on the histogram image).

### Saturation

Adjust the saturation range of the color extraction. The center position and radius of the ellipse can be adjusted along the saturation axis (the green axis on the histogram image).

### Hue

Adjust the hue range of the color extraction. The center position and radius of the ellipse can be adjusted along the hue axis (the cyan axis on the histogram image).



## Save Result Image

If this item is checked, the result image is stored in the selected image register. When there is no image register, an error message is displayed. For the details of the image register, refer to 9.4.1 “IRVSNAP, IRVFIND”.

## Image Display Mode

Select the image display mode from the following choices.

### Color

Display the input color image.

### Grayscale

Display the input image as a grayscale image.

### Color Extracted

Display the color extracted image which is bright in areas that match the trained color and dark everywhere else.

### Histogram

Display how the specified color is distributed in the intensity/saturation/hue space (the color space).

### Histogram (All)

Display how all colors of the image are distributed in the color space.

### Histogram (Trained)


Display how all colors in the trained area are distributed in the Hue, Saturation, and Intensity (HSI) color space. This mode is enabled only after training the base color.

## Histogram brightness

Adjust the brightness (intensity) of a histogram only when one of three histogram modes is selected.

## Command tools using this Result Image


The name of command tools which use the result image of this Color Extraction Tool is displayed. When this Color Extraction Tool is changed, verify that these command tools still operate as intended.




## 7.28.2 Training the Color Extraction Parameters

---


Here is an example of the training procedure for extracting blue.




- 1 Tap the [Set] button of [Base Color] and enclose the color to be extracted with the red rectangle.




- 2 Press F4 OK, then the average color in the specified rectangle is set to [Base Color].




- 3 Change [Image Display Mode] to [Color Extracted]. You can see that the area trained as [Base Color] and their neighborhoods are extracted clearly but a part of the blue cap is not extracted clearly.



- 4 Increase [Radius] of [Intensity] to enclose more of the range of the blue cap color. You can also change the radius of the hue and saturation if necessary, depending on the image.



- 5 Change [Image Display Mode] to [Color Extracted]. You can see that more of the blue cap area is now extracted clearly.




#### NOTE

When there is only one Color Extraction Tool in the vision process, the color extraction can be executed on the camera. When the color extraction is executed on the camera, the execution time will be faster. For details, please refer to the Subsection 4.1.2 “Color Camera”.

### 7.28.3 Running a Test

Press F4 FIND to run a test and see if the color extraction tool operates properly.



### Time to Find


The time the Color Extraction Tool took is displayed in milliseconds.

## 7.28.4 Overridable Parameters

This command tool has no parameters that can be overridden with Vision Override.

## 7.29 1-D BARCODE TOOL

The 1-D barcode tool finds 1-D barcode in an image and reads the string contained in the 1-D barcode. The tool is available only with the reader vision process. If you select the 1-D barcode tool in the tree view of the setup page for the vision process, a screen like the one shown below appears.



The following 1-D barcode are supported.

- Interleaved 2-of-5
- Code 39
- NW7 (Codabar)

- EAN (JAN)
- UPC

**NOTE**

1-D Barcode Tool requires that the narrowest bar appears at least 3 pixels in width in the image in order to be decoded reliably.

## 7.29.1 Setting the Parameters

Set the barcode parameters.

### Input Image

Select the image which is used for training search area and detection 1-D Barcode. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this 1-D Barcode Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

### Barcode Type

The types of barcodes supported by the 1-D barcode tool. Select one of the followings:

- Interleaved 2-of-5
- Code 39
- NW7 / Codabar
- EAN / UPC

Refer to “7.29.4 Terminologies” for more information.

### Num. Scan Lines

The number of scan lines used to read the 1-D barcode. Each scan line goes across the 1-D barcode and reads the edge transitions and uses the data to decode the 1-D barcode.

### Contrast Threshold

The minimum acceptable contrast of boundaries between bars and spaces. The default value is 76.5, and the minimum threshold to be input is 1. The smaller the value is and the more an obscure barcode is detected, but it could take more time for the image processing.

### Code Subtype

The subtype of EAN barcodes. This can be selected when “Barcode Type” is “EAN/UPC”. Select one of the followings:

- EAN-13
- UPC

### Start Digit

The start digit for EAN barcodes. This can be selected when “Barcode Type” is “EAN / UPC” and “Code Subtype” is “EAN-13”.

### Model ID

When you have two or more 1-D barcode tools, you can assign each a unique model ID so that your TP program can distinguish with which 1-D barcode tool the barcode is decoded.

## Score Threshold

The score is the percentage of scan lines that successfully decoded the 1-D barcode. The whole find is regarded as success when the score exceeds the threshold. The value from 10 to 100 can be set, and the default is 20. The smaller value could lead to a wrong detection.

## Use second chance decode


When a usual 1-D barcode decoding fails, a 1-D barcode decoding using the second chance decode algorithm is executed if this checkbox is checked. The second chance decode algorithm is effective when the barcode that appears in the image is small or the 1-D barcode is not perpendicular to the camera optical axis. The chance of decoding a barcode improves if the “Use second chance decode” checkbox is checked, but the accuracy of decoding may deteriorate, sometimes resulting in a wrong string output. Therefore, you have to be careful when enabling the “Use second chance decode” checkbox. “Use second chance decode” is available when “Barcode Type” is “Interleaved 2-of-5” or “Code 39” or “NW7 / Codabar”.

## Search Window

Specify the window that the 1-D barcode tool searches for the specified barcode as follows.

- 1 Press F2 SNAP to change to the live image display.
- 2 Place the 1-D barcode near the center of the camera view.
- 3 Press F2 STOP and then press F3 SNAP to snap the image of the 1-D barcode.
- 4 Tap the [Set] button.
- 5 Enclose the 1-D barcode within the red rectangle that appears, and press F4 OK. The search window should have blanks on both sides of the barcode with tenfold width of Narrow Bar.

For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”




## Show Almost Found

If the 1-D barcode failed to be found because it fell just short of meeting the score, its test result is displayed. The result appears in a red rectangle on the image.

## 7.29.2 Running a Test

Press F4 SNAP to run a test and see if the 1-D barcode was properly found.



### Found

If the result is successfully obtained, 1 is displayed. If the tool fails to find the 1-D barcode, 0 is displayed.

### Almost Found

If the “Show Almost Found” checkbox is checked and the 1-D barcode failed to be found because it was slightly outside the specified range, 1 is displayed. Otherwise 0 is displayed.

### Time to Find

The time the decoding process took is displayed in milliseconds.

### Found Result Table 1

The following values are displayed.

#### Row, Column

The found position of the 1-D barcode (unit: pixel).

#### Angle

The found angle of the 1-D barcode (unit: degrees).

#### Score

The percentage of scan lines that successfully decoded the barcode. If the barcode is decoded by using the second chance decode algorithm, the score is always 100.

#### Second Chance?

If the barcode decoded by using the second chance decode algorithm, “YES” is displayed. “NO” is displayed in the following cases.

- “Use second chance decode” checkbox is not checked.
- “Barcode Type” is “EAN / UPC”.



- The second chance decode algorithm was not used when decoding the barcode.
- The decoding failed.

**String Result**

The decoded string.

**Unknown Chars**

The number of unknown characters in the decoded string.

**Found Result Table 2**

The following values are displayed.

**Scan Line**

The index of the scan line.

**Line Status**

Scan status of the scan line. “OK” is displayed when the scan line successfully decoded the barcode. “NG” is displayed when the scan line failed decoding.

**0-Crossings**

The number of the boundaries between bars and spaces.

**Narrow bars**

The number of found Narrow Bars on the scan line. This column is displayed only when “Barcode Type” is “Interleaved 2-of-5” or “Code 39” or “NW7 / Codabar”.

**Narrow Spaces**

The number of found Narrow Spaces on the scan line. This column is displayed only when “Barcode Type” is “Interleaved 2-of-5” or “Code 39” or “NW7 / Codabar”.

**Wide bars**

The number of found Wide Bars on the scan line. This column is displayed only when “Barcode Type” is “Interleaved 2-of-5” or “Code 39” or “NW7 / Codabar”.

**Wide Spaces**

The number of found Wide Spaces on the scan line. This column is displayed only when “Barcode Type” is “Interleaved 2-of-5” or “Code 39” or “NW7 / Codabar”.

**Bar Elements**

The number of found bars on the scan line. This column is displayed only when “Barcode Type” is “EAN / UPC”.

**Space Elements**

The number of found spaces on the scan line. This column is displayed only when “Barcode Type” is “EAN / UPC”.

---

## 7.29.3 Overridable Parameters

---

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.29.4 Terminologies

---

This section explains some terminologies for 1-D barcode tool.

### Interleaved 2-of-5

Interleaved 2-of-5 is mainly used on the distribution industry. The following figure shows an example of Interleaved 2-of-5.



Interleaved 2-of-5 is made up of black lines that have two kinds of width and blanks that have two kinds of width. A heavier black line is referred to as Wide Bar, a finer black line is referred to as Narrow Bar, a heavier blank will be referred to as Wide Space, and a finer blank is referred to as Narrow Space in this manual. Interleaved 2-of-5 can encode an even-figure number.

Interleaved 2-of-5 is a variable-length barcode. Keeping the narrow bar to be at least 3 pixels in width, 1-D Barcode Tool can decode up to 20 characters of Interleaved 2-of-5 in a 640x480 image. It is recommended to make applicability test in advance because the readable number of characters may change according to conditions.

### Code 39

Code 39 is mainly used on the automobile and electronics industry. The following figure shows an example of Code 39.



Code 39 is made up of Wide Bar, Narrow Bar, Wide Space, and Narrow Space the same as Interleaved 2-of-5. Code 39 can encode a string that consists of single byte characters such as alphabets, numerals, and some symbols.

Code 39 is a variable-length barcode. Keeping the narrow bar to be at least 3 pixels in width, 1-D Barcode Tool can decode up to 8 characters of Code 39 in a 640x480 image. It is recommended to make applicability test in advance because the readable number of characters may change according to conditions.

### NW7 (Codabar)

NW7, which is also known as Codabar in the North American market, is mainly used tags for delivery service. The following figure shows an example of NW7.



NW7 is made up of Wide Bar, Narrow Bar, Wide Space, and Narrow Space the same as Interleaved 2-of-5. NW7 can encode a string that consists of single byte characters such as alphabets, numerals, and some symbols.

NW7 is variable-length barcode. Keeping the narrow bar to be at least 3 pixels in width, 1-D Barcode Tool can decode up to 11 characters of NW7 in a 640x480 image. It is recommended to make applicability test in advance because the readable number of characters may change according to conditions.

## EAN

EAN is used world wide for various consumer products. The following figure shows an example of EAN.



EAN is made up of black lines that have four kinds of width and blanks that have four kinds of width. A black line is referred to as Bar, a blank is referred to as Space in this manual. There are several variations of EAN, but *iR*Vision supports only EAN-13. EAN-8 is not supported. EAN can encode a 13-digit number. JAN is compatible to EAN, and *iR*Vision can decode JAN too. If you want to decode JAN, select “EAN / UPC” for “Barcode Type”.

## UPC


UPC is used for marking products in the North American markets. The following figure shows an example of UPC.



UPC is made up of bars and spaces the same as EAN. There are several variations of UPC, but *iR*Vision supports only UPC-A. UPC-E is not supported. UPC can encode a 12-digit number.

## 7.30 2-D BARCODE TOOL

The 2-D barcode tool finds 2-D barcode in an image and reads the string contained in the 2-D barcode. The tool is available only with the reader vision process. If you select the 2-D barcode tool in the tree view of the setup page for the vision process, a screen like the one shown below appears.



The following 2-D barcode are supported.

- Data Matrix Code
- QR Code

### 7.30.1 Setting the Parameters

Set the barcode parameters.

#### Input Image

Select the image which is used for training search area and detection 2-D Barcode. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this 2-D Barcode Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

#### Model ID


Specify the model ID of the found 2-D barcode.

#### Search Window

Specify the area of the image to be searched as follows.

- 1 Press F2 LIVE to change to the live image display.
- 2 Place a 2-D barcode near the center of the camera view.
- 3 Press F2 STOP and then press F3 SNAP to snap the image of the 2-D barcode.
- 4 Tap the [Set] button.
- 5 Enclose the 2-D barcode within the red rectangle that appears, and press F4 OK. Data Matrix Code requires at least a 1 cell wide white blank around the entire barcode, and QR Code requires a 2 cell

wide white blank around the entire barcode. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”



### Barcode Type

The types of 2-D barcodes supported by the 2-D barcode tool. Select one of the following:

- Data Matrix Code
- QR Code

Refer to “7.30.4 Terminologies” for more information.

### Threshold Mode

The threshold value to binarize the image. This can be selected when “Barcode Type” is “Data Matrix Code”. Select one of the followings:





#### Fixed

The binary threshold is set to the specified threshold set in “Threshold Value”.





#### Auto

The binary threshold is automatically adjusted according to the brightness of the image.

### Threshold Value

Set the threshold by entering a value or by tapping , , , and  buttons. This can be selected when “Barcode Type” is “Data Matrix Code”.

### Contrast Threshold

Set the contrast threshold by entering the value or by tapping , , , and  buttons. This can be selected when “Barcode Type” is “QR Code”.

### Image Display Mode

Select the image display mode for the Setup Page.

#### Original Image

Display the camera image as it is.

**Processed Image**

Display the image resulting from the image processing.

**Binary Image**

Display the processed image in binary using the current threshold. This can select when “Barcode Type” is “Data Matrix Code”.

**Image + Edge**

Display the processed image with the edges found above the current contrast threshold plotted in green. This can be selected when “Barcode Type” is “QR Code”.

**Image Preprocessing Filter**

Select the filter to be applied to the image from the options listed below.

**None**

Do not perform Image processing filter.

**Blur**

Enable this filter to eliminate fine surface texture or image noise that may make it difficult to read the 2-D barcode.

**Median**

Enable this filter to eliminate fine surface texture or image noise that may make it difficult to read the 2-D barcode, but without blurring the edges.

**Sharpen**

Enable this filter to enhance the contrast of the edges to make it easier to read the 2-D barcode.,

**Morphology**

Enable this filter to perform morphology operations on the image to enable it to read the 2-D barcode. The operation is selected on the drop down list of “Morphology Operator”.

**Morphology Operator**

Select the filter to be applied to the binarized image from the options listed below.

**Erode**

Erodes the black area. Helps reduce the black pixel noise.

**Dilate**

Dilates the black area. Helps reduce the white pixel noise.

**Open**

Erodes the black area and then dilates it. This will connect white blobs that are close to touching or disconnect black blobs that are slightly touching,

**Close**

Dilates the white area then erodes it. This will connect black blobs that are close to touching or disconnect white blobs that are slightly touching.

### Filter Iteration


The number of iterations to perform on the selected filter.

### Grayscale Histogram

It displays the grayscale histogram when “Barcode Type” is “Data Matrix Code”. It also displays a vertical green line to indicate the binary threshold.

## 7.30.2 Running a Test

Press F4 SNAP to run a test and see if the barcode was properly found.



### Found

If the result is successfully obtained, 1 is displayed. If the tool fails to find the 2-D barcode, 0 is displayed.

### Almost Found

If the 2-D barcode is located but not decoded correctly, 1 is displayed. Otherwise 0 is displayed.

### Im Prcs Time

The time it took to perform the image processing.

### Total Time

The total time it took to read the 2-D barcode, not including the time it took to snap the image.

### Found Result Table

The following values are displayed in black if the number found is 1 and in red if the number almost found is 1. The following values are displayed.

### Row, Column

The found position of the found code in the image in pixels. It is the coordinates of the pixel at the “L” corner of the Data Matrix code when “Barcode Type” is Data Matrix Code. It is the coordinates of the pixel at the center of top-left Position Detection Pattern when “Barcode Type” is “QR Code”.

**Ang**

The found angle of the barcode in degrees.

**Score**

The relative number of bit errors that were corrected when reading the code. 100% indicates that there were no bit errors. A value of 80% indicates that some number of bit values were corrected equal to about 20% of the error-correcting capacity of this particular 2-D barcode. The error-correcting capacity varies from 14% to 28% for Data Matrix Code and from 7% to 30% for QR Code. If the score reaches 0%, the code cannot be read.

**Contrast**

The average contrast between dark cells and light cells.

**Size**

The size of the found 2-D barcode in terms of the number of cells of width and height.

**Cell Size**

The average width and height of the individual cells in pixels. If this value is below about 2.5, the code may be found less reliably.

**Len**

The length of the decoded string.

**String Result**

The first 254 characters of the decoded string.

## 7.30.3 Overridable Parameters

---

This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.30.4 Terminologies

---

This section explains terminologies of 2-D barcode tool.

### Data Matrix Code

Data Matrix Code is the 2-D barcode which is also called Data Code or Data Matrix. Data Matrix Code is used in the production of LCD, semiconductor wafer and so on. Data Matrix Code is capable of encoding up to 3116 digits, 2335 alphanumeric characters, or 1555 bytes. The 2-D barcode tool only sends the first 254 characters of the string to a string register. The following figure shows an example of Data Matrix Code.






Data Matrix Code is made up of Alignment Pattern, Timing Cell and Data Region. Each square that makes up Data Region is referred to as Cell.



**Alignment Pattern**



**Timing Cell**



**Data Region**

There are two types of Data Matrix Code: ECC 200 and the older ECC 000-140. The 2-D barcode tool only decodes ECC 200.

The 2-D barcode tool does not support the following encoding methods:

- EDIFACT
- ANSI X12

The 2-D barcode tool requires that the cell width and height be at least 2.5 pixels in order to decode reliably. The specification of Data Matrix Code requires a 1 cell wide white border around the entire code. The following table shows how big various sizes of Data Matrix Code have to be relative to the 640x480 iRVision image to be found reliably.

For example, the 36x16 Data Matrix Code shown in the example image would require minimum pixel dimensions of 95x45 to be found reliably.

Data Matrix Code size (unit: the number of cell)		The Maximum number of characters	The minimum size of Data Matrix Code (unit: pixel)	
Row	Col		Width	Height
10	10	6	30	30
12	12	10	35	35
14	14	16	40	40
16	16	24	45	45
18	18	36	50	50
20	20	44	55	55
22	22	60	60	60
24	24	72	65	65
26	26	88	70	70
32	32	124	85	85
36	36	172	95	95
40	40	228	105	105
44	44	288	115	115
48	48	348	125	125
52	52	408	135	135
64	64	560	165	165
72	72	736	185	185
80	80	912	205	205
88	88	1152	225	225
96	96	1392	245	245
104	104	1632	265	265
120	120	2100	305	305
132	132	2608	335	335
144	144	3116	365	365


Data Matrix Code size (unit: the number of cell)		The Maximum number of characters	The minimum size of Data Matrix Code (unit: pixel)	
Row	Col		Width	Height
18	8	10	50	25
32	8	20	85	25
26	12	32	70	35
36	12	44	95	35
36	16	64	95	45
48	16	98	125	45

**QR Code**

QR Code is used on automobile parts, stationary and so on. QR Code is capable of encoding up to 7089 digits, 4296 alphanumeric characters, 2953 bytes of characters, or 1817 Kanji characters. The 2-D barcode tool only sends the first 254 characters of the string to a string register. The following figure shows an example of QR Code.



QR Code is made up of Position Detection Pattern, Alignment Pattern, Timing Pattern and Data Region. Each square that makes up Data Region is referred to as Cell.



There are several types of QR Code: QR Code Model 1, QR Code Model 2, Micro QR Code, and so on. The 2-D barcode tool supports QR Code Model 2 and Micro QR Code.


The 2-D barcode tool requires that the cell width and height be at least 2.5 pixels in order to decode reliably. The specification of QR Code requires a 2 cell wide white border around the entire code. The following table shows how big various sizes of QR Code have to be relative to the 640x480 iRVision image to be found reliably.

For example, the 29x29 QR Code shown in the example image would require minimum pixel dimensions of 83x83 to be found reliably.

Data Matrix Code size (unit: the number of cell)		The version of QR code (M* is micro QR code)	The minimum size of Data Matrix Code (unit: pixel)	
Row	Col		Row	Col
11	11	M1	38	38
13	13	M2	43	43
15	15	M3	48	48
17	17	M4	53	53
21	21	1	63	63
25	25	2	73	73
29	29	3	83	83
33	33	4	93	93
37	37	5	103	103
41	41	6	113	113
45	45	7	123	123
49	49	8	133	133
53	53	9	143	143
57	57	10	153	153
61	61	11	163	163
65	65	12	173	173
69	69	13	183	183
73	73	14	193	193
77	77	15	203	203
81	81	16	213	213
85	85	17	223	223
89	89	18	233	233
93	93	19	243	243
97	97	20	253	253
101	101	21	263	263
105	105	22	273	273
109	109	23	283	283
113	113	24	293	293
117	117	25	303	303
121	121	26	313	313
125	125	27	323	323
129	129	28	333	333
133	133	29	343	343
137	137	30	353	353
141	141	31	363	363
145	145	32	373	373
149	149	33	383	383
153	153	34	393	393
157	157	35	403	403
161	161	36	413	413
165	165	37	423	423
169	169	38	433	433
173	173	39	443	443
177	177	40	453	453

## 7.31 EDGE POINTS LOCATOR TOOL

This locator tool extracts all the points on the outline of a workpiece.



### 7.31.1 Adjusting the Parameters

Adjust the parameters.

#### Input Image

Select the image which is used for training area and detection. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this Edge Point Locator Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

#### Starting Model ID


Specify the head of the model IDs that are assigned to found chains in order.

#### Minimum Contrast


Specify the minimum permissible grayscale contrast for the search. If you set a small value, this locator tool will be able to find the chains in obscure images as well but take longer to complete the location process. If this locator tool tends to inadequately find blemishes and other unwanted edges with low contrast, try setting a larger value. Those image features whose contrast is lower than the specified value are ignored.

#### Max. Gap to Trace

Specify the maximum permissible size of gaps to fill when tracing a chain, in pixels. If the size of the gap between two chains is smaller than the specified value before filtering, this locator tool connects the chains by filtering. When chains get disconnected because of blemishes, this locator tool can connect the chains smoothly by making the specified value larger.



Maximum Gap to Trace: 1



Maximum Gap to Trace:2

### Min. Edge Chain Length

Specify the minimum permissible length required for chains to be found, in pixels. If the length of a chain is shorter than the specified value, the chain is ignored.

### Search Window

Specify the area of the image to be searched. The smaller the area is, the faster the location process will be. To change the search window, tap the [Set] button. When a rectangle appears on the image, adjust its size and location.

If this locator tool is a child tool of another location tool, the search window will automatically move and rotate in accordance with the found result from the parent tool.

### Run-Time Mask

Specify an area of the search window that you do not want processed, as an arbitrary geometry. Use this function when you want to specify a search window of an arbitrary geometry, such as a circle- or donut-shaped window. The filled area will be masked in the rectangle specified as the search window and will not be subject to the image processing. To change the run-time mask, tap the [Edit] button.

### Plot Mode

Choose whether to display points or chains.

#### Points


Extracted points are displayed.

#### Chains

Found chains are displayed.

## 7.31.2 Running a Test

Press F4 to run a test and see how properly the tool can find chains and extract points.



### Found Points

The total number of points extracted from found chains is displayed. These points are returned to the vision process.

### Found Chains

The number of found chains is displayed.

### Time to Find

The time the location process took is displayed in milliseconds.

### Found Result Table (When Plot Mode is Points)

The following values are displayed.

#### Row(V), Column(H)

The coordinate values of the extracted point (unit: pixels).

#### Angle

The orientation of the edge gradient vector at the extracted point (unit: degrees). The vector points from the bright side to the dark side.

#### Contrast

The grayscale magnitude of the edge contrast at the extracted point.

#### Model ID

The Model ID assigned to the found chain that contains the extracted point.

### Found Result Table (When Plot Mode is Chains)

The following values are displayed.

**Length**

The number of points extracted from the found chain (unit: pixel).

**Avg. Contrast.**

The average grayscale contrast of the points extracted from the found chain.

**Model ID**


The Model ID assigned to the found chain.

**7.31.3 Overridable Parameters**

This command tool has no overridable parameters that can be overridden with Vision Override.

**7.32 SELECTED EDGE POINTS LOCATOR TOOL**

This locator tool extracts the selected points on the outline of a workpiece by filtering.

**7.32.1 Adjusting the Parameters**

Adjust the parameters.

**Input Image**

Select the image which is used for training area and detection. When the vision process has a Image Filter Tool or a Color Extraction Tool, you can select a filtered image as the input image to this Selected Edge Point Locator Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.28 “Color Extraction Tool”, 7.44 “COLOR COMPONENT TOOL”, 7.45 “IMAGE ARITHMETIC TOOL”, and 7.46 “FLAT FIELD TOOL”.

**Starting Model ID**


Specify the head of the model IDs that are assigned to found chains in order.

## Minimum Contrast


Specify the minimum permissible grayscale contrast for the search. If you set a small value, this locator tool will be able to find the chains in obscure images as well but take longer to complete the location process. If this locator tool tends to inadequately find blemishes and other unwanted edges with low contrast, try setting a larger value. Those image features whose contrast is lower than the specified value are ignored.

## Max. Gap to Trace

Specify the maximum permissible size of gaps to fill when tracing a chain, in pixels. If the size of the gap between two chains is smaller than the specified value before filtering, this locator tool connects the chains by filtering. When chains get disconnected because of blemishes, this locator tool can connect the chains smoothly by making the specified value larger.



Maximum Gap to Trace: 1



Maximum Gap to Trace: 2

## Min. Chain Length

Specify the minimum permissible length required for chains to be found, in pixels. If the length of a chain is shorter than the specified value, the chain is ignored.

## Closed Chains Only


If checked, only find chains that form closed loops.

## Max. Meandering

Specify the maximum allowed meandering in degrees. A meandering is the amount that a chain changes direction. If the meandering of a chain is larger than the specified value, the chain is ignored. For example, an “S” shape will have a meandering value of about 360 degrees, since it turns 180 degrees to the left and then 180 degrees to the right. The more meandering and longer a chain is, the larger this value is. On the other hand, a perfect straight line will have a meandering value of 0 since it does not change direction.



Maximum Meandering: 9000  
Found Chains: 42



Maximum Meandering: 90  
Found Chains: 22



### Point Sel. Method

Choose the method used to select points from found chains.

#### Deviation from a Line


Each chain is approximated by a polygonal line whose vertices are on the chain. And the vertices are selected points. The polygonal line is chosen so that the maximum of distances from each straight segment of the polygonal line to the farthest point on the chain's curved segment corresponding to the straight segment is less than the value specified for "Max. Deviation From a Line". This results in fewer points along straighter sections of the chain and more points along sharply curved sections.

#### Equal Length Segments


The points in each chain are sampled at an interval specified as the value of "Point Sample Interval".

### Max. Line Deviation

Specify the permissible maximum of distances from each straight segment of polygonal lines to the farthest point on chains' curved segment corresponding to the straight segment when "Deviation from a Straight Line" is selected as "Point Selection Method". It is specified in pixels. Specify 0.0 to select every point on the chains.




**Max. Deviation From a Line: 2.0**  
**Found Points: 35/1682**




**Max. Deviation From a Line: 10.0**  
**Found Points: 17/1682**

### Point Sample Interval

Specify the interval for selecting points from chains when "Equal Length Segments" is selected "Point Selection Method". It is specified in pixels. Specify 1 to select every point on the chains.



**Point Sample Interval: 30**  
**Found Points: 61/1682**



**Point Sample Interval: 50**  
**Found Points: 38/1682**

## Search Window

Specify the area of the image to be searched. The smaller the area is, the faster the location process will be. To change the search window, tap the [Set] button. When a rectangle appears on the image, adjust its size and location. If this locator tool is a child tool of another location tool, the search window will automatically move and rotate in accordance with the found result from the parent tool.

## Run-Time Mask

Specify an area of the search window that you do not want processed, as an arbitrary geometry. Use this function when you want to specify a search window of an arbitrary geometry, such as a circle- or donut-shaped window. The filled area will be masked in the rectangle specified as the search window and will not be subject to the image processing. To change the run-time mask, tap the [Edit] button.

## Plot Mode

Choose whether to display points or chains.

### Points

Selected points are displayed.

### Chains

Found chains are displayed.

## Image Display Mode

Select the image display mode for the Setup Page.

### Plot Edge Points Only

The found chains are plotted in blue and the selected points are plotted in green.

### Plot Direction Vectors

The found chains are plotted in blue. The selected points are plotted in green. The direction vectors are plotted in yellow. Each direction vector corresponds to a selected point and points from the selected point towards the dark side of the edge at that point.

### Plot Labels

The found chains are plotted in blue. The selected points and their index numbers are plotted in green. The index numbers are also displayed in the Found Result Table. Some of the index numbers are not plotted if the selected points are too close together.


	Row	Column	Angle	Contrast	Model ID
1	370.8	198.0	-2.1	89	1
2	375.6	323.0	-1.4	171	1
3	374.6	351.0	13.4	133	1
4	367.7	375.7	22.5	108	1
5	360.7	389.7	30.2	91	1
6	353.7	399.7	29.5	74	1
7	338.8	414.8	53.4	89	1
8	318.7	426.7	70.3	94	1
9	291.0	434.8	78.0	120	1

### Plot Vectors and Labels

The found chains are plotted in blue. The selected points and their index numbers are plotted in green. The direction vectors corresponding to the selected points are plotted in yellow, in green.

## 7.32.2 Running a Test

Press F4 SNAP to run a test and see how properly the tool can find chains and select points.



### Found Points

The total number of the points selected from found chains is displayed. These points are returned to the vision process.

### Found Chains

The number of found chains is displayed.

### Total Points

The total number of all the points extracted (but not selected) from found chains.

### Time to Find

The time the location process took is displayed in milliseconds.

### Found Result Table (When Plot Mode is Points)

The following values are displayed.

#### Row(V), Column(H)

The coordinate values of the selected point (unit: pixels).

#### Angle

The orientation of the edge gradient vector at the selected point (unit: degrees). The vector points from the bright side to the dark side.

#### Contrast

The grayscale magnitude of the edge contrast at the selected point.

#### Model ID

The Model ID assigned to the found chain that contains the selected point.

## Found Result Table (When Plot Mode is Chains)

The following values are displayed.

### Length

The number of points extracted from the found chain (unit: pixel).

### Avg. Contrast.

The average grayscale contrast of the points extracted from the found chain.

### Closed.

Whether the chain is a closed loop or not. If the chain is a closed loop, [Yes] is displayed. If the chain is not a closed loop, [No] is displayed.

### Meandering

The meandering value of the edge chain.

### Model ID


The Model ID assigned to the found chain.

## 7.32.3 Overridable Parameters


This command tool has no overridable parameters that can be overridden with Vision Override.

## 7.33 SEARCH AREA RESTRICTION TOOL

The search area restriction tool enables a search vision process for bin picking to process only small limited areas of the input image where states of plies of workpieces have just been changed. By processing only the small areas, the processing time can be reduced. The search area restriction tool is used with the workpiece management function that is included in the *iR*Vision Bin Picking option.



If you select the search area restriction tool in the tree view of the setup page of the vision process, a screen like the one shown below appears.



### 7.33.1 Setting the Parameters

Set the parameters.

#### Enable Restrict

Specify the index number of the register you want to use to change the following two modes.


#### Mode A

The vision process finds workpieces in the small search areas where the situations of piles of workpieces have just been changed in the last cycle.

#### Mode B

The vision process finds workpieces in a fixed wide search window on the image that corresponds to the bin area.

To change the above two modes, the value of the register specified in [Enable Restrict] must be changed. If the specified register is set to 1, Mode A is selected. If the specified register is set to a value other than 1, Mode B is selected.



## Search Window

Specify the range of the area of the image to be searched. The default value is the entire image. To change the search window, tap the [Set] button. When a rectangle appears on the image, change the search window. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.

## Run-Time Mask

Specify an area of the search window that you do not want processed, as an arbitrary geometry. Use this function when you want to specify a search window of an arbitrary geometry, such as a circle or donut-shaped window. The filled area will be masked in the rectangle specified as the search window and will not be subject to the image processing. To change the run-time mask, tap the [Edit] button. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.

## Parts List ID

Specify a parts list ID to use.

## Diam. Of Sch. Area


Specify the size of limited search area set at a position where states of piles of workpieces have been changed.

## 7.33.2 Setting a Position where Plied Workpieces State Changed

When to set a position where the states of piles of workpieces is the time of executing IPSETTARPOS.PC. For this KAREL programs, please refer to “R-30iB/R-30iB Mate CONTROLLER iRVision Bin Picking Application OPERATOR'S MANUAL”.

## 7.33.3 Running a Test

Press F4 to run a test and see if the tool can find workpieces properly.



## Found

The number of found workpieces is displayed.

## Time to Find

The time the location process took is displayed in milliseconds.

### Found Results table

The items displayed differ depending on the tools set as child tools of the search area restriction tool. For the explanation of each measured value, see the pages describing the set child tools.


## 7.33.4 Overridable Parameters

This command tool has no overridable parameters that can be overridden with Vision Override.


## 7.34 AREA SENSOR PREPROCESS TOOL

The Area Sensor Preprocess tool removes 3D points on the container and outliers, which lead to incorrect results, from a 3D map. The Area Sensor Preprocess tool has mainly the following three functions to remove unnecessary 3D points.

- Bottom Removal : The function to remove 3D points on the container bottom
- Container Removal : The function to remove 3D points on the container rim and wall
- Outlier Removal : The function to remove 3D points considered as outliers



If you select the Area Sensor Preprocess Tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.



## 7.34.1 Setting the Parameters of Bottom Removal


Set the parameters to remove 3D points on the container bottom.

### Enable

If the checkbox is checked, some 3D points on the container bottom are removed.

### Bottom Z

Set the height of the bottom of the container (units: mm). This value is the height of the container bottom from the XY plane of [Offset Frame] of the vision process. If the Z height of a 3D point is lower than the value of [Bottom Z], the 3D point is removed.



## 7.34.2 Setting the Parameters of Container Removal


Set the parameters to remove 3D points on the container rim and wall

### Enable

If the checkbox is checked, some 3D points on the container rim or wall are removed.


### Container Z

Set the height of the container rim (unit: mm). This value is the height of the container rim from the XY plane of [Offset Frame] of the vision process.



### Container Shape


Set the container shape as follows.

- 1 Place the container near the center of the camera view.
- 2 Press F6 2-3D SNAP to snap the image of the workpiece and acquire its 3D map.
- 3 Press the [Teach] button of [Container Shape], then a pointer in magenta  is displayed on a 2D image as shown below.
- 4 Move the pointer to the position of a vertex (corner) of the container rim and press the F4 OK. Then, the position is set and the pointer is displayed again.





- 5 Move the pointer to the position of the next unset vertex of the container and press the F4 OK. Then, the position is set and the pointer is displayed again.
- 6 This operation is done repeatedly to enclose the container shape as follows. Then the container shape can be set.



- 7 Up to 30 positions of the vertices can be set.

## Vertex Index

This is the index of each vertex of [Container Shape]. For the vertex specified by the textbox of [Vertex Index], the following operations can be executed to change [Container Shape].

### Move

Press the [Move] button to move the specified vertex.

### Add

Press the [Add] button to add a new vertex after the specified vertex.

**Delete**

Press the [Delete] button to delete the specified vertex.

**Ref. 2D Pos**

The reference position on a camera image is displayed when a preceding window shift tool that is at the same level as this tool is set and the window shift tool is set to shift a search window by using a result of 2D Locator Tool such as GPM Locator Tool.

**Ref. 3D Pos**

The reference position in [Offset Frame] of the vision process is displayed when a preceding window shift tool that is at the same level as this tool is set and the window shift tool is set to shift a search window by using a result of another vision process.

**Margin from Wall**

Set the margin of [Container Shape] (units: mm). The margin is the distance between the wall of the container and the border of the measurement area set inside [Container Shape]. 3D points outside the measurement area are removed. Specify a number between 0 and 1000.

**7.34.3 Setting the Parameters of Outlier Removal**


Set the parameters to remove 3D points considered as outlier

**Enable**

If the check box is checked, some 3D points considered as outlier are removed.

**Filter Size**

Select the filter size for removing some 3D points considered as outliers. For example, if the value is F, the filter is the area whose base is a  $2F + 1$  square parallel with the XY plane of the 3D Map. And if each 3D point whose Z height is far different from the heights of the other 3D points in the filter whose center is the 3D point, the 3D point is removed as an outlier. Specify a number between 1 and 10.

**Threshold**

Set the threshold which is used for judging if a 3D point is outlier (units: mm). If the difference between the 3D point and the median of the Z heights of all the other 3D points in the filter whose center is the 3D point is larger than the set value, the 3D point is removed as an outlier. Specify a number between 0 and 1000.

**Min. Num. Around**

Set the minimum required number of 3D points around each 3D point not removed as an outlier. If the number of 3D points which are not at the center of the filter but in the filter is lower than the set number, the center 3D point of the filter is removed as an outlier. If a value F was set as [Filter Size], specify a number between 1 and  $(2F + 1)^2 - 1$ . The larger the value, the more 3D points are removed.

## 7.34.4 Setting the Parameters

### Image Display Mode

Select the image display mode for the Setup Page.

#### 2D image

A 2D camera image and [Container Shape] are displayed.

#### 2D image + Result

A 2D Camera image, [Container Shape] and the measurement area calculated from [Container Shape] are displayed.

#### 3D Map

A 3D map is displayed.

#### 3D Map + Result


A 3D map is displayed. And the removed points are plotted in red.

### F6 2-3D Snap

A 2D camera image is snapped and a 3D map is acquired.

## 7.34.5 Running a Test

Press F4 FIND to run a test and see if the tool can remove 3D points on the container and outliers, which lead to incorrect results, from a 3D map.



### Time to Find

The time which the process removing 3D points on the container and outliers took is displayed (units: ms).

### Found Result Table

The following values are displayed.

**Total Number**

Total number of 3D points in a 3D map.

**Removed Number**

Number of 3D points removed as 3D points on the container or outliers.

**Left Number**


Number of 3D points not removed.

**7.34.6 Overridable Parameter**


This command tool has no overridable parameters that can be overridden with Vision Override.

**7.35 AREA SENSOR PEAK LOCATOR TOOL**

The Area Sensor Peak Locator tool finds the regional highest 3D point in a 3D map acquired by a 3D area sensor (local peaks) from a 3D map. By using the Area Sensor Peak Locator tool, the robot can pick up the workpieces in descending order of height. To use the Area Sensor Peak Locator tool, some 3D points which derive incorrect results and waste the processing time must be removed by the Area Sensor Preprocess tool.



If you select the Area Sensor Peak Locator Tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.



## 7.35.1 Setting the Parameters

### Preprocess Tool

Select the Area Sensor Preprocess tool which is used for detection. A preceding Area Sensor Preprocess tool that is set at the same level as this tool can be selected.

### Model ID


When you have taught two or more Area Sensor Peak Locator tools and want to identify which tool detected each workpiece, assign a distinct model ID to each tool. Because the model ID is output with offset data, robot programs can identify the model ID.

### Smoothing Level


Select the level of smoothing a 3D map. The larger the value is, the smoother the 3D map is. If there is a lot of noises in the 3D map, when detecting local peaks whose heights are same in real space, the found Z heights of the local peaks vary widely. Then, set a larger value to [Smoothing Level].

### Search Range

Set the size of the searching range to find local peaks. If the set value is R, the searching range is the range whose base is a '2R + 1' square parallel to XY plane on the 3D map. In the searching range whose center is a local peak, there exists no other local peak. Specify a number between 1 and 192. As shown in the figures below, the smaller number to make the search range narrow, the more local peaks are found. Besides, enough a large number was specified, the highest 3D point of the whole 3D map is found as a local peak. If a target workpiece is long, specify a number which is roughly half of the width of the workpiece as the set value. Otherwise, specify a number which is roughly half of the size of the workpiece.




Search Range: Narrow



Search Range: Wide

### Min. Neighborhood Pnts

Set the minimum permissible number of 3D points around each local peak. If the number of 3D points which are not at the center of the search range but in the search range is lower than the set number, the center 3D point of the search range can not be detected as a local peak. If a number R is set as [Search Range], specify a number between 1 and  $(2R + 1)^2 - 1$ .



## Image Display Mode

Select the image display mode for the Setup Page.

### Image

A 2D camera image is displayed.

### 3D Map

A 3D map is displayed.

## F6 2-3D Snap

A 2D camera image is snapped and a 3D map is acquired.

## 7.35.2 Running a Test

Press F4 FIND to run a test and see if the tool can find workpieces properly.

#	Row(v)	Column(H)	X	Y	Z	Score	Num. Comp. Points
1	379.1	444.0	-158.2	-76.5	870.5	90.2	249
2	343.8	346.7	-92.8	111.6	842.1	80.7	274
3	333.3	391.4	-72.1	22.7	840.9	80.3	287
4	427.7	337.0	-256.7	122.4	823.5	74.5	292

### Found

The number of found local peaks is displayed.

### Time to Find

Time to find is displayed (units: ms).

## Found Result Table

The following values are displayed.

### Vt, Hz

Found local peak position on a camera image.

### X, Y, Z

Coordinate values of the found local peak (units: mm).

### Score

Score of the found local peak. Z value of found position is output as the score after scaled so that the score becomes 100 when Z value of found position is greater than or equal to maximum Z value of [Range] in the 3D Area Sensor Vision Process setup and becomes 0 when that is less than or equal to minimum Z value of [Range] in the 3D Area Sensor Vision Process setup.

### Num. Comp. Points

The number of 3D points within the area whose center position is on the found local peak and size is specified by the [Search Range].

## 7.35.3 Overridable Parameter

---

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Local Peak Search Range


Specify a number between 1 and 192.

### Num. Neighborhood Points


Specify a number between 1 and  $(2 \text{ Local Peak Search Range} + 1)^2 - 1$ .

## 7.36 AREA SENSOR BLOB LOCATOR TOOL

The Area Sensor Blob Locator tool finds a set of 3D points which are continuously-distributed on a 3D map and outputs its found position. Hereafter, the set of 3D points is referred to as 3D blob. It can also measure the plane formed by the 3D blob. To use the Area Sensor Blob Locator tool, some 3D points which derive incorrect results and waste the processing time must be removed by the Area Sensor Preprocess tool.



If you select the Area Sensor Blob Locator Tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.



### 7.36.1 Setting the Parameters

#### Input Image

Select the image which is used for 3D blob detection. When the vision process has an Image Filter Tool or an Image Arithmetic Tool, you can select a filtered image as the input image to this Area Sensor Blob Locator Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26



“Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.45 “Image Arithmetic Tool”, and 7.46 “Flat Field Tool”.

## Preprocess Tool

Select the Area Sensor Preprocess tool which is used for detection. A preceding Area Sensor Preprocess tool that is set at the same level as this tool can be selected.

## Model ID

When you have taught two or more Area Sensor Blob Locator tools and want to identify which tool detected each workpiece, assign a distinct model ID to each tool. Because the model ID is output with offset data, robot programs can identify the model ID.


## Connecting Threshold – Z Height

Set the threshold of the difference between Z heights of 3D points (units: mm). If the difference between Z heights of adjacent 3D points is larger than this threshold, the adjacent 3D points are not connected with each other. Set a value between 0 and 100000.


## Connecting Threshold – Contrast

Specify whether or not to use features of 2D image when judging the connection of the 3D points constituting the 3D blob. If the checkbox is checked, those image features whose contrast is higher than the threshold are used for judging the connection of the 3D points constituting the 3D blob. Set a value between 1 and 200.

In the case that same size workpieces are located densely as shown in the figure below, the connection judgment by using Z height of 3D map causes to be found one 3D blob including some workpieces. But the connection judgment by using Z height of 3D map and features of 2D image causes to be found a 3D blob corresponding to each workpiece.




Connection judgment by  
Z height of 3D map




Connection judgment by  
Z height of 3D map + image feature

## Connecting Threshold – Normal Direction

Specify whether or not to use the normal directions of 3D points when judging the connection of the 3D points constituting the 3D blob. When the checkbox is checked, if the angle between the normal directions of adjacent 3D points are larger than the threshold, the 3D points are not connected with each other. Set a value between 0 and 180 degrees.



Connection judgment by  
Z height of 3D map



Connection judgment by  
Z height of 3D map +  
Normal Vectors of 3D map

### Normal Calc. Range

Set the size of the range to calculate a normal vector of a 3D point. If the set value is R, the range is the range whose base is a '2R - 1' square parallel to XY plane on the 3D map. Set a value between 2 and 10.

### Min. Blob Size

Set the threshold of the number of 3D points of a 3D blob. If the number of 3D points of a 3D blob is lower than this threshold, the 3D blob is removed from found results. Set a value between 1 and 45888.

### Found Position

Select the type of found positions from the followings:

#### Gravity Center

The center of gravity of 3D points which compose a 3D blob is output as a found position. If the checkbox of [Calculate plane] is checked, the center of gravity is calculated only from 3D points on the plane.

#### Dense Pos

The area where the density of 3D points is the highest in a 3D blob is found and the center position of the area is output as a found position. Densities are calculated in areas whose radii are defined by [Density Meas. Radius]. If the checkbox of [Calculate plane] is checked, the densities are calculated only from 3D points on the plane.

#### Hole Pos

The center of hole on a 3D blob is output as a found position. The diameter of the hole to detect is set as [Hole Diameter]. If the checkbox of [Calculate plane] is checked, the center of the hole is calculated only from 3D points on the plane.


#### Minimum Rectangle Center

The center of the minimum bounding rectangle surrounding each 3D blob is output as the found position of the 3D blob. When the [Minimum Rectangle Center] is selected as the [Found Position], the checkbox of [Calculate Plane] is automatically checked and cannot be unchecked because each minimum bounding rectangle is calculated in the plane calculated from a 3D blob. Calculating minimum bounding rectangles make the centers of the workpieces easy to be found stably even if the number and accuracy of 3D points are not enough because of rough surfaces of workpieces.

### Density Meas. Radius

When [Dense Pos] is selected in [Found Position], set the radius of measurement area for calculating densities. For each point in the area which encloses the found 3D blob, the density is calculated from a

circled area in a 3D map as the following. The found position is also calculated from a measurement area which corresponds to the highest density point. Set a value between 0 and 1000.




## Hole Diameter

When [Hole Pos] is selected in [Found Position], set the diameter of a hole to detect (units: mm).

## Calc. Hole Posture

When [Hole Pos] is selected in [Found Position], specify whether or not to calculate the posture of a 3D blob from the 3D points around the hole. This item becomes enabled when [Hole Pos] is selected in [Found Position]. This function should be enabled when a hole does not exist on the main plane of a 3D blob as the following figure. When the checkbox is checked, [Calculate Plane] becomes disabled.



## Calculate Angle


Specify whether or not to calculate the orientation of the found 3D blob. The output angle means the direction where the variance of 3D points in 3D blob becomes the largest.

## Upper Limit Score

Select how to calculate the score of a 3D blob. The score range is evaluated from 0 to 100. Select here how to determine the core 100 correspond for. Besides, 3D points of under the minimum Z value of the [Range] in the 3D Area Sensor Vision Process have score 0.


## Based on Area Sensor Setup

The score of 100 is set to the maximum Z value of [Range] in the 3D Area Sensor Vision Process.



### Based on 3D map

The score of 100 is set to the maximum Z height in 3D map which has already been used for detection.



### Result Plotting Mode

Select how the found results are to be displayed on the image after the process is run.

#### Plot Found Pos

“+” is displayed at the found position of a 3D blob in green. In the case the [3D Map] is selected in the [Image Display Mode], also displayed the found position of a 3D blob on a 3D map.

#### Plot Found Pos + Points

In addition to [Plot Found Pos], 3D points which compose a 3D blob are also plotted in cyan. In the checkbox of [Calculate Plane] is checked, the points on the plane are plotted in cyan, and the other points are in magenta. In the case the [3D Map] is selected in the [Image Display Mode], also displayed the 3D map point.

### Image Display Mode

Select the image display mode for the setup page.

#### Image

A camera image is displayed.

#### 3D Map

3D map is displayed.

## 2D Image + Edges

A camera image and features of the image is displayed. After selecting this item in the [Image Display Mode], adjust the contrast threshold when the checkbox of the [Connect Using Contr.] is checked.

## Calculate Plane

If the checkbox is checked, the plane from 3D points of 3D blob after finding the 3D blob will be calculated. The result, which is Vt, Hz, X, Y and Z, is calculated by using 3D points measured as same plane.

## Min. Num Valid Points

Set the minimum number of 3D points on a measured plane when the checkbox of [Calculate Plane] is checked. If the the number of 3D points on a measured plane of a found 3D blob is is lower than this value, the found 3D blob is removed from the found results. Set a value between 0 and 1000. By setting a small value to the parameter, it is easy to succeed a finding but degraded accuracy 3D blob might be output.

## Fit Error Threshold

Set a threshold of distance from a plane when the checkbox of [Calculate Plane] is checked (units: mm). When the distance of a 3D point from a found plane is smaller than this value, the tool judges that the 3D point is on the found plane. Set a value between 0 and 1000. By setting a large value to the parameter, it is easy to succeed a finding but degraded accuracy 3D blob might be output.

## F6 2-3D Snap

A 2D camera image is snapped and a 3D map is acquired.

## 7.36.2 Running a Test

Press F4 FIND to run a test and see if the tool can find workpieces properly.

Found:	#	Row(W)	Column(H)	Angle	X	Y	Z	Score	Blob Size
Time to Find: 20.6ms	1	349.7	451.9	1.2	-102.1	-95.4	860.0	86.7	200
	2	360.0	402.5	1.2	-125.4	-5.8	826.7	75.6	271
	3	355.0	364.5	1.2	-116.4	68.8	816.8	72.3	202
	4	307.9	488.2	1.2	-21.2	-189.5	812.9	71.0	190

## Found

The number of found 3D blobs is displayed.

## Time to Find

Time to find is displayed (units: ms).

## Found Result Table

The following values are displayed.

### Vt, Hz

Found position of 3D blob on camera image.

### Angle

Angle of 3D blob orientation.

### X, Y, Z, W, P, R

Coordinate values of the found 3D blob. When the checkbox of the [Calculate Plane] is unchecked, the values of W, P and R are not displayed (units: mm, degrees).

### Score

Score of found 3D blob.

### Blob Size

The number of 3D points of found 3D blob.

### Num. Plane Valid Points

The number of 3D points on the measured plane from 3D points of found 3D blob. This item is displayed only when the checkbox of [Calculate Plane] is checked.

### Plane Fit Error

The average of distance valid points from measured plane. This item is displayed only when the checkbox of [Calculate Plane] is checked.

### Density

Density of 3D points around found position (units: %). This item is displayed when [Dense Pos] is selected in [Found Position].

### Hole diameter

Diameter of hole in found 3D blob. This item is displayed when [Hole Pos] is selected in [Found Position].

### Plane Distance

Distance from plane to found position. This item is displayed when the checkbox of [Calculate Plane] is checked

### 3D Blob Length (mm)

Length of found 3D blob along the longer direction of the 3D blob. This item is displayed when the checkbox of the [Calculate Angle] is checked.

### 3D Blob Width (mm)

Length of found 3D blob along the orthogonal direction to the longer direction of the 3D blob. This item is displayed when the checkboxes of the [Calculate Angle] and the [Calculate Plane] are checked.

---

## 7.36.3 Overridable Parameter

---

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### **Z Height Threshold**

Specify a number between 0 and 100000.

### **Min Blob Size**

Specify a number between 1 and 45888.

### **Plane Calculation Enabled**

You can specify the enable / disable of the plane calculation. Specify 0 for disable or 1 for enable.

### **Min Num. Valid Points on Plane**

Specify a number between 3 and 45888.

### **Plane Fit Error Threshold**

Specify a number between 0 and 1000.

### **Hole Diameter**

Specify a number between 15 and 1000.

### **Calc. Hole Posture**

You can specify the enable / disable of the calculation of hole posture. Specify 0 for disable or 1 for enable.

### **Contrast Enabled**

You can specify the enable / disable of 3D blob detection by using features of 2D image. Specify 0 for disable or 1 for enable.

### **Contrast Threshold**

Specify a number 1 and 200 when the checkbox of [Contrast] is checked.

### **Normal Direction Enabled**

You can specify the enable / disable of 3D blob detection by using normal direction of 3D point. Specify 0 for disable or 1 for enable.

### **Normal Direction Threshold**

Specify a number 0.0 and 180.0 when the checkbox of [Normal Direction] is checked.

### **Normal Calc. Range**


Specify a number 2 and 10 when the checkbox of [Normal Direction] is checked.

---


## 7.37 AREA SENSOR COG TOOL

---

The Area Sensor COG tool finds a center of gravity (COG) point from a 3D map. It calculates the center of gravity point with 3D point data in a measurement area that is predefined relatively to the location found by the parent tool as GPM or CSM.



If you select the Area Sensor COG Tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.




## 7.37.1 Setting the Measurement Area

### Setting the Measurement Area

Set the measurement area as follows.

- 1 Place the workpiece near the center of the camera view.
- 2 Press F6 2-3D SNAP to snap the image of the workpiece and acquire its 3D map.
- 3 Press the [Set] button. Then, a setup page like one shown below appears.





- 4 Enclose the workpiece to be taught within the displayed red rectangle, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.

## Window Mask

Set window mask to the area that you want to exclude from the measurement area. The setting is executed on 2D image. The 3D point set here is not used for measuring the center of gravity. When the [Enabled] checkbox is unchecked, the window mask does not work even if the window mask has already set.

## 7.37.2 Setting the Parameters

### Min. Num. Valid Points

Set the minimum number of 3D points to measure the center of gravity. The valid point means a 3D point that is included in the measurement area excluding the window mask and is selected by [Z-Range] described below. When the number of valid 3D points in the measurement area is lower than this value, a finding of a center of gravity point is failed. Set a value between 1 and 45888. If a finding is failed because the measurement area is narrow, set a small value to succeed the finding.

### Z-Range

Set the available Z range of 3D points. Under the condition the set value is  $dZ$ , height of COG  $Z_g$  and the Z height of 3D point is  $Z$ , 3D point selection and COG measurement are executed so as to all 3D point of are  $|Z - Z_g| \leq dZ / 2$ . Specify the value between 0 and 8000(units: mm).

### Plot Mode

Select how the found results are to be displayed on the image after the process is run.

#### Plot Nothing

Nothing is plotted.

#### Plot Measurement Area

The measurement area is plotted in blue. When test running, the measurement area is plotted in red if the finding is failed.

### Plot Points

3D points in valid area are plotted. Points used for finding center are plotted in cyan; other points not used are magenta. When test running, all points are plotted in magenta if the finding is failed.

### Plot Everything


Measurement area and points are plotted.

### F6 2-3D Snap

A 2D camera image is snapped and a 3D map is acquired.

## 7.37.3 Running a Test

Press F4 FIND to run a test and see if the tool can find workpieces properly.



### Time to Find

Time to find is displayed (units: ms).

### Num. Points

The number of 3D points in measurement area excluding window mask is displayed.

### Found Result Table

The following values are displayed.

#### X, Y, Z

Coordinate values of the found center of gravity point (unit: mm).

#### Std. Dev.

The standard deviation of the 3D points used for finding a center of gravity.

#### Num. Valid Points

The number of 3D points used for finding center of gravity.

## 7.37.4 Overridable Parameter

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Min Num. Valid Points on Plane


Specify a number between 1 and 45888.

### Z Range


Specify a number between 0.0 and 8000.0.

## 7.38 AREA SENSOR PLANE TOOL

The Area Sensor Plane tool finds a plane from a certain area in 3D map. It calculates a plane with 3D points in a measurement area that is predefined relatively to the location found by the parent locator tool as GPM Locator tool or CSM Locator. The image feature for the locator tools do not have to be on the same plane.



If you select the Area Sensor Plane Tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.




## 7.38.1 Setting the Measurement Area

### Setting the Measurement Area

Set the measurement area as follows.

- 1 Place the workpiece near the center of the camera view.
- 2 Press F6 2-3D SNAP to snap the image of the workpiece and acquire its 3D map.
- 3 Press the [Set] button. Then, a setup page like one shown below appears.



4. Enclose the workpiece to be taught within the displayed red rectangle, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.

### Window Mask

Set window mask to the area that you want to exclude from the measurement area. The setting is executed on 2D image. The 3D point set here is not used for finding a plane. When the [Enabled] checkbox is unchecked, the window mask does not work even if the window mask has already set.

## 7.38.2 Setting the Parameters

### 2-3D Gap

In [2D-3D Gap], set the difference in height relative to the plane, if there is a height gap between the plane for which the model of the GPM Locator Tool is taught and the plane to be measured with the 3D Area Sensor. This will be a positive value if the model plane is nearer to the camera than the plane measured by 3D points.

### Min. Num Valid Points

Set a minimum number of 3D points to use for measuring plane. The valid point means a 3D point that is included in the measurement area excluding the window mask and is on a plane. When the number of valid 3D points in the measurement area is lower than this value, a finding of a plane is failed. Set a value between 3 and 45888. By setting a small value to the parameter, it is easy to succeed a finding but measurement accuracy is likely to degrade.

### Fit Error Threshold

Set a threshold of the distance from the plane (units: mm). When the distance of a 3D point from a found plane is smaller than this value, the tool judges that the 3D point is on the found plane. Set a

value between 0 and 1000. By setting a large value to the parameter, it is easy to succeed a finding but measurement accuracy is likely to degrade.

### **Fix Normal Direction**

Set whether find or not a plane with a specified normal vector. When the checkbox is checked, a plane with a specified normal vector is found. The parameter works effectively when normal direction of a plane to find is oriented to a determined direction such as depalletizing system of cardboard boxes.

### **Normal Direction**

Set the normal direction in 3 textboxes when the [Fix Normal Direction] is checked. The 3 textboxes for X, Y and Z are for normal vector value of offset frame. The normalized unit vectors are indicated at the side of the boxes.

### **Result Plotting Mode**

Select how the found results are to be displayed on the image after the process is run.

#### **Plot None**

Nothing is plotted.

#### **Plot Measurement Area**

The measurement area is plotted in blue. When test running, the measurement area is plotted in red if the finding is failed.

#### **Plot Points**

3D points in valid area are plotted. Points used for finding a plane are plotted in cyan; other points not used are magenta. When test running, all points are plotted in magenta if the finding is failed.

#### **Plot Everything**

Measurement area and points are plotted.


### **F6 2-3D Snap**

A 2D camera image is snapped and a 3D map is acquired.

## **7.38.3 Running a Test**

---

Press F4 FIND to run a test and see if the tool can find workpieces properly.



### Time to Find

Time to find is displayed (units: ms).

### Found Result Table

The following values are displayed.

#### Num. Points

The number of 3D points in measurement area excluded window mask is displayed.

#### X, Y, Z

Coordinate values of the position of the found plane (units: mm). This position is located on the found plane.

#### Normal X, Normal Y, Normal Z

Normal vector to the found plane.

#### Num. Valid Points

The number of 3D points used for finding the plane.

#### Fit Error

Average of distance between the 3D points used for finding and the plane.

## 7.38.4 Overridable Parameter

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Min Num. Valid Points on Plane


Specify a number between 3 and 45888.

### Plane Fit Error Threshold

Specify a number between 0 and 1000.


# 7.39 OBSTRUCTION MEASUREMENT TOOL

The Obstruction Measurement Tool can obtain the number of obstructing 3D points and obstruction ratio for calculation. Obstructing points mean higher 3D points in measurement area over a plane measured by specified Plane Tool. And the obstruction ratio means the ratio of obstructing points to the 3D points in measurement area.




An Obstruction Measurement Tool can be used under the following each condition.


- This tool is a child tool of a GPM Locator Tool or a CSM Locator Tool and a preceding Area Sensor Plane Tool is set at the same level as this tool.



- This tool is a child tool of an Area Sensor Blob Locator Tool whose [Calculate Plane] checkbox is checked.



If you select an Obstruction Measurement Tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.




## 7.39.1 Setting the Measurement Area

### Setting the Measurement Area

Set the measurement area as follows.

- 1 Case1: Teach the parent (GPM Locator Tool or a CSM Locator Tool) model pattern. And set a measurement area in an Area Sensor Plane tool.  
Case2: Set the parent Area Sensor Blob Locator Tool and check the [Calculate Plane] checkbox.
- 2 Open the setup page of an Obstruction Measurement Tool.
- 3 Select the Plane Tool.
- 4 Press the [Set] button. Then, a setup page like one shown below appears.





- 5 Enclose the area to measure obstruction to be taught within the displayed red rectangle, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.


## Window Mask

Set window mask to the area that you want to exclude from the measurement area. The setting is executed on 2D image. The 3D point set here is not used for measuring some obstructing 3D point. When the [Enabled] checkbox is unchecked, the window mask does not work even if the window mask has already set.

## 7.39.2 Setting the Parameters

### Plane Height Offset

If there is a distance in height between plane measured by specified Plane Tool and area to measure obstruction, set the distance here. By setting a value to the [Plane Height], the plane to decide obstruction is shifted by the value from plane measured by specified Plane Tool in normal direction to the plane. Set positive value if the area to measure obstruction is on the normal vector direction of plane measurement by specified Plane Tool, set negative value that is on the inverse direction.



### Height Margin

Set a distance for deciding that 3D points which are in the measure area and are higher than the plane to decide obstruction are on other obstructing object or not. If a 3D point is more than this margin value away from the plane to decide obstruction in the Z positive direction, it is regarded as an obstructing point. If the [Plane Height Offset] is set to 0.0, the plane to decide obstruction is completely same as the plane measured by specified Plane Tool. If the [Plane Height Offset] is set to a value other than 0.0, the plane to decide obstruction is shifted from plane measured by specified Plane Tool in normal direction to the plane.

## Result Plotting Mode

Select how the found results are to be displayed on the image after the process is run.

### Plot None

Nothing is plotted.

### Plot Measurement Area

The measurement area is plotted in blue.

### Plot Points

3D points in valid area are plotted. Points judged as obstructing 3D points are plotted in magenta; other points not regarded as ones are cyan.

### Plot Everything


Measurement area and points are plotted.

## F6 2-3D Snap

A 2D camera image is snapped and a 3D map is acquired.

## 7.39.3 Running a Test

Press F4 FIND to run a test and see if the tool operates properly.



### Time to Find

Time to find is displayed (units: ms).

### Found Result Table

The following values are displayed.

#### Num. Points

The number of 3D points which are in the measurement area and not masked.

#### Num. Obstructing Points

The number of 3D points which are judged as on other obstructing objects.

### Obstruction Ratio

The ratio of “Num. Obstructing Points” against “Num. Point in Area”.

## 7.39.4 Overridable Parameter

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

### Plane Height Offset


Specify a number between -10000 and 10000.

### Height Margin


Specify a number between 0 and 1000.

## 7.40 AREA SENSOR GF LOCATOR TOOL

The Area Sensor GF Locator tool finds grip positions easy for a robot gripper to grip workpieces using the gripper model and 3D Map acquired by 3D Area Sensor. To use the Area Sensor GF Locator tool, some 3D points which cause incorrect results and waste the processing time must be removed by the Area Sensor Preprocess tool.



If you select the Area Sensor GF Locator Tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.



## 7.40.1 Setting the Parameters

### Preprocess Tool

Select the Area Sensor Preprocess tool which is used for detection. A preceding Area Sensor Preprocess tool that is set at the same level as this tool can be selected.

### Container Shape

If [Use Preprocess] is checked, the found grip positions are limited within the container taught in the Area Sensor Preprocess tool selected on [Preprocess Tool].

[Use Preprocess] generally should be checked if the robot picks up workpieces placed randomly inside a container and you need to teach [Container Shape] on the setup page of the Area Sensor Preprocess tool. If the robot picks up workpieces stacked on a pallet, [Use Preprocess] should be unchecked.

### Model ID

When you have taught two or more Area Sensor GF Locator tools and want to identify which tool detected each grip position, assign a distinct model ID to each tool. Because the model ID is output with offset data, robot programs can identify the model ID.

### Finger Spacing

Set the size of the spacing between two fingers (units: mm). Please refer to Gripper Model described above.

### Finger Thick

Set the size of the finger thick (units: mm). Please refer to Gripper Model described above.

### Finger Width


Set the size of the finger width (units: mm). Please refer to Gripper Model described above.

### Margin

Set the margin of Gripper Model (units: mm). The Area Sensor GF Locator tool internally creates a new gripper model adding the value of [Margin] to [Finger Thick] and [Finger Width].

## Grip Depth

Set the value of the grip depth (units: mm). The grip depth is the distance from the front edge of the gripper to the top side of the workpiece when the gripper is at the grip position as the following figure shows.



## XY Interval

Set the value of the XY interval (units:mm) to search the grip positions.

If the value of [XY Interval] is small, the Area Sensor GF Locator Tool searches the grip positions finely and might be able to find grip positions which can't be found by coarse search. Besides, the interference check which is executed in the Area Sensor GF Locator tool internally becomes higher accurate with the smaller [XY Interval].

However, the processing time becomes much larger when you set the smaller value on [XY Interval]. Please adjust the value considering the accuracy and the processing time.

## R Range

Set the minimum and maximum values of R range (units: degrees). If workpieces are aligned and you would like to limit the R range of the grip positions, please adjust this parameter.

## R Interval


Set the value of the R interval to search the grip positions.

## Min. Num. Grip Points


Set the minimum permissible number of 3D points in each Grip Area. If the number of 3D points in Grip Area is lower than [Min. Num Grip Points], the grip position is not output as a result.

## Overlap Check Area

Set the area size to check if the grip positions are overlapped or not (units: mm). Grip positions are [Overlap Check Area] away from each other. As shown in the figures below, the smaller number you set on [Overlap Check Area], the more grip positions are found. However, with narrow [Overlap Check Area], multiple grip positions might be found on one workpiece. Please specify a number which is roughly half of the size of the workpiece.



Overlap Check Area: Narrow



Overlap Check Area: Wide

### Image Display Mode

Select the image display mode for the Setup Page.

#### Image

A 2D camera image is displayed.

#### 3D Map

A 3D map is displayed.

#### Z-height Image

A Z-height image is displayed.

Z-height image is created by projecting 3D Map to X-Y plane. The sizes of pixels are the same as [XY Interval] and the values of pixels signify Z.

### F6 2-3D Snap

A 2D camera image is snapped and a 3D map is acquired.

## 7.40.2 Running a Test

Press F4 FIND to run a test and see if the tool can find grip positions properly.

The screenshot shows the IRVision software interface. At the top, there are status indicators for 'Busy', 'Setup', 'Work', 'Pause', 'Run', 'I/O', 'Prod', 'Stop', and '10%'. Below this is the 'IRVision Setup Main - VPAS\_EG2' window. The 'Image' tab is active, showing a 2D camera image of the container with green markers on the objects. To the right of the image is the 'Area Sensor GF Locator Tool 1' configuration panel, which includes settings for 'Preprocess Tool', 'Container Shape', 'Model ID', 'Gripper Shape', 'Finger Spacing', 'Finger Thick', 'Finger Width', 'Margin', 'Grip Depth', 'Search Interval', 'XY Interval', 'R Range', and 'R Interval'. At the bottom of the interface is a 'Results' table with the following data:

Found:	#	Vt	Ht	Angle	X	Y	Z	R	Num. Grip Points	Score
3	1	593.3	923.5	58.2	954.3	-348.1	-69.3	60.0	164	90.6
	2	658.4	681.4	28.6	914.3	-218.1	-93.6	30.0	131	87.1
	3	391.6	1044.5	-61.9	1070.3	-428.1	-107.5	-60.0	155	86.4

At the bottom of the interface, there are buttons for '[ TYPE ]', 'LIVE', 'SNAP', 'FIND', 'END EDIT', and '>'. The 'Time to Find: 1360.5ms' is also displayed.

**Found**

The number of found grip positions is displayed.

**Time to Find**

Time to find is displayed (units: ms).

**Found Result Table**

The following values are displayed.

**Vt, Hz**

Found results position on a camera image.

**Angle**

Found results angle on a camera image.

**X, Y, Z, R**

Coordinate values of the found grip position (units: mm, degrees).

**Num. Grip Points**

The number of 3D points within Grip Area.

**Score**

Score of the found grip position. The possibility to succeed in gripping is calculated by the Area Sensor GF Locator tool and the possibility is output as Score. The value is between 0 and 100.

## 7.40.3 Overridable Parameter

---

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

**Finger Spacing**

Specify a number between [XY Interval] and 1000.

**Finger Thick**

Specify a number between [XY Interval] and 500.

**Finger Width**

Specify a number between [XY Interval] and 500.

**Margin**

Specify a number between 0 and 500.

**Grip Depth**

Specify a number between 1 and 500.

**XY Interval**

Specify a number between 1 and 20.

**R-Mimumum**

Specify a number between ([R-Maximum] – 180) and [R-Maximum].

**R-Maximum**

Specify a number between [R-Minimum] and ([R-Minimum] + 180).

**R Interval**

Specify a number between 5 and 180.

**Min. Num. Grip Points**

Specify a number between 1 and 1000.

**Overlap Check Area**

Specify a number between 10 and 1000.

## 7.41 COLOR SORTING TOOL

---

The Color Sorting Tool allows the users to sort found parts by their colors. The color of a found part is compared against the trained colors, and then the model ID of the found part is changed according to the matched trained color.

**NOTE**

White balance of the color camera is important for Color Sorting Tool to sort found colors. Be sure to set white balance of the color camera before teaching a color to Color Sorting Tool.

**Color Representation**

The Color Sorting Tool represents a color by its hue, saturation and intensity.

**Hue**

The hue is the attribute of a color which is discernible as red, blue, green, etc. The range of the hue is 0 to 360 degrees. The hue values of two similar colors are close to each other. For example, the hue value of red is close to that of brown, but far from that of blue.

**Saturation**

The saturation is the attribute that represents how vivid a color is. The range of the saturation is 0 to 100%. Primary colors and vivid colors have a large saturation value.

**Intensity**

The intensity is the attribute that represents the luminance of a color. The range of the intensity is 0 to 255. The intensity value of a color is equal to the pixel value in a grayscale image.

**Term Definition**

The following terms are used in the Color Sorting Tool.

**Unsaturated Color**

Unsaturated colors are colors that have a hue value, which are also called chromatic colors. Red, blue, and green are examples of unsaturated colors. The Color Sorting Tool uses unsaturated colors for sorting.

**Saturated Color**

Saturated color is colors that are saturated and do not have a hue value, which is also called achromatic color. White, black and gray are examples of saturated colors. A saturated color



looks the same in either a color image or a grayscale image. The Color Sorting Tool mainly uses the hue for sorting, so it can't distinguish saturated colors.

**Measured Color**

The measured color is the color of a found part that is measured in the measurement area. Generally colors in the measurement area are not even, so the measured color usually indicates the average color in the measurement area.

**Trained Color**

The trained color is the color that is trained on the setup page. As well as the measured color, colors in the training area are not always even, so the trained color indicates the average color in the training area.


**Good Measurement Condition**

Even when the color of a part is constant, the color that appears on an image can be variable depending on the illumination. Make sure to use uniform illumination such as a diffused white LED light, and measure the same place of the part every time.


**NOTE**  
 When the illumination is too strong or too weak, the color of the part can look too light or too dark to distinguish the color. Adjust the illumination so that all colors that you want to distinguish appear on the image clearly.

**7.41.1 Setting the parameters**

If you select Color Sorting Tool in the tree view of the setup page, a screen like the one shown below appears.



The Image below shows the Color Sorting Tool with the right pane scrolled down.



## List of Trained Colors

The list shows trained colors that have been trained. The following values are displayed.

### Trained Color

The color of the trained color is displayed.

### Color ID

The color ID is the number assigned to the trained color. The color ID can be changed with the steps described later. This number is added to the model ID of the found part.

### Hue

The hue of the trained color

### Saturation


The saturation of the trained color

### Intensity

The intensity of the trained color

## Training the Color

Train the color with the following steps.


- 1 Press the  button.
- 2 Enclose where you want to train a color with the displayed red rectangle, and then press F4 OK.
- 3 If different or unwanted colors or shades are included in the training area, mask them to remove them from the trained color.

### NOTE

Because of characteristics of digital camera, false colors can appear in areas where the color changes sharply, such as outlines of a workpiece, and colors in such an area are unstable. Be sure not to include such an area when training a color, the measurement area and the run-time mask.


## Retraining the Color

You can retrain a trained color with the following steps.

- 1 Select a trained color in the list of trained colors.
- 2 Press the  button.
- 3 Enclose where you want to train a color with the displayed red rectangle, and then press F4 OK.
- 4 If different or unwanted colors or shades are included in the training area, mask them.

## Delete the Trained Color

You can delete a trained color with the following steps.

- 1 Select a trained color in the list of the trained colors.
- 2 Press  button.

## Detail of the Trained Color

The detailed information of the selected trained color is displayed. The color ID, the mean and the standard deviation of the hue, and the mean and the standard deviation of the saturation are displayed. You can change the color ID of the selected trained color here.

## Measurement Area

Specify the search area where you want to measure the color. The smaller the area, the faster the measurement process executes. To change the measurement area, tap the [Set] button. For detailed information about the operation method, see Subsection 3.7.9, “Setting a Window”.



### CAUTION

The Color Sorting Tool measures the color in the measurement area on the assumption that only one color is included in the measurement area. Train the measurement area not to include multiple colors.

## Run-Time Mask

Specify an area within the measurement area that you do not want to be processed. The filled area will be masked in the rectangle specified as the measurement area and will not be subject to the image processing. To change the run-time mask, tap the [Edit] button. For detailed information about the operation method, see Subsection 3.7.14, “Editing Masks”.

## Sort By

Select the method to distinguish the color.

### Hue

The hue is always used to distinguish the color. Set the right text box to the tolerance of the hue. When the difference between the hue of the measured color and that of the trained color is less than the tolerance of the hue, the measured color is judged to match the trained color.

### Saturation

Check the check box if you want to distinguish the color with not only the hue but also the saturation. Set the right text box to the tolerance of the saturation. When the difference between the saturation of the measured color and that of the trained color is less than the tolerance of the saturation, the measured color is judged to match the trained color.

## When appropriate color is found

Select the action to be performed when the measured color matches one of the trained colors.

**Invalidate this result**

Invalidate this result

**Add color ID to model ID**

Add the color ID of the trained color to the model ID of found part.

**No Action**

Do nothing.

**Otherwise**

Select the action to be performed when the measured color does not match any of the trained colors.

**Invalidate this result**

Invalidate this result.

**Add the following value to model ID**

Add the specified value to the model ID of the found part.

**No Action**

Do nothing.

**Image Display Mode**

Select the type of the image to be displayed in the image display frame from the followings:

**Original Image**

Displays the color image captured by the color camera as it is.

**Chromatic Color**

Displays the color image with saturated color pixels filled by black.

**Extraction (Trained Color)**


Displays a grayscale image, in which the intensity of each pixel indicates the similarity to the trained color currently selected in the list of trained colors.

**Extraction (Measured Color)**

Display a grayscale image, in which the intensity of each pixel indicates the similarity to the measured color.


**Color Wheel (Trained)**

Displays the following figure. In the circle on the left, the direction from the center represents the hue and the distance from the center represents the saturation. Trained colors are shown as a fan shape. The selected color is white and the non-selected colors are black. The bar on the right shows the intensity of the color whose hue and saturation are the same as the selected trained color, the brightest at the top of the bar and darkest at the bottom. The white mark on both side of the bar represents the intensity of the selected trained color.




**Color Wheel (Measured)**

Displays the following figure. The direction from the center represents the hue and the distance from the center represents the saturation. Trained colors are shown as a fan shape. Around the selected trained color, auxiliary lines that represent tolerance of the hue and the saturation are shown. Measured colors are shown as green fans. The distribution of the selected measured color is displayed as a cloud.



## 7.41.2 Running a Test

Run a measurement test to see if the tool can measure the color properly.



### Time to Run

The time to run the Color Sorting Tool took is displayed in milliseconds.

### Measurement Result Table

The following values are displayed.

#### Measured Color

The measured color is displayed.

#### Color ID

The color ID of the trained color that matches the measured color is displayed.

#### Hue Error

Absolute difference between the hue of the measured color and that of the trained color is displayed.

#### Hue Mean

The mean of the hue of colors in the measurement area is displayed.

#### Hue Std. Dev.

The standard deviation of the hue of colors in the measurement area is displayed.

#### Saturation Error

Absolute difference between the saturation of the measured color and that of the trained color is displayed.

#### Saturation Mean

The mean of the saturation of colors in the measurement area is display.

### Saturation Std. Dev.

The standard deviation of the saturation of colors in measurement area is displayed.


## 7.41.3 Overridable Parameters

This command tool has no parameters that can be overridden with Vision Override.


## 7.42 AREA SENSOR BOX LOCATOR TOOL

The Area Sensor Box Locator tool finds boxes which are palletized orderly. It uses the size of boxes to find and finds their upper surface by referring to a 3D map and a camera image. To find boxes correctly, the following conditions should be satisfied.


- All objects to find are same sized cuboids.
- For the all palletized objects, the object surface which is facing to the 3D area sensor must be same size. (The size of the surface should be set as "Upper Surface" on the setup page.)
- The upper surfaces are planar. If the upper surfaces are opened as follows, this tool cannot find them.



**OK**




**NG**



**NG**

The Area Sensor Box Locator tools can be created as a child of the 3D Area Sensor Vision Process or as a child of the Multi-locator tool which is a child of the 3D Area Sensor Vision Process. The Area Sensor Box Locator tool uses a 3D map but it does not require high density of 3D points. If you want to shorten detection time, please select "Coarse" as [3D Map Density] on the setup page of 3D Area Sensor. To use the Area Sensor Box Locator tool, some 3D points which cause incorrect results and waste the processing time must be removed by the Area Sensor Preprocess tool.

If you select the Area Sensor Box Locator tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.




## 7.42.1 Setting the Parameters

### Input Image

Select the image which is used for box detection. When the vision process has a Image Filter Tool or an Image Arithmetic Tool, you can select a filtered image as the input image to this Area Sensor Box Locator Tool, instead of the camera snapped original image. For details, please refer to Subsection 7.26 “Image Preprocess Tool”, 7.27 “Image Filter Tool”, 7.45 “Image Arithmetic Tool”, and 7.46 “Flat Field Tool”.

### Preprocess Tool

Select the Area Sensor Preprocess tool which is used for detection. A preceding Area Sensor Preprocess tool that is set at the same level as this tool can be selected. For correct detections, the Area Sensor Box Locator tool requires removal of 3D points which are higher than upper surfaces of objects to find. If there are higher 3D points, you have to remove them, as one example, with [Container Wall RM.] as follows.




### Model ID

When you have taught two or more locator tools and want to identify which tool detected each workpiece, assign a distinct model ID to each tool. Because the model ID is output with offset data, robot programs can identify the model ID.



## Box Size

Specify the size of the box to find. The dimension of upper surface is set to [Upper Surface] and the dimension in vertical direction against the upper surface is set to [Height].



### Upper Surface

Specify the sizes in the width and the length direction(units: mm).

### Height

Specify the size in the height direction(units: mm).

## Score Threshold

The accuracy of the found result is expressed by a score, with the highest score being 100%. The target object is successfully found if its score is equal to or higher than this threshold value. If the score is lower, the target object is not found. Set a value between 10 and 100. The default value is 80. Setting a small value might lead to inaccurate location and long detection.

## Contrast Threshold

Specify the contrast threshold for the search. Set a value between 1 and 200. The default value is 50. If you set a small value, the tool will be able to find the target in obscure images as well but take longer to complete the detection process. Those image features whose contrast is lower than the threshold are ignored. Selecting the [2D Image + Edges] in [Image Display Mode] lets you check the image features extracted based on the current threshold. Set a value to detect contour of the object as edges in the image.

## Elasticity

Specify the tolerance of fitting error between the box model which is specified at [Upper Surface] and features in an image. The default value is 5 pixel. The range of this item changes according to [Search Density]. The minimum value is 0.1 / (the value specified at [Search Density]). The maximum value is 5.0 / (the value specified at [Search Density]). Setting a large value enables the tool to find the target in images that are greatly deviated in geometry. However, the larger the value is, the more likely inaccurate location becomes.

## Overlap Threshold

Specify the threshold of overlap ratio of a found object. The default value is 10%. Set a value between 0 and 20. If the overlapping ratio is higher, the target object is not found. Setting a large value enables the tool to find more target objects but it leads illegal overlap between found objects and other objects.

## Search Density

Specify the interval of search for the box model which is specified at [Upper Surface]. The default value is 100%. Set a value between 30 and 150. Setting a large value enables the tool to reduce misdetection but it leads longer detection. On the other hand, setting a small value enables the tool to reduce detection time but it leads misdetection and inaccurate location.

## Fix Normal Direction

Set whether use specified normal vector or not to find boxes. When the checkbox is checked, normal directions of upper surfaces become same as the direction set at [Normal Direction]. This function works effectively, when the robot has only 5axis or when 3D points from upper surface are not on a ideal plane.

## Normal Direction

Specify the normal direction in 3 textboxes when the [Fix Normal Direction] is checked. The 3 textboxes for X, Y and Z are for normal vector value of the offset frame. Each element of the normalized unit vector is indicated at the side of the textboxes.

## Use Current Result

Using a found result which is currently kept, the normal direction can be set. When this button is pushed, the [Fix Normal Direction] turns to checked and new values which are computed from the upper surface of the found result are set to [Normal Direction].

## Plot Mode

Select how the found results are to be displayed on the image after the process is run.

### Plot Found Pos

“+” is displayed at the found position in green.

### Plot Found Pos + Edges

In addition to [Plot Found Pos], contours of found boxes are also plotted in green.

## Image Display Mode

Select the image display mode for the Setup Page.

### 2D Image

A camera image is displayed.

### 2D Image + Edges

A camera image and features are displayed.

### 3D Map

A 3D map is displayed.

## Time-out

If the detection process takes longer than the time specified here, the tool ends the process without finding all of the objects.

## Show Discarded


When this checkbox is checked, discarded results are displayed in red. There are 2 kinds of discarded results. One is discarded by overlapping with other results. It is meeting the detection parameters. The other is discarded because it fell just short of meeting the detection parameters. The latter does not output "Num. Valid Points" in a result table.

## F6 2-3D Snap

A 2D camera image is snapped and a 3D map is acquired.

## 7.42.2 Running a Test

Press F4 FIND to run a test and see if the tool can find grip positions properly.



## Found

The number of found results is displayed.

## Time to Find

Time to find is displayed (units: ms).

## Found Result Table

The following values are displayed.

### Row, Column

Coordinate values of the center of the box upper surface on a camera image (units: pixel).

### Angle

Orientation of the found results on a camera image (units: degrees).

### X, Y, Z, W, P, R

Coordinate values of the found result position (units: mm, degrees).

**Score**

Score of the found result.

**Fit Error**

Deviation of the found results from the model pattern (units: pixels).

**Num. Valid Points**

The number of 3D points on the upper surface. used for finding the plane.

---

## 7.42.3 Overridable Parameter

---

This command tool has the following overridable parameters that can be overridden with Vision Override. See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

**Box Width**

Specify a number between 10 and 10000.

**Box Length**

Specify a number between 10 and 10000.

**Box Height**

Specify a number between 10 and 10000.

**Score Threshold**

Specify a number between 10 and 100.

**Contrast Threshold**

Specify a number between 1 and 200.

**Elasticity**

Specify a number between 0.1 / (the value specified at [Search Density]) and 5. / (the value specified at [Search Density])

**Overlap Threshold**

Specify a number between 0 and 20.

**Search Density**

Specify a number between 30 and 150.


---

## 7.43 AREA SENSOR CYLINDER LOCATOR TOOL


---

The Area Sensor Cylinder Locator tool finds some cylinder parts from a 3D map. The Area Sensor Cylinder Locator tool finds some cylinder parts in the following two steps.

- 1 Find 3D Blob from a 3D Map.
- 2 Find a cylinder part from a found 3D Blob.



If you select the Area Sensor Cyl. Loc. tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.



## 7.43.1 Setting the Preprocess Tool

### Preprocess Tool

Select the Area Sensor Preprocess tool which is used for detection. A preceding Area Sensor Preprocess tool that is set at the same level as this tool can be selected.

## 7.43.2 Setting up a Model

### Model ID

When you have taught two or more Area Sensor Cylinder Locator tools and want to identify which tool detected each workpiece, assign a distinct model ID to each tool. Because the model ID is output with offset data, robot programs can identify the model ID.

### Cylinder Diameter

Set the diameter of the cylinder to find.

### Cylinder Length

Set the length of the cylinder to find.

## 7.43.3 Setting the Parameters for Finding 3D Blobs

---

### Z Height Threshold

Set the threshold of the difference between Z heights of 3D points (units: mm). If the difference between Z heights of adjacent 3D points is equal to or lower than this threshold, the adjacent 3D points are connected as 3D points in one 3D blob.

### Normal Direction Threshold

Set the threshold of the difference between normal directions of 3D points (units: deg). If the difference between normal directions adjacent 3D points is equal to or lower than this threshold, the adjacent 3D points are connected as 3D points in one 3D blob.

### Normal Calc. Range

Set the size of the range to calculate a normal vector of a 3D point. If the set value is R, the range is the range whose base is a '2R - 1' square parallel to XY plane on the 3D map. Set a value between 2 and 10.

### Min. Blob Size

Set the threshold of the number of 3D points of a 3D blob. If the number of 3D points of a 3D blob is lower than this threshold, the 3D blob is not used for finding cylinders.

## 7.43.4 Setting the Parameters for Finding Cylinder

---

### Score Threshold

The accuracy of the found result is expressed by a score, with the highest score being 100. The target cylinder is successfully found if its score is equal to or higher than this threshold value. If the score is lower, the found result is not output.

### Min Num. Valid Points

Set the minimum number of 3D points on a found cylinder. If the number of 3D points on a found cylinder is lower than this value, the found 3D blob is removed from the found results. By setting a small value to the parameter, it is easy to succeed a finding but degraded accuracy results might be output.

### Cyl. Error Threshold

Set a threshold of distance from a cylinder. When the distance of a 3D point from the curved surface of a found cylinder is smaller than this value, the tool judges that the 3D point is on the curved surface of the found cylinder. By setting a large value to the parameter, it is easy to succeed a finding but degraded accuracy result might be output.

### Result Plotting Mode

Select how the found results are to be displayed on the image after the process is run.

#### Plot Found Pos

“+” is displayed at the found position of a cylinder in green.

#### Plot Found Pos + Points

In addition to [Plot Found Pos], 3D points which compose a 3D blob are also plotted in cyan. The points on the plane are plotted in cyan, and the other points are in magenta.

### Image Display Mode

Select the image display mode for the setup page.

## Image

A camera image is displayed.

## 3D Map


3D map is displayed.

## F6 2-3D Snap

A 2D camera image is snapped and a 3D map is acquired.

## 7.43.5 Running a Test

Press F4 FIND to run a test and see if the tool can find workpieces properly.



## Found

The number of found results is displayed.

## Time to Find

Time to find is displayed (units: ms).

## Found Results Table

The following values are displayed.

## Vt, Ht

Found position of found result on camera image.

## Angle

Angle of found result orientation on camera image.

## X, Y, Z, W, P, R

Coordinate values of the found result (units: mm, degrees).

## Score

Score of found result.

**Blob Size**

The number of 3D points of found 3D Blob.

**Num. Plane Valid Points**

The number of 3D points on the found cylinder from 3D points of found result.

**Fit Error**

The average of distance valid points from found cylinder.

---

**7.43.6 Overridable Parameter**

---

This command tool has the following overridable parameters that can be overridden with Vision Override.

See 8.1 “VISION OVERRIDE” and 9.2.2.8 “OVERRIDE” for details.

**Z Height Threshold**

Specify a number between 0 and 100000.

**Normal Direction Threshold**

Specify a number between 0 and 180.

**Normal Calc. Range**

Specify a number between 2 and 10.

**Min Blob Size**

Specify a number between [Min. Num. Valid Points] and 10000.

**Score Threshold**

Specify a number between 10 and 100.

**Min Num. Valid Points**

Specify a number between 10 and 10000.

**Cyl. Error Threshold**

Specify a number between 0.1 and 1000.


---

**7.44 COLOR COMPONENT TOOL**


---

Color Component Tool creates a grayscale image containing the specified color component of the color image. This tool can be inserted only under Image Preprocess Tool and only if the camera is a color camera. By adding multiple Color Component Tools, command tools can select different color components to use.






To use the result image created by Color Component Tool in a command tool, open the setup page of the command tool and then select the name of the Color Component Tool in the drop-down box of the [Input Image].



If you select Color Component Tool in the tree view of the setup page of the vision process, a setup page like the one shown below appears.



## 7.44.1 Setting the Parameters

### Color Component

Select the color component which is extracted from the color image.

#### Red, Green, Blue

The red, green or blue of the color image is extracted respectively.

#### Cyan, Magenta, Yellow

The average of the green and the blue, the blue and the red, or the red and the green is extracted respectively.

#### Hue

The color hue of each pixel is extracted. The hue of some color is below.

- 0 – Red
- 43 – Yellow

- 85 – Green
- 128 – Cyan
- 171 – Blue
- 213 – Magenta

### Saturation

The color saturation of each pixel is extracted. 0 represents a shade of gray and 255 represents a pure spectral color. Values in-between represent intermediate degrees of color saturation.

### Intensity

The equivalent grayscale image is extracted. This image has all of the color removed by setting the saturation to 0.

### Run in Search Window

By default, Color Component Tool processes the entire image. But if this item is checked, Color Component Tool processes only inside the search window of the command tools which use the result image. According to the number of found, processing only inside the search window may reduce the processing time of Color Component Tool.

Note that Color Component Tool processes inside the search window only in the following cases. In the other cases, Color Component Tool processes entire image even if the item is checked.

- When executing the vision process from a TP program
- When running a test on the setup page

### Save Result Image

If this item is checked, the result image is stored in the selected image register. When there is no image register, an error message is displayed. For the details of the image register, refer to 9.4.1 “IRVSNAP, IRVFIND”.


### Image Display Mode

Select the image display mode from the following choices:

- Input Image
- Result Image

### Command tools using this Result Image

The name of command tools which use the result image of this Color Component Tool is displayed. When this Color Component Tool is changed, verify that these command tools still operate as intended.



## 7.44.2 Running a Test

Press F4 FIND to run a test and see if the Color Component Tool operates properly.

### Time to Find


The time the Color Component Tool took is displayed in milliseconds.

## 7.44.3 Overridable Parameters

This command tool has no parameters that can be overridden with Vision Override.

## 7.45 IMAGE ARITHMETIC TOOL


Image Arithmetic Tool performs simple arithmetic functions on two input images. This tool can be inserted only under Image Preprocess Tool.



To use the result image created by Image Arithmetic Tool in a command tool, open the setup page of the command tool and then select the name of Image Arithmetic Tool in the drop-down box of the [Input Image].

Input Image:

If you select Image Arithmetic Tool in the tree view of the setup page of the vision process, a setup page like the one shown below appears.



### 7.45.1 Setting the Parameters

#### Input Image 1, Input Image 2

Select Input Image 1 and 2 from the drop-down list. The available options are listed below.

#### Camera Image

The input image comes from the camera.

#### Image Register N

The input image comes from the specified image register. An image can be stored in an image register by executing an image filter tool with [Save Result Image] being enabled, or by calling IRVSNAP from a TP program. When no image registers have been allocated, this option will not appear.

**Fixed Image**

Every time the fixed image is used. Tap the Set button to set the fixed image to the current camera image.

**None**

No image. Image Arithmetic Tool only applies the scale and offset to Input Image 1. This option is only available for Input Image 2.

**Tool Name**

The input image comes from the selected tool. The available tool is Flat Field Tool, Image Filter Tool, Image Arithmetic Tool, Color Extraction Tool, or Color Component Tool at the same level as this tool.

**Swap**

This button swaps Input Image 1 for Input Image 2.

**Operation**

Select the operation from the drop-down list to perform on each pixel of the input images. After the operation, the resulting grayscale value is multiplied or divided by the scale factor and then the offset is added to it. The most common scale and offset values are automatically selected as the default values when the operation is changed.

The range for the pixel values of the result image remains from 0 to 255. Result pixels below 0 will be set to 0 and result pixels above 255 will be set to 255.

+

Add Input Image 1 and Input Image 2 as shown below.

$$\frac{I_1 + I_2}{A} + B$$

The default scale A is 2 and the default offset B is 0. The default result is the average of the two images.

-

Subtract Input Image 2 from Input Image 1 as shown below.

$$\frac{I_1 - I_2}{A} + B$$

The default scale A is 2 and the default offset B is 128. The area where the image 1 is brighter than the image 2 has the value more than 128, and the area where the image 1 is darker than the image 2 has the value less than 128.

\*

Multiply Input Image 1 and Input Image 2 as shown below.

$$\frac{I_1 \times I_2}{A} + B$$

The default scale A is 255 and the default offset B is 0.

/

Divide Input Image 1 by Input Image 2 as shown below.

$$\frac{I_1}{A \times I_2} + B$$

The default scale A is 128 and the offset B is 0.

### Maximum

Compute the maximum of Input Image 1 and Input Image 2 as shown below.

$$\frac{\max(I_1, I_2)}{A} + B$$

The default scale A is 1 and the offset B is 0.

### Minimum

Compute the minimum of Input Image 1 and Input Image 2 as shown below.

$$\frac{\min(I_1, I_2)}{A} + B$$

The default scale A is 1 and the offset B is 0.

## Result Equation

The equation which is calculated at each pixel is shown.

### \* / Drop-Down

Select the operation to multiply or divide by the scale factor.

### Scale Factor

Set the scale A in the above equations.

### Offset

Set the offset B in the above equations.

## Run in Search Window

By default, Image Arithmetic Tool processes the entire image. But if this item is checked, Image Arithmetic Tool processes only inside the search window of the command tools which use the result image. According to the number of found, processing only inside the search window may reduce the processing time of Image Arithmetic Tool.

Note that Image Arithmetic Tool processes only inside the search window in the following cases. In the other cases, Image Arithmetic Tool processes entire image even if the item is checked.

- When executing the vision process from a TP program
- When running a test on the setup page

## Save Camera Image

If this item is checked, the camera image is stored in the selected image register. When there is no image register, an error message is displayed. For the details of the image register, refer to 9.4.1 “IRVSNAP, IRVFIND”.

## Save Result Image

If this item is checked, the result image is stored in the selected image register. When there is no image register, an error message is displayed. For the details of the image register, refer to 9.4.1 “IRVSNAP, IRVFIND”.


## Image Display Mode

Select the image display mode from the following choices:

- Input Image 1
- Input Image 2
- Result Image
- Camera Image


## Command tools using this Result Image

The name of command tools which use the result image of this Image Arithmetic Tool is displayed. When this Image Arithmetic Tool is changed, verify that these command tools still operate as intended.



## 7.45.2 Running a Test

Press F4 FIND to run a test and see if the Image Arithmetic Tool operates properly.



### Time to Run

The execution time of the Image Arithmetic Tool is displayed in milliseconds.

## 7.45.3 Overridable Parameters

This command tool has no parameters that can be overridden with Vision Override.

## 7.45.4 Examples


This section shows the application examples of Image Arithmetic Tool.

### Background Removal

When the background does not change, the background can be removed by subtracting the fixed image from the camera image.

- 1 Select [Camera Image] as Input Image 1.
- 2 Select [Fixed Image] as the Input Image 2.


- 3 Remove workpieces from the camera view. And press [Set] button to record the current image as the fixed image.
- 4 Select [-] as the Operation.



## Glare Removal

The glare can be removed by using two images that are acquired under the different lighting condition.

- 1 Turn on the light.
- 2 Run IRVSNAP and store the image to the image register.
- 3 Turn on the other light.
- 4 Select [Camera Image] as Input image 1 in the setup page of Image Arithmetic Tool.
- 5 Select [Image Register] as Input Image 2.
- 6 Select [Minimum] as the Operation.




## Shadow Removal

The shadow can be removed by using two images that are acquired under the different lighting condition.

- 1 Turn on the light.

- 2 Run IRVSNAP and store the image to the image register.
- 3 Turn on the other light.
- 4 Select [Camera Image] as Input image 1 in the setup page of Image Arithmetic Tool.
- 5 Select [Image Register] as Input Image 2.
- 6 Select Maximum as the Operation.




## Motion Detection

The moving object can be detected by using two images that are acquired at different time.

- 1 Run IRVSNAP and store the image to the image register.
- 2 Select [Camera Image] as Input image 1 in the setup page of Image Arithmetic Tool.
- 3 Select [Image Register] as Input Image 2.
- 4 Select [-] as the Operation.


In the example below, dark workpiece represents current location and bright workpiece represents previous location.





## 7.46 FLAT FIELD TOOL


Flat Field Tool corrects for uneven lighting and uneven image sensor response. This tool can be inserted only under Image Preprocess Tool. Only one Flat Field Tool can be created per vision process.



To use the result image created by Flat Field Tool in a command tool, open the setup page of the command tool and then select the name of Flat Field Tool in the drop-down box of the [Input Image].

Input Image: Flat Field Tool 1

If you select Flat Field Tool in the tree view of the setup page of the vision process, a setup page like the one shown below appears.



### 7.46.1 Setting the Parameters

#### Dark Field Image


The zero level of the image is recorded as Dark Field Image. When the value of the pixel in the input image is less than that in Dark Field Image, its value in the result image is set to 0. It is useful when the high camera gain is used. When Dark Field Image is trained, Flat Field Image should be retrained.

Train Dark Field Image with the following procedures:

- 1 Block the camera view with lens cover not to enter the light
- 2 Press Set button to record the Dark Field Image.

After when Dark Field Image has been successfully set, the recorded Dark Field Image displays in the image display and its histogram displays in a graph and a table.

The following image is an example of Dark Field Image.



## Flat Field Image

The image of the flat non-textured plane is recorded as Flat Field Image. The result image is output as the subtracted image between Flat Field Image and Input Image.


Train Flat Field Image with the following procedures:

- 1 Set the flat non-textured plane in front of the camera.
- 2 Adjust the exposure time in order that the peak of the histogram is at the center of the histogram and the maximum value of the pixel is less than 255.
- 3 Press Set button to record [Flat Field Image]. After when Flat Field Image is trained, Flat Field Image displays in the image display and its histogram displays in the graph and the table.
- 4 Select [Result Image] as [Image Display Mode] and make sure that the uneven lighting is corrected in the result image.


### NOTE

When the layout or the intensity of the lighting is changed, Flat Field Image should be retrained.


The following figure shows an example.



Input Image



Flat Filed Image



Result Image

## Run in Search Window

By default, Flat Field Tool processes the entire image. But if this item is checked, Flat Field Tool processes only inside the search window of the command tools which use the result image. According to the number of found, processing only inside the search window may reduce the processing time of Flat Field Tool.

Note that Flat Field Tool processes only inside the search window in the following cases. In the other cases, Flat Field Tool processes entire image even if the item is checked.

- When executing the vision process from a TP program
- When running a test on the setup page

## Save Result Image

If this item is checked, the result image is stored in the selected image register. When there is no image register, an error message is displayed. For the details of the image register, refer to 9.4.1 “IRVSNAP, IRVFIND”.

## Image Display Mode

Select the image display mode from the following choices:


- Input Image
- Dark Field Image
- Flat Field Image
- Result Image

## Show Color Graphics

The color graphics displays in the image display. The pixels that have the same value show in the same color.

The violet shows the darkest (“coldest”) pixels in the current image. In order of brightness, the pixel shows blue, green, yellow, orange, and red respectively. The red shows the brightest (“hottest”) pixels in the current image.

The following example shows the image with color graphics:




## Grayscale Histogram

The histogram of the current image displays as the graph and the table.

### Command tools using this Result Image

The name of command tools which use the result image of this Flat Field Tool is displayed. When this Flat Field Tool is changed, verify that these command tools still operate as intended.



## 7.46.2 Running a Test

---

Press F4 FIND to run a test and see if the Flat Field Tool operates properly.

### Time to Find

The execution time of the Flat Field Tool took is displayed in milliseconds.

## 7.46.3 Overridable Parameters

---

This command tool has no parameters that can be overridden with Vision Override.

# 8 APPLICATION DATA


This chapter describes how to set application data.

## 8.1 VISION OVERRIDE

Vision override is a function that allows you to change a vision process property from a robot program on a temporary basis. By using the vision override function, for example, you can retry a vision process with an exposure time that is different from that originally taught in that vision process.

Each vision override needs to be associated in advance with a specific property of a vision process. For example, when you create a vision override called “EXPO1”, you may associate “EXPO1” with the property “Exposure Time” for the vision tool “Camera View 1” of the vision process “FIND1”. This is tantamount to assigning a short alias “EXPO1” to the “Exposure Time of Camera View 1 of FIND1”. Defining a vision override enables you to temporarily change the associated property from a robot program by using the VISION OVERRIDE instruction. For information about the VISION OVERRIDE instruction, see Subsection 9.2.2, “Vision Execution Commands”.

When the window for vision override is opened, the following screen is displayed.



Associate the vision override with a specific vision process property.

### Vision Process

Select a vision process to be associated.

### Vision Tool

Select the name of the vision tool to be associated (a name displayed in the tree view of the vision process setup page).

### Property

Select a property to be associated.

## Overridable Range

Display maximum value, minimum value, and current value.

## 8.2 OFFSET LIMIT

Offset limit is a function that checks whether the offset found by a vision process is within a specified range. If the check finds the offset is within the range, the tool does nothing. If the offset is found to be outside the range, the tool takes a specified action. The offset limit setup screen lets you define the conditions to be checked and the action to be taken if the offset is found to be outside the range. To actually perform the offset limit check, select which offset limit tool to use in the vision process setup page. The offset limit check is performed when the robot program executes the GET\_OFFSET instruction. When the window for offset limit is opened, the following screen is displayed.

Parameter	Enable	Min Check Value	Max Check Value
X	<input type="checkbox"/>	0.00 mm	0.00 mm
Y	<input type="checkbox"/>	0.00 mm	0.00 mm
Z	<input type="checkbox"/>	0.00 mm	0.00 mm
W	<input type="checkbox"/>	0.00 °	0.00 °
P	<input type="checkbox"/>	0.00 °	0.00 °
R	<input type="checkbox"/>	0.00 °	0.00 °

### Checking Method

Select the offset limit checking method from the following:

#### Relative check vs. reference position

A check is made to see whether the found position is within a range specified by relative positions from the reference position.

#### Absolute check in the application user frame

A check is made to see whether the found position is within a range specified by coordinates of the application user frame.

### Parameter

Specify which element (X, Y, Z, W, P, or R) of the found position is to be checked, as well as the allowable range. Check the check box of the element to be checked, and enter the allowable minimum and maximum values. If [Relative check vs. reference position] is selected for [Checking Method], enter the difference from the reference position. If [Absolute check in the application user frame] is selected for [Checking Method], enter the coordinates of the application user frame.

### Action on failed check

The offset limit check is performed when the GET\_OFFSET instruction is executed. Here, select the action to be taken if the offset limit check fails, from the following:

**Cause the GET\_OFFSET instruction to fail**

If the offset limit check fails, the robot program jumps to the label specified by the GET\_OFFSET instruction; that is, the robot program behaves in the same way as when the offset fails to be found.

**Skip the failed offset and evaluate the next offset**

If the offset limit check fails, the GET\_OFFSET instruction skips this found result and attempts to obtain the next one. In this case, the number of found results that the robot program can obtain decreases by one.

**Raise robot alarm and pause program execution**

If the offset limit check fails, the robot program pauses on the line of the GET\_OFFSET instruction. This stops the production operation and should not be specified under normal circumstances.



# 9 STARTING FROM A ROBOT PROGRAM

This chapter describes how to start *iR*Vision from a robot program.


## 9.1 VISION REGISTERS

The robot controller has special registers for storing *iR*Vision found results. These registers are called *vision registers*. Each vision register contains data for one found workpiece. The vision register contents can be checked on the teach pendant of the robot.

### 9.1.1 Vision Register List Screen

Perform the following steps to display the vision register list screen.

- 1 Press DATA on the teach pendant.
- 2 Press F1 [TYPE].
- 3 Select [Vision Reg]. The following screen is then displayed:



The rightmost character “R” indicates that a value is set.

#### Entering a comment


- 1 Move the cursor to the line of a vision register for which a comment is to be entered.
- 2 Press the Enter key.
- 3 Press an appropriate function key to enter the comment.
- 4 After completing the entry of the comment, press ENTER.

#### Erasing a value


- 1 Move the cursor to the line of a vision register of which contents are to be erased.
- 2 While holding down the SHIFT key, press F5 CLEAR.

## 9.1.2 Detail Screen of a Vision Register

On the list screen of vision registers, move the cursor to the line of the vision register of which contents are to be checked, then press F4 DETAIL.



To show the whole detail screen of vision register, select “Double” display.



### CAUTION

Basically, this screen is designed for reference although values can be entered on this screen. Entering an inappropriate value can cause an unpredictable robot motion.

### Type

Type of offset data stored in the vision register.

### Fixed Frame Offset

Fixed frame offset data

**Tool Offset**

Tool offset data

**Found Position**

Actual found position, which is not offset data. This item remains to provide compatibility with the old software edition.

**Found Position (TOOL)**

Actual found position, which is not offset data. This item remains to provide compatibility with the old software edition.

**Frame**

Frame number for offset data. If [Type] is [Fixed Frame Offset] or [Found Position], it is the user frame number. If [Type] is [Tool Offset] or [Found Position (TOOL)], it is the user tool number. It is the frame number specified in [Offset Frame] on the vision process setup page.

**Model ID**

Model ID of the found workpiece.

**Encoder**

Count of the encoder that triggers visual tracking for a found workpiece. This item is not used for purposes other than visual tracking.

**Group Mask**

Group mask of offset data. Specify the motion groups of the robot to be offset.

**CAUTION**

GET\_OFFSET command does not change Group Mask. Manually set Group Mask in advance so that the necessary robots are offset. By default, Group Mask is set to offset only the robot of motion group 1, so you don't have to change it in most cases.

**Offset**

Offset data in the XYZWPR format. It is represented in the user frame or the tool frame of [Frame].

**Found Pos**

Actual position of each camera view. It is represented in the user frame or the tool frame of [Frame].

**Meas**

Measurement values that Measurement Output Tool outputs.

**F2 PREV**

Displays the detail screen of the previous vision register.

**F3 NEXT**

Displays the detail screen of the next vision register.


**F4 LIST**

Brings you back to the vision register list screen.

### 9.1.3 Changing the Number of Vision Registers

You can change the number of vision registers at Controlled Start in the Program Limits menu. The default number is 10. You can have a maximum of 100 vision registers, or as few as 1. You can modify a number of vision registers with the following steps.

- 1 Perform a Controlled Start. Refer to R-30iB and R-30iB Mate CONTROLLER Operations Manual (Basic Operation).
- 2 Press MENU.
- 3 Press 0, NEXT, and select Program Setup. The following screen is shown.



- 4 Move the cursor to Vision Registers, type the desired number of vision registers (1 - 100), and press ENTER.
- 5 Press FCTN.
- 6 Select Start (Cold).

## 9.2 PROGRAM COMMANDS

Program commands for *iRVision* are provided.

### 9.2.1 Vision Offset

This command offsets the robot position by using offset data stored in a vision register.

#### 9.2.1.1 VOFFSET

VOFFSET is an optional operation command that is added to a robot motion statement. This command moves the robot to a position compensated with a vision offset data in a specified vision register.

If the type of offset data stored in the specified vision register is [Fixed Frame Offset], a fixed frame offset is applied. If the type is [Tool Offset], a tool offset is applied. Position offset is performed properly based on the coordinate system in which *iRVision* calculated the offset data, regardless of the currently selected user frame/user tool and the user frame/user tool of the position data of the motion statement.

**CAUTION**

VOFFSET command does not support Dynamic UFrame. When you want to use the vision offset with Dynamic UFrame, copy the vision offset data to a position register by “9.2.3.5 Offset data command” and use OFFSET command. For details of Dynamic UFrame, please refer to the “Coordinated Motion Function OPERATOR’S MANUAL”.

There are two types of syntax:

**VOFFSET,VR**

This command directly specifies a vision register in-line.

```
L P[1] 500mm/sec FINE VOFFSET,VR[a]
```

**VOFFSET**

This command uses a vision register specified with VOFFSET CONDITION command. See also 9.2.1.2 “VOFFSET CONDITION”.

```
L P[1] 500mm/sec FINE VOFFSET
```

**9.2.1.2 VOFFSET CONDITION**

This command selects a vision register that is used with VOFFSET command. The vision offset condition must be specified before VOFFSET command is used. The specified vision offset condition is effective until the program is aborted or another vision offset condition is specified.

```
VOFFSET CONDITION VR[a]
```

**9.2.1.3 LOCK VREG**

This command locks vision registers.

```
LOCK VREG
```

While the robot is executing a program, it reads the lines ahead of the line currently being executed. It is called “look-ahead execution”. Look-ahead execution is performed for motion statements, but it cannot be performed for motion statements that use vision registers or any other variable (position registers for example). Motion statements using vision registers cannot have the motion planned in advance because the values in the vision registers could change before the cursor reaches the statement.

This command enables look-ahead execution for motion statements that use vision registers to proceed. By means of these instructions, the user can explicitly specify a program portion that use vision registers to perform look ahead. Basically the instruction is making the vision register data a constant value. This is analogous to how the LOCK PREG instruction works.

When the vision registers are locked they can not be updated by vision. (The VISION GET\_OFFSET instruction will fail).

### 9.2.1.4 UNLOCK VREG

This command unlocks vision registers.

```
UNLOCK VREG
```

## 9.2.2 Vision Execution

These commands instruct *iR*Vision to perform processing.

### 9.2.2.1 RUN\_FIND

This command starts a vision process.

When a specified vision process has more than one camera view, location is performed for all camera views.

```
VISION RUN_FIND (vision-process-name)
```

When a vision process has multiple camera views, and location is to be performed for one of these views, add CAMERA\_VIEW[] command.

```
VISION RUN_FIND (vision-process-name) CAMERA_VIEW[a]
```

In the execution of a vision location command, when the vision process has snapped an image, the next line of the program is executed, and image processing is performed in the background. This allows vision image processing and another operation such as a robot motion to be performed in parallel.

### 9.2.2.2 GET\_OFFSET

This command gets a vision offset from a vision process and stores it in a specified vision register. This command is used after RUN\_FIND. If image processing is not yet completed when GET\_OFFSET is executed, it waits for the completion of the image processing.

```
VISION GET_OFFSET (vision-process-name) VR[a] JMP,LBL[b]
```

GET\_OFFSET stores the vision offset for a workpiece in a vision register. When the vision process finds more than one workpiece, GET\_OFFSET should be called repeatedly.

If no workpiece is detected or no more offset data is available because of repeated execution of GET\_OFFSET, it jumps to the specified label.

#### NOTE

Measurement values specified with the measurement value output tool are written to the vision register together with vision offset data when the GET\_OFFSET command is executed.

It is possible for the controller without *iR*Vision to get offset data from other controllers. This is generally used when the robots work big workpieces together. You should add the name of the robot before the name of vision process to gain offset data from other controllers.

```
VISION GET_OFFSET CONTROLLER1.VISPRO1 VR[1]
```

In order to get a vision offset from a remote controller, ROS Internet Packet over Ethernet function (RIPE) need to be set up. As for the RIPE function, refer to Section 3.6 “INTER-CONTROLLER COMMUNICATION” and “R-30iA/R-30iA Mate/R-30iB/R-30iB Mate CONTROLLER Ethernet Function OPERATOR’S MANUAL”.

#### CAUTION

With a vision process that detects multiple small workpieces in one measurement such as the 2-D single view vision process, the offset data obtained by a robot cannot be obtained by another robot. On the other hand, with a vision process that has multiple views ( such as the 2-D multi-view vision process) will return the same offset data to multiple robots until another snap updates one of the views.

### 9.2.2.3 GET\_NFOUND

This command gets the number of found results from a vision process and stores it in a specified register. The command is used after the VISION RUN\_FIND command. If image processing is not yet completed when GET\_NFOUND is executed, the command waits for the completion of the image processing.

```
VISION GET_NFOUND (vision-process-name) R[a]
```

If the vision process has more than one camera view, add the CAMERA\_VIEW[] command.

```
VISION GET_NFOUND (vision-process-name) R[a] CAMERA_VIEW[b]
```

### 9.2.2.4 GET\_PASSFAIL

This command gets the PASS/FAIL result of an inspection or error proofing vision process, then the command stores the result in a specified numeric register.

```
VISION GET_PASSFAIL (vision-process-name) R[a]
```

The following value is set in the numeric register:

Value	Description
0	FAIL
1	PASS
2	Could not be determined

### 9.2.2.5 GET\_READING

This command gets a result string of a reader vision process, then the command stores the string in a specified string register and also stores the length of the string in a specified numeric register. This command is used after RUN\_FIND.

```
VISION GET_READING (vision-process-name) SR[a] R[b] JMP,LBL[c]
```

If no barcode is found, it jumps to the specified label. If the string that the barcode contains is longer than 254 bytes, the first 254 characters are stored in the specified string register.



#### CAUTION

The length of the string indicates number of bytes. If the string is the multibyte character, the length of the string and number of characters do not match.

### 9.2.2.6 SET\_REFERENCE

This command sets the reference position in a vision process. The command is used after RUN\_FIND. The command has the same effect as the [Set Ref. Pos.] button in the setup window for a vision process.

```
VISION SET_REFERENCE (vision-process-name)
```

If a setup window of a vision process remains open when SET\_REFERENCE is executed for the vision process, the reference position cannot be written to the vision process, which results in CVIS-103 “The vision data file is already open for writing” alarm. Close the setup window, then re-execute the command.

When the vision process finds more than one workpiece, the position of the workpiece having the highest score is set as the reference position. It is recommended that only one workpiece be placed within the camera view so that an incorrect position is not set as the reference position.

### 9.2.2.7 CAMERA\_CALIB

This command performs camera calibration.

```
VISION CAMERA_CALIB (camera-calibration-name) (request-code)
```

The value specified as the request code varies depending on the type of camera calibration. Refer to the following table:

Calibration Type	Request Code
Grid Pattern Calibration	Specify the index of the calibration plane, 1 or 2.
Robot-Generated Grid Calibration	Specify a different number for each calibration point. In the case of robot-generated grid calibration, a robot program using this command is automatically generated. For details, see Section 10.1, “ROBOT-GENERATED GRID CALIBRATION”.
3D Laser Calibration	Specify the index of the calibration plane, 1 or 2.
Visual Tracking Calibration	Not supported



### 9.2.2.8 OVERRIDE

This command sets a value for a vision override. The command is used immediately before the VISION RUN\_FIND command.

```
VISION OVERRIDE (vision-override-name) a
```

The OVERRIDE command enables a vision process to run with part of its taught properties changed. For vision override, see Section 8.1, “VISION OVERRIDE”

The value you set with the OVERRIDE command is temporary and is not meant to rewrite the content of a vision process. The value set by this command takes effect only for the RUN\_FIND command that is executed immediately after the OVERRIDE command. Once the RUN\_FIND command is executed, all the values set by the OVERRIDE command (including those vision overrides associated with vision processes other than the vision process that executes location) are cleared.

## 9.2.3 Vision Registers

These commands assign the value of a vision register to a register or a position register.

### 9.2.3.1 Model ID

This command copies the model ID of the found workpiece from a vision register to a register.

```
R[a]=VR[b].MODELID
```

### 9.2.3.2 Measurement value

This command copies the measurement value of the found workpiece from a vision register to a register.

```
R[a]=VR[b].MEAS[c]
```

### 9.2.3.3 Encoder count

This command is used for visual tracking. It copies the encoder count of the found workpiece from a vision register to a register.

```
R[a]=VR[b].ENC
```

### 9.2.3.4 Found position

This command copies the actual position data of the found workpiece from a vision register to a position register.

```
PR[a]=VR[b].FOUND_POS[c]
```

In c, specify a camera view number.

**CAUTION**

The configuration of the position register at the assignment destination is replaced with a predetermined value. The robot may not be able to move to this position with this configuration.

**NOTE**

The position register format after assignment is XYZWPR.

### 9.2.3.5 Offset data

This command copies the offset data of the found workpiece from a vision register to a position register.

```
PR[a]=VR[b].OFFSET
```

**NOTE**

The position register format after assignment differs depending on the value of the system variable \$OFFSET\_CART. If \$OFFSET\_CART is FALSE, the matrix format is used. If the value is TRUE, the XYZWPR format is used. \$OFFSET\_CART allows you to select behavior of the OFFSET command. The command described in this section selects an appropriate position register format depending to the value of \$OFFSET\_CART so that the OFFSET command can work expectedly with the offset data.

## 9.3 ASYNCHRONOUS EXECUTION

iRVision stores the execution results of the five vision processes most recently executed. Thus, the VISION RUN\_FIND command and the VISION GET\_OFFSET command can be executed asynchronously with each other.

In the sample program below, measurements are made successively at two locations by using a robot mounted camera then the results of the two measurements are obtained and a compensation operation is performed on the measurement results.

```

1:  UFRAME_NUM=1
2:  UTOOL_NUM=1
3:
4:  L P[1] 500mm/sec FINE
5:  VISION RUN_FIND VISION1
6:
7:  L P[2] 500mm/sec FINE
8:  VISION RUN_FIND VISION2
9:
10: VISION GET_OFFSET VISION1 VR[1] JMP,LBL[99]
11: CALL HANDOPEN
12: L P[3:Approach1] 500mm/sec FINE VOFFSET,VR[1]
13: L P[4:Pick_pos1] 100mm/sec FINE VOFFSET,VR[1]
14: CALL HANDCLOS
15: L P[3:Approach1] 100mm/sec FINE VOFFSET,VR[1]
16:
17: VISION GET_OFFSET VISION2 VR[1] JMP,LBL[99]
18: CALL HANDOPEN
19: L P[5:Approach2] 500mm/sec FINE VOFFSET,VR[1]
20: L P[6:Pick_pos2] 100mm/sec FINE VOFFSET,VR[1]
21: CALL HANDCLOS
22: L P[5:Approach2] 100mm/sec FINE VOFFSET,VR[1]
23:
24: END
25:
26: LBL[99]
27: UALARM[1]

```

If six or more vision processes are executed asynchronously, the oldest stored detection result is discarded.

## 9.4 KAREL TOOLS

The KAREL programs below can be used.

### HINT

To call a KAREL program from a TP program, you must set the system variable \$KAREL\_ENB to TRUE.

### 9.4.1 IRVSNAP, IRVNFIND

IRVSNAP and IRVNFIND are the functions to store a snapped image in an image register on a temporary basis and restore the image from the image register later to find a vision process.

#### Image Register

An image register is an area to store captured images on a temporary basis. By storing captured images in an image register, as well as the data necessary for finding a vision process such as the robot position at the time of snapping, the image capturing and location operations can be performed separately. This allows you to reduce the cycle time because, in such cases as when you process the same image multiple times for different purposes, you can omit the capturing of the image for the second and subsequent image processing steps.

The number of image registers is determined by the system variable \$VISION\_CFG.\$NUM\_IMREGS. The default value is 0. Enter the necessary number of image registers.

The size of each individual image register is determined by the system variable \$VISION\_CFG.\$IMREG\_SIZE. The default value is 300. Where appropriate, set the register size as follows:

- Gray Digital Camera
 

320 x 240	75
640 x 480	300
1024 x 768	768
1280 x 1024	1280
1280 x 480	600
640 x 960	600
- Color Digital Camera
 

640 x 480	1200
1024 x 768	2304
- Analog Camera 300
- 3D Laser Sensor 1500



### CAUTION

After changing the value of the system register \$VISION\_CFG.\$NUM\_IMREGS or \$VISION\_CFG.\$IMREG\_SIZE, turn off the power of the controller and then back on in order to re-create the image register.

## IRVSNAP

This KAREL program captures an image according to the shooting condition of a specified vision process and stores the captured image in an image register. It also stores the data necessary to find the specified vision process (e.g., the robot position in the case of a robot-mounted camera) in the image register. To find a vision process using images stored in the image register, you use IRVFIND, which is described later. Using IRVSNAP and IRVFIND in combination lets you perform the same operation that the VISION RUN\_FIND command does.

The following three arguments need to be passed.

### Argument 1: Vision Process Name

Specify a vision process name as a character string.

### Argument 2: Camera View Number

Specify a camera view number in case of a multi-view vision process. Specify 1 in case of a single-view vision process.

### Argument 3: Image Register Number

Specify the number of the image register that stores the image.

## IRVFIND

This KAREL program runs a specified vision process using images stored in an image register. To store images in an image register, you use IRVSNAP, which is described above. Using IRVSNAP and IRVFIND in combination lets you perform the same operation that the VISION RUN\_FIND command does.

The following three arguments need to be passed:

**Argument 1: Vision process name**

Specify a vision process name as a character string.

**Argument 2: Camera View Number**

Specify a camera view number in case of a multi-view vision process. Specify 1 in case of a single-view vision process.

**Argument 3: Image Register Number**

Specify the number of the image register to be used for finding the vision process.

**Program Example**

Shown below is an example in which a multi-view vision process with three camera views is found by using the same image for all the camera views. In this case, the same camera calibration needs to be specified for all the camera views.

```
1: CALL IRVSNAP(VISION1, 1, 1)
2: CALL IRVFIND(VISION1, 1, 1)
3: CALL IRVFIND(VISION1, 2, 1)
4: CALL IRVFIND(VISION1, 3, 1)
5: VISION GET_OFFSET VISION1 VR[1] JUMP,LBL[99]
```

**9.4.2 IRVLEDON, IRVLEDOFF**

IRVLEDON and IRVLEDOFF are the functions to put a LED which is connected to the multiplexer for analog camera or the LED Light PSU for digital camera on / off. The multiplexer for analog camera of R-30iB Controller has electrical power supply function of LED.

**IRVLEDON**

Turn on the specified channel of LED light connected to the multiplexer for analog camera or the LED Light PSU for digital camera.

The following arguments can be passed:

**Argument 1: LED Channel Number**

Specify a channel number of a LED. Specify the one of the number from 1 to 8.

**Argument 2: Intensity**

Specify the intensity of LED. Intensity can be specified scale of 1 to 16. Specify the one of the number from 1 to 16.

**⚠ CAUTION**

Only one LED light can be turned on at the same time even when multiple LED lights are connected to the multiplexer. While a channel is turned on, turning another channel on will turn on the new channel after turning on the former channel. It takes about 2.5 seconds after the last channel is turned off until the new channel can be turned on, and the software automatically waits when the new channel is being turned on too quickly.

**IRVLEDOFF**

Turn off LED lights connected to the multiplexer for analog camera or the LED Light PSU for digital camera. This program has no arguments.

## Program Example

Shown below is an example that turns on an LED light, execute a vision detection, and finally turns the LED light off. The intensity of the LED light is about 50% of maximum value.

```
1: CALL IRVLEDON(1, 8)
2: VISION RUN_FIND 'VISION1'
3: CALL IRVLEDOFF
```

## 9.4.3 ACQVAMAP, CLRVAMAP

ACQVAMAP and CLRVAMAP are functions to control 3D Area Sensor.

### ACQVAMAP

This KAREL program acquires a 3D map of the specified 3D Area Sensor. Acquired 3D map is kept until a new 3D map for the same 3D Area Sensor is acquired, the 3D map is explicitly cleared by CLRVAMAP or the robot controller is turned off.

The following one argument needs to be passed.

#### Argument 1: 3D Area Sensor Name

Specify the vision data name of the 3D Area Sensor.

#### Argument 2: Merge Flag

When this argument is set to 1, the newly acquired 3D map is merged to the existing 3D map. When it is set to 0 or isn't specified, merging 3D maps does not occur. Usually you don't need to specify it.

### CLRVAMAP

This KAREL program clears a 3D map of the specified 3D Area Sensor. Usually you don't have to clear a 3D map explicitly, but you can use this KAREL program when you do want to clear a 3D map for some reasons.

The following one argument needs to be passed.

#### Argument 1: 3D Area Sensor Name

Specify the vision data name of the 3D Area Sensor.

## Program Example

Shown below is an example that acquires a 3D map of a specified 3D Area Sensor, finds workpieces in the acquired 3D map, and gets a vision offset for it.

```
1: CALL ACQVAMAP('SENSOR1')
2: VISION RUN_FIND 'VISION1'
3: VISION GET_OFFSET 'VISION1' VR[1] JMP,LBL[99]
```

Functions for acquiring a 3D map and finding workpieces are independently prepared, so you can retry finding workpieces in a same 3D map with different parameters. Shown below is an example of retrying.

```

1: CALL ACQVAMAP('SENSOR1')
2:
3: VISION RUN_FIND 'VISION1'
4: VISION GET_OFFSET 'VISION1' VR[1] JMP,LBL[1]
5: JMP,LBL[2]
6:
7: LBL[1]
8: VISION RUN_FIND 'VISION2'
9: VISION GET_OFFSET 'VISION2' VR[1] JMP,LBL[99]
10:
11: LBL[2]

```

## Managing 3D maps

The number of 3D maps that can be kept in a robot controller is limited. By default, it is one.

You can change the number by changing the system variable \$VAREA\_CFG.\$NUM\_BUFFERS. When this system variable is changed, the controller needs to be restarted.



### CAUTION

3D maps consume a large amount of memory. Increasing the number of 3D maps will decrease the free space of the temporary memory pool. When you increase the number of 3D maps, be sure to confirm the free space of the temporary memory pool after restarting the controller. If the free space of the pool is less than 3 MB, decrease the number of 3D maps.

Because of the memory space issue, you may not be able to fully increase the number of 3D maps for 3D Area Sensors connected to the controller. When the number of 3D maps is smaller than the number of 3D Area Sensors, ACQVAMAP selects an area to store a new 3D map in the following manner:

- 1 Select an area that a 3D map of the specified 3D Area Sensor is stored in
- 2 Select an unused area that no 3D map is stored in
- 3 Select an area that the oldest 3D map is stored in

When you want to make sure to keep a certain 3D map for a while, you can control which area should be used to store a new 3D map by clearing an unnecessary 3D map by calling CLRVAMAP before calling ACQVAMAP.

For example, assume the number of 3D maps is two. When the following program is executed, ACQVAMAP('SENSOR3') in the line 9 will overwrite the 3D map of SENSOR1, because it is the oldest one. Therefore, after the following program is executed, 3D maps of SENSOR2 and SENSOR3 remain in the controller.

```

1: CALL ACQVAMAP('SENSOR1')
2: VISION RUN_FIND 'VISION1'
3: VISION GET_OFFSET 'VISION1' VR[1] JMP,LBL[99]
4:
5: CALL ACQVAMAP('SENSOR2')
6: VISION RUN_FIND 'VISION2'
7: VISION GET_OFFSET 'VISION2' VR[1] JMP,LBL[99]
8:
9: CALL ACQVAMAP('SENSOR3')
10: VISION RUN_FIND 'VISION3'
11: VISION GET_OFFSET 'VISION3' VR[1] JMP,LBL[99]

```

If you want to make sure to keep the 3D map of SENSOR1, you should call CLRMAP('SENSOR2') before calling ACQVAMAP('SENSOR3') as shown below.

```


1: CALL ACQVAMAP('SENSOR1')
2: VISION RUN_FIND 'VISION1'
3: VISION GET_OFFSET 'VISION1' VR[1] JMP,LBL[99]
4:
5: CALL ACQVAMAP('SENSOR2')
6: VISION RUN_FIND 'VISION2'
7: VISION GET_OFFSET 'VISION2' VR[1] JMP,LBL[99]
8:
9: CALL CLRMAP('SENSOR2')
10:
11: CALL ACQVAMAP('SENSOR3')
12: VISION RUN_FIND 'VISION3'
13: VISION GET_OFFSET 'VISION3' VR[1] JMP,LBL[99]

```

## Merging 3D maps

You can merge 3D maps acquired with different exposure times and/or different projector intensities. This function is useful for the following cases.

- There are a bright part and a dark part on the workpiece surface and it is difficult to measure 3D points on the entire surface with a single exposure time.
- The entire surface cannot be measured because of the influence of unevenness of the projector light brightness.



### ⚠ CAUTION

- 1 The measurement time increases because it requires acquiring multiple 3D maps.
- 2 Only 3D maps acquired by the same 3D Area Sensor can be merged.
- 3 Merging 3D maps is only available from ACQVAMAP called from a TP program. In other words, it is not available on Vision Setup.

### NOTE

You can check the merged 3D map on Vision Runtime and Vision Setup screens.

In the following example, the line 1 acquires the first 3D map, the second line overrides the exposure time, and the line 3 acquires the second 3D map and then merges it to the first 3D map.

```

1: CALL ACQVAMAP('SENSOR1')
2: VISION OVERRIDE 'EXPO' 40.0
3: CALL ACQVAMAP('SENSOR1',1)

```



## 9.4.4 IRVTRAIN

IRVTRAIN is a function to train the model pattern of a GPM locator tool from a TP program.

The function to train the model pattern by executing IRVTRAIN from a TP program is called “External Model Train.” The details of the model pattern to be trained are specified in an XML-format text file. This text file is called a “model train file.” In a model train file, search parameters of the GPM locator tool can be specified in addition to the shape of the model pattern to be trained.

External Model Train function has two training modes. The mode is selected by specifying it in the model train file.

### Use Graphics

The shape of the model pattern to be trained is specified using circles, rectangles, lines, and arcs. The locations and dimensions of these graphics are specified in millimeters.

### Use an Image

A model pattern is trained with a specified area within a specified image. Either a captured image or a saved image file can be used to train a model pattern.

When the model pattern of a GPM locator tool is trained with External Model Train, the changes are saved in the executed vision data just as if the model pattern were trained from the GPM locator tool setup page.

External Model Train has the following effects in comparison to the model pattern trained from the GPM locator tool setup page.

- The model pattern can be trained free of contamination from image noise and part variance, because the model pattern can be specified with geometric shapes.
- Workers unfamiliar with *iR*Vision can effortlessly change or add the parts to be handled, because the *iR*Vision setup page operation is not required in the process.
- The downtime in changing or adding parts can be minimized, because the text file can be created off-line without the actual part or a camera.
- A single text file can train model patterns for similar parts with varying measurements, by specifying the measurements with numerical registers in the file
- Problems of FROM capacity and complex TP programs can be moderated, because the number of vision processes with respect to the parts can be reduced.

The following two arguments need to be passed to the KAREL program.

### Argument 1: Vision Process Name

Specify the name of a vision process with a GPM locator tool to train the model pattern for, as a character string. A string register can be specified instead.

### Argument 2: Model Train File Name

Specify the name of a text file containing information about the model, as a character string. A string register can be specified instead.

## Sample TP Program

```
1: CALL IRVTRAIN(Vision Process Name, Model Train File Name)
```

**CAUTION**

The setup page of the vision process intended for running the External Model Train must be closed before executing the TP program.

### 9.4.4.1 Model Train File

The details of the model pattern to be trained are specified in a model train file.

The following information is described in a model train file.

- GPM locator tool name
- Training mode (Use graphics or use an image)
- If graphics were used, the location and dimensions of the graphics
- If an image were used, whether the image is captured or loaded from a file

The dimensions of the graphics described in the model train file can be indirectly specified using numerical registers. By specifying the values using numerical registers, the model pattern with various dimensions can be trained by specifying the values in the registers and executing IRVTRAIN, even without changing the content of the model train file. However, the model pattern is trained using the values in the numerical registers at the time IRVTRAIN is executed, thus simply changing the register values will not retrain the model pattern.

Furthermore, the following parameters can be modified with the training of the model pattern. For instance, the orientation search can be disabled with the model train file if the model pattern to be trained is a circle.

- Model ID
- Score Threshold
- Contrast Threshold
- Area Overlap
- Elasticity
- EA Score Threshold
- Allow Floating EA
- Ignore Polarity
- DOF - Orientation
- DOF - Scale
- DOF - Aspect

### Model Train File Location

External Model Train function operates by referencing a model train file and optionally an image file stored in the specified directory (MC:¥VISION¥TRAIN¥ by default). Create this directory in a memory card, and store the files in the directory before executing External Model Train.

### Model Train File Format

The model train file is written in an XML format. If any discrepancies exist with the format, the line number of the first inadequacy is posted with an alarm message.

**NOTE**

The XML format can be verified using a viewer such as Microsoft Internet Explorer®. We recommend that you check the text file format with such a viewer prior to running External Model Train.

Sample model train file for training a model pattern with a rectangular shape:

```
<?xml version="1.0" encoding="UTF-8" ?>
```

```

<visiontrain>
  <gpmtool name="GPM Locator Tool 1">
    <gpmmodel>
      <shape type="rect">
        <size>R[1] R[2]</size>
      </shape>
    </gpmmodel>
  </gpmtool>
</visiontrain>

```

Sample model train file for training more complicated model pattern with multiple shapes:

```

<?xml version="1.0" encoding="UTF-8" ?>
<visiontrain>
  <gpmtool name="GPM Locator Tool 1">
    <gpmmodel model-id="1" train-height="20">
      <shape type="polyline" closed="true">
        <point>12.0 12.0</point>
        <point>0.0 12.0</point>
        <point>0.0 0.0</point>
        <point>10.0 0.0</point>
        <point type="arc-to" radius="2">12.0 2.0</point>
      </shape>
      <shape type="circle" extra-care="true">
        <point>3.5 3.5</point>
        <value name="radius">R[1]</value>
      </shape>
    </gpmmodel>
    <gpmrunparams>
      <value name="score-thresh">70</value>
      <value name="contrast-thresh">50</value>
    </gpmrunparams>
  </gpmtool>
</visiontrain>

```

Sample model train file for training a model pattern with an captured image:

```

<?xml version="1.0" encoding="UTF-8" ?>
<visiontrain>
  <gpmtool name="GPM Locator Tool 1">
    <gpmmodel model-id="1">
      <image>snap</image>
      <trainroi>
        <point>100 100</point>
        <size>140 240</size>
      </trainroi>
    </gpmmodel>
    <gpmrunparams>
      <value name="score-thresh">80</value>
      <value name="contrast-thresh">30</value>
    </gpmrunparams>
  </gpmtool>
</visiontrain>

```

Sample model train file for training a model pattern with an image file:

```

<?xml version="1.0" encoding="UTF-8" ?>
<visiontrain>
  <gpmtool name="GPM Locator Tool 1">
    <gpmmodel>
      <image center-origin="true">square1.png</image>

```

```

    <trainroi>
      <point>100 100</point>
      <size>140 240</size>
    </trainroi>
  </gpmmodel>
  <gpmrunparams>
    <value name="score-thresh">80</value>
    <value name="contrast-thresh">30</value>
  </gpmrunparams>
</gpmtool>
</visiontrain>

```

Values of elements and attributes can be indirectly specified using registers. The samples above show examples of the usage. The following registers can be specified.

### R[ ]

Numerical register can be used to indirectly specify a numerical value.

### SR[ ]

String register can be used to indirectly specify a text.

## <VISIONTRAIN>

This is the root element of the model train file. This element indicates that the text file is a model train file for *iR*Vision External Model Train function.

```
<visiontrain>...</visiontrain>
```

<gpmtool> element must be inserted as a child element. No attributes can be specified.

## <GPMTOOL>

This is the element for specifying the intended GPM locator tool.

```
<gpmtool name="gpm_tool_name">...</gpmtool>
```

This element is inserted for each GPM locator tool to be trained, as a child element of the <visiontrain> element. Multiple <gpmtool> elements are inserted when model patterns for multiple GPM locator tools are to be trained simultaneously with one model train file. The element can have one <gpmmodel> element and one <gpmrunparams> element as its child elements.

The following attribute can be specified:

### name

The name of the intended GPM locator tool is specified. This attribute must be specified. The text can be indirectly specified with a string register. Texts with capitalization and spaces are distinguished.

## <GPMMODEL>

This is the element for describing the model information.

```
<gpmmodel model-id="val1" train-height="val2">...</gpmmodel>
```

This element is inserted as a child element of the <gpmtree> element. Only one <gpmmodel> element can be inserted as a child tool of each <gpmtree> element. The element can have <shape> elements, an <image> element, a <trainarea> element, and a <trainroi> element as its child elements. Writing the <shape> element or the <image> element determines whether graphics or an image is used to train the model pattern. An alarm is posted if both <shape> element and <image> element are present.

The following attributes can be specified:

### model-id

The model ID of the intended GPM locator tool is specified. A value between -2147483647 and 2147483646 can be specified. This attribute is optional. If omitted, the model ID specified in the GPM locator tool is used. The value can be indirectly specified with a numerical register.

### train-height

The application Z height in the offset frame is specified in millimeters when training a model pattern with graphics. This attribute is optional. If omitted, the application Z value specified in the vision process is used. The value can be indirectly specified with a numerical register.

#### NOTE

The value of the train-height attribute dictates the height of a plane that the graphics are considered to be on, when the model is trained. Specifying this value in the model train file does not modify the application Z height in the vision process setup page.

## <SHAPE>

This is the element for describing a model pattern graphic.

```
<shape type="text" closed="bool" light-inside="bool" light-left="bool" extra-care="bool">...</shape>
```

This element is inserted as a child element of the <gpmmodel> element. Each <shape> element signifies a rectangle, a circle, or sequential lines, and a complex shape can be specified by inserting multiple <shape> elements in the model train file.

The following attributes can be specified:

### type

The type of the graphic is specified. This attribute must be specified. Select from the followings:

rect A rectangle

circle A circle

polyline A polygonal line formed with straight lines and arcs

### closed

The attribute specifies whether the polygonal line is closed or not, when the type attribute is "polyline". The last point and the first point are connected with a straight line if TRUE. This attribute is optional. The value will be FALSE if the attribute is omitted.

### light-inside

The attribute specifies the polarity of the graphic when the type attribute is "rect" or "circle." The graphic will be light against a dark background if TRUE, and dark against a light background if FALSE. This attribute is optional. The value will be FALSE if the attribute is omitted.

**light-left**

The attribute specifies the polarity of the graphic when the type attribute is “polyline.” The left side of a line drawn from the start point to the end point will be light if TRUE, and dark if FALSE. This attribute is optional. The value will be FALSE if the attribute is omitted.

**extra-care**

The attribute specifies whether the graphic is an emphasis area or not. The graphic will be an emphasis area if TRUE. This attribute is optional. The value will be FALSE if the attribute is omitted.

When “rect” is specified as the graphic type, the location, the size, and the orientation of the rectangle should be specified by inserting <point>, <size>, and <value> elements as the child elements of the <shape> element.

```
<shape type="rect" light-inside="bool" extra-care="bool">
  <point type="text">x y</point>
  <size>dx dy</size>
  <value name="angle">a</value>
</shape>
```

The child elements are specified as follows:

**<point>**

The location of the rectangle is specified in millimeters. This element is optional. The center of the rectangle will be positioned at (0, 0) if the element is omitted.

The “type” attribute can be optionally specified. Either “upper-left” or “center” can be specified. When “upper-left” is specified, the element values will be the coordinate of the upper-left corner of the rectangle. When “center” is specified, the element values will be the coordinate of the center of the rectangle. This attribute is optional, and omitting the attribute would be the same as specifying “center.”

**<size>**

The size of the rectangle is specified in millimeters. This element must be specified.

**<value>**

The orientation of the rectangle is specified in degrees. The “name” attribute must be specified, and “angle” is specified as the attribute value. The center of rotation is the point specified with the <point> element. This element is optional. The orientation will be 0 if the element is omitted.

**NOTE**

A square can be drawn by specifying the same value in the <size> element values.

When “circle” is specified as the graphic type, the center and the radius should be specified by inserting <point> and <value> elements as the child elements of the <shape> element.

```
<shape type="circle" light-inside="bool" extra-care="bool">
  <point>x y</point>
  <value name="radius">r</value>
</shape>
```

The child elements are specified as follows:

**<point>**

The center of the circle is specified in millimeters. No attributes are specified. This element is optional. The center of the circle will be positioned at (0, 0) if the element is omitted.

**<value>**

The radius of the circle is specified in millimeters. This element must be specified. The “name” attribute must be specified, and “radius” is specified as the attribute value.

When “polyline” is specified as the graphic type, the coordinates of vertices should be specified by inserting multiple <point> elements as the child elements of the <shape> element.

```
<shape type="polyline" closed="bool" light-left="bool" extra-care="bool">
  <point>x1 y2</point>
  <point>x2 y2</point>
  ...
</shape>
```

The child element is specified as follows:

**<point>**

The coordinate of a vertex is specified in millimeters. This element must be specified. Each <point> element indicate a vertex in the polygonal line, thus at least two <point> elements are required.

By default, the vertices are connected by a straight line. An arc can be formed between the specified vertex and the previous vertex by specifying the “type” attribute with “arc-to” value. The dimensions of the arc are specified with “radius”, “clockwise”, and “roundabout” attributes. Refer to the <point> element description for detail.

**<TRAINAREA>**

This is the element for specifying the model train area, when training the model pattern with graphics.

```
<trainarea>
  <point>x y</point>
  <size>dx dy</size>
</trainarea>
```

When training the model pattern with graphics, the model train area is automatically calculated to circumscribe the specified graphics. Therefore, it is generally not necessary to specify this element. If a train area should be explicitly specified, then the <trainarea> can be inserted as the child element of the <gpmmodel> element. No attributes are specified. The location and the size of the area should be specified by inserting <point> and <size> elements as its child elements.

The child elements are specified as follows:


**<point>**

The upper-left coordinate of the train area is specified in millimeters. This element must be specified. No attributes are specified.

**<size>**

The size of the train area is specified in millimeters. This element must be specified. No attributes are specified.

An example of how the train area is calculated if the <trainarea> element is omitted is shown below. A rectangle shown in dotted lines circumscribing the model origin (0, 0) and the graphics specified with <shape> elements are expanded by 10 pixels in all directions to form a rectangular train area (shown in solid lines).



## <IMAGE>

This is the element for specifying the image to be used.

```
<image center-origin="bool">val</image>
```

This element is inserted as a child element of the <gpmmodel> element to specify the image to be used for training a model pattern. The element does not have any child elements.

To use the captured image as the image for training a model pattern, specify “snap” as the element value. To use an image file as the image for training a model pattern, specify the name of the file as the element value. Image files with the extension BMP and PNG are supported. A string register can be used to indirectly specify the value.

The following attribute can be specified:

### center-origin

Whether or not to set the model origin at the center of rotation is specified. The rotational center is calculated and set as the model origin if TRUE. If FALSE, the model origin will be set to a location such that the found result would coincide with the result of the previous model. This attribute is optional. The value will be FALSE if the attribute is omitted.



### CAUTION

External Model Train needs to be operated such that the reference data and robot positions are not required to be modified after training the model pattern. Refer to 9.4.4.2 “Operation Methods” for detail.

## <TRAINROI>

This is the element for specifying the model train area, when training the model pattern with an image.

```
<trainroi>
  <point>vt hz</point>
  <size>dvt dhz</size>
</trainroi>
```

This element is inserted as a child element of the <gpmmodel> element to specify the position and the size of a train area when training a model pattern with an image. This element must be inserted if an image is used with External Model Train. No attributes are specified. The element should have <point> and <size> element as its child elements to specify the position and the size of the train area.

The child elements are specified as follows:



**<point>**

The upper-left coordinate of the train area within the image is specified in pixels. This element must be specified. No attributes are specified.

**<size>**

The size of the train area within the image is specified in pixels. This element must be specified. No attributes are specified.

**<SIZE>**

This is the element for specifying the size of a rectangle.

```
<size>dx dy</size>
```

This element is inserted as a child element of <shape>, <trainarea>, and <trainroi> elements to specify the size of a rectangle. The two numerical values must be separated by a space. If the unit of the values are in millimeters, the values are entered in the order of x and y, and if the unit of the values are in pixels, the values are entered in the order of vt and hz. Numerical registers can be used to indirectly specify the values. No attributes can be specified. The element does not have any child elements.

**<POINT>**

This is the element for specifying the coordinate of a point.

```
<point type="text" radius="r" clockwise="bool" roundabout="bool">x y</point>
```

This element is inserted as a child element of <shape>, <trainarea>, and <trainroi> elements to specify the coordinate of a point. The two numerical values must be separated by a space. If the unit of the values are in millimeters, the values are entered in the order of x and y, and if the unit of the values are in pixels, the values are entered in the order of vt and hz. Numerical registers can be used to indirectly specify the values. The element does not have any child elements.

The following attributes can be specified:

**type**

The type of a point is specified from the followings:

- center Used to specify the center of a rectangle
- upper-left Used to specify the upper-left corner of a rectangle
- arc-to Used to add an arc in the polygonal line

**radius**

The attribute specifies the radius of an arc when the point type is "arc-to". The attribute must be specified.

**clockwise**


The attribute specifies the direction of the arc when the point type is "arc-to". The arc is drawn clockwise if TRUE, and counter-clockwise if FALSE. The attribute is optional. The value will be FALSE if the attribute is omitted.

**roundabout**

The attribute specifies the route of the arc when the point type is "arc-to". The arc is drawn with a roundabout route if TRUE, and with a shortest route if FALSE. The attribute is optional. The value will be FALSE if the attribute is omitted.

An example of the use of arc related attributes are shown below.

```
<point>x1 y1</point>
<point type="arc-to" radius="r" clockwise="bool1" roundabout="bool2">x2 y2</point>
```



**<GPMRUNPARAMS>**

This is the element for specifying the search parameters.

```
<gpmrunparams>...</gpmrunparams>
```

This element is inserted as a child element of the <gpmtree> element, and contains search parameter information. The element has <value> elements as its child elements to specify the values of search parameters.

**<VALUE>**

This is the element for specifying a value.

```
<value name="text">...</value>
```

This element is inserted as a child element of <shape> and <gpmrunparams> elements. The element does not have any child elements.

The following attribute can be specified:

**name**

The name of a search parameter is specified. This attribute must be specified. The parameters from the following list can be specified as the attribute value.

Parameters	Descriptions
radius	Specify the radius of a circle. A numerical register can be used to indirectly specify the value.
angle	Specify the orientation of a rectangle. A numerical register can be used to indirectly specify the value.
score-thresh	Specify the score threshold between 10.0 and 100.0. A numerical register can be used to indirectly specify the value.
contrast-thresh	Specify the contrast threshold between 1 and 200. A numerical register can be used to indirectly specify the value.
overlap-thresh	Specify the area overlap ratio between 0.0 and 100.0. A numerical register can be used to indirectly specify the value.

Parameters	Descriptions
fit-err-thresh	Specify the elasticity between 0.1 and 5.0. A numerical register can be used to indirectly specify the value.
extra-care-thresh	Specify the emphasis area threshold between 10.0 and 100.0. A numerical register can be used to indirectly specify the value.
extra-care-float	Specify if emphasis area deviation is allowed. TRUE to allow deviation.
ignore-polarity	Specify if polarity is ignored. TRUE to ignore model pattern polarity.
angle-enabled	Specify whether or not to enable orientation search. TRUE to enable orientation search.
angle-nom	Specify the nominal orientation search angle between -180.0 and 180.0. A numerical register can be used to indirectly specify the value.
angle-min	Specify the minimum orientation search angle between -180.0 and 180.0. A numerical register can be used to indirectly specify the value.
angle-max	Specify the maximum orientation search angle between -180.0 and 180.0. A numerical register can be used to indirectly specify the value.
scale-enabled	Specify whether or not to enable scale search. TRUE to enable scale search.
scale-nom	Specify the nominal scale search range between 25.0 and 400.0. A numerical register can be used to indirectly specify the value.
scale-min	Specify the minimum scale search range between 25.0 and 400.0. A numerical register can be used to indirectly specify the value.
scale-max	Specify the maximum scale search range between 25.0 and 400.0. A numerical register can be used to indirectly specify the value.
aspect-enabled	Specify whether or not to enable aspect search. TRUE to enable aspect search.
aspect-nom	Specify the nominal aspect search range between 50.0 and 100.0. A numerical register can be used to indirectly specify the value.
aspect-min	Specify the minimum aspect search range between 50.0 and 100.0. A numerical register can be used to indirectly specify the value.
aspect-max	Specify the maximum aspect search range between 50.0 and 100.0. A numerical register can be used to indirectly specify the value.

The <value> elements provided for the child elements on the <gpmrunparams> element overwrite parameters independently of one another. For example, it is possible to set a value in angle-nom when angle-enabled is set to TRUE. In this case, the angle-nom value that is set is not used during detection, but the parameter itself is rewritten. Also, it is not necessary to specify angle-min and angle-max simply because angle-enabled is changed to TRUE.

#### NOTE

It is not necessary to insert the <value> elements for all parameters when the parent element is <gpmrunparams>. Unspecified parameters are simply not modified.

### 9.4.4.2 Operation Methods

A conventional robot compensation process involves training a model pattern for the GPM locator tool first, setting a reference data by detecting a reference part placed at a reference position next, and creating and teaching robot positions in a TP program to handle the part at the end. The same procedure is required for training the initial model pattern with External Model Train. However, for training subsequent model patterns, reference data and robot positions are not retrained—the robot is compensated using the same reference data and robot positions. In other words, the order of training the model pattern, reference data, and robot positions is altered. There are some critical points for the robot to properly compensate the offset without re-setting the reference data or re-teaching robot positions after

re-training the model pattern. In this section, operation methods for training a model pattern with graphics and with an image are explained.

**⚠ CAUTION**

Interchanging the model pattern training methods for the same GPM locator tool will incapacitate the robot from properly compensating the offset without retraining the reference data and robot positions. If a model pattern was trained using graphics, then subsequent model patterns should be trained using graphics; if a model pattern was trained using an image, then subsequent model patterns should be trained using an image.

**Training with Graphics**

The following steps describe the initial model pattern training for training with graphics.

- 1 Create and train a camera calibration.
- 2 Create and train a vision process.  
Setup the vision process (i.e., selecting a camera calibration, the offset mode, and the offset frame).  
However, do not train the GPM locator tool model pattern or set the reference data.
- 3 Create and store a model train file in a designated directory.
- 4 Move the robot to the search position, if the camera is mounted on the robot.
- 5 Run IRVTRAIN.
- 6 Place a reference part at a reference position.
- 7 Run vision execution (Run VISION RUN\_FIND).
- 8 Set the reference data (Run VISION SET\_REFERENCE).
- 9 Train robot picking motion.


The following steps describe the subsequent model pattern training for training with graphics. Note that reference data and robot positions are not altered; the data and positions trained with the initial model pattern training are used.

- 1 Create and store a model train file in a designated directory.
- 2 Move the robot to the search position, if the camera is mounted on the robot.
- 3 Run IRVTRAIN

**Graphic Projection**

When training a model pattern with graphics, the locations and dimensions of the graphics are specified in millimeters. These graphics are projected onto the camera using a camera calibration; therefore a camera calibration must be trained before running IRVTRAIN.


Points on the graphics are specified as 2-dimensional data, described in a Cartesian coordinate (x, y) as shown in the left diagram below. When the graphics are projected onto the camera, the x-coordinate becomes the horizontal component in the image as shown in the right diagram below, such that the orientation of the graphics remains the same.



The size with which the graphics are projected onto a camera depends on the distance between the camera and the plane where the graphics are considered to be placed on. In general, the part Z height specified in the vision process setup page represents the height of this plane. If you prefer to train the model pattern with the graphics on another height, the height of this plane can be explicitly specified with the train-height attribute of the <gpmmodel> element.

**NOTE**  
 The value of the train-height attribute dictates the height of a plane that the graphics are considered to be on, when the model is trained. Specifying this value in the model train file does not modify the application Z height in the vision process setup page.


The graphics specified in the model train file are considered to be placed squared with the camera. Therefore, even if the camera were mounted at an angle with respect to the offset frame, a circle specified in the model train file would be a circle instead of an oval.



**NOTE**  
 If the camera is mounted at an angle, enabling the aspect search in the GPM locator tool setup page would help with the detection.


## Model Origin

When training a model pattern with graphics, the model origin would always be set at (0, 0). In order for the robot compensation to be correct without retraining the reference position and the robot positions, the model origin must remain the same with respect to the robot gripper when picking the part. For instance, to be able to handle the three parts shown below by inserting a gripper in the hole, each graphic is specified such that the center of the circle is located at (0, 0).



## Robot-mounted Camera

When training a model pattern with graphics, the graphics specified in the model train file are projected onto the camera as described above. Since the projected size varies according to the position of the camera, External Model Train should be executed with the robot at the detection position when the camera is mounted on the robot.



## Training with an Image

The following steps describe the initial model pattern training for training with an image.

- 1 Create and train a camera calibration.
- 2 Create and train a vision process.  
Setup the vision process (i.e., selecting a camera calibration, the offset mode, and the offset frame).  
However, do not train the GPM locator tool model pattern or set the reference data.
- 3 Create and store a model train file in a designated directory.
- 4 Place a reference part at a reference position.
- 5 Move the robot to the search position, if the camera is mounted on the robot.
- 6 Run IRVTRAIN.
- 7 Run vision execution (Run VISION RUN\_FIND).
- 8 Set the reference data (Run VISION SET\_REFERENCE).
- 9 Train robot picking motion.

The following steps describe the subsequent model pattern training for training with graphics. Note that reference data and robot positions are not altered; the data and positions trained with the initial model pattern training are used.

- 1 Create and store a model train file in a designated directory.
- 2 Place a reference part at a reference position (Only when training with a captured image).
- 3 Move the robot to the search position, if the camera is mounted on the robot.
- 4 Run IRVTRAIN.

When the model pattern is retrained with an image, in order for the robot compensation to be correct without retraining the reference data and the robot positions, the detection result of the new model pattern must coincide with the previous model pattern. In order to ensure this, an image with the part placed at a position where the robot can handle it without an offset must be used with External Model Train. To keep the model origin identical to the previous model pattern, specify FALSE as the center-origin attribute value of the <image> element. (Omitting the center-origin attribute will set the value as FALSE.)

If the part is rotationally symmetric, by specifying the center-origin attribute of the <image> element as TRUE would set the model origin at the center of rotation. In the case where all the parts that are to be detected with a specific vision process are rotationally symmetric, and if the model origin were to be set at the rotational center of all parts, specifying the center-origin attribute to TRUE would ensure that the found result would be identical with respect to the handling position. However, the orientation of the detected part is relative to the orientation of the part in the image, with the trained model pattern being 0 degrees. Thus, unless the orientation of the part can be ignored such as with a circle, an image captured with the part placed at a position where the robot can handle it without an offset must be used.

**⚠ CAUTION**

Unless the same image is used to retrain the model pattern, the model origin would be modified if the center-origin attribute of the <image> element is specified as TRUE in the model train file. Therefore, even if the part were rotationally symmetric, it is possible for the calculated offset to have an error. To ensure that the robot position is offset correctly, set the center-origin attribute to FALSE and place the part at a position where the robot can handle it without an offset, before executing External Model Train with an image.

**NOTE**

External Model Train function is meant to automate model pattern training. Therefore it is undesirable to have to edit a model mask on the setup page after executing IRVTRAIN. To eliminate the need to edit the model pattern once trained, the image should be captured with a clean background where the lighting is controlled, such that the image captured would have high contrast and low noise. Thus, preparing a designated model pattern training station is recommended.

In a system where multiple parts are interchanged at certain interval, the same set of images ought to be used to retrain the model pattern for consistency. In such a case, by keeping the images as image files, External Model Train can train model patterns using image files. This is also beneficial since an actual reference part is not required to train the model pattern. However, the image to be saved as an image file must be captured with the conditions specified in this section.

### 9.4.4.3 Precautions

This section describes restrictions and limitations for External Model Train.

#### Power Interruption

Interrupting External Model Train by turning the robot controller off may corrupt the controller memory. A corrupted memory may interfere with normal robot operation. To avoid malfunction, do not turn off the robot controller while running External Model Train.

**CAUTION**

Do not turn off the robot controller while running External Model Train. Doing so may corrupt the FROM module memory and may interfere with normal robot operation.

**Supported Vision Processes**

External Model Train is supported with the following vision processes.

- 2D Single-view Vision Process
- Depalletizing Vision Process

2D Single-view Vision Process cannot calculate the correct offset if the application Z height of the reference part and the detected part are not identical. When retraining model pattern for parts with different heights using External Model Train, use Depalletizing Vision Process with the application Z mode set to “Use Register Value” and set an appropriate value for the measurement plane corresponding to the part.

**Supported Command Tool**

External Model Train is supported only with GPM locator tool. In addition, the model pattern of a GPM locator tool with its search window set to shift dynamically cannot be trained with External Model Train.

**Daily Execution Limit**

When the robot is in production (TP is disabled and the controller is in AUTO mode), the number of times External Model Train can be executed is limited to five a day. This limitation does not apply when the robot is not in production (i.e., executing IRVTRAIN from TP).

**CAUTION**

Vision data are stored in the robot controller FROM module by default. There is a limit to the number of times the data on the flash memory of the FROM can be changed, and by executing External Model Train frequently, the limit may be reached unexpectedly and may interfere with normal robot operation. The daily execution limit is provided to avoid such trouble.

**Model Pattern Mask and Emphasis Area**

By executing External Model Train, previously set model mask and emphasis area are deleted, just as they are deleted when a new model pattern is trained from the setup page.

When the model pattern is trained with graphics, a model mask cannot be set from the GPM locator tool setup page. The graphics in the model train file should only contain features that are pertinent to the model pattern. On the other hand, an emphasis area can be set to the selected sections of the model pattern trained with graphics, from the GPM locator tool setup page.

**9.4.5 IRVBKLSH**

IRBKLSH is the KAREL program that the robot performs an operation intended to cancel the backlash effect at its current position.

**Argument 1: motion group number**

Specify the motion group number of the robot that performs the backlash canceling operation.

**Program Example**

Shown below is an example that the robot of the motion group number 1 performs the backlash canceling operation before performing the CAMERA\_CALIB instruction.



```

1:L P[1] 500mm/sec FINE
2: CALL IRVBKLSH(1)
3: VISION CAMERA CALIB 'CALIB1'REQUEST=1

```

## 9.4.6 IRVHOMING

IRVHOMING is a KAREL program for executing an unconventional type of vision processes that do not require a camera calibration. Henceforth, this type of vision process will be addressed as a “Calibration-free vision process.”

When executing a calibration-free vision process, calling IRVHOMING is equivalent to executing RUN\_FIND for a conventional vision process. By executing a calibration-free vision process with IRVHOMING, the robot automatically moves to match the found pose of a part on the image with the destination pose trained at setup. Offset data is obtained by calling GET\_OFFSET after IRVHOMING, but for calibration-free vision processes, offset data is calculated as the difference between the robot position where the destination pose was trained, and the final robot position after homing in on the target part.

The following two arguments need to be passed to the KAREL program.

### Argument 1: vision process name

Specify the vision process name to execute. SR[] can be used to indirectly specify the name.

### Argument 2: motion speed

Specify an integer value for the motion speed of the robot, in mm/sec. R[] can be used to indirectly specify the value.

### Program Example

Shown below is an example for executing a calibration-free vision process, and offsetting the robot motion.

```

1:J P[1] 100% FINE
2: CALL IRVHOMING('NOCAL', 1000)
3: VISION GET_OFFSET 'NOCAL' VR[1] JMP LBL[10]
4:L P[2] 500mm/sec FINE VOFFSET, VR[1]

```

## 9.4.7 IRVMUXOFF, IRVMUXON, IRVMUXCHK

IRVMUXOFF and IRVMUXON are functions to control the power of the Digital MUX. Turning off the Digital MUX enables to disconnect cameras and/or 3D Laser Sensors connected to the Digital MUX during production. It is mainly used to disconnect the robot hand on which cameras and/or 3D Laser Sensors are mounted, by using the tool changer. And IRVMUXCHK is a function to check the status of the Digital MUX, namely whether it is turned on or off. These functions are optional.



### CAUTION

Relays and cables for controlling the power of the Digital MUX, the tool changer and cables for the tool changer should be arranged by a customer.

### \$MUX\_POWER[]

Settings used to control the power of the Digital MUX is stored in this system variable. Four sets of settings can be stored as \$MUX\_POWER[1]~[4], and one of them is specified when calling the KAREL programs such as IRVMUXOFF. This system variable has the following members:

**\$MUX\_POWER[].\$MUX\_CHANNEL**

Specify the channel of the Digital MUX to which cameras and/or 3D Laser Sensors, which you want to disconnect, are connected. The default value is 1, which indicates the Digital MUX directly connected to the CCU).

**\$MUX\_POWER[].\$DO\_TYPE**

Specify the type of digital signal output that is used to control the power of the Digital MUX, 1 for DO and 2 for RO. The default value is 1 (DO).

**\$MUX\_POWER[].\$DO\_NUM**

Specify the digital signal output number that is used to control the power of the Digital MUX. The default value is 0, which indicates “not specified yet”.

**\$MUX\_POWER[].\$DO\_DELAY**

Should not be changed. The default value is 50.

**\$MUX\_POWER[].\$CCU\_SNO**

Should not be changed. The default value is 0.

**\$MUX\_POWER[].\$USE\_LED**

Specify TRUE when the camera and/or the 3D Laser Sensors to be disconnected has the FANUC LED light. The default value is FALSE.

**IRVMUXOFF**

This KAREL program turns off the specified Digital MUX. This program should be called just before disconnecting cameras and/or 3D Laser Sensors.

The following argument can be passed:

**Argument 1: Index number**

Specify the index number of \$MUX\_POWER. One of 1~4 is specified.

- 1: \$MUX\_POWER[1] is used.
- 2: \$MUX\_POWER[2] is used.
- 3: \$MUX\_POWER[3] is used.
- 4: \$MUX\_POWER[4] is used.

This KAREL program performs the following steps.

- 1 If there is a camera that is snapping an image, wait for its completion.
- 2 If there is an LED light that is turned on, turn it off.
- 3 If there is a 3D Laser Sensor whose laser is turned on, turn it off.
- 4 Turn on the specified digital signal output to turn off the Digital MUX.
- 5 Wait for discharge of capacitors on the cameras, the Digital MUX and the LED power supply.
- 6 Make sure that the Digital MUX is turned off.

While the Digital MUX is turned off, the following process will fail.

- Snap an image with a camera that is connected to the Digital MUX.
- Turn on a laser of a 3D Laser Sensor that is connected to the Digital MUX.
- Turn on a FANUC LED light.

**NOTE**

It is recommended to turn on the Digital MUX soon just after the disconnection completes by calling IRVMUXON.

**IRVMUXON**

This KAREL program turns on the specified Digital MUX. This program should be called just after the disconnection completes.

The following argument can be passed:

**Argument 1: Index number**

- Specify the index number of \$MUX\_POWER. One of 1~4 is specified.
- 1: \$MUX\_POWER[1] is used.
  - 2: \$MUX\_POWER[2] is used.
  - 3: \$MUX\_POWER[3] is used.
  - 4: \$MUX\_POWER[4] is used.

This KAREL program performs the following steps.

- 1 Turn off the specified digital signal output to turn on the Digital MUX.
- 2 Wait for start-up of the Digital MUX and the cameras.
- 3 Make sure that the Digital MUX and the cameras are started.
- 4 Initialize the Digital MUX and the cameras.

When the step 1 completes, the next line of the program, which calls IRVMUXON, is executed, and remaining steps 2~3 are executed in the background. Therefore, the operation of the robot and the camera initialization can be performed in parallel.

**NOTE**

- 1 It would not normally occur, but a warning is displayed if an error occurs in the steps 2~4. The warning does not pause the program that calls IRVMUXON. After that, the program will be paused with an alarm when calling VISION RUN\_FIND.
- 2 If VISION RUN\_FIND or IRVMUXCHK is called before the steps 2~4 complete, VISION RUN\_FIND / IRVMUXCHK is executed after the steps 2~4 complete.

**IRVMUXCHK**

This KAREL program checks the status of the power of the specified Digital MUX. The status is stored in the specified register

The following arguments can be passed:

**Argument 1: Index number**

- Specify the index number of \$MUX\_POWER. One of 1~4 is specified.
- 1: \$MUX\_POWER[1] is used.
  - 2: \$MUX\_POWER[2] is used.
  - 3: \$MUX\_POWER[3] is used.
  - 4: \$MUX\_POWER[4] is used.

**Argument 2: Register number**

- Specify the number of the register to which the status of the power of the Digital MUX is written. The following value is written.
- 1: The power of the Digital MUX is ON.

0: The power of the Digital MUX is OFF.

### Program Example

Shown below is an example that turns off the Digital MUX, disconnects a camera, and then turn on the Digital MUX again.

```
1: CALL IRVMUXOFF(1)
2: CALL CAMERA_DISCONNECT
3: CALL IRVMUXON(1)
```

Shown below is an example to make sure that the power of the Digital MUX is ON before executing VISION RUN FIND. In the following example, R[100] is used as the register to which the status of the power of the Digital MUX is written.

```
1: CALL IRVMUXCHK(1,100)
2: IF R[100]=1,JMP LBL[1]
3: UALM[1]
4: PAUSE
5: END
6: LBL[1]
7: VISION RUN_FIND 'VISION1'
```

## 9.4.8 IRVGETMSR, IRVGETMSL

IRVGETMSR and IRVGETMSL are functions to output measurement values used with the Single-view Inspection vision process to numeric registers. These commands are used after RUN\_FIND.

### IRVGETMSR

This KAREL program outputs measurement values designated by “Variable 1” to “Variable 10” in the last Evaluation Tool on the tree view.

The following four arguments need to be passed.

#### Argument 1: Vision Process Name

Specify the Single-view Inspection vision process name.

#### Argument 2: First Register Number for Measurement Values

Specify the first register number for storing the measurement values. By default, 10 measurement values designated by “Variable 1” to “Variable 10” in Evaluation Tool are stored in 10 consecutive numeric registers, starting from the register number specified by this argument.

#### Argument 3: First Measurement Number

Specify the first measurement number in Evaluation Tool to be output. This argument is optional. If not specified, the default value of 1 is used.

#### Argument 4: The Number of Measurement Values

Specify the number of measurement values in Evaluation Tool to be output. This argument is optional. If not specified, the default value of “11 minus Argument 3” is used.

### IRVGETMSL

This KAREL program outputs measurement values designated by “Variable 1” to “Variable 10” in the child Evaluation Tool of each locator tool.

The following seven arguments need to be passed.


**Argument 1: Vision Process Name**

Specify the Single-view Inspection vision process name.

**Argument 2: Found Part Index**

Specify the index number of the found part to be output.

When there are multiple locator tools in the vision process, as shown in the following image, the index number is the cumulative number of the found parts from the top of the tree (The following image shows an example where GPM Locator Tool 1 detects three parts and Blob Locator Tool 1 detects two parts).



**Argument 3: Register Number for PASS/FAIL Result**

Specify the register number for storing PASS/FAIL result of the found part designated by Argument 2. The following value is set in the numeric register. “FAIL” = 0, “PASS” = 1, “Could not be determined” = 2.

**Argument 4: Register Number for Model ID**

Specify the register number for storing Model ID of the found part designated by Argument 2. As shown in the image above, when there are multiple locator tools in the vision process, measurement values to be output are different for each locator tool. In this case, the users should set different Model ID to each locator tool so that the measurement values can be distinguished by the TP program.

**Argument 5: First Register Number for Measurement Values**

Specify the first register number for storing the measurement values. By default, 10 measurement values designated by “Variable 1” to “Variable 10” in Evaluation Tool are stored in 10 consecutive numeric registers starting from the register number specified by this argument.

**Argument 6: First Measurement Number**

Specify the first measurement number in Evaluation Tool to be output. This argument is optional. If not specified, the default value of 1 is used.

**Argument 7: The Number of Measurement Values**

Specify the number of measurement values in Evaluation Tool to be output. This argument is optional. If not specified, the default value of “11 minus Argument 6” is used.

### Sample Program 1

Shown below is an example of outputting measurement values in the last Evaluation Tool on the tree view.

```
1: VISION RUN_FIND 'VISION1'
2: VISION GET_PASSFAIL 'VISION1' R[1]
3: CALL IRVGETMSR('VISION1', 2, 1, 5)
```

In this example, the PASS/FAIL result is stored in register [1] by GET\_PASSFAIL. Then, the measurement values designated by “Variable 1” to “Variable 5” in the last Evaluation Tool on the tree view are stored in register [2] to [6] by IRVGETMSR.

### Sample Program 2

Shown below is an example of outputting measurement values in the child Evaluation Tool of each locator tool.

```
1: VISION RUN_FIND 'VISION1'
2: VISION GET_NFOUND 'VISION1' R[1]
3: FOR R[2]=1 TO R[1]
4: CALL IRVGETMSL('VISION1', R[2], 3, 4, 5)
5: ...
6: END FOR
```

In this example, the number of found parts is stored in register [1] by GET\_NFOUND. Then, the data of each found part is output by IRVGETMSL. Specifically, the PASS/FAIL result is stored in register [3], the Model ID is stored in register [4], and the measurement values designated by “Variable 1” to “Variable 10” in the child Evaluation Tool of each locator tool are stored in register [5] to [14].

## 9.4.9 IRVOVRDANYVP

IRVOVRDANYVP is the KAREL program to set a value for a vision override. Its basic behavior is the same as VISION OVERRIDE instruction, but it is different in the point that it can be used not only for the vision process selected in the vision override but also for other vision processes.

#### Argument 1: Vision Override name

Specify the vision override name.

#### Argument 2: Value to set

Specify a numerical value to override.

#### Program Example

Shown below is an example that a vision override “EXPO” created for a vision process “TEST1” is applied to another vision process “TEST2”.

```
1: CALL IRVOVRDANYVP('EXPO', 100)
2: VISION RUN_FIND 'TEST2'
3: VISION GET_OFFSET 'TEST2' VR[1] JMP LBL[999]
```

**⚠ CAUTION**

- 1 The vision process to be applied with IRVOVRDANYVP must have the same vision tool and the property.
- 2 It might unexpectedly override a property of a vision process by mistake because it can handle that of any vision process.


## 9.4.10 BPGETAABB, BPGETOBB

BPGETAABB and BPGETOBB outputs the corner positions of 3D blob found by the Area Sensor Blob Locator Tool.

### BPGETAABB

This KAREL program outputs the corner positions of Axis Aligned Bounding Box of 3D blob.

#### AABB (Axis Aligned Bounding Box)



The following arguments can be passed:

#### Argument 1: Vision register number

Specify the index number of vision register storing 3D blob data.

#### Argument 2: Measurement value number

Specify the index number of measurement value storing Min. X of 3D blob.

#### Argument 3: Measurement value number

Specify the index number of measurement value storing Max. X of 3D blob.

#### Argument 4: Measurement value number

Specify the index number of measurement value storing Min. Y of 3D blob.

#### Argument 5: Measurement value number

Specify the index number of measurement value storing Max. Y of 3D blob.

**Argument 6: Position register number**

Specify the index number of position register storing robot configuration data as reference. Position info output through the position register of Arg9 is provided with this configuration data.

**Argument 7: Index number to indicate the corner position.**

Specify one of the corner positions to be output.


0: P0 in the figure shown below

1: P1 in the figure shown below

2: P2 in the figure shown below

3: P3 in the figure shown below

4: P4 in the figure shown below

**Argument 8: Register number (Output)**

Specify index number of register to output the status information of this KAREL program

In the register, one of the values shown below will be set depending on the error that occurs:

0: The program ended normally.

901: The vision register specified by Arg1 is not set 3D blob data.

902: The type of position register specified by Arg6 is not supported.

903: The type of position register specified by Arg9 is not supported.

**Argument 9: Position register number (Output)**

Specify index number of register to output the corner position.

**Program Example**

Shown below is an example that outputs the corner position P1 of 3D blob to the PR[11] and moves the robot to the PR[11].



```

1: CALL ACQVAMAP('SENSOR')
2: VISION RUN_FIND 'VISION'
3: VISION GET_OFFSET 'VISION1' VR[1] JMP,LBL[10]
4: CALL BPGETAABB (1,1,2,3,4,10,1,1,11)
5: IF R[1]<>0, JMP LBL[10]
6:L PR[10] 100mm/sec FINE
7: LBL[10]

```

## BPGETOBB


This KAREL program outputs the corner positions of Oriented Bounding Box of 3D blob.



### CAUTION

Please specify the [Minimum Rectangle Center] as the [Found Position] in the Area Sensor Blob Locator tool when this KARE program is used.

### OBB(Oriented Bounding Box)



The following arguments can be passed:

#### Argument 1: Vision register number

Specify the index number of vision register storing 3D blob data.

#### Argument 2: Measurement value number

Specify the index number of measurement value storing Length of 3D blob.

#### Argument 3: Measurement value number

Specify the index number of measurement value storing Width of 3D blob.


#### Argument 4: Position register number

Specify the index number of position register storing robot configuration data as reference. Position info output through the position register of Arg7 is provided with this configuration data.

**Argument 5: Index number to indicate the corner position.**

Specify one of the corner positions to be output.

- 0: P0 in the figure shown below
- 1: P1 in the figure shown below
- 2: P2 in the figure shown below
- 3: P3 in the figure shown below
- 4: P4 in the figure shown below

**Argument 6: Register number (Output)**

Specify index number of register to output the status information of this KAREL program

In the register, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally.
- 901: The vision register specified by Arg1 is not set 3D blob data.
- 902: The type of position register specified by Arg4 is not supported.
- 903: The type of position register specified by Arg7 is not supported.

**Argument 7: Position register number (Output)**

Specify index number of register to output the corner position.

**Program Example**

Shown below is an example that outputs the corner position P1 of 3D blob to the PR[11] and moves the robot to the PR[11].

```

1: CALL ACQVAMAP('SENSOR')
2: VISION RUN_FIND 'VISION'
3: VISION GET_OFFSET 'VISION1' VR[1] JMP,LBL[10]
4: CALL BPGETOBB (1,1,2,10,1,1,11)
5: IF R[1]<>0, JMP LBL[10]
6:L PR[10] 100mm/sec FINE
7: LBL[10]


```

# 10 UTILITY MENU

The *iR*Vision utilities are a set of functions that help you operate *iR*Vision.

To display the *iR*Vision utility menu, perform the following steps:

- 1 Press MENU key on the teach pendant, and select [8 *iR*Vision].
- 2 Press F1 [TYPE], and choose [5 Utility]. A screen like the one shown below appears.




## 10.1 ROBOT-GENERATED GRID CALIBRATION

Robot-Generated Grid Calibration is a type of general-purpose camera calibration function similar to Grid Pattern Calibration.

### 10.1.1 Overview

The function moves the target, mounted on the robot end of arm tooling, in the camera's field of view to generate a virtual grid pattern for camera calibration. Unlike Grid Pattern Calibration, this calibration method does not require a calibration grid as large as the camera's field of view and is therefore suitable for calibrating a wide-view-angle camera. Also, since it performs 2-plane calibration, the calibration method enables you to accurately calculate the position of the camera and the focal distance of the lens in use. The robot automatically moves and measures the position of the target and the size of the camera's field of view.

Robot-Generated Grid Calibration calibrates a fixed mounted camera. The target should be mounted on the robot end of arm tooling so that the arm does not get in the camera's field of view.



The procedure for robot-generated grid calibration is outlined below.

- 1 Create Robot-Generated Grid Calibration data on the camera calibration tools page. Setup the robot generated grid calibration data by selecting the camera to be calibrated, teaching the measurement start position, and training the locator tool to find the target mark.
- 2 Measure the position of the target mounted on the robot end of arm tooling.
- 3 Measure the size of the camera's field of view, and generate a calibration program.
- 4 Execute the generated calibration program to calibrate the camera.


As long as the position of the target mounted on the robot end of arm tooling is not changed, you can re-calibrate the camera only by taking the step 4.

## 10.1.2 Structure of the Menus

Here, the menu structure of Robot-Generated Grid Calibration Utility is first described.

### 10.1.2.1 Main menu

If you select [Robot-Generated Grid Calibration] in the *iR*Vision Utility menu, a menu like the one shown below appears. This is the main menu for Robot-Generated Grid Calibration.



<p><b>⚠ CAUTION</b>                  Robot-Generated Grid Calibration menu cannot be opened in more than one window at a time.</p>
--

**Calibration Data**

Select a camera calibration. Place the cursor on this line and press F4 [CHOICE]. A camera calibration list is displayed. From this list, select the camera calibration you want to train. Pressing F3 DETAIL with the cursor placed on this line lets you view the details of the currently selected camera calibration.

**Target Position**

This item indicates whether the position of the target mounted on the robot end of arm tooling has been recorded. If the position of the target has been recorded, [Recorded] is displayed. Otherwise, [Not Recorded] is displayed. Pressing F3 DETAIL with the cursor placed on this line lets you view the position information of the recorded target. If you place the cursor on this line and press SHIFT and F5 RUN at the same time, the robot moves and measures the position of the target.

**Program Generation**

Generate a TP program for camera calibration. If you place the cursor on this line and press SHIFT and F5 RUN at the same time, the robot moves and measures the size of the camera's field of view to generate a calibration program automatically.


**F2 DISP\_IMG**

Pressing F2 DISP\_IMG shows the menu for Robot-Generated Grid Calibration and the vision runtime display in a double-window display, as shown below.



### 10.1.2.2 Calibration data menu

If you press F3 **DETAIL** with the cursor placed on [Calibration Data] in the main menu for Robot-Generated Grid Calibration, a menu like the one shown below appears. This menu displays what has been set in the Robot-Generated Grid Calibration setup page. Normally, there is no item you need to set on this menu.



#### Calibration Data

The name of the selected camera calibration is displayed. Pressing F4 [CHOICE] with the cursor placed on this line shows a list of camera calibration that you can select. From this list, you can select a camera calibration you want to teach.

#### Camera Setup

The name of the camera specified in the selected camera calibration is displayed.

#### Robot-mounted

[NO] is displayed if the camera is secured to a fixed surface, or [YES] is displayed if it is mounted on the robot end of arm tooling.

**⚠ CAUTION**  
 For V8.30P/03, Robot-Generated Grid Calibration does not support a robot-mounted camera.

#### Application UFrame

The number of the application user frame specified in the selected camera calibration is displayed. In the case of 2D application, the XY plane of the application user frame needs to be parallel to the plane where the workpiece is to be offset.

#### Plane Spacing [mm]

Display the spacing between calibration planes 1 and 2.

## Start Position

This item indicates whether the measurement start position is recorded in the selected camera calibration. If the start position is recorded, [Recorded] is displayed. Otherwise, [Not Recorded] is displayed. Pressing F3 POSITION with the cursor placed on this line displays the start position menu.

## UTool for work space

Robot-Generated Grid Calibration uses a user tool for the work space when measuring the position of the target or generating a calibration program. Here, specify the number of the user tool for the work space. Since the function conducts the measurement as it rewrites the values of the specified user tool, specify the number of a user tool whose values can be changed without causing any problem.

## Num. of Grid (Col.)

Specify the number of grid points of the grid pattern that the robot draws by moving the target. Here, set the number of grid points to be created in the horizontal direction of the image.

## Num. of Grid (Row)


Specify the number of grid points of the grid pattern that the robot draws by moving the target. Here, set the number of grid points to be created in the vertical direction of the image.

## Program Name

Specify the name of the calibration program to be generated. By default, this program name is the same as the name of the selected camera calibration. Normally, you do not need to change the default name.


### 10.1.2.3 Target position menu

If you press F3 POSITION with the cursor placed on [Target Position] in the main menu for Robot-Generated Grid Calibration, a menu like the one shown below appears.



### 10.1.2.4 Start position menu

If you press F3 POSITION with the cursor placed on [Start Position] in the calibration data menu, a menu like the one shown below appears.



### F4 RECORD

If you press SHIFT and F4 RECORD at the same time causes the current robot position to be recorded as the measurement start position. The position is recorded in the joint format.

### F5 MOVE\_TO

If you press SHIFT and F5 MOVE\_TO at the same time moves the robot to the currently recorded measurement start position.

## 10.1.3 Performing Calibration

Perform Robot-Generated Grid Calibration.

### 10.1.3.1 Selecting and mounting the target


Select the target mark to be used for calibration.

#### Geometry of the target

The target must meet the following conditions:


- The features to be taught are on the same one plane.
- The target has a geometry for which any rotation of  $\pm 45^\circ$  or so can be identified.
- The target has a geometry whose size can be identified.

Examples of appropriate target geometries:





Examples of inappropriate target geometries:



The rotation angle cannot be identified.



The size cannot be identified.

### Size of the target

Make sure that the size of the target, when captured as an image, is 80 to 100 pixels in both vertical and horizontal directions. For example, when the camera's field of view is about 900 mm (8-mm lens; distance between camera and target is 2000 mm or so), prepare a target that is 120 to 160 mm in diameter.

### Mounting the target

Mount the target at the robot end of arm tooling. Make sure that the target does not get behind the robot arm or the tooling even when the robot moves in the camera's field of view.



#### CAUTION


Make sure that the target is fixed securely to the robot end of arm tooling so that it remains in place while the robot moves.

#### NOTE


- 1 Normally, the robot position and posture are set so that the range of robot motion becomes maximal when the robot actually operates. Therefore, mounting the target so that it can be captured by the camera when the robot is in a posture that it takes during operation makes it easier to secure the range of robot motion.
- 2 Positioning pins or other appropriate means may be used so that the target can be mounted at the same position for each measurement. This way, a robot program generated for a previous calibration operation can be used for re-calibration.

### 10.1.3.2 Preparing camera calibration tool

Visit the Vision Setup screen, and create a Robot-Generated Grid Calibration Tool and teach some parameters necessary prior to the execution. If you open the Robot-Generated Grid Calibration setup page, a page like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



#### Robot-Generated Grid Calibration Setup Page

Select the “Robot-Generated Grid Calibration” on the tree view. According to Subsection 5.2.1 “Camera Calibration Tools”, select a Camera Setup, teach Start Position, and make other necessary setups.

#### GPM Locator Tool Setup Page

Select the “GPM Locator Tool” on the tree view, and teach the model pattern. After moving the robot to the recorded start position, teach the model pattern by reference to Section 7.1 “GPM LOCATOR TOOL”. And then, verify the [Training Stability] of the model pattern to see if

[Good] is shown for [Location], [Orientation], and [Scale], respectively. If [None] is shown for any of these items, calibration cannot be performed properly. In that case, use a different shape of target mark.


By default, the range of [Angle] is set to be searched to  $\pm 30^\circ$  and the range of [Scale] is set to be searched to 95% to 120% and the range of [Aspect Ratio] is set to be searched to 90% to 100%. Usually, you don't have to change these parameters. Please adjust these parameters if necessary.

#### NOTE

When training the model pattern, the rectangle should not be unnecessarily larger than the area of the target mark. The robot moves the target mark keeping the trained rectangle within the search area. So the larger the trained rectangle is, the smaller the target mark displacement range is, therefore more likely to decrease the accuracy of the camera calibration.

### 10.1.3.3 Selecting calibration data

Visit the [Robot-Generated Grid Calibration] in the Vision Utility screen, and select the camera calibration data that you just created in [1 Calibration Data].




### 10.1.3.4 Measuring target position

Measures the position of the target mounted on the robot end of arm tooling.

## 6-axis robot

A 6-axis robot can measure the position of robot-mounted target mark by vision.



- 1 Verify whether the calibration data which is selected [1 Calibration Data] is proper.
- 2 Place the cursor on [2 Target Position].
- 3 Enable the teach pendant, and reset the alarm.
- 4 Press SHIFT + F5 RUN to start the measurement. Keep holding down SHIFT while the measurement is in progress.



- 5 When the measurement is complete, the robot stops and the message [Measurement is successfully finished.] appears on the screen.
- 6 Press F4 OK to return to the main menu.

If the last target position measurement was aborted before completion, the message [Are you sure to resume?] appears when you attempt to perform the target position measurement again. To resume the

measurement, press SHIFT + F4 RESUME. To restart the measurement from the beginning, press SHIFT + F5 RESTART.

### ⚠ CAUTION

If the camera calibration setup page is opened in the Vision Setup screen, Robot-Generated Grid Calibration cannot perform the measurement. Make sure that the setup page is closed. You can see the status of the measurement on the Vision Runtime screen.


### NOTE

When the field of view contains some area that the robot cannot reach, the robot sometimes cannot measure the target mark position by vision. In this case, you can set the target position by the same steps as a 4- or 5-axis robot.

## 4- or 5-axis robot

A 4- or 5-axis robot cannot use vision-based measuring. Train the position of the target mark manually.

- 1 Place the cursor on [2 Target Position], and press F3 POSITION to visit the target position menu.
- 2 Input X, Y and Z to the position of the target mark that relative to the robot mechanical interface frame (the robot wrist flange)..
- 3 Input W, P and R to zero.



### NOTE


The target position should correspond to the model origin trained in section 10.1.3.2, "Preparing Camera Calibration Tool". If the positions are different, the camera cannot be calibrated properly.

### 10.1.3.5 Generating calibration program

Measures the size of the camera's field of view, and generates a robot program for camera calibration.



- 1 Verify whether the calibration data which is selected [1 Calibration Data] is proper.
- 2 Verify whether [2 Target Position] is RECORDED.
- 3 Place the cursor on [3 Program Generation].
- 4 Enable the teach pendant, and reset the alarm.
- 5 Press SHIFT + F5 RUN to start the program generation. Keep holding down SHIFT while the measurement is in progress.



- 6 When the measurement is complete, the robot stops and the message [Measurement is successfully finished.] appears on the screen.
- 7 Press F4 OK to return to the main menu.

If the last program generation process was aborted before completion, the message [Are you sure to resume?] appears when you attempt to generate a program again. To resume the process, press SHIFT + F4 RESUME. To restart the process from the beginning, press SHIFT + F5 RESTART.



### CAUTION

If the camera calibration setup page is opened in the Vision Setup screen, Robot-Generated Grid Calibration cannot perform the measurement. Make sure that the setup page is closed. You can see the status of the measurement on the Vision Runtime screen.

## The way to limit the target displacement range

In order to avoid the interference with peripheral equipment, you can limit the target displacement range.

- 1 Open the camera calibration setup page and choose GPM Locator Tool in the tree view.
- 2 Shrink the search window and omit the area that the interference occurred.
- 3 Press F10 SAVE to save the camera calibration.
- 4 Press F5 END EDIT to close the setup page.
- 5 Visit the Robot-Generated Grid Calibration in Vision Utility, and generate a calibration program again.

## Calibration Program

The generated calibration program is like the one shown below. All the robot positions in the calibration program are taught in the joint format.

```

1: UFRAME_NUM=2
2: UTOOL_NUM=2
3:L P[1] 1000mm/sec FINE
4: VISION CAMREA_CALIB 'CALIB1' REQUEST=1
5:L P[1001] 1000mm/sec FINE
6: CALL IRVBKLSH(1)
7: VISION CAMERA_CALIB 'CALIB1' REQUEST=1001
8:L P[1002] 1000mm/sec FINE
9: CALL IRVBKLSH(1)
10: VISION CAMERA_CALIB 'CALIB1' REQUEST=1002

```

(Repeat as many times as the number of points)

```

293:L P[2048] 1000mm/sec FINE
294: CALL IRVBKLSH(1)
295: VISION CAMERA_CALIB 'CALIB1' REQUEST=2048
296:L P[2049] 1000mm/sec FINE
297: CALL IRVBKLSH(1)
298: VISION CAMERA_CALIB 'CALIB1' REQUEST=2049
299:L P[2] 1000mm/sec FINE
300: VISION CAMERA_CALIB 'CALIB1' REQUEST=2

```

The section of the program that finds an individual calibration program consists of the three lines shown below. This set of three lines is repeated in the middle of the calibration program above.

```

5:L P[1001] 1000mm/sec FINE
6: CALL IRVBKLSH(1)
7: VISION CAMERA_CALIB 'CALIB1' REQUEST=1001

```

Each command in the program is briefly explained below.

```
4: VISION CAMREA_CALIB 'CALIB1' REQUEST=1
```

If you specify 1 in the request code of the CAMERA\_CALIB command, all the calibration points in the specified camera calibration are deleted. This is the first command to be executed in the calibration program.

```
300: VISION CAMERA_CALIB 'CALIB1' REQUEST=2
```

If you specify 2 in the request code of the CAMERA\_CALIB command, camera calibration data is calculated using the found calibration points. This is the last command to be executed in the calibration program.

```
7: VISION CAMERA_CALIB 'CALIB1' REQUEST=1001
```

If you specify 1000 or a larger value in the request code of the CAMERA\_CALIB command, the program attempts to find a calibration point. The value specified in the request code is recorded as the index of the calibration point, along with the found position.

In an automatically generated calibration program, 1000 to 1999 represent the calibration points on calibration plane 1, and 2000 to 2999 the calibration points on calibration plane 2. Note also that the index of the position data of the preceding motion statement is the same as the request code that is passed to the CAMERA\_CALIB command.

Calibration points do not necessarily need to be found in the order of request codes. If a calibration point is found twice with the same request code, the data of the calibration point that is found first is overwritten by the data of the calibration point found later.

```
6: CALL IRVBKLSH(1)
```

If the KAREL program IRVBKLSH.PC is called, the robot performs an operation intended to remove the backlash effect at its current position. As the argument, specify the motion group number of the robot that performs the backlash removal operation.

### 10.1.3.6 Executing calibration program

Select the generated calibration program in the SELECT menu, and play it back from the first line to calibrate the camera.



#### **CAUTION**

If running the program as is can cause interference, use lower override values. In this case, execute the program while making sure that no interference occurs during operation.

Each calibration point in the generated calibration program can be re-taught or deleted as necessary.

If there is any calibration point that causes the robot to interfere with peripheral equipment, re-teach that point to move it to a position where it does not cause interference, or delete the calibration point. When



deleting a calibration point, delete not only the motion statement but also the lines of IRVBKLSH and the CAMERA\_CALIB command that are executed after the motion statement.

If there is any calibration point that hinders the robot operation because it is near singularity, re-teach that point to move it to a position where it can avoid singularity, or delete the calibration point. When deleting a calibration point, delete not only the motion statement but also the lines of IRVBKLSH and the CAMERA\_CALIB command that are executed after the motion statement.

When re-teaching a calibration point, you may place the target closer to or further away from the camera within a range in which the camera lens remains in focus.

 **CAUTION**

The calibration program does not stop even if the target fails to be found or it is found incorrectly during the program execution. After the program ends, open the robot-generated grid calibration setup page in the Vision Setup screen and check to see if there is any point incorrectly found.

**NOTE**

As long as the position where the target is mounted remains unchanged, you can re-calibrate the camera simply by executing the generated calibration program.

After executing the calibration program to the last, camera calibration is complete. Please verify the calibration points and the calibration results by reference to Subsection 5.2.2 “Checking Calibration Points” and Subsection 5.2.3 “Checking Calibration Data”.

## 10.2 GRID FRAME SETTING

---

The grid frame setting function sets the calibration grid frame using a camera. Compared with the manual touch-up setting method, the function offers a number of merits, including accurate setting of the frame without requiring user skills, no need for touch-up pointers or to set the TCP for touch-up setting, and semi-automatic easy-to-do operation.


In grid frame setting, the calibration grid is measured from multiple directions by using a camera and the measured calibration grid frame is set in the user frame area or tool frame area of the robot controller.

 **CAUTION**

The grid frame setting function is usable with 6-axis robots only. The function cannot be used with 4-axis robots and 5-axis robots.

## 10.2.1 Overview


In the grid frame setting function, the robot holding the camera or the robot holding calibration grid automatically moves to change relative position and orientation between the camera and the calibration grid, and find the grid pattern repeatedly. Finally, the position of the calibration grid frame relative to the robot base frame or the robot mechanical interface frame (the robot face place) is identified. When the grid frame setting function is executed, a frame is set on the calibration grid, as shown in the following figure.



During the measurement, detection results and measurement execution steps are displayed on the vision runtime display. When the measurement is successfully finished, the robot moves to such a position that the camera and calibration grid directly face each other and the origin of the calibration grid frame is seen at the center of the image.


### When the calibration grid is secured to a fixed surface

When the calibration grid is secured to fixed surface, a camera mounted on the robot end of arm tooling is used to measure the position of the calibration grid frame. The grid frame setting function identifies the position of the calibration grid frame relative to the robot base frame (world), and sets the results in a user specified user frame. When a robot mounted camera is used, the grid frame setting function can be performed with the camera. When a fixed camera is used, prepare a different camera, that is attached to the temporary position on the robot end of arm tooling, and perform the grid frame setting function.



### When the calibration grid is mounted on the robot

When the calibration grid is mounted on the robot, a fixed camera is used to measure the position of the calibration grid frame. The robot moves the calibration grid within the field of view of the fixed camera. The grid frame setting function identifies the position of the calibration grid frame relative to the robot mechanical interface frame (the robot face plate), and the results is written in a user defined user tool.




### Mounting of the calibration grid

When securing the calibration grid to a fixed surface, place the calibration grid at the position where the camera will be calibrated. When mounting the calibration grid on the robot, attach the calibration grid to the robot end of arm tooling. In either case, make sure that the calibration grid is fixed securely so that it does not move during measurement.

**NOTE**  
 To prevent unnecessary circles from being found, check that the calibration grid is free of dirt and flaws. Spreading a plain sheet in the background is effective. Also, make sure to cover the printed text on the calibration grid.

## 10.2.2 Setting the Parameters

If you select [Grid Frame Set] on the *iR*Vision utility menu, a menu like the one shown below appears.



**⚠ CAUTION**  
The Grid Frame Set menu cannot be opened in more than one window at a time.

### Robot Group Number to Use

Specify the group number of the robot to be used for measurement.

### Set UFrame or UTool?

Select the frame to be set with the grid frame setting function - user frame or user tool. To set the user tool with the calibration grid mounted on the robot, select F4 UTOOL. To set the user frame with the calibration grid secured to a table or other fixed surface, select F5 UFRAME.

### User Frame Number to set

Specify the number of the user frame to be set. This parameter is used only when [UFRAME] is selected for [Set UFrame or UTool?]. The range of specifiable user frame numbers is 1 to 9.

### Tool Frame Number to set

Specify the number of the user tool to be set. This parameter is used only when [UTOOL] is selected for [Set UFrame or UTool?]. The range of specifiable user tool numbers is 1 to 10.

### Camera User Tool Number


Specify the number of the user tool for the work space to be used during calculation. This parameter is used only when [UFRAME] is selected for [Set UFrame or UTool?]. The user tool you specify here will be rewritten during the measurement for grid frame setting. The range of specifiable user tool numbers is 1 to 10.

### Camera Name

Specify the name of the camera to be used for measurement. Place the cursor on the line of [Camera Name], press F4 CHOICE, and select a camera from the pull down menu. If camera setups have yet to be created, create a camera setup, as instructed in Chapter 4, "CAMERA SETUP", and select the name of the created camera setup.

### F2 DISP\_IMG

Pressing F2 DISP\_IMG provides a double-window display, with the vision runtime display (camera image) shown on the right side.



### F3 LIVE

Pressing F3 LIVE displays the live image of the selected camera on the vision runtime display, as the F3 label changes to [STOPLIVE]. If you press F3 STOPLIVE, the display of the live image is stopped and the F3 label returns to [LIVE].

### F4 FIND

Pressing F4 FIND detect the calibration grid for a trial. The found result is displayed on the vision runtime display.

### Exposure Time

Specify the exposure time for the camera to capture an image. Adjust the exposure time so that the black circles of the calibration grid are clearly visible.

### Grid Spacing

Set the grid spacing of the calibration grid in use.


### Start Position

Teach the position where measurement is to be started. To teach the start position, take the following steps:

- 1 Move the cursor to [Start Position].
- 2 Jog the robot so that the camera's optical axis is approximately perpendicular to the plate surface of the calibration grid and that all of the four large black circles of the calibration grid are inside the camera's field of view. The distance between the calibration grid and the camera should be appropriate for the grid to come into focus, which is, under normal circumstances, roughly the same as the distance at which camera calibration is performed.


#### NOTE

Grid Frame Setting measures the calibration grid with moving the robot on which the camera or the calibration grid is mounted. So be sure to set the camera field of view somewhat larger than the calibration grid so the four large circles of the calibration grid do not protrude out of the camera field of view.



- 3 Press SHIFT and F4 RECORD at the same time to record the start position. When the start position is recorded, the label changes to [Recorded].

To check the trained start position, press F3 POSITION. The value of each axis of the start position is displayed, as shown below. To return to the previous menu, press PREV.



To move the robot to the start position, press SHIFT and F5 MOVE TO at the same time.

## Operation range

During measurement, the robot automatically moves within the range specified by parameters. To prevent the robot from interfering with peripheral equipment, make sure that there is a sufficient operation space around the measurement area. When the default settings are used, the robot makes the following motions:

- Move  $\pm 100$  mm horizontally in the X, Y, and Z directions
- Rotate by  $\pm 45$  degrees around the camera's optical axis
- Rotate at  $\pm 30$ -degree inclination (WP) relative to the camera's optical axis at the robot start position
- Rotate at  $\pm 30$ -degree inclination (WP) relative to the camera's optical axis at the position where the camera directly faces the calibration grid


If the operation range defined by the default settings cannot be secured, you can make the operation range smaller by changing the parameters such as [R Angle Limit], [W Angle Limit], [P Angle Limit], and [Z Move Dist. Limit]. Note, however, that the precision of grid frame setting depends on the amount of motion at the time of measurement. A smaller operation range can lead to lower measurement precision. It is therefore recommended that measurements be made using a range as close to the default operation range as possible.

## Value initialization

If you press F7 DEFAULT, the set values are initialized. Note that [Camera Name] and [Start Position] are not initialized; set these parameters again individually.

## 10.2.3 Run Measurement


Pressing SHIFT and F5 EXECUTE at the same time starts measurement, causing the robot to start moving. During execution watch image displayed and verify that there are no improperly found calibration grid circles.



### CAUTION


- 1 Releasing SHIFT while measurement is in progress stops the measurement. In that case, perform the measurement again. You can resume the measurement from where stopped.
- 2 During measurement, if you perform any operation intended to move to another menu, such as pressing SELECT, the measurement is stopped. In that case, visit the Grid Frame Set menu again and perform the measurement again. You can resume the measurement from where stopped.
- 3 The robot usually performs operations within an expected range according to the parameter setting. However, the robot can make a motion beyond an expected range, depending on the parameter setting. When running the Grid Frame Set, check that the related parameters are set correctly and decrease the override to 30% or less to ensure that the robot does not interfere with peripheral equipments.
- 4 If another program is paused, the Grid Frame Set may not be able to move the robot. In that case, abort all the programs using the FUNC menu.

When the measurement is successfully completed, a menu like the one shown below appears. The robot stops after moving to a position where the camera directly faces the calibration grid and the origin of the calibration grid comes to the center of the image.



**NOTE**  
 You can confirm that the frame is set accurately with the following procedures. First, change the manual-feed coordinate system to the measured frame. When you set a user tool with Grid Frame Setting, change the manual-feed coordinate system to the user tool. When you set a user frame, change the manual-feed coordinate system to the user frame, and then select the user tool selected as “Camera User Tool Number” in the Section 10.2.2. Next, start the live image display and jog the robot around the X-, Y- and Z-axes. If the frame is set accurately, the center grid of the grid pattern will keep appearing at the center of the image.

If the measurement fails, a menu like the one shown below appears. In that case, press F4 OK to return to the previous menu. Then, change the parameters as appropriate and perform the measurement again. After changing the parameters, pressing SHIFT and F5 RUN at the same time starts the measurement again from the beginning.





## 10.2.4 Troubleshooting

---

If the Grid Frame Set does not operate as expected, first check the information provided here.

### **[CVIS-020 Big circles cannot be distinguished] is issued.**

This alarm is posted when the four large black circles of the calibration grid could not be detected. Detection of large black circles failed because of an improper exposure time, or an object other than a grid point was detected. The Vision Runtime screen shows the image when a measurement failed. Check the image and adjust the snapping condition. When some of the large circles are not seen in the camera field of view, try the followings:

- Use a smaller grid pattern
- Use a lens with smaller focal length
- Lengthen the distance between the camera and the grid pattern so that the grid pattern is seen smaller in the image
- Rotate the camera or the grid pattern so that the X axis of the grid pattern does not point below in the image

### **[CVIS-015 Too few calibration points] is issued.**

This alarm is posted when the number of grid points of the calibration grid detected during measurement is less than 4. Check whether the grid points are contained in the camera's visual field when the robot is placed at the measurement start position, whether the exposure time is proper, and whether the camera port number is correct. This alarm is posted also if a measurement is made when the camera is disabled for hardware trouble.

### **The program was terminated abnormally with an error.**

If an error occurs, the program is terminated forcibly. Modify the setting to enable correct measurement then execute the program from the beginning.

## 10.3 VISION LOG MENU

The vision log menu allows you to perform the following operations for the *iR*Vision log data:

### Export

Convert the vision log data stored in the robot controller to a text format and output the converted data to a specified external device.


### Import

Convert the exported vision log data to the binary format and read the converted data into the robot controller.

### Delete

Delete the vision log data stored in the robot controller.


If you select [Vision Log Menu] on the *iR*Vision Utility menu, a menu like the one shown below appears.



### 10.3.1 Setting the Device

By default, UD1:\VISION\EXLOG\ is set as the external device. You can change the external device path name by taking the following steps:

- 1 On the vision log menu, press [NEXT→] and then F4 DEVICE. A menu like the one shown below appears.



- 2 In [Device], enter a text string that represents the path name of the external device.
- 3 To save the path name of the external device, press F3 OK.  
To quit changing the external device path name, press F5 CANCEL.

If the specified path does not exist on the external device, the message [xxx will be made, OK?] appears. Pressing F4 YES creates a directory with the specified path name on the external device.


#### **⚠ CAUTION**

- 1 An external device that you can specify is a memory card, USB memory device of the controller, or PC share client.
- 2 Set up a necessary device as appropriate for the export device setting. Under the default setting, for example, you need to insert a USB memory device into the robot controller.

## **10.3.2 Exporting Vision Log of a Specified Date**

To export one day worth of vision log stored in the robot controller to the external device, take the following steps:

- 1 Place the cursor on the date of the vision log you want to export.
- 2 Press F3 EXPORT to start the export of the vision log. During the export, a menu like the one shown below stays displayed.



- 3 When the export is complete, the message [Log export succeeded.] appears.

If the external device contains any vision log of the same date, the message [xxx will be overwritten, OK?] appears. If you press F4 YES, the vision log of that date is deleted from the external device before the export begins. If you press F5 NO, the export is canceled.

To cancel the export, press F5 CANCEL. Pressing F5 CANCEL displays the prompt [Operation will be cancelled, OK?]. If you press F4 YES, the export is canceled. If you press F5 NO, the export is continued.

### 10.3.3 Exporting Vision Logs of All Dates

To export all vision log data stored in the robot controller, take the following steps:

- 1 Press [NEXT] and then F2 ALL EXP. The export begins.
- 2 When the export completes, the message [All log export succeeded.] appears.

If the external device contains any vision log of the same date, the message [xxx will be overwritten, OK?] appears for each date in question. If you press F4 YES, the vision log of that date is deleted from the external device before the export begins. If you press F5 NO, the export is canceled.

To cancel the export, press F5 CANCEL. Pressing F5 CANCEL displays the prompt [Operation will be cancelled, OK?]. If you press F4 YES, the export is canceled. If you press F5 NO, the export is continued.

### 10.3.4 Deleting a Vision Log of a Specified Date

To delete one day worth of vision log on the robot controller, take the following steps:

- 1 Place the cursor on the date of the vision log you want to delete.
- 2 Press F4 DELETE.
- 3 The prompt [Log xxxx will be deleted, OK ?] appears. If you press F4 YES, the vision log of the selected date is deleted. If you press F5 NO, the deletion operation is canceled.
- 4 When the deletion operation is complete, the message [Log deletion succeeded.] appears.

To cancel the ongoing deletion operation, press F5 CANCEL. The prompt [Operation will be cancelled, OK?] appears. If you press F4 YES, the deletion operation is canceled. If you press F5 NO, the deletion operation is resumed.

### 10.3.5 Deleting Vision Logs of All Dates

To delete all vision logs stored in the robot controller, take the following steps:


- 1 Press [NEXT] and then F3 ALL DEL.
- 2 The message [All logs will be deleted, OK?] appears. If you press F4 YES, the deleting all vision logs is started. If you press F5 NO, the deletion operation is canceled.
- 3 When all vision logs have been deleted successfully, the message [All log deletion succeeded.] appears.

To cancel the ongoing deletion operation, press F5 CANCEL. Pressing F5 CANCEL displays the prompt [Operation will be cancelled, OK?]. If you press F4 YES, the deletion operation is canceled. If you press F5 NO, the deletion operation is resumed.

### 10.3.6 Importing a Vision Log of a Specified Date

To import one day worth of vision log exported to the external device, take the following steps:

- 1 Press F2 IMP/EXP. A vision log import menu like the one shown below appears.



#### CAUTION

This menu does not appear if the specified external device does not contain any vision log.

- 2 Place the cursor on the date of the vision log you want to import.
- 3 Press F3 IMPORT. The import begins.
- 4 When the import is complete, the message [Log import succeeded.] appears.

If the controller contains any vision log of the same date, the message [xxx will be overwritten, OK?] appears. If you press F4 YES, the vision log of that date stored in the controller is deleted before the import begins. If you press F5 NO, the import is canceled.

To cancel the import, press F5 CANCEL. The prompt [Operation will be cancelled, OK?] appears. If you press F4 YES, the import is canceled. If you press F5 NO, the import is continued.

### 10.3.7 Refreshing the Display

---

Pressing F5 REFRESH refreshes the list of vision logs so as to show the latest information.

### 10.3.8 File Configuration of the Exported Vision Log

---

By default, when a vision log is exported, a sub-folder named the export date is created under the specified external device path, for instance:

UD1:\VISION\EXLOG\Y12APR10\ ...Vision log for April 10, 2012

Under the sub-folder for the sub-folder of each day, three types of files are saved.

.VL      Logged data file  
.PNG     Logged image file

**CAUTION**


If the directory structure of exported vision log files and logged image files is changed, or if any of these exported files is renamed, the correspondence between vision logs and logged images is lost, making it impossible to identify logged images with dates. When you copy or move an exported vision log or logged image, do not change the directory structure or file name.

# 11 CALIBRATION GRID

This chapter provides information about a calibration grid used for *iRVision* camera calibration.

## 11.1 CALIBRATION GRID

*iRVision* performs camera calibration by using a calibration grid on which a predetermined pattern is drawn. When a grid as shown below is viewed through the camera, *iRVision* will automatically recognize the positional relationship between the calibration grid and the camera, lens distortion, focal distance, etc.



All of the black circles are arranged so that they are uniformly spaced horizontally and perpendicularly. Four larger black circles placed in the vicinity of the center indicate the origin and directions of a coordinate system as shown. The ratio of the diameter of a large circle to that of a small circle is about 10:6.

The grid points at the center and the four corners contain a white circle with a diameter of 1 mm. These white circles are used when a coordinate system is set up by touching up them with the TCP of the robot.

## 11.2 CALIBRATION GRID FRAME

The calibration grid might be secured to a table or another place or mounted on the robot end of arm tooling according to the applications. In either case, when camera calibration is performed, it is necessary to set information about the installation position of the calibration grid as viewed from the robot. That information is called the *calibration grid frame*. This section describes how to teach the calibration grid frame.

When the calibration grid is mounted to a fixed surface, the position of the calibration grid frame relative to the robot base frame should be set in the user frame area. On the other hand, when the calibration grid is mounted on a robot, the position of the calibration grid frame relative to the robot mechanical interface frame (robot face plate) should be set in the user tool area.

Two methods of setting the calibration grid frame are available: With one method, the calibration grid frame is set by physically teaching the calibration grid with a pointer attached on the robot end of the arm



tooling. With the other method, the calibration grid frame is set by measuring the grid pattern with a camera without contact. In the following subsections, these two methods are explained.

### 11.2.1 Setting Based on Touch-up

This section explains how to set the calibration grid frame with the legacy method, namely physically touching-up the calibration grid with a pointer mounted on a robot end of the arm tooling.

#### When the calibration grid is secured to a fixed surface

When the calibration grid is installed in a fixed place, the position of the calibration grid frame relative to the robot base frame should be set in the user frame area. After a pointer for touch-up is mounted on the robot end of the arm tooling and TCP is set to the tip of the pointer, select [User Frame Setup / Four Points], and teach the four points shown in the figure below by touch-up operation with the TCP of the robot.







### When the calibration grid is mounted on the robot end of arm tooling

When the calibration grid is mounted on the robot end of arm tooling, the position of the calibration grid frame relative to the robot mechanical interface frame (robot face plate) should be set in the user tool area. After the pointer for touch-up is secured to a secured table, select [Tool Frame Setup / Six Point(XY)] or [Tool Frame Setup / Six Point(XZ)], and teach the six points shown in the figure below by touch-up operation.

The user tool set using the [Tool Frame Setup / Six Point(XZ)] method is rotated by 90 degrees about the X-axis with respect to a desired coordinate system. Upon completion of setting the user tool frame by touch-up operation, **manually enter the value of W plus 90**. The three approach points must have different robot poses. Ideally two of the approach points are close to 180 degrees from each other rotated about tool Z.



## 11.2.2 Setting Based on Measurement with a Camera

Please refer the Grid Frame Setting function described in Section 10.2, “Grid Frame Setting”.

# 12 OTHER OPTIONS

---

This chapter describes other software options, which occasionally used with *iR*Vision.

## 12.1 VISION SUPPORT TOOLS

---

Vision Support Tools are software option consisting of a set of tools intended to support a vision-based robot system. Using these tools, you can have the KAREL programs installed to the controller and run those programs by means of the relevant call commands.

### Offset calculation

Special offset calculation mechanisms are provided that cannot be supported by the standard functions.

OFS\_RJ3, MATRIX, INVERSE, MERGE3D2, STVS1 and GETCROSS

### Saving and restoration of position register data

Functions to store and restore 1000 position registers' worth of data are provided.

SAVENOM and LOADNOM

### Offset adjustment

A function is provided that allows the offset error to be adjusted with ease.

ADJ\_OFS

### Sorting of found results

A function is provided that sorts found results.

SORT\_RJ3

### Offset position checking

A function is provided that checks whether the offset position is within the valid range of robot motion.

CHK\_POS

### Vision Log

Functions are provided that change the vision log folder and delete old vision logs.

VL\_EXPORT

### Restrictions

- These functions are included in the vision support tool option.
- To use these functions, be sure to set the system variable \$KAREL\_ENB to 1.
- The position register formats that you can specify for these tools are the XYZWPR format, matrix format, XYZWPR format with an additional axis, and matrix format with an additional axis. Position registers of the joint format are not supported. If the specified position register is of the joint format, an error occurs.
- If the position register specified by any of these tools has not been initialized (the value in the position register is \*\*\*\*\*), an error occurs.

### Behavior at the time of an error

All the KAREL programs have an argument that specifies “the register number to store the error number”. This argument can be omitted in most of the KAREL programs. How a KAREL program behaves if an

error occurs during the execution of the program differs depending on whether “the register number to store the error number” is specified or not.

When “the register number to store the error number” is specified, 0 is stored in the specified register if the program ends normally. If an error occurs, the corresponding error code is stored in the specified register and an error message appears in the upper part of the teach pendant screen.

If an error occurs when “the register number to store the error number” is omitted, the program is forced to end and the user screen displays a message describing the error. Note that this argument cannot be omitted in CHK\_POS and STVS1.

## 12.1.1 OFS\_RJ3

This program calculates offset data based on the found position and reference position stored in position registers. The robot can perform offset operations using the offset data calculated by OFS\_RJ3. Since iRVision normally calculates offset data within the vision process, it is not necessary to use OFS\_RJ3. Use this program when you need any offset mode that is not supported by vision processes.



### CAUTION

This KAREL program supports only the motion group 1.

#### Argument 1: Register number (Input)

Specify the number of the register storing a flag that indicates whether to set the reference position. When 1 is set in the specified register, the found position will be set as the reference position in the position register specified by argument 4. When 0 is set, the reference position will not be set.

#### Argument 2: Position register number (Input)

Specify the number of the position register storing the found position of the first camera.

#### Argument 3: Position register number (Input)

Specify the number of the position register storing the found position of the second camera.

#### Argument 4: Position register number (Input/Output)

Specify the number of the position register that currently stores the reference position or that will store the reference position.

#### Argument 5: Position register number (Output)

Specify the number of the position register to store the calculated fixed frame offset data of the sensor A format.

#### Argument 6: Position register number (Output)

Specify the number of the position register to store the calculated fixed frame offset data of the sensor B format.

#### Argument 7: Position register number (Output)

Specify the number of the position register to store the calculated tool offset data.

#### Argument 8: Register number (Output)

Specify the number of the position register to store the error number. This argument can be omitted.

In the register to store the error number, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally.
- 501: A required argument is not specified.
- 502: An invalid argument is specified.
- 503: The nominal flag is invalid.
- 504: Data cannot be written to the specified register.
- 505: The format of the specified position register failed to be acquired.
- 506: The format of the specified position register is invalid.
- 507: The specified position register cannot be read.
- 508: The specified position register has not been initialized.
- 509: Offset data failed to be calculated (the two points are too close to each other).
- 510: Data cannot be written to the specified position register.

### Usage example 1

This is an example where one camera is used to find a workpiece and fixed frame offsetting is performed for the robot according to the calculated offset data of the sensor A type.

```
11: CALL OFS_RJ3(P1,P2,0,P4,P5,0,0)
12: L P[1] 1000mm/sec FINE OFFSET,PR[P5]
```

### Usage example 2

This is an example where one camera is used to find a workpiece and fixed frame offsetting is performed for the robot according to the calculated offset data of the sensor B type (the offset data of the sensor A type is referenced). Since fixed frame offsetting is performed using the sensor B format, the format of the position register used for the fixed frame offset command is converted to the matrix format, by copying the offset data to the user frame and then copying it back to the position register.

```
11: CALL OFS_RJ3(P1,P2,0,P4,P5,P6,0)
12: UFRAME[9]=PR[P6]
13: PR[n]=UFRAME[9]
14: L P[1] 1000mm/sec FINE OFFSET,PR [n]
```

### Usage example 3

This is an example where one camera is used to find a workpiece and fixed frame offsetting is performed for the robot according to the offset data of the sensor B type (the offset data of the sensor A type is not referenced). Since fixed frame offsetting is performed using the sensor B format, the format of the position register used for the fixed frame offset command is converted to the matrix format, by copying the offset data to the user frame and then copying it back to the position register.

```
11: CALL OFS_RJ3(P1,P2,0,P4,0,P6,0)
12: UFRAME [9]=PR[P6]
13: PR[n]= UFRAME [9]
14: L P[1] 1000mm/sec FINE OFFSET,PR[n]
```

### Usage example 4

This is an example where one camera is used to find a workpiece and tool offsetting is performed for the robot.

```
11: CALL OFS_RJ3(P1,P2,0,P4,0,0,P7)
12: L P[1] 1000mm/sec FINE TOOL_OFFSET,PR[P7]
```

### Usage example 5

This is an example where two cameras are used to find one workpiece, or one hand camera is used to find two positions on one workpiece, to perform fixed frame offsetting for the robot (offset data of the sensor A type). The two found positions are merged to generate one set of position data. Found positions that can be input are the 2D data of X, Y, and R. The merged position data are also the 2D data of X, Y, and R. X, Y, and R in the merged position data represent an intermediate point between the two positions. To generate 3D data, use MERGE3D2.

```
11: CALL OFS_RJ3(P1,P2,P3,P4,P5,0,0)
12: L PR[1] 1000mm/sec FINE OFFSET,PR[P5]
```

### Usage example 6

This is an example where two cameras are used to find one workpiece, or one hand camera is used to find two positions on one workpiece, to perform fixed frame offsetting for the robot (offset data of the sensor B type). The two found positions are merged to generate one set of position data. Found positions that can be input are the 2D data of X, Y, and R. The merged position data are also the 2D data of X, Y, and R. X, Y, and R in the merged position data represent an intermediate point between the two positions. To generate 3D data, use MERGE3D2.

```
11: CALL OFS_RJ3(P1,P2,P3,P4,0,P6,0)
12: UFRAME[9]=PR[P6]
13: PR[n]=UFRAME[9]
14: L P[1] 1000mm/sec FINE OFFSET,PR[n]
```

### Usage example 7

This is an example where two cameras are used to find one workpiece, or one hand camera is used to find two positions on one workpiece, to perform tool offsetting for the robot. The two found positions are merged to generate one set of position data. Found positions that can be input are the 2D data of X, Y, and R. The merged position data are also the 2D data of X, Y, and R. X, Y, and R in the merged position data represent an intermediate point between the two positions. To generate 3D data, use MERGE3D2.

```
11: CALL OFS_RJ3(P1,P2,P3,P4,0,0,P7)
12: L P[1] 1000mm/sec FINE TOOL_OFFSET,PR[P7]
```

## 12.1.2 MATRIX

This program regards the position register values given in the XYZWPR or matrix format as a homogeneous transform matrix and calculates the product of that matrix. When the input matrixes are A and B and the output matrix is C, the program calculates the equation  $C = AB$ .



#### CAUTION

This KAREL program supports only the motion group 1.

#### Argument 1:Position register number (Input)

Specify the number of the position register storing input matrix A.

#### Argument 2:Position register number (Input)

Specify the number of the position register storing input matrix B.

#### Argument 3:Position register number (Output)

Specify the number of the position register storing input matrix C.

**Argument 4: Register number (Output)**

Specify the number of the position register to store the error number. This argument can be omitted.

In the register to store the error number, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally.
- 301: A required argument is not specified.
- 302: An invalid argument is specified.
- 303: An invalid argument is specified.
- 304: Data cannot be written to the specified register.
- 305: The format of the specified position register failed to be acquired.
- 306: The format of the specified position register is invalid.
- 307: The specified position register cannot be read.
- 308: The specified position register has not been initialized.
- 309: Data cannot be written to the specified position register.

**Usage example 1**

This is an example where the user frame is shifted using 2D offset data. The robot motion can be offset without adding the fixed frame offset command to the motion command.

```

1: VISION RUN_FIND VISION1
2: VISION GET_OFFSET VISION1 VR[1] JUMP,LBL[99]
3: PR[20]=VR[1].OFFSET
4: PR[30]=UFRAME[2]
5: CALL MATRIX(20,30,40)
6: UFRAME[3]=PR[40]
7:
8: UFRAME_NUM=3
9: UTOOL_NUM=1
10: L P[1] 100mm/sec FINE
11: L P[2] 100mm/sec FINE
12: L P[3] 100mm/sec FINE

```

Line 3 The offset data of the sensor B type is calculated in position register [20].

Line 5 The shifted user frame is calculated in position register [40].

Line 10 Since user frame No. 3 itself is shifted, the vision offset is applied to the operation.

**Usage example 2**

This is an example where the reference position is calculated back from the offset data and found position stored in the vision register. In this example, the reference position is stored in position register [1].

```

1: VISION RUN_FIND VISION1
2: VISION GET_OFFSET VISION1 VR[1] JUMP,LBL[99]
3: PR[1]=VR[1].FOUND_POS[1]
4: PR [2]=VR[1].OFFSET
5: CALL INVERSE(2,2)
6: CALL MATRIX(2,1,1)

```

**Usage example 3**

This is an example where the offset robot position is calculated.

It is assumed that the robot moves to the position that is offset by the following motion command:

```
L P[10] 500mm/sec FINE VOFFSET,VR[1];
```

```

1: VISION RUN_FIND VISION1
2: VISION GET_OFFSET VISION1 VR[1] JUMP,LBL[99]
3: PR[21]=VR[1].OFFSET
4: PR[20]=P[10]
5: CALL MATRIX(21,20,22)

```

Line 4: The position of P[10] and the offset data of the vision register are copied to the position register.

Line 5: Multiply the position with the offset data. The offset position is stored in position register [22].

### 12.1.3 INVERSE

This program regards the position register values given in the XYZWPR or matrix format as a homogeneous transform matrix and calculates the inverse matrix of the input matrix. When the input matrix is A and the output matrix is B, the program calculates the equation  $B=A^{-1}$ .



#### CAUTION

This KAREL program supports only the motion group 1.

#### Argument 1:Position register number (Input)

Specify the number of the position register storing input matrix A.

#### Argument 2:Position register number (Output)

Specify the number of the position register storing output matrix B.

#### Argument 3:Register number (Output)

Specify the number of the position register to store the error number. This argument can be omitted.

In the register to store the error number, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally.
- 201: A required argument is not specified.
- 202: An invalid argument is specified.
- 203: An invalid argument is specified.
- 204: The format of the specified position register failed to be acquired.
- 205: The format of the specified position register is invalid.
- 206: The specified position register cannot be read.
- 207: The specified position register has not been initialized.
- 208: Data cannot be written to the specified position register.
- 209: Data cannot be written to the specified register.

#### Usage example 1

This is an example where the matrix format of a position register is converted to the XYZWPR format. Executing INVERSE twice, as shown below, converts the matrix format of position register No. 1 to the XYZWPR format.

```

11: CALL INVERSE(1, 2)
12: CALL INVERSE(2, 1)

```

## 12.1.4 MERGE3D2

This program conducts 3D measurements at two or three positions on one workpiece and merges the results of those measurements to calculate the position and orientation of the entire workpiece. OFS\_RJ3 generates 2D data, while MERGE3D2 generates 3D data.



### CAUTION

This KAREL program supports only the motion group 1.

#### Argument 1:Position register number (Input)

Specify the number of the position register storing 3D measurement results.

#### Argument 2:Position register number (Input)

Specify the number of the position register storing 3D measurement results.

#### Argument 3:Position register number (Input)

Specify the number of the position register storing 3D measurement results.

#### Argument 4:Position register number (Input)

Specify the number of the position register storing 3D measurement results.

#### Argument 5:Position register number (Output)

Specify the number of the position register to store generated 3D position data.

#### Argument 6:Register number (Input)

Specify the number of the position register storing the heights of the first and second points. This argument can be omitted. Note that argument 6 is required when argument 7 is specified.

#### Argument 7:Register number (Output)

Specify the number of the position register to store the error number. This argument can be omitted.

For information about how to specify arguments 1 to 4, see usage examples 1 to 3.

When the first point is measured as a 3D position and the second point is measured as a 3D gaze line (see usage example 3 below), the second point must normally be on the same plane (same height) as point 1. Otherwise, specify a register number in argument 6 and set the height difference between points 1 and 2 in that register.

In the register to store the error number, one of the values shown below will be set depending on the error that occurs:


- 0: The program ended normally.
- 401: A required argument is not specified.
- 402: An invalid argument is specified.
- 403: The plane is parallel to the line.
- 404: The two points are too close to each other.
- 405: The two points are too far away from the plane.
- 406: The combination of arguments is invalid.
- 407: Data cannot be written to the specified register.
- 408: The format of the specified position register failed to be acquired.
- 409: The format of the specified position register is invalid.
- 410: The specified position register cannot be read.



- 411: The specified position register has not been initialized.  
 412: Data cannot be written to the specified position register.  
 413: The specified register cannot be read.

### Usage example 1

This is an example where the 3D position of the entire work is calculated from three 3D positions.




The example calculates a coordinate system in which the first, second, and third points are determined as the origin, an X direction point, and an XY plane point, respectively.

```
11: CALL MERGE3D2(P1, P2, P3, 0, P5)
```

### Usage example 2

This is an example where a coordinate system is calculated from two 3D position/posture values.




The example calculates a coordinate system in which the first point is determined as the origin, the direction connecting the first and second points is determined as the X axis, and the plane including the normal line of the first point and the just mentioned X axis is determined as the XY plane point. The second point determines the phase along the Z axis. This is effective for a large panel or other type of workpiece that has a severe phase requirement for the Z axis.

```
11: CALL MERGE3D2(P1, P2, 0, 0, P5)
```

### Usage example 3

This is an example where a coordinate system is calculated from one 3D position/posture value and one 3D gaze line.



Of the two points, the one that gives the 3D position/posture value is the first point, and the point where the XY plane of the first point intersects the 3D gaze line is internally regarded as the second point. The example calculates a coordinate system in which the first point is determined as the origin, the normal line of the first point is determined as the Z axis, and the second point is determined as the XY plane point. The second point determines the phase along the Z axis. This is effective for a large panel or other type of workpiece that has a severe phase requirement for the Z axis. Although it is similar to usage example 2, the method shown in usage example 3 is used in cases where 3D position/posture measurement cannot be done for the second point.

```
11: CALL MERGE3D2(P1, 0, 0, P4, P5)
```

#### ⚠ CAUTION

In case of calculating a coordinate system from two position data, if one point is on the normal line of another point, calculation cannot be done, and an error occurs.

## 12.1.5 LOADNOM and SAVENOM

If the free space of a position register is insufficient, the data in that position register can be saved. The total number of position registers that can be saved is 1470 - 30 position registers multiplied by 49 tables. Register data is saved and restored on a table-by-table basis.

#### ⚠ CAUTION

This KAREL program supports only the motion group 1.

### SAVENOM

This program saves position register data.

#### Argument 1: Table number (Input)

Specify the number of the table to which to save data. The specifiable value range is 1 to 49.

#### Argument 2: Number of position registers (Input)

Specify the number of position registers to save. The specifiable value range is 1 to 30.

**Argument 3:Position register number (Input)**

Specify the number of the first position register to save.

**Argument 4:Register number (Output)**

Specify the number of the position register to store the error number. This argument can be omitted.

In the register to store the error number, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally.
- 701: A required argument is not specified.
- 702: An invalid argument is specified.
- 703: An invalid argument is specified.
- 704: The format of the specified position register failed to be acquired.
- 705: The format of the specified position register is invalid.
- 706: The specified position register cannot be read.
- 707: The specified position register has not been initialized.
- 708: Data cannot be written to the specified register.

**LOADNOM**

This program restores saved data to one or more position registers.

**Argument 1: Table number (Input)**

Specify the number of the table whose data is to be restored. The specifiable value range is 1 to 49.

**Argument 2: Number of position registers (Input)**

Specify the number of position registers to which to restore saved data. The specifiable value range is 1 to 30.

**Argument 3:Position register number (Input)**

Specify the number of the first position register to which to restore saved data.

**Argument 4:Register number (Output)**

Specify the number of the position register to store the error number. This argument can be omitted.

In the register to store the error number, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally.
- 601: A required argument is not specified.
- 602: An invalid argument is specified.
- 603: An invalid argument is specified.
- 604: Data cannot be written to the specified position register.
- 605: Data cannot be written to the specified register.
- 606: The format of the specified position register failed to be acquired.
- 607: The format of the specified position register is invalid.
- 608: The specified table does not have any saved data.

**Usage example 1**

This is an example where the data of 10 position registers, [31] to [40], is saved to table 1 and then restored.

```

3:  CALL SAVENOM(1,10,31)
   :
27: CALL LOADNOM(1,10,31)

```

## Backup of the variable

The saved data is stored in the KAREL variable defined in the KAREL program SAVENOM. If you choose to save all files on the file screen, the saved data is saved in a file named SAVENOM.VR.

## 12.1.6 ADJ\_OFS

When a system performs 2D compensation, there may be cases where the system accomplishes fixed frame offsetting properly if the workpiece only moves horizontally without rotating, whereas an invalid fixed frame offset result is obtained if the workpiece rotates. The reason for this is that the coordinate system that the vision process recognizes through camera calibration does not match the user frame of the robot. To solve this problem:

- 1 After resetting the touch-up pin TCP for setting the coordinate system, reset the user frame, camera calibration, and reference position, and re-teach the robot position.
- 2 If the fixed frame offset result is still invalid, perform vision mastering for the robot and then take step 1.

This procedure may not be viable.

In that case, using ADJ\_OFS can improve the situation.



### CAUTION

This KAREL program supports only the motion group 1 when the position register is specified as the type of the register storing offset data.

### Argument 1: Type of the register storing offset data (Input)

Specify the type of register. Set 1 for a vision register and 2 for a position register.

### Argument 2: Vision register or position register number (Input)

Specify the number of the vision register or position register storing offset data.

### Argument 3: Position register number (Input)

Specify the number of the position register storing the amount of adjustment.

### Argument 4: Vision register or position register number (Output)

Specify the number of the vision register or position register to store adjusted offset data.

### Argument 5: Register number (Output)

Specify the number of the position register to store the error number. This argument can be omitted.

You can specify the same number in arguments 2 and 4.

If the register storing offset data is a position register, namely if 2 is set in argument 1, the format of the position register specified in argument 4 is automatically converted to the XYZWPR format.

In the register to store the error number, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally.

- 101: A required argument is not specified.
- 102: An invalid argument is specified.
- 103: The specified register type is invalid.
- 104: Data cannot be written to the specified register.
- 107: The format of the specified position register failed to be acquired.
- 108: The format of the specified position register is invalid.
- 109: The specified position register cannot be read.
- 110: The specified position register has not been initialized.
- 111: Data cannot be written to the specified position register.
- 112: The specified vision register cannot be read.
- 113: Data cannot be written to the specified vision register.

### Usage example 1

This is an example where the offset data stored in vision register [1] is adjusted using the amount of adjustment stored in position register [11] and the adjusted offset data is output to vision register [2]. The adjusted offset data stored in vision register [2] is used to offset the robot position. If an error occurs, the program jumps to label [99].

```
11: CALL ADJ_OFS(1, 1, 11, 2, 3)
12: IF R[3]<>0, JUMP,LBL[99]
13: L P[1] 100mm/sec FINE VOFFSET,VR[2]
```

### Setting of the amount of adjustment

Set the amount of adjustment as follows:

- 1 Set XYZWPR=(0, 0, 0, 0, 0, 0) in the position register that stores the amount of adjustment.
- 2 Place the workpiece in the camera's field of view at the same angle as when the reference position was set, and then run the program.
- 3 Touch up the workpiece using the robot.
- 4 If the position is invalid, subtract the offset value and re-teach the position.
- 5 Replace the workpiece by rotating it by 180 degrees, and then run the program.
- 6 Touch up the workpiece again using the robot.
- 7 If the touched up position is 10 mm off the expected position in the X direction, set half of 10 mm - 5 mm - in X of the position register that stores the amount of adjustment.
- 8 Set Y in the same way.

Repeating steps 5 to 8 determines the amount of adjustment.

#### NOTE

Specify the amount of adjustment relative to the offset frame.

## 12.1.7 SORT\_RJ3

This program sorts a position register storing found results of a vision process according to a specified sorting method. There are 13 specifiable sorting methods, as described later.



#### CAUTION

This KAREL program supports only the motion group 1.

#### Argument 1: Sorting method (Input)

Specify the sorting method. The specifiable value range is 1 to 4, 11 to 18, and 21.

**Argument 2: Register number (Input)**

Specify the number of the register storing the number of found results to be sorted.

**Argument 3: Start number of the position register to sort (Input)**

Specify the start number of the position register storing the found results to be sorted.

**Argument 4: X-direction diameter or width of the workpiece (Input)**

Specify the X-direction diameter or width of the workpiece in mm. This argument is required when the value set in argument 1 is 11 to 14. Otherwise, specify 0.

**Argument 5: Y-direction diameter or width of the workpiece (Input)**

Specify the Y-direction diameter or width of the workpiece in mm. This argument is required when the value set in argument 1 is 15 to 18. Otherwise, specify 0.

**Argument 6: Position register number (Input)**

Specify the number of the position register storing the specified position when the value set in argument 1 is 21. Sorting begins with the workpiece that is closest to this point. When the value set in argument 1 is not 21, specify 0.

**Argument 7: Flag (Input)**

Specify the flag that indicates whether to sort a register. If you set 1 in the flag specified here, when a position register is sorted, the register having the same number is sorted as well. Use this argument in such cases as when you want to sort the model IDs stored in a register in addition to position data. The argument can be omitted. Note that argument 7 is required when argument 8 is specified. If you set the number except 0 or 1, Illegal parameter input alarm is generated.

**Argument 8: Register number (Output)**

Specify the number of the position register to store the error number. This argument can be omitted.


In the register to store the error number, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally.
- 1201: A required argument is not specified.
- 1202: An invalid argument is specified.
- 1203: The register storing the number cannot be read.
- 1204: The format of the register storing the number is invalid.
- 1205: The number is 0.
- 1206: The register storing the start number cannot be read.
- 1207: The format of the specified position register failed to be acquired.
- 1208: The format of the specified position register is invalid.
- 1209: The specified position register cannot be read.
- 1210: Data cannot be written to the specified position register.
- 1211: The format of an argument is invalid.
- 1212: The format of an argument is invalid.
- 1213: The value of the argument must be 0.
- 1214: The value set in the specified register must be 0.
- 1215: The value set in the argument must be greater than 0.
- 1216: The value set in the argument must be greater than 0.
- 1217: The value set in the argument must be greater than 0.
- 1218: There is an invalid argument.
- 1219: The format of the specified position register failed to be acquired.

- 1220: The format of the specified position register is invalid.  
 1221: The specified position register cannot be read.  
 1224: The specified position register has not been initialized.


In argument 1, specify one of the values shown below that corresponds to the desired sorting method.

- 1 The position register is sorted, beginning with the workpiece whose X value is the largest.
- 2 The position register is sorted, beginning with the workpiece whose X value is the smallest.
- 3 The position register is sorted, beginning with the workpiece whose Y value is the largest.
- 4 The position register is sorted, beginning with the workpiece whose Y value is the smallest.




From 11 to 18


Use these values when you want to have orderly aligned workpieces picked up sequentially, as shown below. A total of eight different pick-up methods are defined, each corresponding to a distinct pick-up order.



To pick up workpieces on a line-by-line (column-by-column) basis, a workpiece is first selected whose position data X (Y) is the smallest (the largest). Those workpieces that are within the X-direction (Y-direction) radius (half the width) of this workpiece are then selected as a line (row) (see the figure below). This group of workpieces is sorted in the ascending (descending) order of the Y (X) value. By repeating this process for the remaining workpiece groups, you can sort the workpieces on a line-by-line (column-by-column) basis.



- 11 Workpieces are sorted in the ascending order of the X value on a line-by-line basis. Workpieces on the same line are sorted in the ascending order of the Y value. The value specified in argument 4 is used as the X-direction radius (half the width) of the workpiece.
- 12 Workpieces are sorted in the ascending order of the X value on a line-by-line basis. Workpieces on the same line are sorted in the descending order of the Y value. The value specified in argument 4 is used as the X-direction radius (half the width) of the workpiece.
- 13 Workpieces are sorted in the descending order of the X value on a line-by-line basis. Workpieces on the same line are sorted in the ascending order of the Y value. The value specified in argument 4 is used as the X-direction radius (half the width) of the workpiece.
- 14 Workpieces are sorted in the descending order of the X value on a line-by-line basis. Workpieces on the same line are sorted in the descending order of the Y value. The value specified in argument 4 is used as the X-direction radius (half the width) of the workpiece.
- 15 Workpieces are sorted in the ascending order of the Y value on a column-by-column basis. Workpieces on the same column are sorted in the ascending order of the X value. The value specified in argument 5 is used as the Y-direction radius (half the width) of the workpiece.
- 16 Workpieces are sorted in the ascending order of the Y value on a column-by-column basis. Workpieces on the same column are sorted in the descending order of the X value. The value specified in argument 5 is used as the Y-direction radius (half the width) of the workpiece.
- 17 Workpieces are sorted in the descending order of the Y value on a column-by-column basis. Workpieces on the same column are sorted in the ascending order of the X value. The value specified in argument 5 is used as the Y-direction radius (half the width) of the workpiece.
- 18 Workpieces are sorted in the descending order of the Y value on a column-by-column basis. Workpieces on the same column are sorted in the descending order of the X value. The value specified in argument 5 is used as the Y-direction radius (half the width) of the workpiece.
- 21 Workpieces are sorted in the ascending order of the value representing the square  $(x_0 - x)^2 + (y_0 - y)^2$  of the distance from the point  $(x_0, y_0)$  specified in argument 6.



## 12.1.8 CHK\_POS

Offsetting the robot position with *iRVision* may cause the robot to stop due to an alarm such as one that arises when the workpiece is outside the range of robot motion. This occurs, for example, if the workpiece is within the detection range of *iRVision* but outside the range of robot motion or if the robot cannot take the specified posture to pick up the workpiece. *CHK\_POS* checks whether the robot can



move to the offset position before it actually travels there. The use of CHK\_POS ensures that iRVision proceeds to process the next workpiece smoothly without causing any alarm.

### **Argument 1: Group number (Input)**

Specify the motion group number of the robot.

### **Argument 2: User frame number of the position data (Input)**

Specify the user frame number of the position data you want to check.

### **Argument 3: Tool frame number of the position data (Input)**

Specify the tool frame number of the position data you want to check.

### **Argument 4: Position register number (Input)**

Specify the number of the position register storing the position data you want to check.

### **Argument 5: Position register number (Input)**

Specify the number of the position register storing the fixed frame offset data.

### **Argument 6: Position register number (Input)**

Specify the number of the position register storing the tool offset data.

### **Argument 7: Register number (Output)**

Specify the number of the register to store the error number. This argument cannot be omitted.

In the register to store the error number, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally (The robot can move to the offset position).
- 1301: A required argument is not specified.
- 1302: An invalid argument is specified.
- 1303: The specified user frame cannot be read.
- 1304: The specified tool frame cannot be read.
- 1305: Data cannot be written to the specified register.
- 1306: The system variable \$MOR\_GRP[x].\$NIL\_POS cannot be read.
- 1307: The format of the specified position register failed to be acquired.
- 1308: The format of the specified position register is invalid.
- 1309: The specified position register cannot be read.
- 1310: The specified position register has not been initialized.
- Other: Alarm number indicating the reason why the robot cannot move to the offset position (e.g., 15018 - MOTN-018 Position not reachable).

Error codes from 1300 to 1399 indicate that an error has occurred during the execution of the tool. Other error codes are alarm codes that indicate the reason why the robot cannot move to the offset position.

An alarm code consists of two high-order digits representing an alarm ID and three low-order digits representing an alarm number. In the case of 15018, for example, the alarm ID is 15, which indicates an operation alarm, and the alarm code is "MOTN-018". For details of the alarm codes, refer to the "R-30iB/R-30iB Mate CONTROLLER OPERATOR'S MANUAL (Alarm Code List)".

## Usage example 1

```

11: J P[1] 100% FINE
12: PR[1]=P[2]
13: CALL CHK_POS(1,0,1,1,2,0,1)
14: IF R[1]<>0 JUMP,LBL [99]
15: L P[2] 2000mm/sec FINE OFFSET,PR [2]
16: LBL[99]

```

- Line 12 The taught position (pre-offset position) is copied to the position register.  
 Line 13 The group number is 1, the user frame number is 0, and the tool frame number is 1.  
 Line 14 If the robot cannot move to the offset position, the program jumps to label [99].  
 Line 15 If the robot can move to the offset position, the program lets it do so.

### 12.1.9 STVS1

Based on the result of finding one workpiece with two cameras, this function calculates the 3D position of that workpiece in a stereo fashion. Using the bin-pick search vision process to detect the gaze lines from the camera to the workpiece, STVS1 determines the 3D position (XYZ) of the workpiece through stereo calculation utilizing the two cameras' gaze line data and saves the position in a position register. In the calibration data for both of these cameras, the same user frame needs to be set as [Application Frame].



#### CAUTION

This KAREL program supports only the motion group 1.

#### Argument 1: Position register number (Input)

Specify the number of the position register storing the found position of camera A.

#### Argument 2: Position register number (Input)

Specify the number of the position register storing the found position of camera B.

#### Argument 3: Register number (Input)

Specify the number of the register storing the error limit of the distance between the two gaze lines from the two cameras to the workpiece. The distance between gaze lines is the length of a common line that is perpendicular to the two gaze lines. When the two gaze lines completely cross each other, the distance between them is 0. If they do not cross each other due to error, the distance between them is a positive value. The 3D position is calculated only when the distance between gaze lines is below the error limit specified here.

#### Argument 4: Position register number (Output)

Specify the number of the position register storing the calculated 3D position.

#### Argument 5: Register number (Output)


Specify the number of the register to store the error number. This argument can not be omitted.

In the register to store the error number, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally.
- 1401: A required argument is not specified.
- 1402: An invalid argument is specified.
- 1403: The data of the specified register failed to be obtained.
- 1404: Data cannot be written to the specified register.

- 1405: The format of the specified position register failed to be acquired.
- 1406: The format of the specified position register is invalid.
- 1407: The specified position register cannot be read.
- 1408: The specified position register has not been initialized.
- 1409: Data cannot be written to the specified position register.
- 1410: The camera inclination is too small.
- 1411: The gaze lines are too far apart from each other.
- 1412: The error limit of the distance between the two gaze lines is negative.

## Usage example 1



The length of minimum straight line between gaze lines becomes the distance between gaze lines.

```

11: CALL STVS1(P1,P2,P3,P4,P5)
12: IF R[P5]<>0 JUMP,LBL [999]
13: CALL OFS_RJ3(1,P4,0,1,0,2,0)
14: UFRAME [n]=PR[2]
15: PR[2]=UFRAME[n]
16: L P[1] 4000mm/sec FINE OFFSET,PR [2]

```

## 12.1.10 GETCROSS

This program calculates the intersection of a plane and a straight line. As a straight line, a gaze line that is detected by using the bin-pick search vision process can be used.



### CAUTION

This KAREL program supports only the motion group 1.

### Argument 1: Position register number (Input)

Specify the number of the position register storing the plane information. The XY plane of the position is used for the calculation as the plane.

### Argument 2: Position register number (Input)

Specify the number of the position register storing the straight line information. The Z-axis of the position is used for the calculation as the straight line.

### Argument 3: Position register number (Output)

Specify the number of the position register to store the calculated intersection. The X, Y and Z of the position register indicate the intersection point. W, P and R are calculated so that the XY plane of the position is parallel to the XY plane of the argument 1.

**Argument 4: Register number (Output)**

Specify the number of the position register to store the error number. This argument can be omitted.

In the register to store the error number, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally.
- 1501: A required argument is not specified.
- 1502: An invalid argument is specified.
- 1503: The format of the specified position register failed to be acquired.
- 1504: The format of the specified position register is invalid.
- 1505: The specified position register cannot be read.
- 1506: The specified position register has not been initialized.
- 1507: The XY plane and the straight line is parallel.
- 1508: Data cannot be written to the specified position register.
- 1509: Data cannot be written to the specified register.

```
11: CALL GETCROSS(P1,P2,P3,P4)
12: IF R[P4]<>0 JUMP,LBL [999]
```

**12.1.11 VL\_EXPORT**

This KAREL program exports Vision Log and logged images to the specified external device. Export logs and logged images will be removed in the controller. All the logs and logged images will be exported. This KAREL program allows you to perform the same operation as the one described in 10.3 “VISION LOG MENU”. See also 10.3 “VISION LOG MENU” about setting the external device to export to.

The following arguments can be passed:

**Argument 1: Register Number (Output)**

Specify a register number in which the operation status is stored. If the export succeeded, 0 will be stored, otherwise a non-zero value will be stored. This is optional.

**Argument 2: Timeout Time (Input)**

Specify a timeout time in milliseconds. If the export does not complete within the time specified here, the export will be stopped. If all the logs can be exported, 0 will be stored in the register specified with the argument 1. If not all the logs can be exported, 1 will be stored in the register. This is optional.

**Program Example 1**

The following example exports vision logs just after a vision execution. The robot program execution will proceed after waiting for the completion of the export.

```
1: VISION RUN_FIND 'VP1'
2: CALL VL_EXPORT
```

**Program Example 2**

When processing time for the export takes more than 1000msec, which is specified with the argument 2, the program stops exporting and moves to the next line. And the error status 1 will be stored in R[5], which is specified with the argument 1.

```
1: CALL VL_EXPORT(5,1000)
```

### Program Example 3

The following example exports vision logs in a sub task of multitasking, and the main task continues its process without waiting for the completion of the export.

```
1: RUN VL_EXPORT
```

## 12.2 DATA TRANSFER BETWEEN ROBOTS

Data Transfer Between Robots is software option that enables you to transfer data between robots over Ethernet. By calling KAREL program, you can transfer a numeric register or a position register to another robot controllers. This section introduces a part of this software option. For details, please refer to the “R-30iB/R-30iB Mate CONTROLLER Optional Function OPERATOR’S MANUAL”

### ⚠ CAUTION

Data Transfer Between Robots function is different from ROS Interface Packet over Ethernet (RIPE) function, which is introduced in the Section 3.6. Dedicated setting for this function is required separately.

### 12.2.1 RSETNREG, RSETPREG

These programs send a numeric register or a position register to another robot controller.

#### RSETNREG

This program writes the data of a numeric register on this controller in a numeric register on another robot controller.

The following arguments can be passed:

#### Argument 1 : Destination Robot (Input)

Specify the name of the destination robot controller.

#### Argument 2 : Destination Register Number (Input)

Specify the numeric register number on the destination robot controller.

#### Argument 3 : Source Register Number (Input)

Specify the numeric register number on this robot controller.

#### Argument 4 : Mode (Input)

Specify data to write.  
 0 to write numeric data and comment  
 1 to write numeric data only  
 2 to write comment only

#### RSETPREG

This program writes data of a position register on this controller in a position register on another robot controller.

The following arguments can be passed:

**Argument 1 : Destination Robot (Input)**

Specify the name of the destination robot controller.

**Argument 2 : Destination Position Register Number (Input)**

Specify the position register number on the destination robot controller.

**Argument 3 : Destination Group Number (Input)**

Specify the motion group number on the destination robot controller.

**Argument 4 : Source Position Register Number (Input)**

Specify the position register number on this robot controller.

**Argument 5 : Source Group Number (Input)**

Specify the motion group number on this robot controller.

**Argument 6 : Mode (Input)**

Specify data to write.

0 to write position data and comment

1 to write position data only

**Program Example 1**


The following example copies the vision offset from a vision register to a position register, and then sends the position register data to another robot controller.

```
1: VISION RUN_FIND 'FIND1'  
2: VISION GET_OFFSET 'FIND1' VR[1] JUMP,LBL[99]  
3: PR[10]=VR[1].OFFSET  
4: CALL RSETPREG(ROBOT2,20,1,10,1,1)  
5: DO[1]=ON
```

This sample program sets DO[1] to ON in order to let the destination robot controller know. In this case, the destination robot should check that the position register is updated by observing the DI signal.

## 12.3 4D GRAPHICS

4D Graphics function is a software option that enables you to visually view various internal data such as positions taught in a program or a tool center point visually along together the robot. This helps you to understand a system spatially and visually. Regarding *iRVision*, if the 4D Graphics option is installed, you can check the position of cameras and found results visually. This section introduces the 4D Graphics function related to *iRVision*. For details of 4D Graphics function, refer to “R-30iB/R-30iB Mate CONTROLLER Optional Function OPERATOR’S MANUAL”.



The following operations on the 4D Graphics menu make the *iR*Vision related 4D graphics data visible:

- Select [4D *iR*Vision] from F1 [TYPE].
- Select [4D *iR*Vision] from F8 [VISIBLE] and press F10 SHOW.

The following operations cause *iR*Vision to generate 4D graphics data:

- Opening the setup page of a camera calibration tool. When the camera is calibrated, the camera, its field of view, the found calibration points, and the related frames are displayed. When the camera calibration is performed, the 4D graphics data is updated.
- Opening the setup page of a vision process tool. When the calibration tools are selected, they are all displayed at the same time as described above, except for the found calibration points. When a Find is executed, the found results are also displayed.
- Opening the setup page of a 3D area sensor tool. When the calibration tools are selected, they are both displayed at the same time as described above, except for the found calibration points. When a 3D Map is acquired, it is displayed as a point cloud additionally.
- Calling RUN\_FIND from an application program. The calibration data and found results are both displayed.
- Calling CAMERA\_CALIB from an application program. The calibration data is displayed.
- Calling IRVDISPLAY4D() from an application program. For a camera calibration tool or a 3D area sensor tool, the same graphics data as its setup page are displayed. For a vision process, its calibration tools are displayed and if the results are still available from the last RUN\_FIND call, they are also displayed.


### ⚠ CAUTION

There are some vision processes that do not support 4D graphics yet.


### NOTE

Displaying 4D graphics at calling RUN\_FIND from an application program is disabled by default because it can affect cycle time. Enable it by checking "Plot 4D Graphics During RUN\_FIND" on the Vision Config page accordingly.

Some example screen shots are shown below:




- Calibration display of a fixed 2D camera with a robot-held grid.




- Calibration display of a robot-mounted 3DL sensor and a fixed grid






- Close-up of 2D single view vision process results display showing 2 Z heights



- Close-up of 3DL curved surface vision process results showing laser points



- 3D area sensor vision process results highlighting a found area sensor plane tool result

### 12.3.1 IRVDISPLAY4D

This KAREL program displays 4D graphics data of the specified vision data. Use this program when you want to refresh 4D graphics data without opening the setup page or calling RUN\_FIND or CAMERA\_CALIB.

The following arguments can be passed:

#### Argument 1 : Vision Data Name (Input)

Specify the name of a camera calibration tool or a vision process tool.


#### Program Example

The following example calls RUN\_FIND for vision processes VP1 and VP2, and then calls IRVDISPLAY4D to display 4D graphics data of the vision process VP1 (Note that RUN\_FIND does not generated 4D graphics data by default).

```
1: VISION RUN_FIND 'VP1'
2: VISION RUN_FIND 'VP2'
3: CALL IRVDISPLAY4D('VP1')
```

## 12.4 iRCONNECT

The *iRConnect* function is a software option that enables your robot controller to send various data to your mobile device, such as status of the robot and/or events that occurred on the robot. As for *iRVision*, the *iRConnect* function can send the most recent found results to your mobile device. This section introduces *iRVision* related part of the *iRConnect* function. For details of the *iRConnect* function, refer to "R-30iA/R-30iA Mate/R-30iB/R-30iB Mate CONTROLLER Ethernet Function OPERATOR'S MANUAL."



## 12.4.1 IRVICONN

This KAREL program sends the most recent *iR*Vision results to your mobile device by using the *iR*Connect function. By configuring your TP program to call IRVICONN after RUN\_FIND, you can send the same information that you see on Vision Runtime, i.e. the image, number of found, and found positions, to your mobile device.

The following arguments can be passed:

### Argument 1: Description string (Input)

Specify a text string you wish to associate with the vision result data. The specified text is displayed on your mobile device as it is along with the vision result data.

### Argument 2: Priority (Input)

Specify an integer 0 ~ 3 which is the priority level of the vision result data. The sent result data are highlighted in different colors on your mobile device based on the associated priority level.

The values indicate the following levels of priority:

- 0: Specify when sending data purely informational. The data is not highlighted.
- 1: Specify when sending data purely informational. The data is highlighted in green.
- 2: Specify when sending a potential problem or a warning. The data is highlighted in yellow.
- 3: Specify when sending a serious issue. The data is highlighted in red.

### Program Example

The following is an example of sending *iR*Vision result data to a mobile device. This example sends the data in the following cases:

- When parts are not found:  
When no part is found, GET\_OFFSET in the line 2 fails. In this case, it jumps to LBL[998], the event “part not found” is sent to your mobile device. This is the most typical usage of this function.
- When the found score is low:  
The found score is checked in the line 4. If the score is lower than the specified value, the event “score is low” is sent to your mobile device (It is assumed that the vision process is configured to output the score as the measurement value 1 by using the measurement output tool). Although the score was low, the program continues to pick the part, because the part was found. This is an example to notify as a precaution.

- When pick fails:  
The program checks whether the part is picked properly or not in the line 7. When the pick fails, it jumps to LBL[999], and the event “pick failed” is sent to your mobile device in the line 16. You can check whether the cause of the pick failure was vision detection or not by looking the image sent to your mobile device.

```
1: VISION RUN_FIND 'VP1'  
2: VISION GET_OFFSET 'VP1' VR[1] JMP,LBL[998]  
3: R[1]=VR[1].MEAS[1]  
4: IF R[1:score]<60 CALL IRVICONN('Score is low',2)  
5: CALL PICK  
6:  
7: IF RI[1:SENSOR]=OFF JMP,LBL[999]  
8: CALL DROP  
9: END  
10:  
11: LBL[998]  
12: CALL IRVICONN('Part not found',3)  
13: END  
14:  
15: LBL[999]  
16: CALL IRVICONN('Pick failed',3)  
17: END
```

# **APPENDIX**



# A TEACHING FROM PC

You can set up *iR*Vision by using a PC. This chapter describes how to setup a PC for *iR*Vision and how to open *iR*Vision pages on the PC.

## A.1 CONNECTING A SETUP PC

Connect a PC to the robot controller and prepare to set up the *iR*Vision system. The PC is used only for teaching *iR*Vision and can be disconnected during production operation.

### ⚠ CAUTION

This section explains only the setting items that need to be changed based on the assumption that your Windows and IE are in a typical configuration. Therefore, when setting items which are not described here are set differently from the typical, it may cause the *iR*Vision setup not working properly.

### A.1.1 Setup PC

A PC can be used to set up *iR*Vision. After the setup operation for *iR*Vision is completed, the PC can be removed. Refer to the following table for the tested PC and browser.

OS	Windows 7 Professional (32bit) Windows 7 Professional (64bit) Windows 8.1 Professional (64bit)
Browser	Internet Explorer 9 (32bit) Internet Explorer 10 Internet Explorer 11

### ⚠ CAUTION

- 1 The tested languages of Windows are Japanese and US English.
- 2 All Windows versions assume that the latest Service Pack is installed.
- 3 When you log in to your PC as a user without the Administrator password, the PC might not normally communicate with the robot. Log in to your PC as a user with the Administrator password.
- 4 Windows8.1 contains two types of Internet Explorer, Desktop mode and Metro mode. Only Desktop mode is compatible to *iR*Vision setup. Metro mode cannot be used for *iR*Vision setup.


### A.1.2 Communication Cable

A cable is used to connect the robot controller and the PC to set up *iR*Vision. Choose a 100BASE-T cable that meets the specifications shown below.

Cable	Twisted pair
Shield	Shielded

### A.1.3 Connecting a Communication Cable

Connect the robot controller and the PC using an Ethernet cable. On the robot controller side, plug the

cable into the Ethernet connector on the front of the MAIN board. On the PC side, plug the cable into the network connector, usually marked .

## A.1.4 Determining the IP Addresses

Set the IP addresses to be assigned to the robot controller and the setup PC. Typically, these IP addresses are determined by the network administrator. To find out what addresses to assign, contact the network administrator of your organization.


When the robot controller and the PC are connected on a one-on-one basis and not connected to any other network device, the IP addresses can be set as shown below.

Robot controller	192.168.0.1
PC	192.168.0.2
Gateway	192.168.0.3
Subnet mask	255.255.0.0

## A.1.5 Setting the IP Address of the Robot Controller


Set the IP address of the robot controller.

- 1 Press MENU key on the teach pendant of the robot controller.
- 2 From the pull-down menu, select [6 SETUP].
- 3 Press F1 [TYPE].
- 4 Select [Host Comm] from the list.



- 5 Move the cursor to “TCP/IP” and press ENTER.





- 6 Enter the name of the robot controller in [Robot name].
- 7 Enter the IP address of the robot controller in [Port#1 IP addr].
- 8 Enter the subnet mask in [Subnet mask].
- 9 Enter the IP address of the default gateway in [Router IP addr].
- 10 Turn off the power of the robot controller, and then turn it back on.


**CAUTION**

- 1 When setting the IP address, do not insert any unnecessary spaces or "0". If an unnecessary space or "0" is inserted, communication cannot be performed normally.
- 2 When setting the Robot Name, do not insert any spaces in the name.


## A.1.6 Setting the IP Address of the PC

Set the IP address of the PC.


- 1 In the Control Panel window, open [Network and Sharing Center].




- Click [Local Area Connections] in [View your active networks].



- Click the [Properties] button.



- Select [Internet Protocol Version 4 (TCP/IPv4)], and click the [Properties] button.




- Check the [Use the following IP address] box, and enter values in [IP address], [Subnet mask], and [Default gateway].
- Click the [OK] button to close the window.

## A.1.7 Modifying Settings of Internet Explorer


Set Internet Explorer to prevent Windows from blocking communication with the robot controller.

- In the Control Panel window, open [Internet Options].




## Trusted Sites


- 1 Select the [Security] tab.



- 2 Select [Trusted Site], and then click the [Sites] button.




- 3 Uncheck the [Require server verification (https:) for all the sites in this zone] box.
- 4 In the [Add this Web site to the zone] textbox, enter the IP address of the robot controller (or the last digit of the IP address can be replaced by \*). Then, click the [Add] button.
- 5 Move to the [Security] tab. Click the [Custom level] button. Enable “Allow websites to open windows without address or status bars” in “Miscellaneous”.
- 6 Enable “Allow websites to open windows without address or status bars” in “Miscellaneous”.




- 7 Click the [Close] button to close the dialog box.
- 8 Re-open the Internet Explorer.

## Popup Blockers

- 1 Select the [Privacy] tab.



- 2 Click the [Settings] button of [Pop-up Blocker].




- 3 Enter the IP address of the robot controller in the [Address of Web site to allow] textbox, and click the [Add] button.
- 4 Click the [Close] button to close the dialog box.

## Disable Automatic Crash Recovery

Automatic Crash Recovery should be disabled in Internet Explorer. This setting is necessary to install Vision Controls properly.


- 1 Select the [Advanced] tab, and scroll to the Browsing section.
- 2 If the [Enable automatic crash recovery] box is checked, uncheck it.




- 3 Click [OK]. When you changed the item, restart your PC.

## Proxy Setting


- 1 Select the [Connections] tab.



- 2 Click the [LAN Settings] button.



- 3 When the [Use a proxy server for your LAN] check box is not checked, proceed to the step 7. When it is checked, perform the steps 4 to 6.
- 4 Click the [Advanced...] button of [Proxy server].




- 5 Enter the IP address of the robot controller in the text box under [Exceptions].
- 6 Click the [Close] button to close the dialog box.
- 7 Click the [OK] button to close the Internet property page.


## A.1.8 Modifying Setting of Windows Firewall

Modify the settings of Windows Firewall to prevent Windows Firewall from blocking communication with the robot controller.


- 1 In the Control Panel window, open [Windows Firewall].



- 2 Click [Allow a program or feature through Windows Firewall].



- 3 Click the [Change settings] button.



- 4 Select [Internet Explorer] in the list, and click the [Add] button.
- 5 Click the [OK] button to close the window.


#### NOTE

Communication with the robot controller might be prevented due to a cause other than the above, which is, for example, a Microsoft® Internet Explorer add-on or security software installed in your PC. If an error occurs during teaching of *iRVision*, see Subsection A.5.1, “PC UIF Troubles” first.

## A.2 OPENING VISION PAGES

First, display the robot homepage by following the steps below.

- 1 Click the [Start] button on the PC screen, and start Internet Explorer.
- 2 Enter the IP address or the host name of the robot controller in [Address].



The robot homepage is not dedicated to *iRVision* but also is provided for every robot controller. When the robot controller has the *iRVision* option, the following three links for *iRVision* appear on the homepage of the robot:

### Vision Setup

Displays the Vision Setup page, on which you can setup and test vision data.  
For details, see Section 3.1, “VISION SEUTP”.

### Vision Runtime

Displays the Vision Runtime page, on which you can monitor *iRVision* execution.  
For details, see Section 3.2, “VISION RUN-TIME”.

### Vision Log

Displays the Vision Log page, on which you can view execution log of *iRVision*.  
For details, see Section 3.3, “VISION LOG”.


The system settings of the *iRVision* are not available on PC. It is available only on *iPendant*. For details, see Section 3.4, “VISION CONFIG”




## A.2.1 Installing Vision UIF Controls

You must install Vision UIF Controls on your PC in order to display the *iR*Vision user interface. You can install Vision UIF Controls from the robot controller when you click a *iR*Vision related link. Follow the steps below:

- 1 Click [Vision Setup] in the *iR*Vision section.  
If Vision UIF Controls are already installed in the PC used, the Vision Setup Page opens.  
If Vision UIF Controls are not installed in the PC, the following screen appears:



- 2 Click the [INSTALL] button.




3 After a while, the following dialog appears.




4 Click the [Run] button.


- 5 After a while, the following dialog appears.



- 6 Click the [Run] button.  
7 The following dialog box appears.



- 8 Click the [Yes] button.  
9 Installation of Vision UIF Controls starts.



- 10 When the installation is completed, all Internet Explorer windows are closed.
- 11 Start Internet Explorer again, and open the homepage of the robot.

## A.3 OPERATIONS ON PC

---

This section describes operations of *iR*Vision Setup specific to PC, which is consistent to that on *i*Pendant, but optimized for PC and is slightly different from *i*Pendant.

### A.3.1 Function Keys

---

The function keys are displayed on PC as follows.




- All 10 F-keys are shown together.
- The order of the F-keys on PC may be different from that on *i*Pendant. For example, F3 SNAP is the 3rd F-key on *i*Pendant but it is the 2nd F-key on PC.
- F-keys are enlarged, and have intuitive icons.

### A.3.2 Vision Data List Screen

---

The Vision Data List Screen is displayed on PC as follows.



Name	Comment	Type	Created	Modified	Size
CAMERA	KOWA Digital Camera		28-MAY-2014 17:45:36	28-MAY-2014 17:46:48	98


(W)

CREATE EDIT [ VTYPE ] COPY DETAIL DELETE FILTER


- All attributes of vision data (Name, Comment, Type, Created date/time, Modified date/time and Size in bytes) are shown together.
- F4 [ATTR] is removed.

### A.3.3 Vision Data Edit Screen


On PC, the vision data edit screen has the following structure.



- The Tree View frame and Results frame are always displayed along together the Image Display frame.
- The Image Display frame is shown on the left.
- The Tree View frame and the Parameter frame for the selected vision tool are shown on the right. The Tree View frame is above the Parameter frame.
- The height of the Tree View frame can be changed by dragging the border line between the Tree View frame and the Parameter frame.



- The tab to expand or close the Result frame is not shown on PC. The height of the Result frame can be changed by dragging the border line between the Result frame and a frame just above.



### A.3.4 Moving Control Point

During the window teach, mask edit and so on, control points can be dragged on PC in addition to the operations available on *iPendant*.


- 1 Press down the left button of the mouse on a control point and hold.
- 2 Move the mouse.
- 3 Release the button at a point where you want to move the control point to.

### A.3.5 Editing Mask


During the mask edit, masks can be drawn or erased freehand in addition to the operations available on *iPendant*.

#### Drawing Freehand

A mask is drawn freehand.


- 1 Click  button
- 2 Select the thickness of the pen in “Thin”, “Medium” and “Thick” with the drop-down box of pen.
- 3 Move the mouse with holding the left mouse button down. Mask is drawn as the mouse pointer moves.






## Erasing Freehand

A mask is erased freehand.

- 1 Click  button.
- 2 Select the thickness of the pen in "Thin", "Medium" and "Thick" with the drop-down box of pen.
- 3 Moves the mouse with holding the left mouse button down. Mask is erased as the mouse pointer moves.



## A.4 RESTRICTING LOGIN TO VISION SETUP


Login to [Vision Setup] of *iR*Vision can be protected by password. Password protection prevents setup data for *iR*Vision from being modified by unauthorized users.

**NOTE**


Even when login to [Vision Setup] of *iR*Vision is protected by password, the [Vision Log] and [Vision Runtime] pages can be opened without a password.

### A.4.1 Setting Password Protection

- 1 Press MENU key on the teach pendant.
- 2 Select [6 SETUP].
- 3 Press F1 [TYPE].
- 4 Select [Host Comm].



- 5 Move the cursor to [HTTP] and press ENTER.



- 6 Move the cursor to the [Name] field in the [VISION SETUP] line, press ENTER, and enter a user name that is up to six characters.
- 7 Move the cursor to the [Pwr] field in the [VISION SETUP] line, press ENTER, and enter a password that is up to six characters.

**CAUTION**

The characters entered as a password appear on the teach pendant immediately after the password has been entered, but when the cursor is moved, the displayed password is replaced by "\*\*\*\*\*" and is no longer visible.

- 8 Move the cursor to [U] in the [VISION SETUP] line, and press F4 [AUTH].

When [Vision Setup] of *iR*Vision is clicked on the homepage of the robot when password protection is enabled, a dialog as shown below appears, asking the user to enter a user name and password. If a correct user name and password are entered, the *iR*Vision setup page is displayed. If an incorrect user name or password is entered, the login to the setup page is rejected.



Reference: The leftmost character on the HTTP authentication screen indicates the following state:

- U:UNLOCK Enables login without a password.
- L:LOCK Disables login regardless of the password.
- A:AUTH Enables login if a password is entered.

## A.4.2 Canceling a Password

- 1 On the HTTP authentication screen, move the cursor to [A] in the [VISION SETUP] line, and press F3 [UNLOCK].

## A.5 FREQUENTLY ASKED QUESTIONS

---

### A.5.1 PC UIF Troubles

---

If there is a problem with *iR*Vision teach operation on a PC, first check this subsection.

#### **The robot home page cannot be opened.**

If Internet Explorer of your PC is configured to use the proxy server, the PC and controller may not be able to communicate with each other correctly. Set it as described in Subsection A.1.7, “Modifying Settings of Internet Explorer”.

#### **Links to *iR*Vision pages are not shown on the robot homepage.**

Navigation links to *iR*Vision pages such as Vision Setup and Vision Runtime are not shown on the robot homepage. The problem can happen when a backup of a controller without *iR*Vision option is loaded to a controller with *iR*Vision option. Set the system variable \$VISION\_CFG.\$PC\_SETUP to TRUE and reopen the robot homepage.

#### **When you click *iR*Vision Vision Setup, the message “Failed to login Vision Setup” appears.**

The Windows firewall might be set incorrectly. Set it as described in Subsection A.1.8, “Modifying Setting of Windows Firewall”.

#### **When you open the *iR*Vision Vision Setup, the message “Enables popup on Internet Explorer” appears.**

Internet Explorer might be set incorrectly. Set it as described in Subsection A.1.7, “Modifying Settings of Internet Explorer”.

#### **When you create a new vision data file, a runtime error occurs.**

Internet Explorer might be set incorrectly. Set it as described in Subsection A.1.7 “Modifying Settings of Internet Explorer”.

#### **Clicking *iR*Vision Vision Setup displays the alarm [70: Cannot write].**

Internet Explorer might be set incorrectly. Set it as described in Subsection A.1.7, “Modifying Settings of Internet Explorer”.

#### **No window opens even though *iR*Vision Vision Setup is clicked.**

Verify the following points.

##### **Setting Windows Firewall**

The Windows firewall might be set incorrectly. Set it as described in Subsection A.1.8, “Modifying Setting of Windows Firewall”.

##### **Security Software**

If security software is installed in your PC, communication might be blocked by the security software. Disabled the security software.

##### **Internet Explorer**

An issue that Internet Explorer fails to open a new window on Windows 7 is reported. It can cause the case. Verify whether it is the case with the following procedures:

- 1 Open the robot homepage on Internet Explorer.
- 2 Open [Tools] – [Developer Tools]. (It can be opened by pressing the F12 key.)
- 3 Select [Script] tab on the Developer Tools and select [Console] on the right pane.
- 4 Click [VISION SETUP] on the robot homepage.
- 5 If the message “script16386 no such interface supported” is shown on the console of the Developer Tools, it can be the case.

Some countermeasures are suggested on the Internet. If you contact your FANUC technical representative, they will provide you a countermeasure which has been effective.

## **Installing Vision UIF Controls is required even after it has been installed.**

Verify the following points.

### **Trusted Sites**

If the setting of Trusted Sites in Internet Explorer is incorrect, you may not be able to install the Vision UIF Controls. Refer to Subsection A.1.7, “Modifying Settings of Internet Explorer”, and make sure that of the robot IP address is in Trusted Sites.

### **Add-ons**

If the Vision UIF Controls is disabled in [Manage add-ons] of Internet Explorer, the problem can occur. You can verify whether it is disabled or not with the following procedures:

- 1 Open the robot homepage on Internet Explorer.
- 2 Open [Tools] - [Manage add-ons].
- 3 Select [Toolbars and Extensions] and then select [FRImageDisplay Control] in the list.
- 4 If its status is “Disabled”, click the [Enable] button at the bottom right of the window.
- 5 Click [Close]. Close all Internet Explorer windows, then restart IE.

### **ActiveX Filtering**

If the ActiveX Filtering is enabled in Internet Explorer, the problem can occur. Open [Tool] – [Safety], and make sure that the [ActiveX Filtering] box is unchecked.

## **The alarm [PMON-001 Failed to notify PC Monitor] is displayed on the teach pendant of the robot.**

The Windows firewall might be set incorrectly. Set it as described in Subsection A.1.8, “Modifying Setting of Windows Firewall”.

If security software is installed in your PC, communication might be blocked by the security software. Disabled the security software.

## **Clicking *i*RVision Vision Setup displays [A problem occurred] and closes Internet Explorer.**

Communication with the robot controller may not be performed normally due to the influence of the add-on software of Internet Explorer. Disable all add-on's issued by other than FANUC Robotics North America or FRNA, by choosing “Manage Add-on's” from the “Tools” menu of Internet Explorer. In this state, check whether *i*RVision teach operation can be performed normally. If no problem arises, enable the disabled add-on's one at a time while checking that *i*RVision teach operation is not affected.

## **No image is displayed on the *i*RVision teach screen.**

Verify the following points.

## Restarting PC

Cases restarting PC resolves the problem have been reported. Restart your PC and re-open the iRVision setup screen.

## Administrator password

When you log in to your PC as a user without the Administrator password, the PC might not normally communicate with the robot. Log in to your PC as a user with the Administrator password.

## Internet Information Server

When Microsoft® Internet Information Server is installed in your PC and Worldwide Web Publishing Service is enabled, the PC might not communicate normally with the robot controller. Disable the Worldwide Web Publishing Service.

## Temporary Internet Files

If you use a single PC to open Vision Setup on multiple robot controllers, the same IP address are used for the controllers, and different versions of robot software are installed to them, various problems, for example Vision Setup cannot be displayed or operated properly, may occur. This is because a setup page file from a controller is cached by IE, and the caches page file is used for Vision Setup of another controller. In this case, delete temporary internet files by opening [Delete Browsing History] dialog box from [Internet Options] – [General] – [Delete] and clicking [Delete] button. The problem can occur also when the controller software is updated.

Note: The [Delete Browsing History] dialog box has the check box [Preserve favorite website data] in recent versions of Internet Explorer. If it is checked, the [Delete] button does not delete the browsing history of the favorite website. It means the cached page files from a controller are not deleted if you added the robot homepage to the favorite website list. Un-checking it before clicking the [Delete] button.

## When you try to load an image file, [Runtime error '0'] occurs.

When Internet Information Services (IIS) is enabled, communication with the robot controller may not be performed correctly. Choose Control Panel then open “Add or Remove Program”. Next, uncheck “Internet Information Services (IIS)” on the list of “Windows Components”.

## Buttons to edit mask are hidden, and not operatable.

Verify the following points.

### Trusted Sites

If the setting of trusted sites in Internet Explorer is incorrect, the mask setting buttons are hidden and you may not be able to operate them. Refer to Subsection A.1.7, “Modifying Settings of Internet Explorer”, and make sure that of the robot IP address is in Trusted Sites.

### Address Bar, Status Bar

If the address bar or the status bar is shown on the Vision Setup window, the mask setting buttons are hidden and you may not be able to operate them. Refer to Subsection A.1.7, “Modifying Settings of Internet Explorer” and make sure that the [Allow websites to open windows without address or status bars] box is checked.

## The address bar is displayed on the Vision Setup page.

If the setting of trusted sites in Internet Explorer is incorrectly, the address bar is displayed on the Vision Setup screen and you may not be able to operate it. Refer to Subsection A.1.7, “Modifying Settings of Internet Explorer”, and make sure that of the robot IP address is in Trusted Sites.

**When you try to finish editing masks, the CVIS-005 alarm is issued.**

When Internet Information Services (IIS) is enabled, communication with the robot controller may not be performed correctly. Choose Control Panel then open “Add or Remove Program”. Next, uncheck “Internet Information Services (IIS)” on the list of “Windows Components”.

**On ROBOGUIDE, vision data cannot be newly created.**

Set ROBOGUIDE so that Internet Explorer is used instead of the browser built into ROBOGUIDE. The installation destination directory of ROBOGUIDE includes the file “OrderInfo.xfr”. Open this file with a text editor then modify the line:

```
<RoboguideFeature Name=“UseIE” Support=“No”/>
```

to:

```
<RoboguideFeature Name=“UseIE” Support=“Yes”/>
```

**On Roboguide, nothing is displayed on the *iR*Vision main setup page**

Set ROBOGUIDE so that Internet Explorer is used instead of the browser built into ROBOGUIDE. The installation destination directory of ROBOGUIDE includes the file “OrderInfo.xfr”. Open this file with a text editor then modify the line:

```
<RoboguideFeature Name=“UseIE” Support=“No”/>
```

to:

```
<RoboguideFeature Name=“UseIE” Support=“Yes”/>
```

**On ROBOGUIDE, when you try to finish editing masks, [Runtime error '0'] occurs.**

Set ROBOGUIDE so that Internet Explorer is used instead of the browser built into ROBOGUIDE. The installation destination directory of ROBOGUIDE includes the file “OrderInfo.xfr”. Open this file with a text editor then modify the line:

```
<RoboguideFeature Name=“UseIE” Support=“No”/>
```

to:

```
<RoboguideFeature Name=“UseIE” Support=“Yes”/>
```

**A.5.2 Vision UIF Control Cannot be Installed**

---

Check that the “*iR*Vision UIF Controls” option is ordered. If the option is not ordered, contact your FANUC technical representative.




# B iPENDANT FIRMWARE UPDATE


When Vision Setup or Vision Log is selected on *i*Pendant, a message may prompt the users to update the *i*Pendant firmware and they cannot get into *i*RVision menus. In this case, updating *i*Pendant firmware is required to get into *i*RVision related menus on *i*Pendant. This chapter describes how to update *i*Pendant firmware.


The message depends on the software version of the controller.

On 7DC1/03 (V8.10P/03) of controllers, the following message is displayed. The link “Install Vision UIF Controls” exists, but the *i*Pendant firmware cannot be updated with the link.



On 7DC1/17 (V8.10P/17), 7DD0/08 (V8.13P/08), 7DC2/01 (V8.20P/01) or later versions of controller, one of the following two messages is displayed.





These messages are displayed when one of the following conditions is met.

- The *iPendant* firmware version is older than the controller software version.
- The *iPendant* firmware is for a different series/major-version from the controller software, and the controller software version is 7DC1/17 (V8.10P/17), 7DD0/08 (V8.13P/08), 7DC2/01 (V8.20P/01) or later.

In such a case, applying one of the following measures is required.

- Exchange *iPendant* with the one which a firmware compatible to the controller software is loaded to.
- Update the *iPendant* firmware to the one compatible to the controller software. The procedure to update the firmware depends on the controller software version. Refer the update procedures corresponding to the software version of the controller below:

### When the controller software version is 7DC1/03~06.

Contact your FANUC technical representative.

### When the controller software version is 7DC1/07~16 or 7DD0/01~07.

See the section B.2 “Procedures B”.

### When the controller software version is 7DC1/17, 7DD0/08, 7DC2/02 or later.

The procedure depends on the current version of *iPendant* firmware. Verify the *iPendant* firmware version with the following procedure:

- 1 Press MENU on the *iPendant*.
- 2 Select [0 – NEXT --], and then select [4 STATUS], [2 Version ID].
- 3 [18 TP Core Firmware] shows the firmware version.


When the firmware version is newer than V8.1058, see the section B.1 “Procedures A”.

When the firmware version is older than or equal to V8.1058, see the section B.2 “Procedures B”.

## B.1 PROCEDURES A

You can update the *iPendant* firmware with the following procedure without re-booting the controller.

- 1 For safety, make sure that the E-stop button is pressed down.
- 2 On *iPendant*, select [8 iRVision] from MENU, and then Vision Setup.
- 3 The following screen is displayed.



- 4 Make sure either the controller is in T1/T2 mode or the teach pendant is enabled. And then press F4 OK.
- 5 Updating the firmware starts. While updating, the following screen is displayed.



### Caution

Updating the firmware takes several minutes. Never power off while updating!!!

- 6 When it finishes, the iPendant becomes operable.


## B.2 PROCEDURES B

You can update the iPendant firmware with performing the controlled start and cold start in a row.


### Hint

As for details of the controlled start and the cold start, see the section B.1 "START MODE" of the "R-30iB/ R-30iB Mate CONTROLLER OPERATOR'S MANUAL (Basic Operation)".


- 1 For safety, make sure that the E-stop button is pressed down.
- 2 Power off the controller.
- 3 Confirm that MC card and USB memory are NOT inserted to the controller.
- 4 Power on the controller with pressing PREV and NEXT.
- 5 Waits for CONFIGURATION MENU being displayed.



- 6 Select [3.Controlled start] to perform Controlled Start.
- 7 Wait for the Controlled Start Menu being displayed.



- 8 Press FCTN and select [1 START (COLD)] to perform Cold Start.
- 9 Updating the firmware starts. While updating, the following screen is displayed.

**Caution**

Updating the firmware takes several minutes. Never power off while updating!!!

10 When it finishes, the *iPendant* becomes operable.



# **ADDITIONAL INFORMATION**





Addition of the description about 3D model matching function for  
 FANUC Robot series R-30iB/ R-30iB Mate CONTROLLER  
 iRVision OPERATOR'S MANUAL (Reference)

1.Type of applied technical documents

Name	FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)
Spec.No./Ed.	B-83304EN/04

2.Summary of Change

Group	Name/Outline	New, Add, Correct, Delete	Applicable Date
Basic			
Optional Function	Modify 6.16 3D AREA SENSOR VISION PROCESS Add 6.18 3D MODEL BASED VISION PROCESS Modify 7.34 AREA SENSOR PREPROCESS TOOL Modify 7.35 AREA SENSOR PEAK LOCATOR TOOL Add 7.47 ONE-SIGHT-MODEL LOCATOR TOOL	New	Immediately
Unit			
Maintenance Parts			
Notice			
Correction			
Another			


				Title		Addition of the description about 3D model matching function for FANUC Robot series R-30iB/ R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)				
				Draw. No.		B-83304EN/04-01				
1	2016.06.17	T.Satou	Initial creation							
<b>Ed</b>	<b>Date</b>	<b>Desig</b>	<b>Description</b>							
Date	2016.06.17	Desig	T.Satou	Check		Apprv	<b>FANUC CORPORATION</b>		Sheet	1/33

# 6 VISION PROCESSES


## 6.16 3D AREA SENSOR VISION PROCESS

### 6.16.1 Setting up a Vision Process

If you open the setup page of [3D Area Sensor Vision Process], a screen like the one shown below appears.



If you tap [Tree] tab, a screen like the one shown below appears.



1	2016.06.17	T. Satou	Initial creation						
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>						
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>		<b>Apprv</b>			
					<b>Title</b>	Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iR-Vision OPERATOR'S MANUAL (Reference)			
					<b>Draw. No.</b>	B-83304EN/04-01			
					<b>FANUC CORPORATION</b>			Sheet	2/33

## Area Sensor

Select the 3D area sensor you want to use.

## Camera Calibration

Camera calibration of 3D area sensor selected as the 1st and 2nd calibration are listed in a drop-down box. Select the camera calibration you want to use for 2D measurement.

## Camera

The name of the camera specified for the selected camera calibration is displayed.

## Setting the Exposure Time

Set the camera's exposure time to be applied when running the vision process. For detailed information about the individual items to be set, see Subsection 3.7.15, "Setting Exposure Mode".

## Multiple Locator Mode

If you have created more than one locator tool, select how to execute those tools.

### Find Best

All the locator tools will be executed, and the best result will be chosen. This is effective when you want to identify the type or put location reliability before processing time.

### Find First

The locator tools will be executed sequentially from the top until the specified number of workpieces has been found. The subsequent locator tools will not be executed once the number of found exceeds the specified number. For your information, the duplicate check is executed every time one locator tool is executed, the number of found, which is compared to the specified number, does not include duplicated workpieces.

## Number to Find

Enter the maximum number of workpieces to be found per measurement. The specifiable range is 1 to 100.

## Offset Frame

Specify a user frame number. A 3D area sensor vision process measures the offset data with respect to this specified user frame.

## Range

Set the range of X, Y and Z to be measured in respect to the offset frame. The measured 3D map consists of only 3D points that are in the range. Z range needs to be set, but X and Y ranges are optional.

## Image Logging Mode

Specify whether to save image and 3D map to the vision log when running the vision process. However, if you have the vision log disabled in the system variable, logged images are not saved.

### Do Not Log

Do not save any image and 3D map to the vision log

### Log Failed Images

Save image and 3D map only when the vision operation fails.

				Title		Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER $\mu$ RVision OPERATOR'S MANUAL (Reference)	
				Draw. No.		B-83304EN/04-01	
1	2016.06.17	T. Satou	Initial creation				
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>				
Date	2016.06.17	Desig	T. Satou	Check	Apprv	<b>FANUC CORPORATION</b>	
						Sheet	3/33

## Log All Images

Save all images and 3D maps.

### ⚠ CAUTION

The execution of the next vision process cannot start until the image logging operation for the preceding vision process execution is completed. The time required to save images depends on the type of storage device in use. Use this function after checking whether the delay of saving the images is acceptable for your application.

## Setting the Sorting Parameter

Set the sorting parameters to be applied when more than one workpiece have been found. For details, see Subsection 3.7.16, "Sorting".

## Delete Duplicate if

The position and angle of each found result on the camera image are checked to see whether the result is the same as another result. If there are multiple found results within the specified pixels and angle, the results are assumed to indicate the same workpiece and only the found result with the most reliable result is output.

### Dup. Check Key

Select the key for the duplication check. If there are multiple found results with in the specified pixels and angle, the result of that the selected key value is the highest or lowest in these found results is output. You can specify the following items as the duplication check key.

- Score
- Measurement1-10

### Dup. Check Order

Specify the order of the duplication check. If you select the [Score] in the [Dup. Check Key], the [Remove Low Result] is automatically specified.

#### Remove Low Result

The result of that the selected key value is the highest in the found results with in the specified pixels and angle is output.

#### Remove High Result

The result of that the selected key value is the lowest in the found results with in the specified pixels and angle is output.

## Image Display Mode

Select the image display mode for the Setup Page.

### 2D image

2D camera image and a container are displayed.

### 3D Map

3D map is displayed.

## Ref. Data To Use

Choose one of the following to specify how to determine the reference data to use.

						Title	Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER $\mu$ RVision OPERATOR'S MANUAL (Reference)			
						Draw. No.	B-83304EN/04-01			
1	2016.06.17	T. Satou	Initial creation							
Ed	Date	Design	Description			<b>FANUC CORPORATION</b>			Sheet	4/33
Date	2016.06.17	Desig	T. Satou	Check	Apprv					







## 6.18 3D MODEL BASED VISION PROCESS

This vision process constitutes 3D model matching function with One-Sight-Model Locator tool. 3D model matching detects a position of the workpiece by using its 3D shape as model data. This vision process performs 3D matching with a 3D map acquired by [3D Area Sensor], and offsets the robot position. In order to discriminate the vision process of 3D Area Sensor from the equipment of 3D Area Sensor, this document encloses the vision process of 3D Area Sensor in parentheses like [3D Area Sensor].

### CAUTION

3D Model Based Vision Process requires larger memory capacity and needs 128MB DRAM. Moreover, according to detecting conditions, a controller can raise the following alarms even if 128MB DRAM are applied.

- CVIS-021 Exceed VisPool.
- CVIS-001 Not enough memory to process.

To avoid them, please increase Vision pool as follows before using 3D Model Based Vision Process.

- 1 Perform a complete controller back up as image.
- 2 Press MENU.
- 3 Select [SYSTEM], and then [Variables].
- 4 Select \$VISION\_CFG.
- 5 Set \$VPOOL\_SZ128 to 50,000,000.
- 6 Reboot the controller.


- The controller can fail to reboot. When the reboot fails, restore the backup. And then, set a 10MB (10,000,000) smaller value than the previous change. When the retry of rebooting fails, set a still smaller value.

### 6.18.1 Setting up a Vision Process


If you open the setup page of [3D Model Based Vision Process], a screen like the one shown below appears.

								Title	Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER Vision OPERATOR'S MANUAL (Reference)		
								Draw. No.	B-83304EN/04-01		
1	2016.06.17	T. Satou	Initial creation								
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>			<b>FANUC CORPORATION</b>			Sheet	8/33	
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>		<b>Apprv</b>					





If you tap [Tree] tab, a screen like the one shown below appears.



### Offset Frame

Specify a user frame number. This vision process measures the offset data with respect to this specified user frame.

### Range

Set the range of X, Y and Z to be measured in respect to the offset frame. The measured 3D map consists of only 3D points that are in the range. Z range needs to be set, but X and Y ranges are optional.

### Area Sensor

Select the [3D Area Sensor] which measures a 3D map.

1	2016.06.17	T.Satou	Initial creation						
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>			<b>FANUC CORPORATION</b>	Sheet	9/33	
<b>Date</b>	2016.06.17	<b>Desig</b>	T.Satou	<b>Check</b>	<b>Apprv</b>				

**Title** Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)

**Draw. No.** B-83304EN/04-01

**FANUC CORPORATION** Sheet 9/33








## 6.18.2 Running a Test

Press F4 FIND to run a test and check whether the tool behaves as expected.



### Found

The number of found workpieces is displayed.

### Time to Find

The time the vision process took is displayed in milliseconds.

### Found Result Table

The following values are displayed.

#### X, Y, Z

Coordinate values of the model origin of the found workpiece (units: mm).

#### W, P, R

Rotation angle of the found workpiece around the X, Y, and Z axis (units: degrees).

#### Model ID

Model ID of the found workpiece

#### Score

Score of the found workpiece. The score is calculated by the locator tool.

#### Visibility Ratio

Visibility ratio of the found workpiece.

#### Pick Score

Pick score of the found workpiece.

						Title	Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iR-Vision OPERATOR'S MANUAL (Reference)				
						Draw. No.	B-83304EN/04-01				
1	2016.06.17	T.Satou	Initial creation			<b>FANUC CORPORATION</b> Sheet 13/33					
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>								
<b>Date</b>	2016.06.17	<b>Desig</b>	T.Satou	<b>Check</b>	<b>Apprv</b>						



### Visibility Ratio Threshold

Specify a number between 30 and 100.

								<b>Title</b>	Addition of the description about 3D model matching function for FANUC Robot series R-30iB/ R-30iB Mate CONTROLLER $\mu$ RVision OPERATOR'S MANUAL (Reference)			
								<b>Draw. No.</b>	B-83304EN/04-01			
1	2016.06.17	T. Satou	Initial creation									
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>					<b>FANUC CORPORATION</b>				
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>		<b>Apprv</b>						Sheet

# 7 COMMAND TOOLS

## 7.34 AREA SENSOR PREPROCESS TOOL

### 7.34.4 Setting the Parameters of Normal calculation

Set the parameters to calculate surface normal of the workpiece for each 3D point. These setup items are displayed in 3D Model Based vision process.

#### Enable

If the checkbox is checked, surface normal is calculated for each 3D point.

#### Filter Size

Select the filter size for calculating surface normal. For example, if the value is F, a surface normal is calculated from 3D points in a '2F + 1' square whose center is identical to it. Specify a number between 1 and 5.

### 7.34.5 Setting the Parameters

#### Image Display Mode

Select the image display mode for the Setup Page.

##### 2D image

A 2D camera image and [Container Shape] are displayed.

##### 2D image + Result

A 2D Camera image, [Container Shape] and 3D points are displayed. Removed 3D points are plotted in magenta and others are plotted in cyan.

##### 3D Map

A 3D map is displayed.

##### 3D Map + Result

A 3D map is displayed. And the removed points are plotted in red. If normal calculation is enabled, 3D points which fail to calculate normal are plotted in magenta.

#### Normal


A 3D map which is colored according to surface normal is displayed. A 3D point is colored in red when its normal directs to +Hz. In the case of +Vt, a point is colored in blue. The details are as follows.

1	2016.06.17	T. Satou	Initial creation						
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>	<b>FANUC CORPORATION</b>				Sheet	16/33
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>		<b>Apprv</b>			

Title Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER  $\mu$ RVision OPERATOR'S MANUAL (Reference)

Draw. No. B-83304EN/04-01






## F6 2-3D Snap


A 2D camera image is snapped and a 3D map is acquired.

# 7.35 AREA SENSOR PEAK LOCATOR TOOL

The Area Sensor Peak Locator tool finds the regional highest 3D point in a 3D map acquired by a 3D area sensor (local peaks) from a 3D map. By using the Area Sensor Peak Locator tool, the robot can pick up the workpieces in descending order of height. To use the Area Sensor Peak Locator tool, some 3D points which derive incorrect results and waste the processing time must be removed by the Area Sensor Preprocess tool.



						Title		Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER $\mathcal{R}$ Vision OPERATOR'S MANUAL (Reference)			
						Draw. No.		B-83304EN/04-01			
1	2016.06.17	T. Satou	Initial creation			<b>FANUC CORPORATION</b>					
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>							Sheet	17/33
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>						<b>Apprv</b>	



## 7.35.1 Setting the Parameters

### Preprocess Tool

Select the Area Sensor Preprocess tool which is used for detection. A preceding Area Sensor Preprocess tool that is set at the same level as this tool can be selected.

### Model ID

When you have taught two or more Area Sensor Peak Locator tools and want to identify which tool detected each workpiece, assign a distinct model ID to each tool. Because the model ID is output with offset data, robot programs can identify the model ID.


### Smoothing Level

Select the level of smoothing a 3D map. The larger the value is, the smoother the 3D map is. If there is a lot of noises in the 3D map, when detecting local peaks whose heights are same in real space, the found Z heights of the local peaks vary widely. Then, set a larger value to [Smoothing Level].


### Search Range

Set the size of the searching range to find local peaks. If the set value is R, the searching range is the range whose base is a ' $2R + 1$ ' square parallel to XY plane on the 3D map. In the searching range whose center is a local peak, there exists no other local peak. Specify a number between 1 and 192. As shown in the figures below, the smaller number to make the search range narrow, the more local peaks are found. Besides, enough a large number was specified, the highest 3D point of the whole 3D map is found as a local peak. If a target workpiece is long, specify a number which is roughly half of the width of the workpiece as the set value. Otherwise, specify a number which is roughly half of the size of the workpiece.

						Title	Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)		
						Draw. No.	B-83304EN/04-01		
1	2016.06.17	T. Satou	Initial creation						
<b>Ed</b>	<b>Date</b>	<b>Design</b>		<b>Description</b>					
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>		<b>Apprv</b>			
							<b>FANUC CORPORATION</b>	Sheet	18/33




Search Range: Narrow



Search Range: Wide

### Min. Neighborhood Pnts

Set the minimum permissible number of 3D points around each local peak. If the number of 3D points which are not at the center of the search range but in the search range is lower than the set number, the center 3D point of the search range can not be detected as a local peak. If a number R is set as [Search Range], specify a number between 1 and  $(2R + 1)^2 - 1$ .



1	2016.06.17	T. Satou	Initial creation						
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>			<b>FANUC CORPORATION</b>	Sheet	19/33	
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>	<b>Apprv</b>				

Title Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER  $\mu$ R-Vision OPERATOR'S MANUAL (Reference)

Draw. No. B-83304EN/04-01

FANUC CORPORATION Sheet 19/33

### Plot Found Pos+Search Range

In addition to [Plot Found Pos], a square of search range is displayed.

### Plot Found Pos+Neighbor Points


In addition to [Plot Found Pos], 3D points around the found position are displayed in cyan.

### F6 2-3D Snap

A 2D camera image is snapped and a 3D map is acquired.

## 7.35.2 Running a Test

Press F4 FIND to run a test and see if the tool can find workpieces properly.



### Found

The number of found local peaks is displayed.

### Time to Find

Time to find is displayed (units: ms).

### Found Result Table

The following values are displayed.

### Vt, Hz

Found local peak position on a camera image.

### X, Y, Z

Coordinate values of the found local peak (units: mm).

### Score

Score of the found local peak. Z value of found position is output as the score after scaled so that the score becomes 100 when Z value of found position is greater than or equal to maximum Z value of [Range] in the

1	2016.06.17	T. Satou	Initial creation			Title			
						Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)			
						Draw. No.			
						B-83304EN/04-01			
Ed	Date	Design	Description			<b>FANUC CORPORATION</b>			
Date	2016.06.17	Desig	T. Satou	Check	Apprv				

3D Area Sensor Vision Process setup and becomes 0 when that is less than or equal to minimum Z value of [Range] in the 3D Area Sensor Vision Process setup.


**Num. Comp. Points**

The number of 3D points within the area whose center position is on the found local peak and size is specified by the [Search Range].

				Title		Addition of the description about 3D model matching function for FANUC Robot series R-30iB/ R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)	
				Draw. No.		B-83304EN/04-01	
1	2016.06.17	T. Satou	Initial creation				
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>				
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>		<b>Apprv</b>	
<b>FANUC CORPORATION</b>							Sheet 21/33

## 7.47 ONE-SIGHT-MODEL LOCATOR TOOL

This command tool creates a 3D model from a 3D map and detects workpieces by using the 3D model. This command tool can be used in 3D Model Based vision process. If you select One-Sight-Model Locator tool in the tree view of the setup page for the vision process, a setup page like the one shown below appears.



To execute test running, setting of input, model and search area need to be completed. For the first step, completes these settings, and the next, adjusts other settings with executing test running.

### 7.47.1 Setting the Parameters of Input Data

#### Preprocess Tool

Select a command tool which removes unnecessary 3D points. A preceding Area Sensor Preprocess tool or another One-Sight-Model Locator tool can be selected. When a One-Sight-Model Locator tool selects another One-Sight-Model Locator tool as the preprocess tool, 3D points around results of specified tool are removed, and the detection time of the One-Sight-Model Locator tool will be shorter.

### 7.47.2 Setting up a Model


#### Set the Model Area

For the first step of setting model data, specify a rectangular area which encloses the workpiece on a camera image.

First, place the workpiece near the center of the measurement area. Then press F6 2-3D SNAP to snap the image of the workpiece and acquire its 3D map.


Next, press [Area]. Then, setup page for window is displayed. Enclose the workpiece by the displayed red rectangle, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, "Window Setup".

1	2016.06.17	T. Satou	Initial creation						
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>			<b>FANUC CORPORATION</b>	Sheet	22/33	
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>	<b>Apprv</b>				



### Remove Unnecessary 3D points


The following page is displayed after setting the model area.



In the next step, remove unnecessary 3D points from the model area. Remove 3D points which belong to the background or don't suitable for detection from the model data by the mask.

To edit a training mask, press the [Edit] button on the [Mask] line. When an enlarged view of the model area appears on the image display control, fill the unnecessary 3D points with the color of red. For detailed information about the operation method, see Subsection 3.7.14, "Editing Masks".

				Title		Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)	
				Draw. No.		B-83304EN/04-01	
1	2016.06.17	T. Satou	Initial creation				
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>				
Date	2016.06.17	Desig	T. Satou	Check	Apprv		
<b>FANUC CORPORATION</b>						Sheet	23/33



### Classify 3D points by the faces

In a setup page after setting the model area, 3D points are classified by continuous face. The faces are determined by the following parameters.

#### Z-Height

A threshold to determine whether 3D points are continuous or not. Two 3D points are assumed that they belong to different faces when the difference of their height is larger than it.

#### Min. Blob Size

A threshold of the size of continuous faces. Continuous faces are recognized as blobs of 3D points. When their size is smaller than this parameter, feature points, mentioned below, are not generated on the face.

Adjust them so that blobs of 3D points represent faces of the workpiece correctly. After the adjustment, press F5 NEXT.


**⚠ CAUTION**  
 After F5 NEXT is pressed, the process to extract feature points from 3D points represent faces is initiated. The process can take long time, several ten seconds, according to the state of 3D points.

### Set Feature Points

The following page is displayed after setting of the classification.

1	2016.06.17	T. Satou	Initial creation						
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>			<b>FANUC CORPORATION</b>	Sheet	24/33	
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>	<b>Apprv</b>				






For fast detection, this command tool extracts feature points from the model data and deals with them as priority. Feature points are automatically extracted from each faces which are determined in the previous step. Feature points are displayed in green in the image display. [Feature Interval] defines intervals between feature points. By changing them, you can also control the number of feature points. More feature points lead less misdetection but also longer detection time. Feature points of 10 to 30 points will be suitable. After the setting of feature points, press F5 FINISH. After that, the conventional setup page is displayed but you need to set X-axis of model data to complete setting the model.

**⚠ CAUTION**  
 The process to extract feature points can take long time, several ten seconds, according to the state of 3D points.

### Set Emphasis Area

Use an emphasis area when the position of the workpiece cannot be determined correctly unless attention is paid to a small characteristic part of that workpiece. To set an emphasis area, press the [Set] button on the [Emphasis Area] line. When the [Set] button is pressed, the following screen is displayed.

1	2016.06.17	T. Satou	Initial creation						
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>			<b>FANUC CORPORATION</b>	Sheet	25/33	
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>	<b>Apprv</b>				




An emphasis area is set by the continuous face. In the list view, select a face to be emphasis area, and press the [Add Emphasis Area]. For the emphasis area, the feature score, mentioned below, is calculated independently from the whole feature score. The workpiece whose score of emphasis area is lower than [Feature Score Threshold] is not detected.

### Set X-axis

In this command tool, a posture of workpiece to be searched is specified by the axes of an orthogonal coordinate. Here, set the X axis of the coordinate. The Z axis corresponds to that of the offset frame. Y axis is calculated from X and Z axis.

First, press the [Set] button on the [Model X-Axis] line. When the [Set] button is pressed, the following screen is displayed.



When an enlarged view of the model area appears on the image display control, set the line to be parallel to the X axis of the model, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.12, "Single Line Setup".

				Title		Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)	
				Draw. No.		B-83304EN/04-01	
1	2016.06.17	T. Satou	Initial creation				
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>				
Date	2016.06.17	Desig	T. Satou	Check	Apprv	<b>FANUC CORPORATION</b>	
						Sheet	26/33

## 7.47.3 Setting the Parameters of Detection

Detection process of this command tool can be classified into two processes. The first is search process, which determines locations of workpieces quickly but roughly by using feature points. After the search process, align process is initiated. The process determines detailed locations by using other 3D points of the model. After the setting of model, set [Search Area] and, if needed, tune other detection parameters.

### 7.47.3.1 Search Parameter

#### Feature Score Threshold

This command tool calculates a ratio of feature points which has been matched to a 3D map in the search process. The ratio is outputted as a feature score. If the feature score is lower than the threshold, the workpiece is not detected.

#### Normal Check

When [Enabled] is checked, this command tool matches feature points to a 3D map with normal directions. In the case that normal directions are stable, detection processes can be shortened by this function.

To use this function, you must change the Area Sensor Preprocess tool so that the tool calculates normal directions.

#### Search Interval

Specify a distance interval in search process. The default value is automatically determined by the model. As this item becomes larger, the detection time becomes shorter. As it becomes smaller, searched location becomes more precisely.

The following item, Search Angle Interval, is a parameter which is automatically calculated. Ideally Search Angle Interval should be about 5 to 10 degree. Please confirm that the value is not so far off.

#### Overlap Threshold


If two search results overlap spatially more than this threshold, the result of lower Search Score is discarded. Search Score is the ratio by which a search result matches to a 3D map. When you run a test, search score of each result is displayed in the result view. Search score tends to be larger than score because the matching is done by the lax standards.

#### Search Area


This command tool can possess multiple search areas. An search area includes an area of location to be searched, which is [Origin Search Area], and an area of posture of workpiece, which is [Angle Search Ranges].

It is important to set as small search areas as possible in order to reduce the processing time. For example, in the case of the following figure, two search areas which cover each side and each posture lead shorter detections than a large search area.

				Title		Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER $\mathcal{R}$ Vision OPERATOR'S MANUAL (Reference)		
				Draw. No.		B-83304EN/04-01		
1	2016.06.17	T. Satou	Initial creation					
Ed	Date	Design	Description					
Date	2016.06.17	Desig	T. Satou	Check		Apprv		
<b>FANUC CORPORATION</b>							Sheet	27/33




### Adding Search Area

You can add a search area by pressing the  button.

### Copying Search Area

You can copy the displayed search area by pressing the  button.

### Deleting Search Area

You can delete the displayed search area by pressing the  button.


### Search Area Number

Specify the number of a search area to display in the setup page.


### Origin Search Area

Specify the area to search the origin of model in a XY image. You can confirm the origin of the model by setting [Model XY Image] in [Image Display Mode]. When [Model XY Image] is selected, the origin is displayed as follows.

							Title		Addition of the description about 3D model matching function for FANUC Robot series R-30iB/ R-30iB Mate CONTROLLER $\mu$ RVision OPERATOR'S MANUAL (Reference)	
							Draw. No.		B-83304EN/04-01	
1	2016.06.17	T. Satou	Initial creation							
Ed	Date	Design	Description				FANUC CORPORATION		Sheet	28/33
	2016.06.17	Desig	T. Satou	Check		Apprv				



To set [Origin Search Area], press the [Set] button on the same line. Then, setup page for window is displayed as follows. Enclose the area where the origin can exist within the displayed red rectangle, and press F4 OK. For detailed information about the operation method, see Subsection 3.7.9, “Window Setup”.



### Angle Search Ranges

Specify the ranges of rotation angles to be searched. In this command tool, the rotation is defined by rotations around X-axis, Y-axis and Z-axis. For each axis, [Min. angle] and [Max. angle] need to be specified.

### 7.47.3.2 Align Parameter

#### Matching Level

Select from [Fast], [Normal] and [Fine]. [Fast] prioritizes the process time. On the other hand, [Fine] prioritizes the precision of alignment. [Normal] is a middle setting of [Fast] and [Fine].

1	2016.06.17	T. Satou	Initial creation									
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>							<b>FANUC CORPORATION</b>	Sheet	29/33
<b>Date</b>	2016.06.17	<b>Desig</b>	T. Satou	<b>Check</b>		<b>Apprv</b>						

Title Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)

Draw. No. B-83304EN/04-01

## Align Method

By default, [Min Point to Plane] is selected. The precision of alignment can be improved by changing this item according to a 3D map.

### Min Point to Point

This option is effective when normal directions cannot be calculated stably because of few 3D points on the workpiece. When this option is selected, this command tool aligns to decrease distance between 3D points of the model and those of the 3D map.

### Min Point to Plane

When normal direction can be calculated stably, this option is more effective than [Min Point to Point] in most cases. To use this option, you must change the Area Sensor Preprocess tool so that the tool calculates normal directions.

## Score Threshold

This command tool calculates a ratio by which a found result matches to a 3D Map in the align process. The ratio is outputted as a score. If the score is lower than the threshold, the workpiece is not detected.


## 7.47.4 Other Parameters

### Model ID

When you have taught two or more Locator tools and want to identify which tool was used to detect the workpiece, assign a distinct model ID to each tool. The model ID of the tool, which found the workpieces, is reported to the robot controller along with offset data. This enables the robot program to identify the type of the found workpieces.

### Incongruous Points

When this checkbox is checked, incongruous 3D points in a 3D map with a detected workpiece are counted. If the number of incongruous points is larger than [Inc. Points Thresh], the workpiece is not detected. It leads less misdetection.



The upper figure shows incongruous points, as an example. The workpiece which is framed in red is a misdetection. The 3D points which must not be measured if the detection is correct are counted as incongruous points.

				Title		Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER $\mu$ RVision OPERATOR'S MANUAL (Reference)	
				Draw. No.		B-83304EN/04-01	
1	2016.06.17	T. Satou	Initial creation				
Ed	Date	Design	Description				
Date	2016.06.17	Desig	T. Satou	Check		Apprv	
<b>FANUC CORPORATION</b>						Sheet	30/33

**Inc. Points Thresh**

Specify the threshold for incongruous points. If the number of incongruous points is larger than the threshold, the workpiece is not detected. This item is available when [Incongruous Points] is checked.

**Time-out**

If the location process takes longer than the time specified here, the command tool ends the process without finding all of the workpieces.

**Image Display Mode**

Select the image display mode for the Setup Page.

**Camera Image**

2D camera image is displayed.

**3D Map**

3D map is displayed.

**XY Image**

A height image of a 3D map is displayed. The height image is created by projecting 3D Map to X-Y plane.

**Model**

The camera image in the model area is displayed. On the image, 3D points which belong to the model are plotted in cyan and feature points are plotted in green

**Model XY Image**

A height image of the model is displayed. The origin of the model is displayed in green. The X-axis is displayed in cyan.

**Display Result**

Select the displaying results for the Setup Page. This item is changed automatically to [FIND Results] when F4 FIND is pressed.

**FIND Results**

Conclusive results of detection are displayed. Results displayed with this mode are passed to a parent vision process.

**Discarded in Align**

In addition to the conclusive results, results which are discarded in align process are displayed. The discarded results are also displayed in list view in red.

**Search Result**

Results of search process are displayed. Use this mode when you tuning search parameters.

**Param. Evaluation**

This command tool tests detection parameters by executing detection, internally, with model data. When [Execute] is pressed, the internal detection is executed and the following items are displayed.

					Title	Addition of the description about 3D model matching function for FANUC Robot series R-30iB/ R-30iB Mate CONTROLLER iR Vision OPERATOR'S MANUAL (Reference)		
					Draw. No.	B-83304EN/04-01		
1	2016.06.17	T.Satou	Initial creation					
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>			<b>FANUC CORPORATION</b>	Sheet	31/33
<b>Date</b>	2016.06.17	<b>Desig</b>	T.Satou	<b>Check</b>	<b>Apprv</b>			

### Position Error Ave.

Average of position errors which are estimated by the internal detection.

### Posture Error Ave.

Average of posture errors which are estimated by the internal detection.

### Proc. Time Ave.

Average of processing time to align one workpiece which is estimated by the internal detection.

### Success Rate

The success rate in the internal detection. If this item does not reach the 100%, ScoreThreshold or Search Interval will be improper.

## 7.47.5 Postprocess of 3D Map

This command tool removes unnecessary 3D points for other tools like Area Sensor Preprocess tool. 3D points on a detected workpiece are not necessary for other tools in most cases. This tool removes 3D points around own results. You can confirm 3D map after the removal on the setup page of a command tool which set the removing One-Sight-Model Locator tool in [Preprocess Tool] by setting [3D Map] in [Image Display Mode].

### Remove Near Results


When the checkbox is checked, this command tool removes 3D points around own results. When you want to shorten the detection time of multiple One-Sight-Model Locator tools, check the checkbox.

### RM. Score Thresh.

This command tool removes 3D points around only the results whose score is higher than this item. By setting higher value than [Score Threshold], you can remove 3D points around only reliable results.

## 7.47.6 Running a Test

Press F4 FIND to run a test and see if the tool can find workpieces properly.



				Title		Addition of the description about 3D model matching function for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)		
				Draw. No.		B-83304EN/04-01		
1	2016.06.17	T. Satou	Initial creation		<b>FANUC CORPORATION</b> Sheet 32/33			
<b>Ed</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>					
Date	2016.06.17	Desig	T. Satou	Check				










# 12 OTHER OPTIONS

## 12.1.12 TRANSROT

This program separates a two-dimensional fixed frame offset into the fixed frame offset for translation offset and the tool offset for rotation.

The pick position should be taught in a position register instead of a position data P[x] in a TP program. The user frame of the robot position taught in the position register and the user frame specified as the offset frame selected in the vision process must be the same. The output fixed frame offset for translation is in respect to the user frame specified as the offset frame in the vision process. The output tool offset for rotation is in respect to the tool frame selected for the pick position.

 **CAUTION**  
This KAREL program supports only the motion group 1.

### Argument 1: Position register number (Input)

Specify the number of position register storing the pick position.

### Argument 2: Vision register number (Input)

Specify the number of vision register storing the input vision offset.

### Argument 3: Vision register number (Output)

Specify the number of vision register to store the fixed frame offset for translation.

### Argument 4: Vision register number (Output)

Specify the number of vision register to store the tool offset for rotation. It is optional.  
Note that argument 4 is required when argument 5 is specified. Then specify 0 as argument 4.

### Argument 5: Register number (Output)

Specify the number of the register to store the error number. It is optional.

In the register to store the error number, one of the values shown below will be set depending on the error that occurs:

- 0: The program ended normally.
- 1601: A required argument is not specified.
- 1602: An invalid argument is specified.
- 1603: The same vision register is specified for multiple arguments.
- 1604: The specified vision register for argument 2 cannot be read.
- 1605: The specified vision register for argument 3 cannot be read.
- 1606: The specified vision register for argument 4 cannot be read.
- 1607: The specified vision register has not been initialized.
- 1608: The format of the specified position register is invalid.
- 1609: The specified position register has not been initialized.
- 1610: The specified position register cannot be read.

						Title Addition of the description about Separate Translation and Rotation for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)	
					Draw No.	B-83304EN/04-02	
Ed.	Date	Design	Description			<b>FANUC CORPORATION</b>	Page 2/3
	Date	2018.2.2	Design.	Y.Ota	Apprv.		

## Usage example 1

Shown below is an example that picks a part without rotation and places the part with rotation.

```

1: VISION RUN_FIND 'VISION1'
2: VISION GET_OFFSET 'VISION1' VR[1] JMP LBL[99]
3: CALL TRANSROT(5, 1, 2, 3, 10)
4: L PR[5] 100mm/sec FINE VOFFSET, VR[2]
5: ...
6: L PR[6] 100mm/sec FINE VOFFSET, VR[3]
    
```

In this example, the vision offset stored in VR[1] is separated into two offset data using the pick position stored in PR[5]. The fixed frame offset for translation is output to VR[2] and the tool offset for rotation is output to VR[3].

					Title	Addition of the description about Separate Translation and Rotation for FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)				
						Draw No.	B-83304EN/04-02			
<b>Ed.</b>	<b>Date</b>	<b>Design</b>	<b>Description</b>				<b>FANUC CORPORATION</b>			Page
	Date	2018.2.2	Design.	Y.Ota	Apprv.					



Modification of FANUC Robot series R-30iB/R-30iB Mate CONTROLLER

iRVision OPERATOR'S MANUAL (Reference)

1.Type of applied technical documents

Name	FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)
Spec.No./Ed.	B-83304EN/04

2.Summary of Change

Group	Name/Outline	New, Add, Correct, Delete	Applicable Date
Basic			
Optional Function	Add following 9. 4. 11 VD CONV_V8_V9	Add	Immediately
Unit			
Maintenance Parts			
Notice			
Correction			
Another			

<b>Title</b>	Modification of FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)	Ed 01	<b>Draw</b>	B-83304EN / 04 - 3
		Date 2021. 3/1		

## 9.4.11 VD CONV\_V8\_V9

VD CONV\_V8\_V9 is the KAREL program to convert vision data for R-30iB to that for R-30iB Plus. All vision data displayed in the list of vision data are converted and are output to the specified folder.

### Argument 1: Folder name

Specify a folder where converted vision data are output as a character string.

### Program Example

Shown below is an example that converts vision data and output the converted VD files to MC:¥DIR folder. If this TP program is executed on the R-30iB controller, converted vision data for R-30iB Plus are output to the specified folder.

```
1: CALL VD CONV_V8_V9('MC:¥DIR')
```

### CAUTION

- 1 Settings that do not exist in R-30iB Plus are not converted.
- 2 When there is vision data that does not support the conversion, CVIS-109 occurs. If the conversion fails, removing unsupported command tools makes it convertible.
- 3 Following vision data do not support the conversion.
  - Vision processes and command tools for 3D Area Sensor and 3D Laser Vision Sensor
  - 2D Calibration-free, Visual Tracking, Image To Points
  - Combination Locator Tool, Conditional Execution Tool, Position Adjustment Tool, Count Tool, Arithmetic Calculation Tool, Geometric Calculation Tool, Statistics Calculation Tool, Position Calculation Tool, Image Preprocess Tool, Edge Points Locator Tool, Selected Edge Points Locator Tool, Color Component Tool, Image Arithmetic Tool, Flat Field Tool
- 4 Whether the conversion succeeded or not is written in a log file named as LOGFILE.TXT. This file is output to the same folder with the converted vision data Description examples are as follows.  
In case of success: A.VD was converted.  
In case of failure: B.VD cannot be converted with CVIS-109.

<b>Title</b>	Modification of FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)	Ed 01	<b>Draw</b>	B-83304EN / 04 - 3
		Date 2021. 3/1		



【Version history】

Ed	Date	Description
01	2021/03/01	The first edition registration

<b>Title</b>	Modification of FANUC Robot series R-30iB/R-30iB Mate CONTROLLER iRVision OPERATOR'S MANUAL (Reference)	<b>Ed</b> 01	<b>Draw</b> B-83304EN / 04 - 3
		<b>Date</b> 2021. 3/1	
			<b>Sheet</b> 3/3



# INDEX

## <Number>

1-D BARCODE TOOL .....	379
2-D BARCODE TOOL .....	386
2D CALIBRATION-FREE VISION PROCESS .....	111
2D Measurement setups .....	134,143,151,156
2D MULTI-VIEW VISION PROCESS .....	97
2D SINGLE VIEW VISION PROCESS .....	91
3D AREA SENSOR .....	182
3D AREA SENSOR VISION PROCESS .....	194
3D LASER VISION CALIBRATION .....	77
3D TRI-VIEW VISION PROCESS .....	123
3DL CROSS-SECTION VISION PROCESS .....	147
3DL CURVED SURFACE SINGLE VIEW VISION PROCESS .....	153
3DL CYLINDER TOOL .....	314
3DL DISPL COMMAND TOOL .....	311
3DL MULTI-VIEW VISION PROCESS .....	139
3DL PLANE COMMAND TOOL .....	306
3DL SINGLE VIEW VISION PROCESS .....	131
4D GRAPHICS .....	564

## <A>

ABOUT VISION SYSTEM .....	4
ACQVAMAP, CLRVAMAP .....	484
Add Logged Images .....	220
Add Snapped Images .....	223
Adding Child Tools .....	296
ADJ_OFS .....	554
Adjusting Parameters .....	334
Adjusting the Location Parameters . 212,250,263,270,278, 307,312,316	
Adjusting the Parameters .....	394,397
Adjusting the Range Parameters .....	327
Adjusting the Search Parameters .....	323
Advanced Mode .....	121
Application Consideration .....	123
APPLICATION DATA .....	468
AREA SENSOR BLOB LOCATOR TOOL .....	414
AREA SENSOR BOX LOCATOR TOOL .....	445
AREA SENSOR COG TOOL .....	421
AREA SENSOR CYLINDER LOCATOR TOOL .....	450
AREA SENSOR GF LOCATOR TOOL .....	433
AREA SENSOR PEAK LOCATOR TOOL .....	410
AREA SENSOR PLANE TOOL .....	425
AREA SENSOR PREPROCESS TOOL .....	405
ARITHMETIC CALCULATION TOOL .....	339
ASYNCHRONOUS EXECUTION .....	480
Automatic Re-Calibration .....	71,77,83
Available Child Tools .....	336
Average Model Shape .....	229

## <B>

Background removal .....	325
Backing up Vision Data .....	27

BASIC CONFIGURATION .....	4
BASIC OPERATIONS .....	10
BASLER USB CAMERA .....	65
BEAD INSPECTION TOOL .....	332
BIN-PICK SEARCH VISION PROCESS .....	167
BLOB LOCATOR TOOL .....	260
BPGETAABB, BPGETOBB .....	509

## <C>

Calibrating Camera .....	66,77,84
Calibration data menu .....	516
CALIBRATION GRID .....	541
CALIBRATION GRID FRAME .....	541
CAMERA CALIBRATION .....	6,66
Camera Calibration Tools .....	73
Camera position .....	124
CAMERA SETUP .....	59
CAMERA_CALIB .....	478
Canceling a Password .....	594
Changing the Number of Vision Registers .....	474
Checking Calibration Data .....	70,76,81,89
Checking Calibration Points .....	69,75,80,88
CHK_POS .....	558
Circle Setup .....	43
Color Camera .....	61
COLOR COMPONENT TOOL .....	454
COLOR EXTRACTION TOOL .....	373
COLOR SORTING TOOL .....	438
COMBINATION LOCATOR TOOL .....	275
COMMAND TOOLS .....	207
Communication Cable .....	573
CONDITIONAL EXECUTION TOOL .....	293
Confirm Images and Results .....	224
Confirm Learning Model .....	229
Connecting a Communication Cable .....	573
CONNECTING A SETUP PC .....	573
Copying Vision Data .....	13
COUNT TOOL .....	337
Creating New Vision Data .....	12
CURVED SURFACE LOCATOR TOOL .....	248

## <D>

DATA TRANSFER BETWEEN ROBOTS .....	563
Deleting a Vision Log of a Specified Date .....	538
Deleting Vision Data .....	13
Deleting Vision Logs of All Dates .....	539
DEPALLETIZING VISION PROCESS .....	104
Destination Pose .....	116
Detail Screen of a Vision Register .....	472
Determining the IP Addresses .....	574
Display Modes .....	328
Double Line Setup .....	45
Drop-Down Box .....	28

**<E>**

EDGE HISTOGRAM TOOL .....	285
EDGE PAIR LOCATOR TOOL .....	277
EDGE POINTS LOCATOR TOOL .....	394
Editing Mask .....	590
Editing Masks .....	47
Editing Vision Data .....	14
Encoder count .....	479
EVALUATION TOOL .....	319
Examples .....	460
Executing calibration program .....	526
Exporting Vision Log of a Specified Date .....	537
Exporting Vision Logs of All Dates .....	538

**<F>**

File Configuration of the Exported Vision Log .....	540
Filters .....	326,358
FIXED CAMERA AND ROBOT-MOUNTED CAMERA .....	5
FIXED FRAME OFFSET AND TOOL OFFSET .....	5
FLAT FIELD TOOL .....	463
FLOATING FRAME VISION PROCESS .....	200
Found Pattern .....	239
Found position .....	479
Freezing Vision Runtime .....	20
FREQUENTLY ASKED QUESTIONS .....	595
FREQUENTLY-USED OPERATIONS .....	27
Function Keys .....	587

**<G>**

Generating calibration program .....	524
GEOMETRIC CALCULATION TOOL .....	341
GET_NFOUND .....	477
GET_OFFSET .....	476
GET_PASSFAIL .....	477
GET_READING .....	478
GETCROSS .....	561
GPM LOCATOR TOOL .....	207
Grayscale Camera .....	60
GRID FRAME SETTING .....	527
GRID PATTERN CALIBRATION .....	66
Guideline .....	274

**<H>**

HISTOGRAM TOOL .....	281
----------------------	-----

**<I>**

IMAGE ARITHMETIC TOOL .....	457
Image Binarization .....	260
Image Display Control .....	29
IMAGE FILTER TOOL .....	356
Image Playback .....	56
IMAGE PREPROCESS TOOL .....	355
Image Preprocessing .....	325
IMAGE TO POINTS VISION PROCESS .....	179
Importing a Vision Log of a Specified Date .....	539
Installing Vision UIF Controls .....	583
INTER-CONTROLLER COMMUNICATION .....	27

INVERSE .....	549
iPENDANT FIRMWARE UPDATE .....	599
iCONNECT .....	568
IRVBKLSH .....	502
IRVDISPLAY4D .....	568
IRVGETMSR, IRVGETMSL .....	506
IRVHOMING .....	503
IRVICONN .....	569
IRVLEDON, IRVLEDOFF .....	483
IRVMUXOFF, IRVMUXON, IRVMUXCHK .....	503
IRVOVRDANYVP .....	508
IRVSNAP, IRVNFIND .....	481
IRVTRAIN .....	487

**<K>**

KAREL TOOLS .....	481
KOWA DIGITAL CAMERA .....	59
KOWA USB CAMERA .....	64

**<L>**

Laser measurement setup .....	149,157
Laser measurement setups .....	135,143
Learning .....	113
Lighting environment .....	258
LINE LOCATOR TOOL .....	268
List View .....	28
LOADNOM and SAVENOM .....	552
Location parameters .....	241
LOCK VREG .....	475

**<M>**

Main menu .....	514
MATRIX .....	547
Maximum Vision Data That can be Created .....	7
MEASUREMENT OUTPUT TOOL .....	304
Measurement value .....	479
Measuring target position .....	521
MERGE3D2 .....	550
Model ID .....	479
Model Learning .....	216
Model pattern .....	236,258
Model Train File .....	488
Modifying Setting of Windows Firewall .....	580
Modifying Settings of Internet Explorer .....	576
Moving Control Point .....	590
MULTI-LOCATOR TOOL .....	296
MULTI-WINDOW TOOL .....	298

**<O>**

OBSTRUCTION MEASUREMENT TOOL .....	429
Offset data .....	480
OFFSET LIMIT .....	469
OFS_RJ3 .....	545
OPENING VISION PAGES .....	582
Operation Methods .....	497
OPERATIONS ON PC .....	587
OTHER OPTIONS .....	544
Overridable Parameter .....	410,413,421,425,428,433,437,

450,454	
Overridable Parameters	97,103,110,131,138,146,153,160, 167,173,176,179,182,194,199,205,231,254,267,274, 276,281,285,292,295,297,300,304,306,310,314,318, 323,330,336,338,340,343,345,350,355,358,379,383, 390,397,402,405,445,456,460,467
OVERRIDE	479
Overview	513,528
Overview and functions	232,254
Overview of Model Learning Wizard	217
OVERVIEW OF THE MANUAL	1
<b>&lt;P&gt;</b>	
PASSWORD PROTECTION OF VISION DATA	58
PC UIF Troubles	595
Performing Calibration	518
POSITION ADJUSTMENT TOOL	300
POSITION CALCULATION TOOL	345
Precautions	501
PREFACE	1
Preparing camera calibration tool	520
PROCEDURES A	600
PROCEDURES B	601
PROGRAM COMMANDS	474
Projection FOV and Standoff of Projector Unit	182
<b>&lt;R&gt;</b>	
READER VISION PROCESS	177
Reference data	136,144,158
Refreshing the Display	540
RELATED MANUALS	2
Remove Needless Features	228
Restoring Vision Data	27
RESTRICTING LOGIN TO VISION SETUP	593
Result View	37
ROBOT-GENERATED GRID CALIBRATION	73,513
RSETNREG, RSETPREG	563
Run Measurement	533
RUN_FIND	476
Running a Test	95,102,109,129,137,145,152,159,165, 171,176,178,181,198,204,215,253,266,273,276,280, 284,291,295,297,299,303,305,309,313,317,322,329, 335,338,340,342,344,349,354,355,358,378,382,389, 396,401,404,409,412,419,424,427,432,436,444,449, 453,456,460,467
<b>&lt;S&gt;</b>	
SAFETY PRECAUTIONS	s-1
SEARCH AREA RESTRICTION TOOL	402
Segmented-Line Setup	40
Select Method to Add Images	219
SELECTED EDGE POINTS LOCATOR TOOL	397
Selecting and mounting the target	518
Selecting calibration data	521
SET_REFERENCE	478
Setting a Filter to List of Vision Data	16
Setting a Measurement Plane	174
Setting a Position where Plied Workpieces State Changed	404
Setting a Window	299
Setting Based on Measurement with a Camera	543
Setting Based on Touch-up	542
Setting Exposure Mode	53
Setting Filter to Vision Runtime	19
Setting Parameters	300
Setting Password Protection	593
Setting Points	38
Setting the Device	536
Setting the IP Address of the PC	575
Setting the IP Address of the Robot Controller	574
Setting the Measurement Area	282,286,306,311,315,422, 426,430
Setting the Measurement Values	304
Setting the Parameters	293,319,337,339,341,343,345,351, 356,374,380,386,403,409,411,414,423,426,431,434, 439,446,455,457,463,529
Setting the Parameters for Finding 3D Blobs	452
Setting the Parameters for Finding Cylinder	452
Setting the Parameters of Bottom Removal	406
Setting the Parameters of Container Removal	406
Setting the Parameters of Outlier Removal	408
Setting the Paramters	355
Setting the Preprocess Tool	451
Setting the Reference Position	96,103,110,130,138,146, 160,166,172,199,205
Setting the Register	296,298
Setting the Search Window	277
Setting up a Camera View	101,127,142,190
Setting up a Model	207,248,268,451
Setting up a Vision Process	91,98,104,111,125,132,139, 147,154,161,167,173,177,180,186,195,201
Setting up an Inspection Line	332
Setup	275
Setup Guidelines	118,232,254
Setup PC	573
Setup Procedures	190
Shifting windows based on a locator tool's results	352
Shifting windows based on another vision process' results	352
Shifting windows based on interference avoidance results	354
Single Line Setup	44
SINGLE VIEW INSPECTION VISION PROCESS	173
SINGLE VIEW VISUAL TRACKING	161
SONY ANALOG CAMERA	63
SORT_RJ3	555
Sorting	55
Start position menu	518
STARTING FROM A ROBOT PROGRAM	471
STATISTIC CALCULATION TOOL	343
Structure of the Menus	514
STVS1	560
Supplementary Explanation	193
SURFACE FLAW INSPECTION TOOL	323

**<T>**

Tab .....	37
Target position menu.....	517
Teaching a Model.....	262,278
TEACHING FROM PC .....	573
Terminologies .....	384,390
Test Run.....	117
Text Box.....	27
To Create More Vision Data .....	7
Training the Color Extraction Parameters.....	375
Tree View.....	33
Troubleshooting .....	535
Types of Vision Data .....	6

**<U>**

UNLOCK VREG .....	476
USER FRAME AND USER TOOL.....	8
UTILITY MENU .....	513

**<V>**

Verifying Vision Data Detail Information .....	14
VISION CONFIG .....	24
VISION DATA .....	6
Vision Data Edit Screen .....	588
Vision Data List Screen .....	587
Vision Execution.....	476
VISION LOG.....	21
VISION LOG MENU .....	536
Vision Offset.....	474
VISION OVERRIDE .....	468
VISION PROCESSES .....	91
Vision Register List Screen.....	471
VISION REGISTERS .....	471,479
VISION RUN-TIME.....	18
VISION SETUP .....	10
VISION SUPPORT TOOLS .....	544
Vision UIF Control Cannot be Installed.....	598
VISION-GUIDED ROBOT MOTION.....	4
VISUAL TRACKING CALIBRATION .....	84
VL_EXPORT .....	562
VOFFSET .....	474
VOFFSET CONDITION .....	475

**<W>**

What to consider .....	123
Window Setup.....	38
WINDOW SHIFT TOOL.....	350

# REVISION RECORD

<b>Edition</b>	<b>Date</b>	<b>Contents</b>
04	Jan., 2016	Applied to series 7DC3/18 (V8.30P/18)
03	July, 2014	Applied to series 7DC3 (V8.30P)
02	June, 2013	Applied to series 7DC2 (V8.20P)
01	June, 2012	

**B-83304EN/04**



\* B - 8 3 3 0 4 E N / 0 4 . 0 3 \*