FANUC Robot R-2000iC

MECHANICAL UNIT OPERATOR'S MANUAL

B-83644EN/09

Original Instructions

Thank you very much for purchasing FANUC Robot.

Before using the Robot, be sure to read the "FANUC Robot series SAFETY HANDBOOK (B-80687EN)" and understand the content.

- No part of this manual may be reproduced in any form.
- All specifications and designs are subject to change without notice.

The products in this manual are controlled based on Japan's "Foreign Exchange and Foreign Trade Law". The export from Japan may be subject to an export license by the government of Japan.

Further, re-export to another country may be subject to the license of the government of the country from where the product is re-exported. Furthermore, the product may also be controlled by re-export regulations of the United States government.

Should you wish to export or re-export these products, please contact FANUC for advice.

In this manual, we endeavor to include all pertinent matters. There are, however, a very large number of operations that must not or cannot be performed, and if the manual contained them all, it would be enormous in volume. It is, therefore, requested to assume that any operations that are not explicitly described as being possible are "not possible".

SAFETY PRECAUTIONS

This chapter describes the precautions which must be followed to enable the safe use of the robot. Before using the robot, be sure to read this chapter thoroughly.

For detailed functions of the robot operation, read the relevant operator's manual to understand fully its specification.

For the safety of the operator and the system, follow all safety precautions when operating a robot and its peripheral equipment installed in a work cell.

For safe use of FANUC robots, you must read and follow the instructions in the "FANUC Robot series SAFETY HANDBOOK (B-80687EN)".

1 PERSONNEL

Personnel can be classified as follows.

Operator:

- Turns the robot controller power ON/OFF
- Starts the robot program from operator panel

Programmer or Teaching operator:

- Operates the robot
- Teaches the robot inside the safeguarded space

Maintenance technician:

- Operates the robot
- Teaches the robot inside the safeguarded space
- Performs maintenance (repair, adjustment, replacement)
- The operator is not allowed to work in the safeguarded space.
- The programmer or teaching operator and maintenance technician are allowed to work in the safeguarded space. Work carried out in the safeguarded space include transportation, installation, teaching, adjustment, and maintenance.
- To work inside the safeguarded space, the person must be trained on proper robot operation.

Table 1 (a) lists the work outside the safeguarded space. In this table, the symbol "O" means the work allowed to be carried out by the specified personnel.

Table 1 (a) List of work outside the Safeguarded Space

	Operator	Programmer or Teaching operator	Maintenance technician
Turn power ON/OFF to Robot controller	0	0	0
Select operating mode (AUTO/T1/T2)		0	0
Select remote/local mode		0	0
Select robot program with teach pendant		0	0
Select robot program with external device		0	0
Start robot program with operator's panel	0	0	0
Start robot program with teach pendant		0	0
Reset alarm with operator's panel		0	0
Reset alarm with teach pendant		0	0
Set data on teach pendant		0	0
Teaching with teach pendant		0	0
Emergency stop with operator's panel	0	0	0
Emergency stop with teach pendant	0	0	0
Operator's panel maintenance			0
Teach pendant maintenance			0

During robot operation, programming and maintenance, the operator, programmer, teaching operator and maintenance technician take care of their safety using at least the following safety protectors:

- Use clothes, uniform, overall adequate for the work
- Safety shoes
- Helmet

2 DEFINITION OF SAFETY NOTATIONS

To ensure the safety of users and prevent damage to the machine, this manual indicates each precaution on safety with "WARNING" or "CAUTION" according to its severity. Supplementary information is indicated by "NOTE". Read the contents of each "WARNING", "CAUTION" and "NOTE" before using the robot.

Symbol	Definitions
∱WARNING	Used if hazard resulting in the death or serious injury of the user will be expected to occur if he or she fails to follow the approved procedure.
⚠CAUTION	Used if a hazard resulting in the minor or moderate injury of the user, or equipment damage may be expected to occur if he or she fails to follow the approved procedure.
NOTE	Used if a supplementary explanation not related to any of WARNING and CAUTION is to be indicated.

PROCEDURE TO MOVE ARM WITHOUT DRIVE POWER IN EMERGENCY OR **ABNORMAL SITUATIONS**

(1) For emergency or abnormal situations (e.g. persons trapped in or pinched by the robot), brake release unit can be used to move the robot axes without drive power. Please order following unit and cable.

Name	Specification
Brake release unit	A05B-2450-J350 (Input Voltage AC100-115V single-phase)
Brake release unit	A05B-2450-J351 (Input Voltage AC200-240V single-phase)
Robot connection cable	A05B-2450-J360 (5m)
Robot connection cable	A05B-2450-J361(10m)
	A05B-2525-J010 (5m) (AC100-115V Power plug) (*)
Dower coble	A05B-2525-J011(10m) (AC100-115V Power plug) (*)
Power cable	A05B-2450-J364 (5m) (AC100-115V or AC200-240V No power plug)
	A05B-2450-J365(10m) (AC100-115V or AC200-240V No power plug)

- Not supporting CE Marking.
- (2) Prepare and store adequate numbers of brake release units which are ready and readily accessible for robot system before installation.
- (3) Regarding how to use brake release unit, please refer to "Robot controller maintenance manual".

CAUTION

Robot systems installed without adequate number of brake release units or similar means are neither in compliance with EN ISO 10218-1 nor with the Machinery Directive and therefore cannot bear the CE marking.

♠ WARNING

Robot arm would fall down by releasing its brake because of gravity. Especially because spring balancer is used for J2-axis, it is hard to predict J2-arm movement by the condition of Robot posture and end effector. Therefore it is strongly recommended to take adequate measures such as hanging Robot arm by a crane before releasing a brake.




Fig. 3 (a) Releasing J2-axis motor brake and measures (except R-2000iC/220U/190U)




Fig. 3 (b) Releasing J3-axis motor brake and measures (except R-2000*i*C/220U/190U)




Fig. 3 (c) Releasing J2-axis motor brake and measures (R-2000*i*C/220U/190S upside-down mounting)




Fig. 3 (d) Releasing J2-axis motor brake and measures (R-2000*i*C/190U)




Fig. 3 (e) Releasing J3-axis motor brake and measures (R-2000*i*C/220U/190S upside-down mounting/190U)

4 WARNING & CAUTION LABEL

(1) Greasing and degreasing label



Fig. 4 (a) Greasing and degreasing label

Description

When greasing and degreasing, observe the instructions indicated on this label.

- 1) When greasing, be sure to keep the grease outlet open.
- 2) Use a manual pump to grease.
- 3) Be sure to use a specified grease.

CAUTION

See Chapter 7 "CHECKS AND MAINTENANCE" for explanations about specified grease, the grease amount, and the locations of grease and degrease outlets for individual models.

(2) Disassembly prohibitive label



Fig. 4 (b) Disassembly prohibitive label

Description

Do not disassemble the balancer unit because it contains a spring, which may cause serious danger (for the R-2000*i*C, a disassembly prohibitive label is affixed only to the balancer).

(3) Step-on prohibitive label



Fig. 4 (c) Step-on prohibitive label

Description

Do not step on or climb the robot or controller as it may adversely affect the robot or controller and you may get hurt if you lose your footing as well.

(4) High-temperature warning label





Fig. 4 (d) High-temperature warning label

Description

Be cautious about a section where this label is affixed, as the section generates heat. If you have to inevitably touch such a section when it is hot, use a protective provision such as heat-resistant gloves.

(5) Transportation label







R-2000iC/165F/210F/240F/125L/220U

R-2000iC/165R/210R/100P/100PH


Fig. 4 (e) Transportation label







R-2000iC/190U



R-2000*i*C/270R Fig. 4 (f) Transportation label

Description

When transporting the robot, observe the instructions indicated on this label. The above label indicates the following:

- Using a forklift 1)
- Use a forklift having a load capacity of 2500 kg or greater.
- In case of R-2000iC/165F/210F/240F/220U/125L/270F/190S, keep the total weight of the robot to be transported to within 2200 kg, because the load capacity of the forklift bracket (option) is 5390 N (550
- In case of R-2000iC/165R/210R/100P/100PH/270R, keep the total weight of the robot to be transported to within 2400 kg, because the load capacity of the forklift bracket (option) is 11760 N
- In case of R-2000iC/210L/190U, keep the total weight of the robot to be transported to within 2200 kg, because the load capacity of the forklift bracket (option) is 10780 N (1100 kgf).
- 2) Using a crane
- Use a crane with a load capacity of 2500 kg or greater.
- Use four slings each with each load capacity of 1000 kg or greater.
- In case of using eyebolts, use four eyebolts with each allowable load of 6174 N (630 kgf) or greater.
- In case of R-2000*i*C/165F/210F/240F/220U/125L/270F/190S/210L/190U, keep the total weight of the robot to be transported to within 2200 kg, because the load capacity of the forklift bracket (option) is 5390 N (550 kgf).
- In case of R-2000iC/165R/210R/100P/100PH/270R, keep the total weight of the robot to be transported to within 2400 kg, because the load capacity of the forklift bracket (option) is 11760 N (1200 kgf).





∴ CAUTION

Transportation labels are model-specific. Before transporting the robot, see the transportation label affixed to the J2 arm side.

See Subsection 1.1 TRANSPORTATION for explanations about the posture a specific model should take when it is transported.

(6) Balancer replacement label







R-2000iC/165F/210F/240F/125L

R-2000iC/165R/210R/100P/100PH

Fig. 4 (g) Balancer replacement label



R-2000iC/270F/210L



R-2000iC/270R



R-2000iC/190U

Fig. 4 (h) Balancer replacement label

Description

When replacing the balancer, observe the instructions indicated on this label.

The above balancer replacement label indicates the following:

- While replacing the balancer for R-2000iC/165F/210F/240F/125L/270F/210L keep the J2-axis at 0°.
- While replacing the balancer for R-2000iC/165R/210R/100P/100PH/270R keep the J2-axis at -90°.
- While replacing the balancer for R-2000*i*C/190U follow the steps designated by FANUC.
- The mass of the balancer for R-2000*i*C/165F/210F/240F/125L/270F/210L is 150 kg.
- The mass of the balancer for R-2000*i*C/165R/210R/100P/100PH/270R is 250 kg.
- The mass of the balancer for R-2000*i*C/190U is 200 kg.

⚠ CAUTION

For information about balancer replacement, contact your local FANUC representatives.

(7) Reach and payload capacity label

When CE specification is specified, the following label is added:




Fig. 4 (i) Reach and payload label (Example of R-2000iC/165F/210F/240F/125L/220U/165R/210R/100P/100PH)

(8) Danger label

When CE specification is specified, the following label is added:




Fig. 4 (j) Danger label

(9) Transportation caution label



Fig. 4 (k) Transportation prohibitive label (for eyebolt option)

Description

Do not pull eyebolts sideways when transporting the robot.



Fig. 4 (I) Transportation prohibitive label (Example of transport equipment option)



Fig. 4 (m) Transportation prohibitive label (Example of transport equipment option)

Description

Keep the following in mind when transporting the robot.

- 1) Do not pull eyebolts sideways.
- 2) Do not pull hanging hole of this part sideways.
- 3) Prevent the forks of the forklift from having impact on a transport equipment.
- 4) Do not thread a chain or the like through a transport equipment.




Fig. 4 (n) Transportation caution label (For transport equipment option of R-2000*i*C/165R/210R/100P/100PH/270R J2 base type)

Description

- 1) Be sure to remove the transport equipment after installing the robot.
- 2) Be sure to remove all loads when transporting the robot.
- Be sure to place the robot in transportation posture referring to the manual when transporting the robot.
- 4) Be sure to remove all eyebolts before transporting with a forklift.

(10) Transportation caution label (For transport equipment option of R-2000*i*C/165R/210R/100P/100PH/270R J1 base type)



Fig. 4 (o) Transportation caution label (For transport equipment option of R-2000*i*C/165R/210R/100PH/270R J1 base type)

Description

Remove all eyebolts before transporting with a forklift.

(11) Mastering caution label



マスタリング中は動作範囲の設定が一時的に 無効になります。J1軸で±185°を超えて軸を 送り続けるとケーブルを断線させてしまう恐れ があるので、注意してください。

The motion limits are temporarily invalid during mastering. Cables may be damaged if the J1-axis exceeds $\pm 185^\circ$.

进行零点标定时动作范围限定的设置会暂时处于无效状态。请注意J1轴的旋转角度。如果J1轴的角度超过了±185°,有可能导致电缆的

Fig. 4 (p) Mastering caution label

Description

Keep the following in mind when performing the mastering. The motion limits are temporarily invalid during mastering. Cables may be damaged if the J1-axis exceeds +/-185°.

B-83644EN/09 PREFACE

PREFACE


This manual explains about the operation procedures for the following robot mechanical units:

Model name Note 1)	Mechanical unit specification No.	Max. payload
FANUC Robot R-2000iC/165F	A05B-1333-B201	165kg
FANUC Robot R-2000iC/210F	A05B-1333-B205	210kg
FANUC Robot R-2000iC/240F	A05B-1333-B215	240kg
FANUC Robot R-2000iC/125L	A05B-1333-B261	125kg
FANUC Robot R-2000iC/220U	A05B-1333-B295	220kg
FANUC Robot R-2000iC/165R	A05B-1334-B201	165kg
FANUC Robot R-2000iC/210R	A05B-1334-B205	210kg
FANUC Robot R-2000iC/100P	A05B-1334-B231	100kg
FANUC Robot R-2000iC/100PH	A05B-1334-B232	100kg
FANUC Robot R-2000iC/270F	A05B-1337-B201	270kg / 300kg Note 2)
FANUC Robot R-2000iC/270R	A05B-1337-B221	270kg
FANUC Robot R-2000iC/190S	A05B-1337-B241	190kg
FANUC Robot R-2000iC/210L	A05B-1337-B261	210kg
FANUC Robot R-2000iC/190U	A05B-1337-B295	190kg

Note 1) Please refer to the "FANUC Robot R-2000*i*C/210WE MECHANICAL UNIT OPERATOR'S MANUAL (B-84014EN)" for the FANUC Robot R-2000*i*C/210WE.

Note 2) When 300kg option is specified.

The label stating the mechanical unit specification number is affixed in the following position. Before reading this manual, verify the specification number of the mechanical unit.



Position of label indicating mechanical unit specification number

PREFACE B-83644EN/09

TABLE 1

	(1)	(2)	(3)	(4)	(5)
CONTENTS	MODEL NAME	TYPE	No.	DATE	WEIGHT kg (Without controller)
	FANUC Robot R-2000iC/165F	A05B-1333-B201			1090
	FANUC Robot R-2000iC/210F	A05B-1333-B205			1090
	FANUC Robot R-2000iC/240F	A05B-1333-B215			1090
	FANUC Robot R-2000iC/125L	A05B-1333-B261			1115
	FANUC Robot R-2000iC/220U	A05B-1333-B295			1020
	FANUC Robot R-2000iC/165R	A05B-1334-B201			1370
LETTERS	FANUC Robot R-2000iC/210R	A05B-1334-B205	SERIAL NO.		1370
LETTERS	FANUC Robot R-2000iC/100P	A05B-1334-B231	IS PRINTED		1470
	FANUC Robot R-2000iC/100PH	A05B-1334-B232			1495
	FANUC Robot R-2000iC/270F	A05B-1337-B201			1320
	FANUC Robot R-2000iC/270R	A05B-1337-B221			1590
	FANUC Robot R-2000iC/190S	A05B-1337-B241			1120
	FANUC Robot R-2000iC/210L	A05B-1337-B261		1350	
	FANUC Robot R-2000iC/190U	A05B-1337-B295			1400

RELATED MANUALS

For the FANUC Robot series, the following manuals are available:

designer must read handbook	the FANUC Robot and system and understand thoroughly this	Intended readers : Operator, System designer Topics : Safety items for robot system design, Operation, Maintenance
R-30 <i>i</i> B, R-30 <i>i</i> B Mate, R-30 <i>i</i> B Plus, R-30 <i>i</i> B Mate Plus controller	OPERATOR'S MANUAL (Basic Operation) B-83284EN OPERATOR'S MANUAL (Alarm Code List) B-83284EN-1 Optional Function OPERATOR'S MANUAL B-83284EN-2 Spot Welding Function OPERATOR'S MANUAL B-83284EN-4 Dispense Function OPERATOR'S MANUAL B-83284EN-5 Servo Gun Function OPERATOR'S MANUAL B-83264EN	Intended readers: Operator, Programmer, Maintenance technician, System designer Topics: Robot functions, Operations, Programming, Start-up, Interfaces, Alarms Use: Robot operation, Teaching, System design
	MAINTENANCE MANUAL R-30iB, R-30iB Plus: B-83195EN R-30iB Mate, R-30iB Mate Plus: B-83525EN	Intended readers : Maintenance technician, System designer Topics : Installation, Start-up, Connection, Maintenance Use : Installation, Start-up, Connection, Maintenance

This manual uses following terms.

Name	Terms in this manual
Connection cable between robot and controller	Robot connection cable
Robot mechanical unit	Mechanical unit

TABLE OF CONTENTS

SA	FETY	PRECAUTIONS	s-1
PR	REFAC	E	p-1
1		NSPORTATION AND INSTALLATION	
	1.1	TRANSPORTATION	
	1.2	INSTALLATION	
		1.2.1 Actual Installation Example	
	1.3	MAINTENANCE AREA	
	1.4	INSTALLATION CONDITIONS	31
2	CON	NECTION WITH THE CONTROLLER	32
3	BAS	IC SPECIFICATIONS	33
	3.1	ROBOT CONFIGURATION	
	3.2	MECHANICAL UNIT EXTERNAL DIMENSIONS AND	
		OPERATING SPACE	
	3.3	ZERO POINT POSITION AND MOTION LIMIT	
	3.4 3.5	WRIST LOAD CONDITIONSLOAD CONDITIONS ON J2 BASE, J3 ARM AND J3 CASING	
4		IPMENT INSTALLATION TO THE ROBOT	
	4.1	END EFFECTOR INSTALLATION TO WRIST	
	4.2	EQUIPMENT MOUNTING FACE	
	4.3 4.4	LOAD SETTINGINERTIA LOAD SETTING	
	4.4 4.5	SWITCHING METHOD OF MAX PAYLOAD SPECIFICATION	
	4.0	4.5.1 Method of Executing KAREL Program by Using "Call program"	
		4.5.2 Method of Executing KAREL Program Directly	103
5	PIPII	NG AND WIRING TO THE END EFFECTOR	106
	5.1	AIR SUPPLY (OPTION)	
	5.2	AIR PIPING (OPTION)	
	5.3	INTERFACE FOR OPTION CABLE (OPTION)	
6	AXIS	LIMITS SETUP	138
	6.1	CHANGE AXIS LIMIT BY DCS (OPTION)	
	6.2	ADJUSTABLE MECHANICAL STOPPER AND LIMIT SWITCH	
		SETTING (OPTION)	142
		6.2.1 Installing adjustable mechanical stopper option	145
		6.2.2 Changing the parameter setting6.2.3 The maximum stopping distance (position) of adjustable mechanical	157
		stopper	158

	6.3	CHANGING THE MOTION RANGE BY THE LIMIT SWITCH (OPTION)	162
	6.4	ADJUSTING LIMIT SWITCH (OPTION)	
7	CHE	CKS AND MAINTENANCE	166
•	7.1	CHECKS AND MAINTENANCE	
		7.1.1 Daily Checks	
		7.1.2 Periodic Checks and Maintenance	167
	7.2	CHECK POINTS	
		7.2.1 Confirmation of Oil Seepage	
		7.2.2 Confirmation of the Air Control Set (option)7.2.3 Check the Mechanical Unit Cables and Connectors	
		7.2.4 Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper	
	7.3	MAINTENANCE	
		7.3.1 Greasing the Balancer Bush (1 year (3840 hours) Periodic Maintenance)	
		7.3.2 Replacing the Batteries (1.5 year Periodic Maintenance)	175
		7.3.3 Replacing the Grease of the Drive Mechanism	4=4
		(3 years (11520 hours) Periodic Maintenance)	
	7.4	STORAGE	
8	MAS	TERING	184
	8.1	OVERVIEW	184
	8.2	RESETTING ALARMS AND PREPARING FOR MASTERING	185
	8.3	ZERO POSITION MASTERING	186
	8.4	QUICK MASTERING	
	8.5	QUICK MASTERING FOR SINGLE AXIS	
	8.6	SINGLE AXIS MASTERING	
	8.7	MASTERING DATA ENTRY	
	8.8	VERIFYING MASTERING	202
9	TRO	UBLESHOOTING	203
	9.1	TROUBLESHOOTING	203
10	SEVI	ERE DUST/LIQUID PROTECTION PACKAGE	212
		SEVERE DUST/LIQUID PROTECTION PACKAGE(OPTION)	
		CONFIGURATION OF THE SEVERE DUST/LIQUID	2 12
	10.2	PROTECTION PACKAGE	212
11	PRE	SS HANDLING PACKAGE (OPTION)	214
12	ACC	URACY AND STIFFNESS ENHANCEMENT OPTION	216
ΑP	PEND)IX	
Α	PERI	ODIC MAINTENANCE TABLE	219
R	STRI	ENGTH OF BOLT AND BOLT TORQUE LIST	224

1 TRANSPORTATION AND INSTALLATION

1.1 TRANSPORTATION

Use a crane or a forklift to transport the robot. Before transporting the robot, be sure to change the posture of the robot to that shown below and lift by using the eyebolts and the transport equipment at designed points.




Fig. 1.1 (a) Position of the eyebolts and transportation equipment

(1) Transportation using a crane (Fig. 1.1 (b) to (k))
Fasten M20 eyebolts or the transport equipment and eyebolts or the transport equipment at the four points and lift the robot by the four slings. (Some transport equipment does not need eyebolts.)

⚠ CAUTION

When lifting the robot, be careful not to damage motors, connectors, or cables of the robot by slings.

(2) Transportation using a forklift (Fig. 1.1 (l) to (u))

The robot is transported with the specific transport equipment attached.

There are two types of transport equipment: one to be attached to the J1 base and the other to the J2 base. Transport equipment are prepared as an option.

⚠ WARNING

- 1 When hoisting or lowering the robot with a crane or forklift, move it slowly with great care. When placing the robot on the floor, exercise care to prevent the installation surface of the robot from striking the floor.
- 2 Detach the end effectors and the floor plate before transporting the robot. If the robot need to be transported with the floor plate or end effectors attached, take the following precautions:
 - The entire position of center of gravity is changed by installing the end effector and the floor plate. Please note the balance enough.
 - The end effector swings by the vibration when transported, and there is a
 possibility that an excessive load acts on the robot. Secure the end effector
 firmly according to Subsection 1.1.1.
 - When you lift robot with the floor plate installed, please lift up not the robot but the floor plate.
- 3 Use the forklift transport equipment only to transport the robot with a forklift. Do not use the forklift transport equipment to secure the robot.
- 4 Before moving the robot by using transport equipment, check the bolts on the transport equipment and tighten any loose bolts if any.
- 5 When J1/J2-axis motor covers (option) are installed, be sure to remove them before transporting robot with a crane.

NOTE

- 1 If the transport equipment of the J2 base type for the R2000iC/165R/210R/100P/100PH/270R are used with a crane or forklift to hoist
 or lower the robot in the state where the robot is tilted, all load may be imposed
 on the strut bar used to protect against falling, thus deforming the strut bar.
 When you operate a crane or fork lift, please confirm whether the robot is the
 horizontal enough.
- 2 Please be sure to remove the strut bar after fixing the robot J1 base with bolts.




Fig. 1.1 (b) Transportation using a crane (R-2000iC/165F/210F/240F/125L/220U)




Fig. 1.1 (c) Transportation using a crane (R-2000*i*C/165F/210F/240F/125L/220U when using the transport equipment)




Fig. 1.1 (d) Transportation using a crane (R-2000iC/165R/210R/100P/100PH J1 base type)




Fig. 1.1 (e) Transportation using a crane (R-2000iC/270R J1 base type)




Fig. 1.1 (f) Transportation using a crane (R-2000iC/165R/210R/100P/100PH J2 base type)




Fig. 1.1 (g) Transportation using a crane (R-2000iC/270R J2 base type)




Fig. 1.1 (h) Transportation using a crane (R-2000*i*C/270F/210L/190U)




Fig. 1.1 (i) Transportation using a crane (R-2000iC/270F/210L/190U when using the transport equipment)




Fig. 1.1 (j) Transportation using a crane (R-2000iC/190S)




Fig. 1.1 (k) Transportation using a crane (R-2000iC/190S when using the transport equipment)




Fig. 1.1 (I) Transportation using a forklift (R-2000iC/165F/210F/240F/125L/220U J1 base type)




Fig. 1.1 (m) Transportation using a forklift (R-2000iC/165F/210F/240F/125L/220U J2 base type)

⚠ CAUTION




Fig. 1.1 (n) Transportation using a forklift (R-2000iC/165R/210R/100P/100PH J1 base type)




Fig. 1.1 (o) Transportation using a forklift (R-2000iC/165R/210R/100P/100PH J2 base type)

⚠ CAUTION




Fig. 1.1 (p) Transportation using a forklift (R-2000iC/270F/210L/190U J1 base type)




Fig. 1.1 (q) Transportation using a forklift (R-2000iC/270F/210L/190U J2 base type)

⚠ CAUTION




Fig. 1.1 (r) Transportation using a forklift (R-2000iC/270R J1 base type)




Fig. 1.1 (s) Transportation using a forklift (R-2000iC/270R J2 base type)

↑ CAUTION




Fig. 1.1 (t) Transportation using a forklift (R-2000iC/190S J1 base type)




Fig. 1.1 (u) Transportation using a forklift (R-2000iC/190S J2 base type)

↑ CAUTION

1.1.1 Transportation with an End Effector Attached

When transporting a robot with an end effector such as a welding gun or hand attached, secure the arm with wood. If the arm is not secured, the end effector may oscillate for a cause such as vibration during transportation, as a result, a large impact load, imposes on the reducer of the robot, cause premature failure of the reducer.




Fig. 1.1.1 (a) Example of securing the arm during transportation when an end effector is attached

1.2 INSTALLATION

Fig. 1.2 (a) and (b) show the robot base dimensions. Avoid placing any object in front of the robot on the locating surface to facilitate the installation of the mastering fixture. (Shaded portion)

NOTE

For the R-2000*i*C/165R/210R, the mastering fixture is placed below the J1 base installation surface.




Fig. 1.2 (a) Dimensions of the robot base (R-2000iC/165F/210F/240F/125L/220U/165R/210R)

For the R-2000iC/100P/100PH/270R, the mastering fixture is placed below the J1 base installation surface.




Fig. 1.2 (b) Dimensions of the robot base (R-2000iC/100P/100PH/270F/190S/270R/210L/190U)

1.2.1 Actual Installation Example

The following show three actual examples of the robot installation. Select a method according to the customer's installation environment, and install the robot.

- Installation example I Fig. 1.2.1 (a), (d)
 The floor plate is imbedded in concrete and fastened with twelve M20 (Tensile strength 400N/mm² or more) chemical anchors. Also fasten the base plate to the robot base using eight M20 x 65 bolts (Tensile strength 1200N/mm² or more). Next, position the robot, and weld the base plate to the floor plate. (Floor length is 10 to 15mm.) (The base plate is prepared as the option.)
- Installation example II Fig. 1.2.1 (b), (e)
 The floor plate is not imbedded in concrete. The floor plate is fastened at the twelve points with M20 chemical anchors (Tensile strength 400N/mm² or more) and the inclination of the floor plate is adjusted with the four fixing screws. The robot is positioned with the robot base pushed against the three φ20 parallel pins inserted into the floor plate and the robot base is fastened on the floor plate with eight M20 x 65 bolts (Tensile strength 1200N/mm² or more).
- Installation example III Fig. 1.2.1 (c), (f)
 The installation method is generally the same as described above except that the parallel pins for pushing the robot base are not used.

The strength of the chemical anchor depends on the concrete strength. See the design guideline of the manufacturer for the execution of the chemical anchor and consider the safety ratio sufficiently before use.

NOTE

For the R-2000*i*C/165R/210R/100P/100PH/270R, the mastering fixture is placed below the J1 base installation surface.

The following parts are required to install the robot.

(: Parts needs to be prepared.)

Required parts	Remarks	Example I	Example II	Example III
Robot mounting bolts	M20 x 65 (Tensile strength 1200N/mm² or more) 8 pcs	0	0	0
Plain washers	For M20 (HRC 35 or more, thickness between 4 and 5 mm) 8 pcs	0	0	0
Chemical anchors	M20 (Tensile strength 400N/mm² or more) 12 pcs	0	0	0
Floor plate	Thickness 32t 1 pc	0	0	0
Base plates	Thickness 32t 4 pcs	0		
Fixing screws	M20 4 pcs		0	0
Nuts	M20 4 pcs		0	0
Parallel pins	ϕ 20 3 pcs		0	

NOTE

- Customer must provide all necessary arrangements for the actual installation work (such as welding and anchoring).
- Flatness of robot installation surface must be less than or equal to 0.5mm. Inclination of robot installation surface must be less than or equal to 0.5°. If robot base is placed on uneven ground, it may result in the base breakage or low performance of the robot.




Fig. 1.2.1 (a) Actual installation example I (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R)




Fig. 1.2.1 (b) Actual installation example II (R-2000iC/165F/210F/240F/125L/220U/165R/210R)




Fig. 1.2.1 (c) Actual installation example III (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R)




Fig. 1.2.1 (d) Actual installation example I (R-2000iC/100P/100PH/270F/270R/190S/210L/190U)




Fig. 1.2.1 (e) Actual installation example II (R-2000iC/100P/100PH/270F/270R/190S/210L/190U)




Fig. 1.2.1 (f) Actual installation example III (R-2000iC/100P/100PH/270F/270R/190S/210L/190U)

Fig. 1.2.1 (g) and Table 1.2.1 (a) indicate the force and moment applied to the base plate at the time of Power-off stop of the robot. Table 1.2.1 (b) to (d) indicate the stopping distance and time of the J1 to J3 axis until the robot stopping by Power-Off stop, by Smooth stop or by Controlled stop after input of the stop signal. Refer to the data when considering the strength of the installation face.

NOTE

Table 1.2.1 (b) to (d) are measured reference value complied with ISO10218-1. Values differs depending on each robot individual difference, payload and the program. So confirm the real value by measurement. Values in Table 1.2.1 (b) is affected by the robot operating status and number of times of the Servo-Off stop. Periodically measure the real values and confirm those.

Table 1.2.1 (a) Force and moment during Power-Off stop

Model	Vertical moment M _V [kNm(kgfm)]	Force in vertical direction F _V [kN(kgf)]	Horizontal moment M _H [kNm(kgfm)]	Force in horizontal direction F _H [kN(kgf)]
R-2000iC/165F	63.70 (6500)	37.24 (3800)	24.50 (2500)	28.42 (2900)
R-2000iC/210F	73.50 (7500)	41.16 (4200)	25.48 (2600)	29.40 (3000)
R-2000iC/240F	75.46 (7700)	41.16 (4200)	25.48 (2600)	30.38 (3100)
R-2000iC/125L	62.72 (6400)	35.28 (3600)	24.50 (2500)	26.46 (2700)
R-2000iC/220U	62.72 (6400)	32.34 (3300)	24.50 (2500)	26.46 (2700)
R-2000iC/165R	75.46 (7700)	39.20 (4000)	25.48 (2600)	28.42 (2900)
R-2000iC/210R	84.28 (8600)	41.16 (4200)	25.48 (2600)	28.42 (2900)
R-2000iC/100P	77.42 (7900)	38.22 (3900)	25.48 (2600)	26.46 (2700)
R-2000iC/100PH	78.40 (8000)	39.20 (4000)	25.48 (2600)	27.44 (2800)
R-2000iC/270F	90.16 (9200)	47.04 (4800)	27.44 (2800)	33.32 (3400)
R-2000iC/270F	00.16 (0200)	47.04.(4900)	27 44 (2000)	24.20 (2500)
300kg option	90.16 (9200)	47.04 (4800)	27.44 (2800)	34.30 (3500)
R-2000iC/270R	100.94 (10300)	48.02 (4900)	26.46 (2700)	33.32 (3400)
R-2000iC/190S	65.66 (6700)	43.12 (4400)	23.52 (2400)	32.34 (3300)
R-2000iC/210L	91.14 (9300)	44.10 (4500)	27.44 (2800)	30.38 (3100)
R-2000iC/190U	86.24 (8800)	38.22 (3900)	27.44 (2800)	28.42 (2900)




Fig. 1.2.1 (g) Force and moment during Power-Off stop

Table 1.2.1 (b) Stopping time and distance until the robot stopping by Power-Off stop after input of stop signal

Model		J1-axis	J2-axis	J3-axis
R-2000iC/165F	Stopping time [ms]	458	291	228
R-2000/G/100F	Stopping distance [deg] (rad)	31.1 (0.54)	16.3 (0.28)	10.9 (0.19)
R-2000iC/210F	Stopping time [ms]	515	419	204
R-2000/G/210F	Stopping distance [deg] (rad)	29.2 (0.51)	18.8 (0.33)	11.0 (0.19)
R-2000iC/240F	Stopping time [ms]	620	416	336
K-2000/G/240F	Stopping distance [deg] (rad)	38.2 (0.67)	17.8 (0.31)	17.8 (0.31)
D 2000:C/42EI	Stopping time [ms]	472	371	272
R-2000iC/125L	Stopping distance [deg] (rad)	30.9 (0.54)	18.3 (0.32)	14.2 (0.25)
R-2000iC/220U	Stopping time [ms]	472	325	193
R-2000/G/2200	Stopping distance [deg] (rad)	24.3 (0.42)	12.8 (0.22)	9.8 (0.17)
R-2000iC/165R	Stopping time [ms]	484	384	189
K-2000/G/105K	Stopping distance [deg] (rad)	27.8 (0.49)	18.6 (0.32)	10.8 (0.19)
R-2000iC/210R	Stopping time [ms]	609	405	215
11-2000/0/2 TOT	Stopping distance [deg] (rad)	30.0 (0.52)	16.5 (0.29)	10.5 (0.18)
R-2000iC/100P	Stopping time [ms]	571	417	305
11-2000/0/1001	Stopping distance [deg] (rad)	32.5 (0.57)	18.6 (0.32)	15.4 (0.27)
R-2000iC/100PH	Stopping time [ms]	640	432	320
11-2000/0/100111	Stopping distance [deg] (rad)	33.2 (0.58)	18.0 (0.31)	14.2 (0.25)
R-2000iC/270F	Stopping time [ms]	503	359	192
11-2000/0/2701	Stopping distance [deg] (rad)	24.7 (0.43)	14.1 (0.25)	7.8 (0.14)
R-2000iC/270F	Stopping time [ms]	520	416	272
300kg option	Stopping distance [deg] (rad)	23.9 (0.42)	17.0 (0.30)	9.6 (0.17)
R-2000iC/270R	Stopping time [ms]	769	385	265
R-20001G/270R	Stopping distance [deg] (rad)	36.2(0.63)	16.4 (0.29)	8.4 (0.15)
D 2000:C/4000	Stopping time [ms]	324	228	228
R-2000iC/190S	Stopping distance [deg] (rad)	15.5 (0.27)	10.2 (0.18)	17.2 (0.30)
D 2000;C/240!	Stopping time [ms]	522	440	249
R-2000iC/210L	Stopping distance [deg] (rad)	26.9 (0.47)	17.9 (0.31)	9.3 (0.16)
D 2000;C/10011	Stopping time [ms]	554	419	256
R-2000iC/190U	Stopping distance [deg] (rad)	27.5 (0.48)	18.0 (0.31)	10.5 (0.18)

Table 1.2.1 (c) Stopping time and distance until the robot stopping by Smooth stop after input of stop signal

Model		J1-axis	J2-axis	J3-axis
R-2000iC/165F	Stopping time [ms]	874	1020	910
R-2000/G/105F	Stopping distance [deg] (rad)	53.5 (0.93)	41.4 (0.72)	51.4 (0.90)
R-2000iC/210F	Stopping time [ms]	1014	1210	1082
R-2000/G/210F	Stopping distance [deg] (rad)	55.3 (0.97)	45.3 (0.79)	48.3 (0.84)
R-2000iC/240F	Stopping time [ms]	1032	1076	924
K-2000/G/240F	Stopping distance [deg] (rad)	55.6 (0.97)	42.6 (0.74)	41.7 (0.73)
D 2000:C/42EI	Stopping time [ms]	856	996	910
R-2000iC/125L	Stopping distance [deg] (rad)	48.1 (0.84)	39.9 (0.70)	46.0 (0.80)
R-2000iC/220U	Stopping time [ms]	978	928	1034
R-20001C/2200	Stopping distance [deg] (rad)	57.7 (1.01)	36.2 (0.63)	46.0 (0.80)
R-2000iC/165R	Stopping time [ms]	1074	1118	969
K-2000/G/100K	Stopping distance [deg] (rad)	59.9 (1.05)	46.1 (0.80)	53.3 (0.93)
R-2000iC/210R	Stopping time [ms]	1134	1146	866
K-2000/G/210K	Stopping distance [deg] (rad)	57.1 (1.00)	41.2 (0.72)	35.5 (0.62)
R-2000iC/100P	Stopping time [ms]	896	1005	999
K-2000/G/100P	Stopping distance [deg] (rad)	50.1 (0.87)	36.9 (0.64)	45.7 (0.80)
R-2000iC/100PH	Stopping time [ms]	928	792	1008
N-2000/C/100F11	Stopping distance [deg] (rad)	50.4 (0.88)	37.1 (0.65)	46.1 (0.80)
R-2000iC/270F	Stopping time [ms]	752	854	444
11-20001012101	Stopping distance [deg] (rad)	38.7 (0.68)	33.3 (0.58)	18.7 (0.33)
R-2000iC/270F	Stopping time [ms]	820	830	590
300kg option	Stopping distance [deg] (rad)	38.3 (0.67)	34.0 (0.59)	23.2 (0.40)

Model		J1-axis	J2-axis	J3-axis
R-2000iC/270R	Stopping time [ms]	1005	821	433
R-20001C/210R	Stopping distance [deg] (rad)	51.5 (0.90)	30.3 (0.53)	17.7 (0.31)
R-2000iC/190S	Stopping time [ms]	725	730	470
R-2000/C/1905	Stopping distance [deg] (rad)	37.0 (0.65)	29.7 (0.52)	29.9 (0.52)
R-2000 <i>i</i> C/210L	Stopping time [ms]	818	928	698
R-2000/C/210L	Stopping distance [deg] (rad)	42.5 (0.74)	36.1 (0.63)	30.4 (0.53)
R-2000iC/190U	Stopping time [ms]	930	940	668
	Stopping distance [deg] (rad)	45.0 (0.79)	37.1 (0.65)	28.2 (0.49)

ible 1.2.1 (d) Stopping	le 1.2.1 (d) Stopping time and distance until the robot stopping by Controlled stop after input of stop signal					
Model		J1-axis	J2-axis	J3-axis		
R-2000iC/165F	Stopping time [ms]	966	1024	1038		
R-2000/G/100F	Stopping distance [deg] (rad)	65.2 (1.14)	53.9 (0.94)	61.8 (1.08)		
R-2000iC/210F	Stopping time [ms]	1022	1388	1192		
11-2000/0/2101	Stopping distance [deg] (rad)	66.8 (1.17)	57.7 (1.01)	60.8 (1.06)		
R-2000iC/240F	Stopping time [ms]	1232	1400	1400		
N-2000/0/240F	Stopping distance [deg] (rad)	67.3 (1.17)	56.5 (0.99)	66.0 (1.15)		
R-2000 <i>i</i> C/125L	Stopping time [ms]	1180	1364	1372		
11-2000/O/123L	Stopping distance [deg] (rad)	77.7 (1.36)	61.9 (1.08)	75.1 (1.31)		
R-2000iC/220U	Stopping time [ms]	1074	1020	1094		
11-2000/0/2200	Stopping distance [deg] (rad)	63.6 (1.11)	41.4 (0.72)	56.0 (0.98)		
R-2000 <i>i</i> C/165R	Stopping time [ms]	1178	1400	1245		
11-2000/O/10311	Stopping distance [deg] (rad)	68.2 (1.19)	63.0 (1.10)	75.5 (1.32)		
R-2000iC/210R	Stopping time [ms]	1210	1380	1365		
11-2000/0/21011	Stopping distance [deg] (rad)	66.6 (1.16)	61.8 (1.08)	70.0 (1.22)		
R-2000iC/100P	Stopping time [ms]	1124	1202	1216		
11-2000/0/1001	Stopping distance [deg] (rad)	64.3 (1.12)	50.3 (0.88)	61.4 (1.07)		
R-2000iC/100PH	Stopping time [ms]	1176	1048	1224		
11-2000/0/100111	Stopping distance [deg] (rad)	64.4 (1.12)	48.4 (0.84)	61.1 (1.07)		
R-2000iC/270F	Stopping time [ms]	1060	1092	1020		
11-2000/0/2701	Stopping distance [deg] (rad)	57.8 (1.01)	48.0 (0.84)	45.9 (0.80)		
R-2000iC/270F	Stopping time [ms]	1090	1140	1070		
300kg option	Stopping distance [deg] (rad)	55.1 (0.96)	48.4 (0.84)	47.2 (0.82)		
R-2000iC/270R	Stopping time [ms]	1153	1253	1165		
R-2000/C/270R	Stopping distance [deg] (rad)	57.4 (1.00)	49.3 (0.86)	49.9 (0.87)		
R-2000iC/210L	Stopping time [ms]	1075	1050	955		
N-2000/0/2 TUL	Stopping distance [deg] (rad)	55.7 (0.97)	45.0 (0.79)	43.7 (0.76)		
R-2000iC/190U	Stopping time [ms]	1012	1040	988		
11-200010/1900	Stopping distance [deg] (rad)	52.9 (0.92)	43.7 (0.76)	42.8 (0.75)		

1.3 MAINTENANCE AREA

Fig. 1.3 (a) to (d) show the maintenance area of the mechanical unit. Dotted line area is necessary for mastering. Be sure to leave enough room for the robot to be mastered. See Chapter 8 for mastering information.




Fig. 1.3 (a) Maintenance area (R-2000iC/165F/210F/240F/125L/220U)




Fig. 1.3 (b) Maintenance area (R-2000iC/165R/210R)




Fig. 1.3 (c) Maintenance area (R-2000iC/100P/100PH/270R)




Fig. 1.3 (d) Maintenance area (R-2000iC/270F/190S/210L/190U)

1.4 INSTALLATION CONDITIONS

Refer to the caution below concerning installation conditions. Refer to also to the specifications found in Section 3.1.

! CAUTION

- 1 If the robot is used especially in an adverse environment stated below, grease the balancer as required.
 - Dusty environment; for example, an application in which the robot is used to handle tiles or bricks.
 - Environment full of spatters developed in spot welding; for example, an application in which welding spatters deposit and accumulate on and around the balancer

In addition, if the robot is used in a special environment stated below, use a robot jacket or some other means to protect the balancer support part (which joins with the J2 arm and J2 base) and rod sliding part.

- Environment where glass abrasive powders and others are used; for example, and application in which the robot or balancer is subjected to splashes of powders in handling and other operations during glass abrasion.
- Environment where metal powders are used; for example, an application in which the robot or balancer is subjected to splashes of powders in handling and other operations during metal working.
- 2 Damage to the cable jacket can cause water intrusion. Take care not to damage the cable jacket when installing the robot. Replace the cable if it is damaged.
- 3 Liqud intrusion into the balancer inside might cause corrosion of the spring. Be careful to prevent liquid splashing to the balancer.

2 CONNECTION WITH THE CONTROLLER

The robot is connected with the controller via the power cable, the signal cable and the earth cable. Connect these cables to the connectors on the back of the robot base. For details on air and option cables, see Chapter 5.

$\hat{\Lambda}$

WARNING

Before turning on controller power, be sure to connect the robot and controller with the earth line (ground). Otherwise, there is the risk of electrical shock.

⚠ CAUTION

- 1 Before connecting the cables, be sure to turn off the controller power.
- 2 Don't use 10m or longer coiled cable without first untying it. The long coiled cable will heat up and become damaged.




Fig. 2 (a) Cable connection

3 BASIC SPECIFICATIONS

3.1 ROBOT CONFIGURATION




Fig. 3.1 (a) Mechanical unit configuration, each axis coordinates, and mechanical interface coordinates (R-2000*i*C/165F/210F/240F/125L/220U)

NOTE

- 1 There is no balancer for R-2000iC/220U.
- 2 The end effector mounting face center is 0, 0, 0 of the mechanical interface coordinates.




Fig. 3.1 (b) Mechanical unit configuration, each axis coordinates, and mechanical interface coordinates (R-2000*i*C/165R/210R/100P/100PH)

The end effector mounting face center is 0, 0, 0 of the mechanical interface coordinates.




Fig. 3.1 (c) Mechanical unit configuration, each axis coordinates, and mechanical interface coordinates (R-2000*i*C/270F/190S/210L/190U)

- 1 There is no balancer for R-2000*i*C/190S.
- 2 The end effector mounting face center is 0, 0, 0 of the mechanical interface coordinates.




Fig. 3.1 (d) Mechanical unit configuration, each axis coordinates, and mechanical interface coordinates (R-2000iC/270R)

The end effector mounting face center is 0, 0, 0 of the mechanical interface coordinates.

Specifications Note 1) (1/5)

	Model		R-2000 <i>i</i> C/165F	R-2000 <i>i</i> C/210F	R-2000iC/240F	
Type		17-2001011001	Articulated Type	17-2000:0:2-101		
Controlled axis			6 axes(J1,J2,J3,J4,J5,J6)			
	nstallation	•	Floor mount			
		Upper limit	185° (3.23rad)	185° (3.23rad)	185° (3.23rad)	
	J1-axis	Lower limit	-185° (-3.23rad)	-185° (-3.23rad)	-185° (-3.23rad)	
		Upper limit	76° (1.33rad)	76° (1.33rad)	76° (1.33rad)	
	J2-axis	Lower limit	-60° (-1.05rad)	-60° (-1.05rad)	-60° (-1.05rad)	
		Upper limit	180° (3.14rad)	180° (3.14rad)	180° (3.14rad)	
	J3-axis	Lower limit	-132° (-2.30rad)	-132° (-2.30rad)	-132° (-2.30rad)	
Motion range		Upper limit	360° (6.28rad)	360° (6.28rad)	360° (6.28rad)	
	J4-axis	Lower limit	-360° (-6.28rad)	-360° (-6.28rad)	-360° (-6.28rad)	
		Upper limit	125° (2.18rad)	125° (2.18rad)	125° (2.18rad)	
	J5-axis	Lower limit	-125° (-2.18rad)	-125° (-2.18rad)	-125° (-2.18rad)	
		Upper limit	360° (6.28rad)	360° (6.28rad)	360° (6.28rad)	
	J6-axis	Lower limit	-360° (-6.28rad)	-360° (-6.28rad)	-360° (-6.28rad)	
		J1-axis	130°/s (2.27rad/s)	120°/s (2.09rad/s)	115°/s (2.01rad/s)	
		J2-axis	115°/s (2.01rad/s)	105°/s (1.83rad/s)	90°/s (1.57rad/s)	
Max. speed		J3-axis	125°/s (2.18rad/s)	110°/s (1.92rad/s)	105°/s (1.83rad/s)	
Note 2)		J4-axis	180°/s (3.14rad/s)	140°/s (2.44rad/s)	130°/s (2.27rad/s)	
,		J5-axis	180°/s (3.14rad/s)	140°/s (2.44rad/s)	130°/s (2.27rad/s)	
		J6-axis	260°/s (4.54rad/s)	220°/s (3.84rad/s)	210°/s (3.67rad/s)	
	At wrist		165kg	210kg	240kg	
		n J3 arm	25kg (A)	25kg (A)	25kg (A)	
Max. payload On J3 casing		$\begin{array}{c c} \hline 50\text{kg (B)} & (A)+(B) \leq 50\text{kg} \end{array}$	50kg (B) (A)+(B)≦50kg	$\begin{array}{c c} \hline 50\text{kg (B)} & \text{(A)+(B)} \leq 50\text{kg} \end{array}$		
		n J2 base	550kg	550kg	550kg	
	,	J4-axis	940N·m (96kgf·m)	1360N·m (139kgf·m)	1400N·m (143kgf·m)	
Allowable load moment at wrist	,	J5-axis	940N·m (96kgf·m)	1360N·m (139kgf·m)	1400N·m (143kgf·m)	
moment at wist		J6-axis	490N·m (50kgf·m)	735N·m (75kgf·m)	800N·m (82kgf·m)	
			Note 3) 89kg·m ²	Note 3) 147kg·m²		
		J4-axis	(908kgf·cm·s²)	(1500kgf·cm·s²)	250kg⋅m²	
	'	J4-axi5	Note 3) 120kg·m²	Note 3) 225.4kg·m ²	(2551kgf·cm·s²)	
			(1225kgf·cm·s²)	(2300kgf·cm·s ²)		
			Note 3) 89kg·m ²	Note 3) 147kg·m ²		
Allowable load		J5-axis	(908kgf·cm·s²)	(1500kgf·cm·s²)	250kg·m ²	
inertia at wrist			Note 3) 120kg·m ²	Note 3) 225.4kg·m²	(2551kgf·cm·s²)	
			(1225kgf·cm·s²)	(2300kgf·cm·s²)		
			Note 3) 46kg·m²	Note 3) 82kg·m ²	2001	
	J6-axis		(469kgf·cm·s²)	(837kgf·cm·s²)	200kg⋅m² (2041kgf⋅cm⋅s²)	
		Note 3) 100kg·m ² (1020kgf·cm·s ²)	Note 3) 196kg⋅m² (2000kgf⋅cm⋅s²)	(204 rkgi-cm-s-)		
Dr	ive method		(1020kgi-ciii-s)	Electric servo drive by AC servo	motor	
		a 4)		±0.05mm		
Repeatability Note 4) Mass		1090kg	1090kg	1090kg		
Acous	stic noise le	vel	1000119	70.5dB Note 5)	1000kg	
	tion environ		Ambient temperature: Ambient humidity: Permitted altitude:	0 to 45°C Note 6) Normally 75%RH or less. (No construction of time (within one month) M (No condensation allowed.) Up to 1000 m above sea level.		
			Vibration acceleration : Free of corrosive gases No	4.9m/s ² (0.5G) or less		

- Note 1) Even if the robot is used according to the defined specifications, motion programs might shorten reducer life or cause the robot to overheat. Use ROBOGUIDE (system design support tool by FANUC) for further evaluation before running production.
- Note 2) During short distance motions, the axis speed may not reach the maximum value stated.
- Note 3) The allowable load in standard inertia mode is shown in upper half and the allowable load in high inertia mode in lower half. For details, see Section 4.4.
- Note 4) Compliant with ISO9283.
- Note 5) This value is the equivalent continuous A-weighted sound pressure level that applied with ISO11201 (EN31201). This value is measured with the following conditions.
 - Maximum load and speed
 - Operating mode is AUTO
- Note 6) When the robot is used in a low temperature environment that is near to 0°C, or the robot is not operated for a long time in an environment that is less than 0°C, for example during a holiday or overnight, viscous resistance of the drive train may cause occurrence of collision detect alarm (SRVO –050) etc. In this case, we recommend performing a warm up operation for several minutes.
- Note 7) Contact the service representative, if the robot is to be used in an environment or a place subjected to hot/cold temperatures, severe vibrations, heavy dust, water, water vapor, cutting oil, cleaning fluid splash and or other foreign materials.
- Note 8) Liquid intrusion into the balancer inside might cause corrosion of the spring. Be careful to prevent liquid splashing to the balancer.

Specifications Note 1) (2/5)

Model				000 <i>i</i> C/125L		000iC/220U	R-200	00iC/165R
Туре			Articulated Type					
Controlled axis		6 axes (J1,J2,J3,J4,J5,J6)						
	tallation		Floor mount		,	side-down	Rac	k mount
		Upper limit	185°	(3.23rad)	185°	(3.23rad)	185°	(3.23rad)
	J1-axis	Lower limit	-185°	(-3.23rad)	-185°	(-3.23rad)	-185°	(-3.23rad)
		Upper limit	76°	(1.33rad)	76°	(1.33rad)	80°	(1.40rad)
	J2-axis	Lower limit	-60°	(-1.05rad)	-60°	(-1.05rad)	-120°	(-2.09rad)
	10	Upper limit	180°	(3.14rad)	180°	(3.14rad)	270°	(4.71rad)
Motion range	J3-axis	Lower limit	-121°	(-2.11rad)	-132°	(-2.30rad)	-105°	(-1.83rad)
Motion range	J4-axis	Upper limit	360°	(6.28rad)	360°	(6.28rad)	360°	(6.28rad)
	J4-axis	Lower limit	-360°	(-6.28rad)	-360°	(-6.28rad)	-360°	(-6.28rad)
	J5-axis	Upper limit	125°	(2.18rad)	125°	(2.18rad)	125°	(2.18rad)
	JJ-axis	Lower limit	-125°	(-2.18rad)	-125°	(-2.18rad)	-125°	(-2.18rad)
	J6-axis	Upper limit	360°	(6.28rad)	360°	/	360°	(6.28rad)
	00-axi3	Lower limit	-360°	,	-360°			(-6.28rad)
		-axis		(2.27rad/s)		s (2.09rad/s)		(2.01rad/s)
	J2	?-axis		(2.01rad/s)		s (1.48rad/s)		(1.92rad/s)
Max. speed		-axis		(2.18rad/s)	110°/s (1.92rad/s)			(2.18rad/s)
Note 2)		-axis		(3.14rad/s)	140°/s (2.44rad/s)			(3.14rad/s)
		-axis	180°/s (3.14rad/s)			s (2.44rad/s)	180°/s (3.14rad/s)	
	J6-axis		260°/s (4.54rad/s)		220°/s	s (3.84rad/s)	260°/s (4.54rad/s)	
	At wrist		051 (4)	125kg	051 (4)	220kg	i r	65kg
Max. payload		J3 arm	25kg (A)	(A)+(B)≦40kg	25kg (A)	6/5*(A)+(B)≦30kg	25kg (A)	(A)+(B)≦50kg
		3 casing I2 base	40kg (B)	550kg	30kg (B)		50kg (B)	550kg
		-axis	710N	710N·m (72kgf·m) 1360N·m (139kgf		m (139kaf.m)		(96kgf·m)
Allowable load		i-axis		m (72kgf·m)		m (139kgf·m)		(96kgf·m)
moment at wrist		i-axis		m (36kgf·m)	735N-	· •		(50kgf·m)
				72kg·m²		47kg·m ²		9kg·m²
	J4	-axis		5kgf·cm·s²)		00kgf·cm·s²)		(gf·cm·s²)
Allowable load	16	i-axis		72kg⋅m²	1	47kg·m²	89	9kg⋅m²
inertia at wrist	Je	i-axis	(73	5kgf·cm·s²)	(1500kgf·cm·s²)		(908)	κgf⋅cm⋅s²)
	.16	i-axis		40kg⋅m²		82kg·m²	46	3kg⋅m²
00-axis		(40	8kgf·cm·s²)		7kgf·cm·s²)		(gf·cm·s²)	
	e method	2)		E		drive by AC servo mo	tor	
Repeatability Note 3)			44451	r	±0.05mm		0701	
Mass Acoustic noise level			1115kg		1020kg	1;	370kg	
Acoustic	c noise lev	eı	Ambient ter	maratura	70. O to 45°C No	5dB Note 4)		
		Ambient hu				lensation allow	ved)	
			Ambient humidity: Normally 75%RH or less. (No condensation allowed.) Short time (within one month) Max 95%RH				,	
Installation	n environn	nent		(No condensa	tion allowed.)		
			Permitted a			above sea level.		
					4.9m/s ² (0.5	G) or less		
			ree of corr	osive gases Note	6) Note 7)			

- Note 1) Even if the robot is used according to the defined specifications, motion programs might shorten reducer life or cause the robot to overheat.

 Use ROBOGUIDE (system design support tool by FANUC) for further evaluation before running production.
- Note 2) During short distance motions, the axis speed may not reach the maximum value stated.
- Note 3) Compliant with ISO9283.
- Note 4) This value is the equivalent continuous A-weighted sound pressure level that applied with ISO11201 (EN31201). This value is measured with the following conditions.
 - Maximum load and speed
 - Operating mode is AUTO
- Note 5) When the robot is used in a low temperature environment that is near to 0°C, or the robot is not operated for a long time in an environment that is less than 0°C, for example during a holiday or overnight, viscous resistance of the drive train may cause occurrence of collision detect alarm (SRVO –050) etc. In this case, we recommend performing a warm up operation for several minutes.
- Note 6) Contact the service representative, if the robot is to be used in an environment or a place subjected to hot/cold temperatures, severe vibrations, heavy dust, water, water vapor, cutting oil, cleaning fluid splash and or other contaminations.
- Note 7) Liquid intrusion into the balancer inside might cause corrosion of the spring. Be careful to prevent liquid splashing to the balancer.

Specifications Note 1) (3/5)

	Madal		R-2000iC/210R		C/100P/100PH	R-2000iC/270F	
	Model		R-20001C/210R			R-2000/C/2/0F	
	Type Controlled axis		Articulated Type				
	tallation		6 axes(J1,J2,J3,J4,J5,J6) Rack mount Floor mount				
1113	tallation	Upper limit	185° (3.23rad)	1	5° (3.23rad)	185° (3.23rad)	
	J1-axis	Lower limit	-185° (-3.23rad)	-18	- ,	-185° (-3.23rad)	
		Upper limit	80° (1.40rad)		0° (1.40rad)	76° (1.33rad)	
	J2-axis	Lower limit	-120° (-2.09rad)	-12	(-60° (-1.05rad)	
		Upper limit	270° (4.71rad)		0° (4.71rad)	180° (3.14rad)	
	J3-axis	Lower limit	-105° (-1.83rad)	-10	,	-132° (-2.30rad)	
Motion range		Upper limit	360° (6.28rad)	36	- (/	360° (6.28rad)	
	J4-axis	Lower limit	-360° (-6.28rad)	-36	· (· · · /	-360° (-6.28rad)	
		Upper limit	125° (2.18rad)		5° (2.18rad)	125° (2.18rad)	
	J5-axis	Lower limit	-125° (-2.18rad)	-12	, ,	-125° (-2.18rad)	
		Upper limit	360° (6.28rad)	36		360° (6.28rad)	
	J6-axis	Lower limit	-360° (-6.28rad)	-36		-360° (-6.28rad)	
			,		,	105°/s (1.83rad/s)	
	J1	-axis	105°/s (1.83rad/s)	120	0°/s (2.09rad/s)	100°/s (1.75rad/s) Note 8)	
	J2	2-axis	100°/s (1.75rad/s)	100	0°/s (1.75rad/s)	90°/s (1.57rad/s)	
Max. speed	J3	3-axis	110°/s (1.92rad/s)	11:	5°/s (2.01rad/s)	85°/s (1.48rad/s)	
Note 2)	J4	l-axis	140°/s (2.44rad/s)	140	0°/s (2.44rad/s)	120°/s (2.09rad/s)	
	J5	-axis	140°/s (2.44rad/s)	140°/s (2.44rad/s)		120°/s (2.09rad/s)	
			220°/s (3.84rad/s) 210°/s (3.66rad/s)		200°/s (3.49rad/s)		
	J6-axis		` ′	` '		190°/s (3.32rad/s) Note 8)	
	At wrist		210kg	051 (4)	100kg	270kg / 300kg Note 8)	
Max. payload		J3 arm	30kg (A) 4/3*(A)+(B)≦	25kg (A)	2*(A)+(B)≦50kg	$\frac{40\text{kg (A)}}{50\text{kg}}$ 5/4*(A)+(B)≤50kg	
		3 casing J2 base	40kg (B) 40kg 550kg	50kg (B)	550kg	50kg (B) 550kg	
	On a	DZ Dase			JJUNG	1730N·m (177kgf·m)	
	.14	l-axis	1360N·m (139kgf·m)	1000N:	m (102kgf·m)	1755N·m (179kgf·m) Note 8)	
Allowable load					(102ng)	1730N·m (177kgf·m)	
moment at wrist	J5	5-axis	1360N·m (139kgf·m)	1000N-	m (102kgf·m)	1755N·m (179kgf·m) Note 8)	
			, , ,		, ,	900N·m (92kgf·m)	
	J6	3-axis	735N·m (75kgf·m)	706N-	m (72kgf·m)	1000N·m (102kgf·m) Note 8)	
	.14	l-axis	147kg⋅m²		27kg⋅m²	320kg⋅m²	
	0-1	r uxio	(1500kgf·cm·s ²)		6kgf·cm·s ²)	(3265kgf·cm·s ²)	
Allowable load	J5	5-axis	147kg·m²		27kg·m²	320kg·m ²	
inertia at wrist			(1500kgf·cm·s²)		6kgf·cm·s²)	(3265kgf·cm·s²)	
	J6-axis		82kg·m² (837kqf·cm·s²)		96kg·m² 00kqf·cm·s²)	230kg·m² (2347kqf·cm·s²)	
Drive	L Drive method		(037 Kgi-Cili-S-)		vo drive by AC servo m		
	ability Note	3)		LICOLIIO SCI	±0.05mm	0.01	
	Mass		1370kg	1470 kg (100)	P) / 1495 kg (100PH)	1320kg	
	Acoustic noise level		70.5dB Note 4)		7dB Note 4)	70.5dB Note 4)	
Installation environment		Ambient temperature: Ambient humidity: Permitted altitude: Vibration acceleration:	bient temperature: 0 to 45°C Note 5) bient humidity: Normally 75%RH or less. (No condensation allowed.) Short time (within one month) Max 95%RH (No condensation allowed.) (No to 1000 m above sea level.				
			Free of corrosive gases No				

- Note 1) Even if the robot is used according to the defined specifications, motion programs might shorten reducer life or cause the robot to overheat.

 Use ROBOGUIDE (system design support tool by FANUC) for further evaluation before running production.
- Note 2) During short distance motions, the axis speed may not reach the maximum value stated.
- Note 3) Compliant with ISO9283.
- Note 4) This value is the equivalent continuous A-weighted sound pressure level that applied with ISO11201 (EN31201). This value is measured with the following conditions.
 - Maximum load and speed
 - Operating mode is AUTO
- Note 5) When the robot is used in a low temperature environment that is near to 0°C, or the robot is not operated for a long time in an environment that is less than 0°C, for example during a holiday or overnight, viscous resistance of the drive train may cause occurrence of collision detect alarm (SRVO –050) etc. In this case, we recommend performing a warm up operation for several minutes.
- Note 6) Contact the service representative, if the robot is to be used in an environment or a place subjected to hot/cold temperatures, severe vibrations, heavy dust, water, water vapor, cutting oil, cleaning fluid splash and or other contaminations.
- Note 7) Liquid intrusion into the balancer inside might cause corrosion of the spring. Be careful to prevent liquid splashing to the balancer.
- Note 8) When 300kg option is specified at R-2000*i*C/270F.

Specifications Note 1) (4/5)

<u> </u>			Specifications					
	lodel		R-2000iC/270R	R-	2000 <i>i</i> C/190S	R-2000 <i>i</i> C/210L		
Туре		Articulated Type						
Conti	Controlled axis		6 axes(J1,J2,J3,J4,J5,J6)					
Ins	tallation		Rack mount	Floor me	ount, Upside-down	Floor mount		
		Upper limit	185° (3.23rad)	185° 165°	(3.23rad) (2.88rad) Note 2)	185° (3.23rad)		
	J1-axis	Lower limit	-185° (-3.23rad)	-185° -165°	(-3.23rad) (-2.88rad) Note 2)	-185° (-3.23rad)		
	IO avia	Upper limit	80° (1.40rad)	130°	(2.27rad)	76° (1.33rad)		
	J2-axis	Lower limit	-120°(-2.09rad)	-80°	(-1.40rad)	-60° (-1.05rad)		
		Upper limit	270° (4.71rad)	180°	(3.14rad)	180° (3.14rad)		
Matian name	J3-axis	Lower limit	-105°(-1.83rad)	-160°	(-2.79rad)	-121° (-2.11rad)		
Motion range		Upper limit	360° (6.28rad)	360° 153°	(6.28rad) (2.67rad) Note 2)	360° (6.28rad)		
	J4-axis	Lower limit	-360°(-6.28rad)	-360° -153°	(-6.28rad) (-2.67rad) Note2)	-360° (-6.28rad)		
	15	Upper limit	125° (2.18rad)	125°	(2.18rad)	125° (2.18rad)		
	J5-axis	Lower limit	-125°(-2.18rad)	-125°	(-2.18rad)	-125° (-2.18rad)		
	10 1	Upper limit	360° (6.28rad)	360°	(6.28rad)	360° (6.28rad)		
	J6-axis	Lower limit	-360°(-6.28rad)	-360°	(-6.28rad)	-360° (-6.28rad)		
	J1	-axis	105°/s (1.83rad/s)	10:	5°/s (1.83rad/s)	105°/s (1.83rad/s)		
	J2	-axis	85°/s (1.48rad/s)	90°/s (1.57rad/s)		85°/s (1.48rad/s)		
Max. speed	J3	-axis	85°/s (1.48rad/s)	145°/s (2.53rad/s)		85°/s (1.48rad/s)		
Note 3)	J4-axis		120°/s (2.09rad/s)		0°/s (2.09rad/s)	120°/s (2.09rad/s)		
	J5-axis		120°/s (2.09rad/s)		0°/s (2.09rad/s)	120°/s (2.09rad/s)		
	J6	-axis	200°/s (3.49rad/s)	200°/s (3.49rad/s)		200°/s (3.49rad/s)		
	At	wrist	270kg	190kg		210kg		
Max. payload		J3 arm	001 (A)	40kg (A)		20kg (A) $5/2*(A)+(B) \le$		
Note 4)		3 casing	$40 \text{kg (A)} = 4/3*(A)+(B) \le 40 \text{kg}$	50kg (B)	5/4*(A)+(B)≦50kg	50kg (B) 50 kg		
	On J	l2 base	550kg	550kg		550kg		
Allanos Islanda ad	J4	-axis	1730N·m (177kgf·m)	1200N·m (122kgf·m)		1700N·m (173kgf·m)		
Allowable load moment at wrist	J5	-axis	1730N·m (177kgf·m)	12001	√n (122kgf·m)	1700N·m (173kgf·m)		
moment at wist	J6	-axis	900N·m (92kgf·m)	6301	N·m (64kgf·m)	900N·m (92kgf·m)		
	J4	-axis	320kg⋅m² (3265kgf⋅cm • s²)	(20-	200kg⋅m² 41kgf⋅cm • s²)	320kg·m² (3265kgf·cm·s²)		
Allowable load inertia at wrist	J5	-axis	320kg·m ² (3265kgf·cm·s ²)	(20	200kg·m² 041kgf·cm·s²)	320kg·m² (3265kgf·cm·s²)		
	J6-axis		230kg·m² (2347kgf·cm·s²)	(18	180kg·m² 337kgf·cm·s²)	230kg·m² (2347kgf·cm·s²)		
Drive	Drive method		(==	Electric servo	drive by AC servo motor	(==		
Repeatability Note 5)		5)	±0.05mm		±0.03mm	±0.05mm		
	Mass		1590 kg		g / 1135kg Note 2)	1350 kg		
Acousti	c noise lev	rel .	V		.5dB Note 6)	·		
Installation environment		nent	Ambient temperature: Ambient humidity: 0 to 45°C Note 7) Normally 75%RH or less. (No condensation allowed.) Short time (within one month) Max 95%RH (No condensation allowed.) Permitted altitude: Up to 1000 m above sea level. Vibration acceleration: 4.9m/s² (0.5G) or less					
			Free of corrosive gases Note	e 8) Note 9)				

- Note 1) Even if the robot is used according to the defined specifications, motion programs might shorten reducer life or cause the robot to overheat.

 Use ROBOGUIDE (system design support tool by FANUC) for further evaluation before running production.
- Note 2) When accuracy and stiffness enhancement option is specified
- Note 3) During short distance motions, the axis speed may not reach the maximum value stated.
- Note 4) Load at fore J3 arm is unavailable when accuracy and stiffness enhancement option is specified.
- Note 5) Compliant with ISO9283.
- Note 6) This value is the equivalent continuous A-weighted sound pressure level that applied with ISO11201 (EN31201). This value is measured with the following conditions.
 - Maximum load and speed
 - Operating mode is AUTO
- Note 7) When the robot is used in a low temperature environment that is near to 0°C, or the robot is not operated for a long time in an environment that is less than 0°C, for example during a holiday or overnight, viscous resistance of the drive train may cause occurrence of collision detect alarm (SRVO –050) etc. In this case, we recommend performing a warm up operation for several minutes.
- Note 8) Contact the service representative, if the robot is to be used in an environment or a place subjected to hot/cold temperatures, severe vibrations, heavy dust, water, water vapor, cutting oil, cleaning fluid splash and or other contaminations.
- Note 9) Liquid intrusion into the balancer inside might cause corrosion of the spring. Be careful to prevent liquid splashing to the balancer.

Specifications Note 1) (5/5)

			Specifications Note 1) (5/5)				
Model			R-2000 <i>i</i> C/190U				
Туре			Articulated Type				
Contr	olled axis		6 axes(J1,J2,J3,J4,J5,J6)				
Inst	tallation		Upside-down				
	14	Upper limit	185°(3.23rad)				
	J1-axis	Lower limit	-185°(-3.23rad)				
	J2-axis	Upper limit	76°(1.33rad)				
	JZ-axis	Lower limit	-60°(-1.05rad)				
	J3-axis	Upper limit	180°(3.14rad)				
Motion range	JO-axis	Lower limit	-121°(-2.11rad)				
Wollon range	J4-axis	Upper limit	360°(6.28rad)				
	J4-axis	Lower limit	-360°(-6.28rad)				
	J5-axis	Upper limit	125°(2.18rad)				
	JJ-axis	Lower limit	· · · · · · · · · · · · · · · · · · ·				
	J6-axis	Upper limit	, , ,				
	00 dxio	Lower limit	-360°(-6.28rad)				
	J1	-axis	105°/s (1.83rad/s)				
	J2	-axis	85°/s (1.48rad/s)				
Max. speed		-axis	85°/s (1.48rad/s)				
Note 2)		-axis	120°/s (2.09rad/s)				
		-axis	120°/s (2.09rad/s)				
		-axis	200°/s (3.49rad/s)				
	At wrist		190kg				
Max. payload		J3 arm	20kg (A) 5/2*(A)+ (B) \leq 50 kg				
. ,		3 casing I2 base	5UKg (B)				
			550kg 1700N·m (173kgf·m)				
Allowable load		-axis -axis					
moment at wrist		-axis -axis	1700N·m (173kgf·m) 900N·m (92kgf·m)				
	30	-4115	320kg·m²				
	J4	-axis	(3265kgf·cm·s²)				
Allowable load			320kg·m²				
inertia at wrist	J5	-axis	(3265kgf·cm·s²)				
	.16	-axis	230kg·m²				
	30	-axis	(2347kgf·cm·s²)				
	e method		Electric servo drive by AC servo motor				
Repeatability Note 3)		3)	±0.05mm				
Mass			1400 kg				
Acoustic noise level		el	70.5dB Note 4)				
			Ambient temperature: 0 to 45°C Note 5)				
			Ambient humidity: Normally 75%RH or less. (No condensation allowed.)				
			Short time (within one month) Max 95%RH				
Installation	n environm	nent	(No condensation allowed.)				
			Permitted altitude: Up to 1000 m above sea level.				
ĺ			Vibration acceleration: 4.9m/s ² (0.5G) or less				
			Free of corrosive gases Note 6) Note 7)				

- Note 1) Even if the robot is used according to the defined specifications, motion programs might shorten reducer life or cause the robot to overheat.

 Use ROBOGUIDE (system design support tool by FANUC) for further evaluation before running production.
- Note 2) During short distance motions, the axis speed may not reach the maximum value stated.
- Note 3) Compliant with ISO9283.
- Note 4) This value is the equivalent continuous A-weighted sound pressure level that applied with ISO11201 (EN31201). This value is measured with the following conditions.
 - Maximum load and speed
 - Operating mode is AUTO
- Note 5) When the robot is used in a low temperature environment that is near to 0°C, or the robot is not operated for a long time in an environment that is less than 0°C, for example during a holiday or overnight, viscous resistance of the drive train may cause occurrence of collision detect alarm (SRVO –050) etc. In this case, we recommend performing a warm up operation for several minutes.
- Note 6) Contact the service representative, if the robot is to be used in an environment or a place subjected to hot/cold temperatures, severe vibrations, heavy dust, water, water vapor, cutting oil, cleaning fluid splash and or other contaminations.
- Note 7) Liquid intrusion into the balancer inside might cause corrosion of the spring. Be careful to prevent liquid splashing to the balancer.

The following table lists the IEC60529-based Severe dust/liquid protection characteristics of the R-2000*i*C. Refer to Chapter 10 about severe dust/liquid protection package (option).

	Standard	Severe dust/liquid protection package (option)
J3 arm and wrist section	IP67	IP67
Drive unit of the main body	IP66	IP66
Main body	IP54 (*)	IP56

(*) Except some connectors




Fig. 3.1 (e) Severe dust/liquid protection characteristics of R-2000iC

NOTE

Definition of IP code

Definition of IP 67

- 6= Dust-tight: Complete protection against contact
- 7= Protection from water immersion: Ingress of water in harmful quantity shall not be possible when the enclosure is immersed in water under defined conditions of pressure and time.

Definition of IP 66

- 6= Dust-tight: Complete protection against contact
- 6= Protection from powerful water jets: Water projected in powerful jets against the enclosure from any direction shall have no harmful effects.

Definition of IP 54

- 5= Dust-tight: Ingress of dust is not entirely prevented, but it must not enter in sufficient quantity to interfere with the satisfactory of the equipment.
- 4= Protection from water immersion: Water splashing against the enclosure from any direction shall have no harmful effect.

Definition of IP 56

- 5= Dust-tight: Ingress of dust is not entirely prevented, but it must not enter in sufficient quantity to interfere with the satisfactory of the equipment.
- 6= Protection from powerful water jets: Water projected in powerful jets against the enclosure from any direction shall have no harmful effects.

Performance of resistant chemicals and resistant solvents

- (1) The robot (including severe dust/liquid protection model) cannot be used with the following liquids. Potentially these liquids will cause irreversible damage to the rubber parts (such as: gaskets, oil seals, O-rings etc.) and deterioration or corrosion of the balancer spring. (As exception to this only liquids tested and approved by FANUC can be used with the robot.)
 - (a) Organic solvents
 - (b) Cutting fluid or detergent including chlorine / gasoline
 - (c) Amine type cutting fluid or detergent
 - (d) Acid, alkali and liquid causing rust
 - (e) Other liquids or solutions, that will harm NBR or CR rubber
- (2) When the robots work in the environment, using water or liquid, complete draining of J1 base must be done. Incomplete draining of J1 base will make the robot break down.
- (3) Don not use unconfirmed liquid.
- (4) Do not use the robot immersed in water, neither temporary nor permanent. Robot must not be wet permanently.
 - * Example: In case motor surface is exposed to water for a long time, liquid may invade inside the motor and cause failure.
 - * In case of liquid splashing to the balancer, it might cause corrosion and deterioration of the spring and failures.

3.2 MECHANICAL UNIT EXTERNAL DIMENSIONS AND OPERATING SPACE

Fig. 3.2 (a) to (j) show the robot operating space. When installing peripheral devices, be careful not to interfere with the robot and its operating space.




Fig. 3.2 (a) Operating space (R-2000iC/165F/210F/240F)




Fig. 3.2 (b) Operating space (R-2000*i*C/125L)




Fig. 3.2 (c) Operating space (R-2000*i*C/220U)




Fig. 3.2 (d) Operating space (R-2000*i*C/165R/210R)




Fig. 3.2 (e) Operating space (R-2000*i*C/100P/100PH)




Fig. 3.2 (f) Operating space (R-2000*i*C/270F)




Fig. 3.2 (g) Operating space (R-2000*i*C/270R)




Fig. 3.2 (h) Operating space (R-2000*i*C/190S)




Fig. 3.2 (i) Operating space (R-2000iC/210L)




Fig. 3.2 (j) Operating space (R-2000*i*C/190U)

3.3 ZERO POINT POSITION AND MOTION LIMIT

Zero point and motion range are provided for each controlled axis. Exceeding the software motion limit of a controlled axis is called overtravel (OT). Overtravel is detected at both ends of the motion limit for each axis. The robot cannot exceed the motion range unless there is a loss of zero point position due to abnormalities in servo system or system error. In addition, the motion range limit by a fixed mechanical stopper or limit switch is also prepared to improve safety.

Fig. 3.3 (a) shows the position of fixed mechanical stopper.

Only in case of J1, robot stops by transforming fixed mechanical stopper (option).

Be sure to replace transformed stopper to new one. Tighten bolts with regulated torque referring to Appendix B [MOUNTING BOLT TORQUE LIST].

Replace mechanical stopper of J1-axis referring to Section 6.2.

1

WARNING

Do not reconstruct the fixed mechanical stopper. There is a possibility that the robot doesn't stop normally.




Fig. 3.3 (a) Position of fixed mechanical stopper

Fig. 3.3 (b) to (l) show the zero point and motion limit, limit switch detection position, and maximum stopping distance (stopping distance in condition of maximum speed and maximum load) of each axis.

* The motion range can be changed. For information on how to change the motion range, see Chapter 6, "AXIS LIMITS SETUP".




Fig. 3.3 (b) J1-axis motion limit (When fixed mechanical stopper is not specified)




Fig. 3.3 (c) J1-axis motion limit (When fixed mechanical stopper is specified)




Fig. 3.3 (d) J1-axis motion limit (When accuracy and stiffness enhancement option is specified)




Fig. 3.3 (e) J2-axis motion limit (R-2000iC/165F/210F/240F/125L/220U/270F/210L/190U)




Fig. 3.3 (f) J2-axis motion limit (R-2000iC/190S)




Fig. 3.3 (g) J2-axis motion limit (R-2000iC/165R/210R/100P/100PH/270R)




Fig. 3.3 (h) J3-axis motion limit




Fig. 3.3 (i) J5-axis motion limit




Fig. 3.3 (j) J4-axis motion limit

Fig. 3.3 (k) J6-axis motion limit




Fig. 3.3 (I) J4-axis motion limit (When accuracy and stiffness enhancement option is specified)

3.4 WRIST LOAD CONDITIONS

Fig. 3.4 (a) to (t) are diagrams to limit loads applied to the wrist.

- · Apply a load within the region indicated in the graph.
- Apply the conditions of the allowable load moment and the allowable load inertia. See Section 3.1 about the allowable load moment and the allowable load inertia.
- See Section 4.1 about the mounting of the end effector.




Fig. 3.4 (a) Wrist load diagram (ISO flange) (R-2000*i*C/165F/165R)




Fig. 3.4 (b) Wrist load diagram (Insulated ISO flange) (R-2000*i*C/165F/165R)




Fig. 3.4 (c) Wrist load diagram (ISO flange) (R-2000*i*C/210F/220U/210R)




Fig. 3.4 (d) Wrist load diagram (Insulated ISO flange) (R-2000*i*C/210F/220U/210R)




Fig. 3.4 (e) Wrist load diagram (ISO flange) (R-2000*i*C/240F)




Fig. 3.4 (f) Wrist load diagram (Insulated ISO flange) (R-2000iC/240F)




Fig. 3.4 (g) Wrist load diagram (ISO flange) (R-2000*i*C/125L)




Fig. 3.4 (h) Wrist load diagram (Insulated ISO flange) (R-2000*i*C/125L)




Fig. 3.4 (i) Wrist load diagram (Insulated ISO flange) (R-2000*i*C/100P/100PH)




Fig. 3.4 (j) Wrist load diagram (Insulated ISO flange) (R-2000*i*C/100P/100PH)




Fig. 3.4 (k) Wrist load diagram (ISO flange) (R-2000*i*C/270F/270R)




Fig. 3.4 (I) Wrist load diagram (Insulated ISO flange) (R-2000*i*C/270F/270R)




Fig. 3.4 (m) Wrist load diagram (ISO flange) (R-2000*i*C/270F 300kg option)




Fig. 3.4 (n) Wrist load diagram (Insulated ISO flange) (R-2000*i*C/270F 300kg option)




Fig. 3.4 (o) Wrist load diagram (ISO flange) (Accuracy and stiffness enhancement option flange) (R-2000iC/190S)




Fig. 3.4 (p) Wrist load diagram (Insulated ISO flange) (R-2000*i*C/190S)




Fig. 3.4 (q) Wrist load diagram (ISO flange) (R-2000iC/210L)




Fig. 3.4 (r) Wrist load diagram (Insulated ISO flange) (R-2000*i*C/210L)




Fig. 3.4 (s) Wrist load diagram (ISO flange) (R-2000*i*C/190U)




Fig. 3.4 (t) Wrist load diagram (Insulated ISO flange) (R-2000*i*C/190U)

3.5 LOAD CONDITIONS ON J2 BASE, J3 ARM AND J3 CASING

Table 3.5 (a) to (i) and Fig. 3.5 (b) to (e) show J2 base, J3 arm and J3 casing load condition.

! CAUTION

Take great care to avoid the load on the J3 arm from interfering with the J2 balancer during backflip operation of the J3-axis.




Fig. 3.5 (a) Interference of the J3 arm and the balancer




Fig. 3.5 (b) J2 base/J3 arm/J3 casing load condition (R-2000*i*C/165F/210F/240F/125L/220U)

Table 3.5 (a) J3 arm/J3 casing load condition (R-2000iC/165F/210F/240F)

J3 arm load weight (A)	J3 casing load weight (B)
25kg or less	50kg or less
(A)+(B)≦50kg	

Table 3.5 (b) J3 arm/J3 casing load condition (R-2000iC/125L)

J3 arm load weight (A)	J3 casing load weight (B)
25kg or less	40kg or less
(A)+(B)≦40kg	

Table 3.5 (c) J3 arm/J3 casing load condition (R-2000iC/220U)

J3 arm load weight (A)	J3 casing load weight (B)
25kg or less	30kg or less
6/5*(A)+(B)≦30kg	




Fig. 3.5 (c) J2 base /J3 arm/J3 casing load condition (R-2000*i*C/165R/210R/100P/100PH)

Table 3.5 (d) J3 arm/J3 casing load condition (R-2000iC/165R)

J3 arm load weight (A)	J3 casing load weight (B)
25kg or less	50kg or less
(A)+(B)≦50kg	

Table 3.5 (e) J3 arm/J3 casing load condition (R-2000iC/210R)

J3 arm load weight (A)	J3 casing load weight (B)
30kg or less	40kg or less
4/3*(A)+(B)≦40kg	

Table 3.5 (f) J3 arm/J3 casing load condition (R-2000iC/100P/100PH)

J3 arm load weight (A)	J3 casing load weight (B)
25kg or less	50kg or less
2*(A)+(B)≦50kg	




Fig. 3.5 (d) J2 base/J3 arm load condition (R-2000iC/270F/190S/210L/190U)

Table 3.5 (g) J3 arm load condition (R-2000*i*C/270F/190S)

J3 arm load weight 1 (A) Note 1)	J3 arm load weight 2 (B)
40kg or less	50kg or less
5/4*(A)+(B)≦50kg	

(Note 1) When accuracy and stiffness enhancement option is specified, the load cannot be installed on here.

Table 3.5 (h) J3 arm load condition (R-2000*i*C/210L/190U)

J3 arm load weight 1 (A)	J3 arm load weight 2 (B)
20kg or less	50kg or less
5/2*(A)+(B)≦50kg	




Fig. 3.5 (e) J2 base/J3 arm load condition (R-2000iC/270R)

Table 3.5 (i) J3 arm load condition (R-2000iC/270R)

J3 arm load weight 1 (A)	J3 arm load weight 2 (B)
30kg or less	40kg or less
4/3*(A)+(B)≦40kg	

4 EQUIPMENT INSTALLATION TO THE ROBOT

4.1 END EFFECTOR INSTALLATION TO WRIST

Fig. 4.1 (a) to (h) are the diagrams for installing end effectors on the wrist. To fasten the end effector, first position it by using fitting [A] or [B], two pin holes at [C], then lock it using screws at [D]. Select screws and positioning pins of a length that matches the depth of the tapped and pin holes. Fasten the bolt for fixing the end effector with following torque.

73.5±3.4Nm (750±35kgfcm)

↑ CAUTION

- 1 Notice the tooling coupling depth to wrist flange should be shorter than the flange coupling length.
- 2 For the high inertia mode, it is desirable to attach the end effector with 10 bolts.




Fig. 4.1 (a) End effector mounting face (ISO flange) (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R)




Fig. 4.1 (b) End effector mounting face (Insulated ISO flange A05B-1329-H151) (R-2000;C/165F/210F/240F/125L/220U/165R/210R)




Fig. 4.1 (c) End effector mounting face (Insulated ISO flange A05B-1333-H153) (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R)




Fig. 4.1 (d) End effector mounting face (ISO flange) (R-2000iC/100P/100PH)




Fig. 4.1 (e) End effector mounting face (Insulated ISO flange A05B-1329-H151) (R-2000iC/100P/100PH)




Fig. 4.1 (f) End effector mounting face (Insulated ISO flange A05B-1333-H153) (R-2000;C/100P/100PH)




Fig. 4.1 (g) End effector mounting face (ISO flange) (R-2000*i*C/270F/270R/190S/210L/190U)




Fig. 4.1 (h) End effector mounting face (Insulated ISO flange) (R-2000iC/270F/270R/190S/210L/190U)




Fig. 4.1 (i) End effector mounting face (Accuracy and stiffness enhancement option flange) (R-2000iC/190S)

4.2 EQUIPMENT MOUNTING FACE

As shown in Fig. 4.2 (a) to (h), tapped holes are provided to install equipment to the robot.

↑ CAUTION

- 1 Never perform additional machining operation such as drilling or tapping on the robot body. This will seriously affect the safety and function of the robot.
- 2 When using a user tap shown in Fig. 4.2 (a) to (h), keep the center of gravity position of the equipment according to Section 3.5.
- 3 Equipment should be installed so that mechanical unit cable does not interfere. If equipment interferes, the mechanical unit cable might be disconnected, and unexpected troubles might occur.
- 4 Note that the use of a tapped hole not shown in the following figure is not assured. Please do not use existing bolts that fasten the mechanical units to install equipment to the robot.




Fig. 4.2 (a) Equipment mounting faces (R-2000iC/165F/210F/240F/220U)




Fig. 4.2 (b) Equipment mounting faces (R-2000*i*C/125L)




Fig. 4.2 (c) Equipment mounting faces (R-2000iC/165R/210R)




Fig. 4.2 (d) Equipment mounting faces (R-2000iC/100P/100PH)




Fig. 4.2 (e) Equipment mounting faces (R-2000*i*C/270F/210L/190U)




Fig. 4.2 (f) Equipment mounting faces (R-2000iC/270R)




Fig. 4.2 (g) Equipment mounting faces (R-2000iC/190S)




Fig. 4.2 (h) Equipment mounting faces (R-2000*i*C/190S When accuracy and stiffness enhancement option is specified.)

4.3 LOAD SETTING

! CAUTION

- 1 Set the correct load condition parameter before the robot runs. Do not operate the robot in over when its payload is exceeded or incorrect. Do not exceed the allowable payload including connection cables. Operation with the robot over payload may result in troubles such as reducer life reduction.
- 2 WHEN PERFORMING LOAD ESTIMATION AFTER PARTS REPLACEMENT If wrist axis motors (J5/J6-axis) or reducers are replaced, payload estimation accuracy may decrease. Perform calibration of load estimation without the load such as hand before performing load estimation. Refer to Chapter 9 "LOAD ESTIMATION" in the CONTROLLER Optional Function OPERATOR'S MANUAL (B-83284EN-2).

The operation motion performance screens include the MOTION PERFORMANCE screen, MOTION PAYLOAD SET screen, and payload information and equipment information on the robot.

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [6 SYSTEM] on the next page,
- 3 Press the F1 ([TYPE]) key to display the screen switch menu.
- 4 Select "MOTION." The MOTION PERFORMANCE screen will be displayed.

MOTIO	NI DEDECO	MANAGE			IOD IT 100/
	N PERFOR	MANCE			JOINT 10%
Grou					
No. PA	AYLOAD[k			Comment	
1	10	65.00	Γ		1
2		0.00	Ì		Ī
3		0.00	Ì		ĺ
4		0.00	Ì		i
5		0.00	ř		i
6		0.00	ŀ		1
7		0.00	ŀ		1
8		0.00	ŀ		4
9		0.00	Ļ		4
_			Ļ		ļ
10		0.00	L		J
Active PAYLOAD number =0					
[TYPE]	GROUP	DETAIL	Α	RMLOAD) SETIND >

Ten different pieces of payload information can be set using condition No. 1 to 10 on this screen. Place the cursor on one of the numbers, and press F3 [DETAIL]. The MOTION PAYLOAD SET screen will be displayed.

MOTION PAYLOAD SET .	JOINT 10%
Group 1	
1 Schedule No[1]:[Comment	1
2 PAYLOAD [kg]	165.00
3 PAYLOAD CENTER X [cm]	-28.53
4 PAYLOAD CENTER Y [cm]	0.00
5 PAYLOAD CENTER Z [cm]	27.78
6 PAYLOAD INERTIA X [kgfcms^2]	56.84
7 PAYLOAD INERTIA Y [kgfcms^2]	59.39
8 PAYLOAD INERTIA Z [kgfcms^2]	15.10
[TYPE] GROUP NUMBER DEFAU	LT HELP




Fig. 4.3 (a) Standard tool coordinate

- 6 Set the payload, gravity center position, and inertia around the gravity center on the MOTION PAYLOAD SET screen. The X, Y, and Z directions displayed on this screen correspond to the respective standard tool coordinates (with no tool coordinate system set up). When values are entered, the following message will be displayed: "Path and Cycletime will change. Set it?" Respond to the message with F4 [YES] or F5 [NO].
- Pressing F3 [NUMBER] will bring you to the MOTION PAYLOAD SET screen for another condition number. For a multigroup system, pressing F2 [GROUP] will bring you to the MOTION PAYLOAD SET screen for another group
- Press the [PREV] key to return to the MOTION PERFORMANCE screen. Press F5 [SETIND], and enter the desired payload setting condition number.
- 9 On the MOTION PERFORMANCE screen, press F4 [ARMLOAD] to display the MOTION ARMLOAD SET screen.
 - (* This screen differs depending on the robot model.)

MOTION ARMLOAD SET	JOINT 100%
Group 1	
1 J2 BASE LOAD [kg]	550.00
2 J3 ARM LOAD [kg]	25.00
3 J3 CASING LOAD [kg]	10.00
l	
[TYPE] GROUP	DEFAULT HELP

- 10 Specify the weight of the load on the J2 base, J3 arm and J3 casing as follows:
- (*) Load mounting face differs depending on the robot model. Refer to "3.5 LOAD CONDITIONS ON J2 BASE, J3 ARM AND J3 CASING".

J2 BASE LOAD[kg]: Weight of the load on the J2 base
J3 ARM LOAD[kg]: Weight of the load on the J3 arm
J3 CASING LOAD[kg]: Weight of the load on the J3 casing

The following message will be displayed: "Path and Cycletime will change. Set it?" Select F4 [YES] or F5 [NO]. Once the loads are set up, the settings are completed by switching the power off and on again.

4.4 INERTIA LOAD SETTING

High inertia mode is provided for R-2000iC/165F/210F. The inertia mode is automatically set according to the load value set in Section 4.3. Table 4.4 (a) shows allowable load moment at wrist of standard inertia mode and high inertia mode.

Table 4.4 (a) Wrist unit allowable load inertia of standard inertia mode and high inertia mode

			Standard inertia mode	High inertia mode
Wrist unit allowable load inertia	J4-axis	165F	89kg·m² (908kgf·cm·s²)	120kg⋅m² (1225kgf⋅cm⋅s²)
		210F	147kg·m² (1500kgf·cm·s²)	225.4kg⋅m² (2300kgf⋅cm⋅s²)
	J5-axis	165F	89kg·m² (908kgf·cm·s²)	120kg⋅m² (1225kgf⋅cm⋅s²)
		210F	147kg·m² (1500kgf·cm·s²)	225.4kg⋅m² (2300kgf⋅cm⋅s²)
	J6-axis	165F	46kg·m² (469kgf·cm·s²)	100kg⋅m² (1020kgf⋅cm⋅s²)
		210F	82kg·m² (837kgf·cm·s²)	196kg⋅m² (2000kgf⋅cm⋅s²)

4.5 SWITCHING METHOD OF MAX PAYLOAD SPECIFICATION

About switching max payload specification

At R-2000*i*C/270F, payload 270kg setting and payload 300kg setting are prepared. By ordering R-2000*i*C/270F 300kg option (A05B-2600-S535), 300kg payload specification will be set when it is shipped by our factory.

The best addition and subtraction velocity operation can be achieved by the setting matched to the max payload specification. The setting is changed by executing the following KAREL.

R27SET27.PC: max payload 270kg specification
 R27SET30.PC: max payload 300kg specification

However these KAREL programs cannot be used with the wrist axis solution arm.


⚠ CAUTION

- 1 Refer to "Specification table" in Section 3.1 and "Wrist load diagram" in Section 3.4, and set max payload specification so that the payload does not exceed it. When the robot is moved with the wrong max payload specification, the robot functions and life might be affected significantly.
- 2 Be careful that the tracks and the cycle time of an existing instruction program change if setting change is executed.

Method of switching

There are the following two in the method of executing KAREL for switching method of max payload specification. Please use them properly according to the purpose.

1 Method of executing KAREL program by using "Call program" → Subsection 4.5.1 The KAREL program is set in the program call instruction of the TP program and the setting is changed by specifying with the argument that shows the group number, and executing it. The setting of a specific group R-2000*i*C/270F can be switched in this method.



2 Method of executing KAREL program directly → Subsection 4.5.2 Select and execute the KAREL program in program select screen. If two or more R-2000*i*C/270F exist in the multi group system, it is possible to change the setting of two or more R-2000*i*C/270F together by this method.

It depends as follows, and it explains the methods of executing KAREL for switching methods of max payload specification.

4.5.1 Method of Executing KAREL Program by Using "Call program"

The following procedures assume that R-2000*i*C/270F of the first group is switched to the max payload 300kg setting.


Execution procedure

1 Call the system variable screen.


- 2 Set system variables \$KAREL ENB to 1.
- 3 Open TP program edit screen.
- 4 Select "call program" from among the program instruction.

F1 key (INST)
$$\rightarrow$$
Select "CALL" \rightarrow Select "CALL program"


Then, the following screen will be displayed.




5 Press the F3 key (KAREL). The following screen will be displayed. Then select KAREL R27SET30 (for 300kg payload specification).



6 Press F4 key (CHOICE). Choose "Constant" from there. Then, the following screen will be displayed.




7 The group number (It is 1 here) is put with the cursor in "Constant".



8 Execute this program.

Push the [FWD] key while pushing the [SHIFT] key

Then, the following screen will be displayed. This shows that KAREL R27SET30.PC of max payload 300kg specification is executed.



9 Turn on the controller power again.

The change of the setting ends above.

4.5.2 Method of Executing KAREL Program Directly

Use scene

For instance, it is assumed that the following multi group system exists.


1st group: R-2000*i*C/270F (except wrist axis solution arm) 2nd group: R-2000*i*C/270F (except wrist axis solution arm)

It is possible to set R-2000*i*C/270F of the 1st group and 2nd to the max payload 300kg at the same time by the method explained in this Subsection.

NOTE

To set R-2000*i*C/270F of 1st group to max payload 300kg specification and R-2000*i*C/270F of 2nd group to max payload 270kg specification, method of this subsection cannot be used. In that case, please make two programs as follows, and change the setting by the method of Subsection 4.5.1.

- 1 Turn on the controller power again after executing the program 1.
- 2 Turn on the controller power again after executing the program 2.



Execution procedure


1 Call the system variable screen.

MENU key → Press F1 key (screen) after selecting "system" → Select system variables


- 2 Set system variables \$KAREL ENB to 1.
- 3 Call program select screen and select "KAREL".

```
program select key→ select KAREL by F1 key (type)
```

Then, two KAREL programs are displayed as follows.




4 Match the cursor to the KAREL program of the load that wants to be set, and press the [ENTER] key. It is time when it selected R27SET30.PC that is KAREL of max payload 300kg specification as follows. The selected program name is displayed to two places as follows.



5 Execute the program.

Press the [FWD] key while pushing the [SHIFT] key

Then, the following screen will be displayed. This is case of executing KAREL R27SET30.PC of max payload 300kg specification.



6 Turn on the controller power again.

The change of the setting ends above.

5 PIPING AND WIRING TO THE END EFFECTOR

↑ WARNING

- Only use appropriately-specified mechanical unit cables.
- Do not add user cables or hoses inside of the mechanical unit.
- Please do not obstruct the movement of the mechanical unit when cables are added to the outside of the mechanical unit.
- Please do not perform remodeling (adding a protective cover, or secure an additional outside cable) that obstructs the behavior of the cable.
- When external equipment is installed on the robot, make sure that it does not interfere with other parts of the robot.
- Cut and discard any unnecessary length of wire strand of the end effector (hand) cable. Insulate the cable with seal tape. (See Fig. 5 (a))
- If you have end effector wiring and a process that develops static electricity, keep the end effector wiring as far away from the process as possible. If the end effector and process must remain close, be sure to insulate the cable.
- Be sure to seal the connectors of the user cable and terminal parts of all cables to prevent water from entering the mechanical unit. Also, attach the cover to the unused connector.
- Frequently check that connectors are tight and cable jackets are not damaged.
- When precautions are not followed, damage to cables might occur. Cable failure
 may result in incorrect function of the end effector, robot faults, or damage to
 robot electrical hardware. In addition, electric shock could occur when touching
 the power cables.




Fig. 5 (a) Treatment method of end effector (hand) cable

5.1 AIR SUPPLY (OPTION)

Robot has air inlets and air outlets openings on the back of the J1 base and the side of the J3 casing or the J3 arm used to supply air pressure to the end effector. The connector is a Rc1/2 female (ISO). As coupling are not supplied, it will be necessary to prepare couplings which suit to the hose size.




Fig. 5.1 (a) Air supply (option) (R-2000iC/165F/210F/240F/125L/220U)




Fig. 5.1 (b) Air supply (option) (R-2000*i*C/165R/210R/100P/100PH)




Fig. 5.1 (c) Air supply (option) (R-2000iC/270F/270R/190S/210L/190U)

5.2 AIR PIPING (OPTION)

Fig. 5.2 (a) shows how to connect air hose to the robot. If the air control set is specified as an option, the air hose between the mechanical unit and the air control set is provided. Mount the air control set using the information in Fig. 5.2 (b). This is outside FANUC delivery scope.




Fig. 5.2 (a) Air piping (option)

Air control set

Fill the lubricator having air control set to the specified level with turbine oil #90 to # 140. The machine tool builder is required to prepare mounting bolts. This is outside FANUC delivery scope.




Fig. 5.2 (b) Air control set option (option)

NOTE

The capacity values of the three air components are determined as follows. These values must not be exceeded.

Air pressure	Supply air pressure	0.49 to 0.69MPa (5 to 7kgf/cm²), Setting: 0.49MPa (5kgf/cm²)		
	Amount of consumption	Maximum instantaneous amount 150NI/min (0.15Nm³/min)		

5.3 INTERFACE FOR OPTION CABLE (OPTION)

Fig. 5.3 (a), (b), (j), (k) show the position of the option cable interface. Fig. 5.3 (c) to (i) and (l) to (o) show the option cable interface. EE interface (RI/RO), user cable (signal line, signal line usable to the force sensors and 3D Laser Vision sensor, signal line usable to the force sensor, power lines), DeviceNet cable (signal line), DeviceNet cable (power line), additional axis motor cable (Pulsecoder line), additional axis motor cable (power, brake line), camera cable, sensor cable, Ethernet cable (signal line/power line), PROFINET cable (signal line/power line), accuracy and stiffness enhancement option cable are prepared as options.

NO	OTE				
1	1 Each option cable is written as shown below on the connector panel.				
	EE interface (RI/RO)	: EE			
	User cable (signal)	: AS			
	User cable (signal usable to force sensor and 3D Laser Vision sensor)	: ASi			
	User cable (signal usable to force sensor)	: ASH			
	User cable (power)	: AP			
	DeviceNet cable (signal)	: DS			
	DeviceNet cable (power)	: DP			
	Additional axis motor cable (Pulsecoder)	: ARP			
	Additional axis motor cable (power, brake)	: ARM			
	Camera cable	: CAM			
	Sensor cable	: SEN			
	Ethernet cable (signal)	: ES			
	Ethernet cable (power)	: EP			
	PROFINET cable (signal)	: PNS			
	PROFINET cable (power)	: PNP			
	Accuracy and stiffness enhancement option cable	: ARE			
	(only for R-2000iC/190S)				
2	There is no option cable and an air piping for mechanical unit cable A05B-1333-				
	H557, A05B-1334-H554, A05B-1337-H252, A05B-1337-H557.				
3	Specifications of camera cable for R-30 <i>i</i> B/R-30 <i>i</i> B Mate and R-30 <i>i</i> B Plus/ R-30 <i>i</i> B				
	Mate Plus are different.				




Fig. 5.3 (a) Position of interface for option cable (OPTION) (R-2000;C/165F/210F/240F/125L/220U)




Fig. 5.3 (b) Position of interface for optional cable (OPTION) (R-2000*i*C/165R/210R/100P/100PH)




Fig. 5.3 (c) Interface for option cable (1/11)




Fig. 5.3 (d) Interface for option cable (2/11)




Fig. 5.3 (e) Interface for option cable (3/11)




Fig. 5.3 (f) Interface for option cable (4/11)




Fig. 5.3 (g) Interface for option cable (5/11)




Fig. 5.3 (h) Interface for option cable (6/11) (When severe dust/liquid protection package is specified)




Fig. 5.3 (i) Interface for option cable (7/11) (When severe dust/liquid protection package is specified)




Fig. 5.3 (j) Position of interface for optional cable (option) (R-2000*i*C/270F/190S/210L/190U)




Fig. 5.3 (k) Position of interface for optional cable (OPTION) (R-2000iC/270R)




Fig. 5.3 (I) Interface for option cable (8/11)




Fig. 5.3 (m) Interface for option cable (9/11)




Fig. 5.3 (n) Interface for option cable (10/11) (When severe dust/liquid protection package is specified)




Fig. 5.3 (o) Interface for option cable (11/11) (When severe dust/liquid protection package is specified)

1 EE interface (RI/RO) (option)

Fig. 5.3 (p) and (q) show pin layout for EE interface (RI/RO). When severe dust/liquid protection package is specified, the connector has guide pins and bushes for preventing improper insertion. For cables prepared by the user, use these guide pins and bushes.




Fig. 5.3 (p) Pin layout for EE interface(RI/RO) (option)




Fig. 5.3 (q) Pin layout for EE interface (RI/RO) (When severe dust/liquid protection package is specified) (option)

NOTE

For wiring of the peripheral device to the EE interface, refer to the "ELECTRICAL CONNECTIONS Chapter of CONTROLLER MAINTENANCE MANUAL", too.

User cable (signal line) (AS) Interface (option)
 Fig. 5.3 (r) shows pin layout for user cable (signal line) interface.
 The connector has a code pin for preventing improper insertion. For cables prepared by the user, use this code pin.




Fig. 5.3 (r) Pin layout for user cable (signal line) (AS) interface and code pin layout (option)

3 User cable (signal line usable to force sensor and 3D Laser Vision sensor) (ASi) (signal line usable to force sensor Vision sensor) (ASH) Interface (option)

Fig. 5.3 (s) shows the pin layout for the user cable (signal line usable to force sensor and 3D Laser Vision sensor)/(signal line usable to force sensor Vision sensor) (ASH) interface.

The connector has a code pin for preventing improper insertion. The code pin is required for the cable which is prepared by the user.




Fig. 5.3 (s) Pin layout for user cable (signal line usable to force sensor and 3D Laser Vision sensor) (ASi) (signal line usable to force sensor) (ASH)/interface and code pin layout (option)

User cable (power line) (AP) Interface (option)
 Fig. 5.3 (t) shows the pin layout for the user cable (power line) interface.
 The connector has a code pin for preventing improper insertion. The code pin is required for the cable which is prepared by the user.




Fig. 5.3 (t) Pin layout for user cable (power line) (AP) interface and code pin layout (option)

5 DeviceNet cable (signal line) (DS) Interface (option) Fig. 5.3 (u) shows the pin layout for the DeviceNet cable (signal line) interface.




Fig. 5.3 (u) Pin layout for DeviceNet cable (signal line) (DS) interface (option)

6 DeviceNet cable (power line) (DP) Interface (option) Fig. 5.3 (v) shows the pin layout for the DeviceNet cable (power line) interface.




Fig. 5.3 (v) Pin layout for DeviceNet cable (power line) (DP) interface (option)

Additional axis motor cable (Pulsecoder cable) (ARP) interface (option)

Fig. 5.3 (w) shows the pin layout of the additional axis motor cable (Pulsecoder cable) interface.

The connector has a code pin for preventing improper insertion.




Fig. 5.3 (w) Pin layout of the additional axis motor cable (Pulsecoder cable) (ARP) interface and layout position of the code pin (option)

Table 5.3 (a) Comparative table of signal name according to the motor

ARP	α motor, β motor	αi , αi –B motor, βi , βi -B motor
SPD	SD	-
XSPD	*SD	-
PRQ	REQ	RD
XPRQ	*REQ	*RD

8 Additional axis motor cable (power and brake cables) (ARM) interface (option)
Fig. 5.3 (x) shows the pin layout of the additional axis motor cable (power and brake cables) interface.
The connector has a code pin for preventing improper insertion.




Fig. 5.3 (x) Pin layout of the additional axis motor cable (power and brake cables) (ARM) interface and layout position of the code pin (option)

9 Ethernet cable (signal line) (ES) interface (option) Fig. 5.3 (y) shows the pin layout of the Ethernet cable (signal line) (ES) interface.




Fig. 5.3 (y) Pin layout for Ethernet cable (signal line) (ES) interface (option)

10 Ethernet cable (power line) (EP) interface (option)
Fig. 5.3 (z) shows the pin layout of the Ethernet cable (power line) (EP) interface. The connector has a code pin for preventing improper insertion.




Fig. 5.3 (z) Pin layout for Ethernet cable (power line) (EP) interface (option)

PROFINET cable (signal line) (PNS) interface (option)
Fig. 5.3 (aa) shows the pin layout of the PROFINET cable (signal line) (PNS) interface.




Fig. 5.3 (aa) Pin layout for PROFINET cable (signal line) (PNS) interface (option)

PROFINET cable (power line) (PNP) interface (option)
Fig. 5.3 (ab) shows the pin layout of the PROFINET cable (power line) (PNP) interface.




Fig. 5.3 (ab) Pin layout for PROFINET cable (power line) (PNP) interface (option)

Connector specifications

	Table 5.3 (b) Connector specifications (Mechanical unit side)					
Cable		nput side	Maker		Output side	Maker
Cable	(J1 co	nnector panel)	/dealer	(J3 cd	onnector panel)	/dealer
EE (RI/RO)				JI	MWR2524F	Fujikura Ltd.
EE (RI/RO) (When severe dust/liquid protection package is specified)				Housing Insert Contact Guide pin Bush	09 30 006 0301 09 16 024 3101 09 15 000 6204 09 33 000 9908 09 33 000 9909	
AS ASi ASH AP	Housing Insert Contact Code pin Housing Insert Contact	09 30 006 0301 09 16 024 3001 09 15 000 6103 09 30 000 9901 09 20 010 0301 09 21 015 3001 09 15 000 6101		Housing Insert Contact Code pin Housing Insert Contact	09 30 006 0301 09 16 024 3101 09 15 000 6203 09 30 000 9901 09 20 010 0301 09 21 015 3101 09 15 000 6201	
ARP	Code pin Housing Insert Contact Contact Code pin	09 30 000 9901 09 30 006 0301 09 16 024 3001 09 15 000 6103 09 15 000 6104 09 30 000 9901	HARTING	Code pin Housing Insert Contact Contact Code pin	09 30 000 9901 09 30 006 0301 09 16 024 3101 09 15 000 6203 09 15 000 6204 09 30 000 9901	HARTING K.K.
ARM	Housing Insert Contact Contact Code pin	09 20 010 0301 09 21 015 3001 09 15 000 6101 09 15 000 6106 09 30 000 9901	K.K.	Housing Insert Contact Contact Code pin	09 20 010 0301 09 21 015 3101 09 15 000 6201 09 15 000 6206 09 30 000 9901	
ES	Connector Contact	21 03 881 2425 09 67 000 7476		Connector Contact	21 03 881 2425 09 67 000 7476	
EP	Housing Insert Contact Contact Guide pin Bush	09 30 006 0301 09 32 010 3001 09 33 000 6105 09 33 000 6121 09 33 000 9908 09 33 000 9909		Housing Insert Contact Contact Guide pin Bush	09 30 006 0301 09 32 010 3101 09 33 000 6205 09 33 000 6220 09 33 000 9908 09 33 000 9909	
PNS	XS5P-T426-	5	OMRON Corporation	XS5P-T426-	-5	OMRON Corporation
DS	CMC	3A-R5P-S-2	Fujikura Ltd.	CMO	03A-PR5S-S-2	
DP	Housing Insert Contact	09 30 006 0301 09 32 010 3001 09 33 000 6105	. sjindra Etd.		03A-PR4S-S-2	
PNP	Housing Insert Contact Guide pin Bush	09 30 006 0301 09 32 010 3001 09 33 000 6105 09 33 000 9908 09 33 000 9909	HARTING K.K.	СМО	03A-PR5S-S-2	Fujikura Ltd.

Table 5.3 (c) Connector specifications (User side) (1/4)

Cable	Input side (J1 connector panel)		ut side (J3 connect	or panel)	Maker /dealer
FF (BI/BO)		JMSP252	<u>4M</u> (*1)	Straight	Fujikura
EE (RI/RO)		JMLP252	4M /	Angle	Ltd.
EE (RI/RO) (When severe dust/liquid protection package is		Hood (NOTE 2) Insert Contact (24 pcs)	09 30 006 1540 1541 0542 0543 1440 (*2 1441 0442 0443 09 16 024 3001 (*3 09 15 000 6104 (*4 6103 6105 6102 6101 6106	·	HARTING K.K.
specified)		Clamp (NOTE 2) Guide pin (2 pcs)	09 00 000 5085 (*5 5086 5090 5094 Many other types 09 33 000 9908 (*6	are available	
		Bush (2 pcs)	09 33 000 9909 (*7	")	

NOTE 1

Underlined parts are attached. Below shows spec. to order in our company.

(*1)A63L-0001-0234#S2524M

(*2)A63L-0001-0453#06B1440

(*3)A63L-0001-0453#24DDM

(*4)A63L-0001-0453#CA6104

(*5)A63L-0001-0453#A-152D

(*6)A63L-0001-0453#A-9908

(*7)A63L-0001-0453#A-9909

Table 5.3 (d) Connector specifications (User side) (2/4)

Cable	Input	Table 5.3 (d) Cor side (J1 connector			t side (J3 connector panel)	Maker
Cable	input	·	• •	Juipu	l state (ou confidential panier)	/dealer
	Hood (NOTE 2)	09 30 006 1540 1541 0542 0543 1440 1441 0442 0443	Side entry Top entry	Hood	←The same	
	Insert	09 16 024 3101		Insert	09 16 024 3001	1
AS ASi ASH	Contact (NOTE 2)	09 15 000 6204 A 6203 A 6205 A 6202 A 6201 A 6206 A	AWG 20 AWG 18 AWG 18 AWG 16	Contact (NOTE 2)	09 15 000 6104 AWG 26-22 6103 AWG 20 6105 AWG 18 6102 AWG 18 6101 AWG 16 6106 AWG 14	
	Clamp (NOTE 2)	09 00 000 5083 5086 5090	etc.	Clamp	←The same	HARTING
	Code pin	09 30 000 9901		Code pin	09 30 000 9901	K.K.
	Hood (NOTE 2)	09 20 010 1541 0540 0541 1440 0440 0441	Side entry Top entry	Hood	←The same	
	Insert	09 21 015 3101		Insert	09 21 015 3001	
АР	Contact (NOTE 2)	09 15 000 6204 A 6203 A 6205 A 6202 A 6201 A 6206 A	AWG 20 AWG 18 AWG 18 AWG 16	Contact (NOTE 2)	09 15 000 6104 AWG 26-22 6103 AWG 20 6105 AWG 18 6102 AWG 18 6101 AWG 16 6106 AWG 14	
	Clamp (NOTE 2)	09 00 000 5083 5086 5090 5094 6 Many other types a		Clamp	←The same	
	Code pin	09 30 000 9901		Code pin	09 30 000 9901	
PNS	XS5W-T42 XS5W-T42	21-□M0-K 21-□M2-K 21-□M2-KR 21-□MC-K 21-□MC-KR Many other types	are available		←The same	OMRON Corporation
	Connector	21 03 881 1405		Connector	←The same	
ES	Contact (NOTE 2)	8576 A	WG 28-24 WG 26-22 WG 24-20 WG 22-18	Contact	←The same	HARTING K.K.

Table 5.3 (e) Connector specifications (User side) (3/4)

	Table 5.3 (e) Connector specifications (User side) (3/4)						,
Cable		Input side				Output side	Maker
Gubic		(J1 connector panel)		/dealer	((J3 connector panel)	/dealer
	Hood (NOTE 2)	09 20 010 1540 1541 0542 0543 1440 1441 0442	Side entry V Top entry		Hood	←The same	
	Insert	09 32 010 3101			Insert	09 32 010 3001	
EP	Contact (NOTE 2)	09 33 000 6220 6214 6205 6204 6202 6207	AWG 20 AWG 18 AWG 18 AWG 16 AWG 14 AWG 12	HARTING K.K.	Contact (NOTE 2)	09 33 000 6121 AWG 20 6114 AWG 18 6105 AWG 18 6104 AWG 16 6102 AWG 14 6107 AWG 12	HARTING K.K.
	Clamp (NOTE 2)	09 00 000 5083 5086 5090 5094 Many other types a			Clamp	←The same	
	Guide pin	09 33 000 9908			Guide pin	←The same	
	Bush	09 33 000 9909			Bush	←The same	
DS	MINI connect 5-pin, FEMA CM03-P5S	tor for use on the device net LE		Fujikura Ltd.	MINI connector for use on the device net 5-pin, MALE CM03-J5P		Fujikura Ltd.
	Hood (NOTE 2)	09 30 006 1540 1541 0542 0543 1440 1441 0442 0443	Side entry V Top entry				
	Insert	09 32 010 3101			MINILCOR	nnector for use on the	
DP	Contact (NOTE 2)	09 33 000 6220 6214 6205 6204 6202 6207	AWG20 AWG18 AWG18 AWG16 AWG14 AWG12	HARTING K.K.		et 4-pin, MALE	Fujikura Ltd.
	Clamp (NOTE 2)	09 00 000 5083 5086 5090 5094 Many other type					

Table 5.3 (f) Connector specifications (User side) (4/4)

Cable	Inpu	ıt side (J1 connecto	or panel)	Maker /dealer	Output side (J3 connector panel)	Maker /dealer
PNP	Contact	09 15 000 1541	AWG 26-22 AWG 20 AWG 18 AWG 18 AWG 16 AWG 14	HARTING K.K.	MINI connector for use on the device net 5-pin, MALE CM03-J5P	Fujikura Ltd.
	Guide pin	09 33 000 9908]		
	Bush	09 33 000 9909				

NOTE 2

For details, such as the dimensions, of the parts listed above, refer to the related catalogs offered by the respective manufactures, or contact your local FANUC representative.

6 AXIS LIMITS SETUP

By setting the motion range of each axis, you can change the robot's motion range from the standard values. Changing the motion range of the robot is effective under the following circumstances:

- · Used motion range of the robot is limited.
- There is an area where tool and peripheral devices interfere with the robot.
- The length of cables and hoses attached for application is limited.

There are three methods used to prevent the robot from going beyond the necessary motion range.

- Limit axis motion range by DCS (All axes (option))
- Limit axis motion range adjustable mechanical stopper (J1/J2/J3-axes (option))
- Limit axis motion range by adjustable mechanical stopper and switches (J1-axis (option))

⚠ WARNING

- 1 Changing the motion range of any axis affects the operating range of the robot. To avoid trouble, carefully consider any possible effect of the change to the movable range of each axis in advance. Otherwise, it is likely that an unexpected condition will occur; for example, an alarm may occur in a previously taught position.
- 2 For J1-axis, use adjustable mechanical stoppers, for J2/J3-axis, use the adjustable mechanical stoppers or DCS function so that damage to peripheral equipment and injuries to human bodies can be avoided.
- 3 Mechanical stoppers are physical obstacles. For J1 to J3-axis, it is possible to re-position the adjustable mechanical stoppers. But the robot cannot move beyond them. For J5-axis, the mechanical stoppers are fixed. For the J4 and J6-axes, only DCS-specified limits are available.
- 4 For changing J2 and J3-axes interference angles, only adjustable mechanical stoppers are available; DCS specified movable range cannot be changed.
- 5 Adjustable mechanical stoppers (J1, J2, and J3-axes) are deformed in a collision to stop the robot. Once a stopper is subject to a collision, it can no longer assure its original strength and, therefore, may not stop the robot. When this happens, replace it with a new one.

6.1 CHANGE AXIS LIMIT BY DCS (OPTION)


The robot motion can be restricted with DCS (Dual check safety) function by using the following software. For J2/J3-axis, the same effect as adjustable mechanical stopper described in Section 6.2 can be obtained. The robot motion can be restricted at any angle and position if it is in robot motion area. DCS functions are certified to meet the requirements of International Standard ISO13849-1 and IEC61508 approved by notified body. If only the operating space is set using Joint Position Check, the robot stops after it goes beyond the workspace. When the motor power is shut down, the robot's momentum causes it to move some distance before it completely stops. The actual "Robot Stop Position" will be beyond the workspace. To stop the robot within the robot workspace, use the DCS Stop Position Prediction function. The stop position prediction is disabled by default.

• DCS position/speed check function (J567)


As an example, we shows the procedure to set $\pm 30^{\circ}$ for J2-axis in here. Refer to Dual check safety function Operator's Manual (B-83184EN) for details of other setting, function and DCS stop position prediction.

Setting procedure


- 1 Press the [MENU] key to display the screen menu.
- 2 Press [0 NEXT] and press [6 SYSTEM].
- 3 Press the F1 ([TYPE]).
- 4 Select [DCS]. The following screen will be displayed.



Move the cursor to [1 Joint position check], then press the [DETAIL].




6 Move the cursor to [1], then press the [DETAIL].




- 7 Move the cursor to [DISABLE], then press [CHOICE], set the status to [ENABLE].
- 8 Move the cursor to [Group], then input the robot group number, then press the [ENTER] key.
- 9 Move the cursor to [Axis], then input "2", then press the [ENTER] key.
- 10 Move the cursor to [Upper limit] right side, then input "30", then press the [ENTER] key.
- 11 Move the cursor to [Lower limit] right side, then input "-30", then press the [ENTER] key.

⚠ WARNING


If only the operating space is set using Joint Position Check, the robot stops after it goes beyond the workspace. When the motor power is shut down, the robot's momentum causes it to move some distance before it completely stops. The actual "Robot Stop Position" will be beyond the workspace. To stop the robot within the robot workspace, use the DCS Stop Position Prediction function. The stop position prediction is disabled by default.




12 Press the [PREV] key two times, back to the first screen.



- 13 Press the [APPLY].
- Input 4-digit password, then press the [ENTER] key. (Password default setting is "1111".)
- 15 The following screen will be displayed, then press the [OK].



[CHGD] on the right side of [1 Joint position check] will change to [PEND].



16 Cycle the power of the controller in the cold start mode so the new settings are enabled.



. ₩ARNING

You must cycle the power of the controller to enable the new setting. If you fail to do so, the robot does not work normally and it may injure personnel or damage the equipment.

6.2 ADJUSTABLE MECHANICAL STOPPER AND LIMIT SWITCH SETTING (OPTION)

For the J1, J2, and J3-axes, adjustable mechanical stopper (option) can be installed. It is possible to reposition adjustable mechanical stoppers. Change the position of the adjustable mechanical stoppers according to the desired movable range. For the J1-axis, the limit switch-based movable range can be used together. Refer to Section 6.3 and 6.4 for details.

Table 6.2 (a) Motion range that can be set by the adjustable mechanical stopper and space between the upper and lower limits (R-2000*i*C/165F/210F/240F/125L/220U)

Item	1	Settable motion range
J1-axis adjustable	Upper limit	Settable in steps of 7.5° in the range of -120° to +180°
mechanical stopper,	Lower limit	Settable in steps of 7.5° in the range of -180° to +120°
limit switch	Space between the upper and lower limits	A space of 60° or more is required.
J2-axis adjustable mechanical stopper	Upper limit	Settable in steps of 15° in the range of -60° to +60°. A fixed mechanical stopper is also provided at +76°. (+76° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 15° in the range of -30° to +75°. A fixed mechanical stopper is also provided at the -60°. (-60° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 30° or more is required.
J3-axis (J2+J3) adjustable mechanical stopper	Upper limit	Settable in steps of 15° in the range of -30° to +105°. A fixed mechanical stopper is also provided at +180°. (+180° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 15° in the range of 0° to +135°. A fixed mechanical stopper is also provided at -79°. (-79° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 15° or more is required.

Table 6.2 (b) Motion range that can be set by the adjustable mechanical stopper and space between the upper and lower limits (R-2000*i*C/165R/210R)

Item	1	Settable motion range
J1-axis adjustable	Upper limit	Settable in steps of 7.5° in a range of -120° to +180°
mechanical stopper,	Lower limit	Settable in steps of 7.5° in the range of -180° to +120°
limit switch	Space between the upper and lower limits	A space of 60° or more is required.
J2-axis adjustable mechanical stopper	Upper limit	Settable in steps of 15° in the range of -120° to +60°. A fixed mechanical stopper is also provided at +80°. (+80° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 15° in the range of -90° to +75°. A fixed mechanical stopper is also provided at -120°.(-120° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 30° or more is required.
J3-axis (J2+J3) adjustable	Upper limit	Settable in steps of 15° in the range of -30° to +105°. A
mechanical stopper		fixed mechanical stopper is also provided at +180°.(+180° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 0° in the range of 0° to +135°. A fixed mechanical stopper is also provided at -79°. (-79° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 15° or more is required.

Table 6.2 (c) Motion range that can be set by the adjustable mechanical stopper and space between the upper and lower limits (R-2000*i*C/100P/100PH)

Item	•	Settable motion range
J1-axis adjustable	Upper limit	Settable in steps of 5° in the range of -110° to +180°
mechanical stopper	Lower limit	Settable in steps of 5° in the range of -180° to +110°
	Space between the upper and lower limits	A space of 70° or more is required.
J2-axis adjustable mechanical stopper	Upper limit	Settable in steps of 15° in the range of -120° to +60°. A fixed mechanical stopper is also provided at +80°. (+80° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 15° in the range of -90° to +75°. A fixed mechanical stopper is also provided at -120°. (-120° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 30° or more is required.
J3-axis (J2+J3) adjustable mechanical stopper	Upper limit	Settable in steps of 15° in the range of -30° to +105°. A fixed mechanical stopper is also provided at +180°. (+180° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 15° in the range of 0° to +135°. A fixed mechanical stopper is also provided at -79°. (-79° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 15° or more is required.

Table 6.2 (d) Motion range that can be set by the adjustable mechanical stopper and space between the upper and lower limits (R-2000*i*C/270F/210L/190U)

Item	1	Settable motion range
J1-axis adjustable	Upper limit	Settable in steps of 5° in the range of -110° to +180°
mechanical stopper,	Lower limit	Settable in steps of 5° in the range of -180° to +110°
limit switch	Space between the upper and lower limits	A space of 70° or more is required.
J2-axis adjustable mechanical stopper	Upper limit	In case of 270F/210L, settable in steps of 15° in the range of -60° to +60°. In case of 190U, settable in steps of 15° in the range of -45° to +60°. A fixed mechanical stopper is also provided at +76°.(+76° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 15° in the range of -45° to +75°. A fixed mechanical stopper is also provided at -60°.(-60° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 30° or more is required.
J3-axis (J2+J3) adjustable mechanical stopper	Upper limit	Settable in steps of 15° in the range of -30° to +90°. A fixed mechanical stopper is also provided at +180°.(+180° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 15° in the range of 0° to +120°. A fixed mechanical stopper is also provided at -79°. (-79° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 15° or more is required.

Table 6.2 (e) Motion range that can be set by the adjustable mechanical stopper and space between the upper and lower limits (R-2000*i*C/270R)

	apper and lower	I IIIIIII (K-2000/C/270K)
Item	1	Settable motion range
J1-axis adjustable	Upper limit	Settable in steps of 5° in the range of -110° to +180°
mechanical stopper,	Lower limit	Settable in steps of 5° in the range of -180° to +110°
limit switch	Space between the upper and lower limits	A space of 70° or more is required.
J2-axis adjustable mechanical stopper	Upper limit	Settable in steps of 15° in the range of -120° to +60°. A fixed mechanical stopper is also provided at +80°.(+80° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 15° in the range of -90° to +75°. A fixed mechanical stopper is also provided at -120°.(-120° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 30° or more is required.
J3-axis (J2+J3) adjustable mechanical stopper	Upper limit	Settable in steps of 15° in the range of -30° to +90°. A fixed mechanical stopper is also provided at +180°.(+180° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 15° in the range of 0° to +120°. A fixed mechanical stopper is also provided at -79°. (-79° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 15° or more is required.

Table 6.2 (f) Motion range that can be set by the adjustable mechanical stopper and space between the upper and lower limits (R-2000*i*C/190S)

Iten	1	Settable motion range
J1-axis adjustable mechanical stopper, limit switch	Upper limit	Settable in steps of 5° in the range of -110° to +180° When accuracy and stiffness enhancement option is specified, set to -110° to -60°, -50° is impossible.
	Lower limit	Settable in steps of 5° in the range of -180° to +110° When accuracy and stiffness enhancement option is specified, set to -145°, -135° to -60°, -50° is impossible.
	Space between the upper and lower limits	A space of 70° or more is required.
J2-axis adjustable mechanical stopper	Upper limit	Settable in steps of 15° in the range of -60° to +60°. A fixed mechanical stopper is also provided at +130°.(+130° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 15° in the range of -45° to +90°. A fixed mechanical stopper is also provided at -80°.(-80° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 30° or more is required.
J3-axis (J2+J3) adjustable mechanical stopper	Upper limit	Settable in steps of 15° in the range of -30° to +90°. A fixed mechanical stopper is also provided at +180°.(+180° is upper limit of the standard motion range.)
	Lower limit	Settable in steps of 15° in the range of 0° to +120°. A fixed mechanical stopper is also provided at -79°. (-79° is lower limit of the standard motion range.)
	Space between the upper and lower limits	A space of 15° or more is required.

NOTE

- 1 If the newly set operation range does not include 0° , you must change it by zero degree mastering so that 0° is included.
- 2 When adjustable mechanical stopper is ordered, mounting bolt is attached.
- 3 When motion range is changed by movable mechanical stopper, be sure to set the motion range of soft same refer to Subsection 6.2.2.

6.2.1 Installing adjustable mechanical stopper option

Attach adjustable mechanical stoppers referring to Fig. 6.2.1 (a) to (w).




Fig. 6.2.1 (a) J1-axis adjustable mechanical stopper (option) (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R)




Fig. 6.2.1 (b) Mounting the J1-axis adjustable mechanical stopper (1/2) $(R-2000 \it{i} C/165F/210F/240F/125L/220U/165R/210R)$




Fig. 6.2.1 (c) Mounting the J1-axis adjustable mechanical stopper (2/2) (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R)




Fig. 6.2.1 (d) J1-axis adjustable mechanical stopper (option) (R-2000*i*C/100P/100PH/270F/270R/190S/210L/190U)





Fig. 6.2.1 (e) Mounting the J1-axis adjustable mechanical stopper (1/3) (R-2000 i C/100 P/100 PH/270 F/270 R/190 S/210 L/190 U)

Note on attaching the J1-axis adjustable mechanical stopper

The motion range limited by the J1-axis adjustable mechanical stopper can be changed in steps of 5°by changing the installation holes of the adapter .Select the appropriate installation hole corresponding to the desired limit angle with reference to the following figure.

Adapter A290-7335-X215 hole number



	Mounting face X	Mounting face Y
For holes A,C,E and G	Mounting pattern A Bolt	Mounting pattern B
For holes B,D,F and H	Mounting pattern C	Mounting pattern D




Fig. 6.2.1 (f) Mounting the J1-axis adjustable mechanical stopper (2/3) (R-2000*i*C/100P/100PH/270F/270R/190S/210L/190U)




Fig. 6.2.1 (g) Mounting the J1-axis adjustable mechanical stopper (3/3) (R-2000 i C/100 P/100 PH/270 F/270 R/190 S/210 L/190 U)




Fig. 6.2.1 (h) J2-axis adjustable mechanical stopper (option) (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R/100P/100PH)




Fig. 6.2.1 (i) J2-axis adjustable mechanical stopper (option) (R-2000iC/270F/270R/190S/210L/190U)




Fig. 6.2.1 (j) Mounting the J2-axis adjustable mechanical stopper (1/2) $(R-2000 \it i C/165F/210F/240F/125L/220U)$




Fig. 6.2.1 (k) Mounting the J2-axis adjustable mechanical stopper (2/2) $(R-2000 \it i C/165F/210F/240F/125L/220U)$




Fig. 6.2.1 (I) Mounting the J2-axis adjustable mechanical stopper (1/2) (R-2000iC/165R/210R/100P/100PH/270R)




Fig. 6.2.1 (m) Mounting the J2-axis adjustable mechanical stopper (2/2) (R-2000*i*C/165R/210R/100P/100PH/270R)




Fig. 6.2.1 (n) Mounting the J2-axis adjustable mechanical stopper (1/3) (R-2000 i C/270 F/190 S/210 L/190 U)




Fig. 6.2.1 (o) Mounting the J2-axis adjustable mechanical stopper (2/3) (R-2000iC/270F/190S/210L)




Fig. 6.2.1 (p) Mounting the J2-axis adjustable mechanical stopper (3/3) (R-2000iC/190U)




Fig. 6.2.1 (q) J3-axis adjustable mechanical stopper (option) (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R/100P/100PH)

For R-2000*i*C/165F/210F/240F/125L/165R/210R, when the J3/J4/J5/J6-axis motor full cover option (A05B-1333-J044) is specified, remove the lower side cover B, then install the J3-axis adjustable mechanical stopper. After installation, install the cover B.




Fig. 6.2.1 (r) Mounting the J3-axis adjustable mechanical stopper (1/3) (R-2000*i*C/165F/210F/240F/125L/165R/210R)




Fig. 6.2.1 (s) Mounting the J3-axis adjustable mechanical stopper (2/3) (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R/100P/100PH)




Fig. 6.2.1 (t) Mounting the J3-axis adjustable mechanical stopper (3/3) (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R/100P/100PH)




Fig. 6.2.1 (u) J3-axis adjustable mechanical stopper (option) $(R-2000 \it{i} C/270F/270R/190S/210L/190U)$




Fig. 6.2.1 (v) Mounting the J3-axis adjustable mechanical stopper (1/2) $(R-2000\it{i}C/270F/270R/190S/210L/190U)$




Fig. 6.2.1 (w) Mounting the J3-axis adjustable mechanical stopper (2/2) $(R-2000 \it i C/270F/270R/190S/210L/190U)$

6.2.2 Changing the parameter setting

Setting procedure


- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE].
- 4 Select [Axis Limits]. The following screen will be displayed.

System A	Axis Limits		JOINT 10	00%
Group	1			1/16
AXIS	GROUP	LOWER	UPPER	
1	1	-185.00	185.00	deg
2	1	-90.00	135.00	deg
3	1	-160.00	180.00	deg
4	1	-360.00	360.00	deg
5	1	-125.00	125.00	deg
6	1	-360.00	360.00	deg
7	1	0.00	0.00	mm
8	1	0.00	0.00	mm
9	1	0.00	0.00	mm
[TYPE]				

NOTE

0.00 indicates the robot does not have these axes.

Move the cursor to the axis limit to be set. Type the new value using the numeric keys on the teach pendant. In this time, set the axial upper limit and the lower limit at the position same as adjustable mechanical stoppers are attached.



6 Cycle power of the controller and then turn it back on again in the cold start mode so the new information can be used.

↑ WARNING

- 1 You must cycle power of the controller to use the new information; otherwise, the old settings remain valid and could cause personnel injury or equipment damage.
- 2 After changing system variables, be sure to run the robot at a low speed and make sure that the robot stops at the ends of the stroke.
- 3 If a collision should occur, the adjustable mechanical stopper becomes deformed to absorb energy, so that the robot can stop safely. If the stopper is deformed by mistake, replace it.
- 4 Do not depend on parameter settings to control the motion range of your robot.

6.2.3 The maximum stopping distance (position) of adjustable mechanical stopper

The adjustable mechanical stopper is a mechanism that can be adjusted in its position. The robot can work safely inside the adjusted motion range, up to the maximum range as shown in Table 6.2.3 (a) to (d) and Fig. 6.2.3 (a) to (f). A robot attempting to travel beyond this set range of motion, will be stopped by these stoppers, by collision; and therefore the robot will remain contained within the setup range.

Stopping the robot will cause the mechanical stopper to be "transformed" (means: permanently damaged). Be sure to replace the deformed stopper before using the robot again.

Table 6.2.3 (a) The maximum stopping distance (position) of adjustable mechanical stopper (R-2000*i*C/165F/210F/240F/125L/220U)

	Plus side	Minus side
J1-axis	+16°	-16°
J2-axis	+18°	-17°
J3-axis	+11°	-13°

Table 6.2.3 (b) The maximum stopping distance (position) of adjustable mechanical stopper (R-2000*i*C/165R/210R/100P/100PH)

	Plus side	Minus side
J1-axis	+21°	-21°
J2-axis	+22°	-16°
J3-axis	+11°	-13°

Table 6.2.3 (c) The maximum stopping distance (position) of adjustable mechanical stopper (R-2000*i*C/270F/190S/210L/190U)

	1		
	Plus side	Minus side	
J1-axis	+18°	-18°	
J2-axis	+17°	-13° (270F/210L) -17° (190S/190U)	
J3-axis	+15°	-14° (270F/210L) -15° (190S/190U)	

Table 6.2.3 (d) The maximum stopping distance (position) of adjustable mechanical stopper (R-2000*i*C/270R)

	Plus side	Minus side
J1-axis	+21°	-21°
J2-axis	+17°	-13°
J3-axis	+15°	-14°




Fig. 6.2.3 (a) The maximum stopping distance of adjustable mechanical stopper of J1-axis




Fig. 6.2.3 (b) The maximum stopping distance of adjustable mechanical stopper of J2-axis (R-2000*i*C/165F/210F/240F/125L/220U)




Fig. 6.2.3 (c) The maximum stopping distance of adjustable mechanical stopper of J2-axis (R-2000*i*C/165R/210R/100P/100PH)




Fig. 6.2.3 (d) The maximum stopping distance of adjustable mechanical stopper of J2-axis (R-2000;C/270F/270R/190S/210L/190U)




Fig. 6.2.3 (e) The maximum stopping distance of adjustable mechanical stopper of J3-axis (R-2000iC/165F/210F/240F/125L/220U/165R/210R/100P/100PH)




Fig. 6.2.3 (f) The maximum stopping distance of adjustable mechanical stopper of J3-axis (R-2000iC/270F/270R/190S/210L/190U)

6.3 CHANGING THE MOTION RANGE BY THE LIMIT SWITCH (OPTION)

The limit switch is an over travel switch, which interrupts power to the servo motor and stops the robot when turned on. The limit switch is optionally provided for the J1-axis.

To change the motion range by the limit switch, move the dog. The following figure shows the relationship between the dog position and the motion range.

The dog of the J1-axis is placed in the same position as with the adjustable mechanical stopper.




Fig. 6.3 (a) J1-axis dog position and motion range (option) (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R)




Fig. 6.3 (b) J1-axis dog position and motion range (option) $(R-2000 \it i C/270F/210L/190U)$

6.4 ADJUSTING LIMIT SWITCH (OPTION)

After the motion range is changed by the adjustable mechanical stopper and limit switch, be sure to make adjustment.

ADJUSTING PROCEDURE

- 1 Set the \$MOR_GRP.\$CAL_DONE system parameter to FALSE. This disables the motion limit specified by the software. As a result, the operator can rotate the robot by a jog feed which goes beyond the motion limit.
- 2 Loosen the following bolts that hold the limit switch. J1-axis: M8 x 12 2 pcs M4 x 25 2 pcs
- Move the limit switch so that the robot activates it at about 0.5° before the stroke end. Step on the dog, and position the limit switch in such a place that only one of the step-on allowance indication lines at the tip of the switch is hidden.
- When the limit switch operates and detects overtravel (OT), the robot stops, and an error message, "OVERTRAVEL", is displayed. To restart the robot, hold on the SHIFT key and press the [RESET] key. Then, while holding on the [SHIFT] key, move the adjusting axis off the OT limit switch by jogging in joint mode.
- 5 Check that the robot also activates the limit switch when the robot is approx. 0.5° from the opposite stroke end in the same way as above. If the limit switch does not operate at the position, adjust the position of the switch again.
- 6 Set the \$MOR GRP.\$CAL DONE system parameter to TRUE.
- 7 Turn off the controller power, then turn it on again to restart the controller.




Fig. 6.4 (a) Adjusting J1-axis limit switch (option) (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R)




Fig. 6.4 (b) Adjusting J1-axis limit switch (option) (R-2000*i*C/270F/210L/190U)

7 CHECKS AND MAINTENANCE

Optimum performance of the robot can be maintained by performing the checks and maintenance procedures presented in this chapter. (See APPENDIX A PERIODIC MAINTENANCE TABLE.)

NOTE

The periodic maintenance procedures described in this chapter assume that the FANUC robot is used for up to 3840 hours a year. In cases where robot use exceeds 3840 hours/year, adjust the given maintenance frequencies accordingly. The ratio of actual operation time/year vs. the 3840 hours/year should be used to calculate the new (higher) frequencies. For example, when using the robot 7680 hours a year with a recommended maintenance interval of 3 years or 11520 hours, use the following calculation to determine the maintenance frequency: 3 years / 2 = perform maintenance every 1.5 years.

7.1 CHECKS AND MAINTENANCE

7.1.1 Daily Checks

Clean each part, and visually check component parts for damage before daily system operation. Check the following items when necessary.

Check items	Check points and management
Oil seepage	Check to see if there is oil on the sealed part of each joint. If there is an oil seepage, clean it. ⇒"7.2.1 Confirmation of Oil Seepage"
Air control set	(When air control set is used) ⇒"7.2.2 Confirmation of the Air Control Set"
Vibration, abnormal noises	Check whether vibration or abnormal noises occur. When vibration or abnormal noises occur, perform measures referring to the following section: ⇒"9.1 TROUBLESHOOTING" (Symptom : Vibration, Noise)
Positioning accuracy	Check that the taught positions of the robot have not deviated from the previously taught positions. When the displacement occurs, perform the measures as described in the following section: ⇒"9.1 TROUBLESHOOTING" (Symptom : Displacement)
Peripheral equipment for proper operation	Check whether the peripheral equipment operate properly according to commands from the robot and the peripheral equipment.
Brakes for each axis	Check that the end effector drops 0.2 mm or less when servo power is turned off. If the end effector (hand) drops, perform the measures as described in the following section: ⇒"9.1 TROUBLESHOOTING" (Symptom : Dropping axis)
Warnings	Check whether unexpected warnings occur in the alarm screen on the teach pendant. If unexpected warnings occur, perform the measures as described in the following manual: ⇒" CONTROLLER OPERATOR'S MANUAL (Alarm Code List)(B-83284EN-1)"

7.1.2 Periodic Checks and Maintenance

Check the following items at the intervals recommended below based on the period or the accumulated operating time, whichever comes first. (\bigcirc : Item needs to be performed.)

Check and maintenance intervals (Period, Accumulated operating time)			intervals Period, Accumulated Check and maintenance Check points, management and					Periodic maintenance table No.
month 320h	3 months 960h	year 3840h	years	3 years 11520h	4 years 15360h			
Only 1st check	0					Cleaning the controller ventilation system	Confirm the controller ventilation system is not dusty. If dust has accumulated, remove it.	21
	0					Check the external damage or peeling paint	Check whether the robot has external damage or peeling paint due to the interference with the peripheral equipment. If an interference occurs, eliminate the cause. Also, if the external damage is serious, and causes a problem in which the robot will not operate, replace the damaged parts.	1
	0					Check damages of the cable protective sleeves	Check whether the cable protective sleeves of the mechanical unit cable have holes or tears. If damage is found, replace the cable protective sleeve. If the cable protective sleeve is damaged due to the interference with peripheral equipment, eliminate the cause. ⇒"7.2.3 Check the Mechanical Unit Cables and Connectors"	2
	0					Check wear debris of the balancer and J1-axis swing stopper	Check whether wear debris is generated on the following parts. Balancer rod, support part of in front and behind of the balancer J1-axis swing stopper rotation part If serious wear occurs on the part that generated the wear debris, replace the part.	3
	0					Check for water	Check whether the robot is subjected to water or cutting fluid. If water is found, remove the cause and wipe off the liquid.	4
	Only 1st check	0				Check for damages to the teach pendant cable, the operation box connection cable or the robot connection cable	Check whether the cable connected to the teach pendant, operation box and robot are unevenly twisted or damaged. If damage is found, replace the damaged cables.	22
	Only 1st check	0				Check for damage to the mechanical unit cable (movable part)	Observe the movable part of the mechanical unit cable, and check for damage. Also, check whether the cables are excessively bent or unevenly twisted. ⇒"7.2.3 Check the Mechanical Unit Cables and Connectors"	5
	Only 1st Check	0				Check for damage to the end effector (hand) connection cable	Check whether the end effector connection cables are unevenly twisted or damaged. If damage is found, replace the damaged cables.	6

Check and maintenance intervals			nce	Check and		Periodic		
(P	erioc ope		cum		ed	maintenance item	Check points, management and maintenance method	maintenance table No.
month 320h	months 960h	year 3840h	years		years 15360h			
	O Only 1st check	0				Check the connection of each axis motor and other exposed connectors	Check the connection of each axis motor and other exposed connectors. ⇒"7.2.3 Check the Mechanical Unit Cables and Connectors"	7
	O Only 1st check	0				Retightening the end effector mounting bolts	Retighten the end effector mounting bolts. Refer to the following section for tightening torque information: ⇒"4.1 END EFFECTOR INSTALLATION TO WRIST"	8
	Only 1st check	0				Retightening the external main bolts	Retighten the bolts which were installed, removed, or exposed during inspection. Refer to the recommended bolt tightening torque guidelines at the end of the manual. Some bolts are attached with adhesive. If the bolts are tightened with greater than the recommended torque, the adhesive might be removed. Therefore, follow the recommended bolt tightening torque guidelines when retightening the bolts.	9
	Only 1st check	0				Check the mechanical stopper and the adjustable mechanical stopper	Check that there is no evidence of a collision on the mechanical stopper, the adjustable mechanical stopper, and check the looseness of the stopper mounting bolts. Check that the J1-axis swing stopper rotates smoothly. ⇒"7.2.4 Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper"	10
	O Only 1st check	0				Clean spatters, sawdust and dust	Check that spatters, sawdust, or dust does not exist on the robot main body. If dust has accumulated, remove it. Especially, clean the robot movable parts well (each joint, the balancer rod. the support part of in front and behind of the balancer, and the cable protective sleeves).	11
	O Only 1st check	0				Check the operation of the cooling fan	(When cooling fans are installed on the each axis motor) Check whether the cooling fans are operating correctly. If the cooling fans do not operate, replace them.	12
		0				Greasing to the balancer bush	Supply grease to the balancer bush. ⇒"7.3.1 Greasing the Balancer Bush"	13
			0			Replacing the mechanical unit batteries	Replace the mechanical unit batteries. Regardless of operating time, replace batteries at 1.5 years. ⇒"7.3.2 Replacing the Batteries"	14
				0		Replacing the grease of each axis reducer	Replace the grease of each axis reducer ⇒"7.3.3 Replacing the Grease of the Drive Mechanism"	15 to 19
					0	Replacing the mechanical unit cable	Replace the mechanical unit cable Contact your local FANUC representative for information regarding replacing the cable.	20
					0	Replacing the controller batteries	Replace the controller batteries. Regardless of operating time, replace batteries at 4 years. ⇒"Chapter 7 Replacing batteries of R-30iB/R-30iB Plus CONTROLLER MAINTENANCE MANUAL (B-83195EN) or R-30iB Mate/R-30iB Mate Plus CONTROLLER MAINTENANCE MANUAL (B-83525EN)"	23

7.2 CHECK POINTS

7.2.1 Confirmation of Oil Seepage

Check items

Check to see whether there is an oil seepage on the rotating parts of each joint axis.




Fig.7.2.1 (a) Check points of oil seepage

Management

- Oil might accumulate on the outside of the seal lip depending on the movement condition or environment of the axis. If the oil changes to a state of liquid, the oil might fall depending on the axis movement. To prevent oil spots, be sure to wipe away any accumulated oil under the axis components before you operate the robot.
- Also, drive mechanisms might become hot and the internal pressure of the grease bath might rise by frequent repetitive movement and use in high temperature environments. In these cases, normal internal pressure can be restored by venting the grease outlet. (When opening the grease outlet, refer to Subsection 7.3.3 and ensure that grease is not expelled onto the machine or tooling.)

⚠ WARNING

Hot grease might eject suddenly when you open the grease outlet. Attach bags for collecting grease, and use appropriate protective equipment such as heat-resistant gloves, protective glasses, a face shield, or a body suit if necessary.

• If you must wipe oil frequently, and opening the grease outlet does not stop the seepage, perform the measures below.

⇒"9.1 TROUBLESHOOTING"(symptom : Grease leakage)

7.2.2 Confirmation of the Air Control Set (option)

When an air control set is used, check the items below.

Item	Check items	Check points
1	Air pressure	Check the air pressure using the pressure gauge on the air regulator as shown in Fig.7.2.2 (a). If it does not meet the specified pressure of 0.49 to 0.69 MPa (5-7 kgf/cm²), adjust it using the regulator pressure-setting handle.
2	Lubricator oil mist quantity	Check the number of oil drops during operation. If it does not meet the specified value (1 drop/10-20 sec), adjust it using the lubricator control knob. The lubricator becomes empty in about 10 to 20 days under normal operation.
3	Lubricator oil level	Check to see that the air control set oil level is within the specified level.
4	Leakage from hose	Check the joints, tubes, etc. for leaks. Retighten the joints or replace parts, as required.
5	Drain	Check the drain and release it. When quantity of the drain is remarkable, examine the setting of the air dryer to the air supply side.




Fig. 7.2.2 (a) Air control set (option)

7.2.3 Check the Mechanical Unit Cables and Connectors

Check points of the mechanical unit cables

Fixed part cables can interfere with the J1, J2, and J3 movable parts and peripheral equipment

* For the J1-axis, inspect the cables from above the J2 base and from the side by removing the metal plate on the side of the J1 base.




Fig. 7.2.3 (a) Check points of the mechanical unit cables

Check items

< Cable protective sleeve >

- Check that no holes or tears exist on the cable protective sleeves.
- If there is damage as shown in Fig.7.2.3 (b), replace the cable protective sleeves.



Fig. 7.2.3 (b) Damage on the cable protective sleeve

< Cables >

- · Check that there is no wear or damage on the cable jacket.
- If the inside wire strands are exposed due to wear or damage, replace the cables.




Fig. 7.2.3 (c) Cable check method

Inspection points of the connectors

- · Power/brake connectors of the motor exposed externally
- · Robot connection cables, earth terminal and user cables

Check items

· Circular connector: Check the connector for tightness by turning it manually.

• Square connector: Check the connector for engagement of its lever.

• Earth terminal: Check the terminal for tightness.




Fig. 7.2.3 (d) Connector Inspection points (R-2000iC/165F/210F/240F/125L/220U/165R/210R/100P/100PH)




Fig. 7.2.3 (e) Connector Inspection points (R-2000iC/270F/270R/190S/210L/190U)

7.2.4 Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper

- Check that there is no evidence of a collision on the mechanical stopper and the adjustable mechanical stopper. If there is evidence of a collision on the stopper, replace the parts.
- Check the looseness of the stopper mounting bolts. If they are loose, retighten them. Be sure to check the looseness of the mounting bolts of the J1-axis swing stopper.
- Check that the J1-axis swing stopper rotates smoothly.
- · Refer to Section 6.2 of the operator's manual for details regarding the adjustable mechanical stopper.




Fig. 7.2.4 (a) Check of fixed mechanical stopper and adjustable mechanical stopper

7.3 MAINTENANCE

7.3.1 Greasing the Balancer Bush (1 year (3840 hours) Periodic Maintenance)

Be sure to grease the balancer bush at specified intervals as shown in Tables 7.3.1 (a) to (b). When the installation environment of the robot is bad, however, greasing needs to be made as appropriate. If water splashes on the robot, supply grease immediately. Fig. 7.3.1 (a) shows the greasing points of the balancer bush.

Table 7.3.1 (a) Greasing the balancer bush

Recommended grease	Amount of grease	Greasing interval
Shell Lubricants		
Shell Alvania grease S2	10 ml for each	1 year or every 3840 hours of
Specification: A98L-0004-	(two points)	accumulated operation time
0602#CTG		

Table 7.3.1 (b) Grease alternative to Alvania GREASE S2

Maker	Grease name
Exxon Mobile	Mobilux EP2
ENEOS	Multinoc 2
ENEOS	Epinoc grease AP(N)2
Idemitsu Kosan Co., Ltd.	Eponex grease No. 2
Cosmo Oil Co., Ltd.	Dynamax No. 2
Shell Lubricant	Shell Gadus S2 V100 2




Fig. 7.3.1 (a) Balancer bush greasing points

7.3.2 Replacing the Batteries (1.5 year Periodic Maintenance)

The position data of each axis is preserved by the backup batteries. The batteries need to be replaced every 1.5 year. Also use the following procedure to replace when the backup battery voltage drop alarm occurs.

Procedure of replacing the battery

1 Press the EMERGENCY STOP button to stop the robot motion.

! CAUTION

Be sure to keep the power turning on. Replacing the batteries with the power turned off causes all current position data to be lost. Therefore, mastering will be required again.

- 2 Remove the battery case cap. (Fig. 7.3.2 (a))
- 3 Take out the old batteries from the battery case.
- 4 Insert new batteries into the battery case while observing their correct direction.
- 5 Close the battery case cap.

⚠ CAUTION

When using a robot with the severe dust/liquid protection option, remove the plate from the battery case as shown in Fig. 7.3.2 (b) to replace the battery. After replacing the battery, reinstall the plate. At this time, please be sure to replace gasket with new one for severe dust/liquid protection.




Fig. 7.3.2 (a) Replacing the battery




Fig.7.3.2 (b) Removing the battery cover plate (When severe dust/liquid protection is specified)

7.3.3 Replacing the Grease of the Drive Mechanism (3 years (11520 hours) Periodic Maintenance)

According to below, replace the grease of the reducers of J1, J2, and J3 axes, and the wrist at the intervals based on every 3 years or 11520 hours, whichever comes first. See Table 7.3.3 (a) for the grease name and the quantity.

Table 7.3.3 (a) Grease for 3-years (11520 hours) periodical replacement

Models	Greasing point	Quantity	Gun tip pressure	Specified grease
R-2000iC/165F	J1-axis reducer	4250g (4730ml)		
R-2000iC/210F R-2000iC/240F	J2-axis reducer	2250g (2500ml)		
R-2000iC/125L	J3-axis reducer	1950g (2170ml)		
R-2000iC/220U R-2000iC/165R	wrist 1 (J4/J5-axis reducer)	2300g (2560ml)		
R-2000iC/210R	wrist 2 (J6-axis reducer)	400g (440ml)		
	J1-axis reducer	6200g (6900ml)		
R-2000 <i>i</i> C/100P	J2-axis reducer	2250g (2500ml)		Spec:
	J3-axis reducer	1950g (2170ml)	0.15MPa or less	
R-2000iC/100PH	wrist 1 (J4/J5-axis reducer)	2300g (2560ml)		
	wrist 2 (J6-axis reducer)	620g (690ml)	(NOTE)	A98L-0040-0174
R-2000iC/270F	J1-axis reducer	5620g (6250ml)	(-)	
R-2000 <i>i</i> C/270F	J2-axis reducer	3120g (3470ml)		
	J3-axis reducer	2370g (2640ml)		
R-2000iC/210L	wrist 1 (J4/J5-axis reducer)	4980g (5540ml)		
R-2000iC/190U	wrist 2 (J6-axis reducer)	560g (630ml)		
	J1-axis reducer	5150g (5720ml)		
	J2-axis reducer	3120g (3470ml)	-	
R-2000iC/190S	J3-axis reducer	2370g (2640ml)		
	wrist 1 (J4/J5-axis reducer)	4980g (5540ml)		
	wrist 2 (J6-axis reducer)	560g (630ml)		

NOTE

When a manual pump is used for greasing, the standard rate is two pumping cycles per three seconds.

⚠ WARNING

Hot grease might eject suddenly when you open the grease outlet. Attach bags for collecting grease, and use appropriate protective equipment such as heatresistant gloves, protective glasses, a face shield, or a body suit if necessary.

For grease replacement or replenishment, use the posture indicated below.

Table 7.3.3 (b) Postures for great	ing (R-2000 <i>i</i> C/165F/210F/240F/125L/220U/270F	:/190S/210L/190U)
Tubic field (b) I dotal od for grou	9 (14 2000) 07 1001 72 101 72 101 7 1202/2200/21 01	,

Cumply position			Pos	ture		
Supply position	J1	J2	J3	J4	J5	J6
J1-axis reducer		Arbitrary	Arbitrary Arbitrary	Arbitrary	Arbitrary	Arbitrary
J2-axis reducer	A whatter a way	0°				
J3-axis reducer	Arbitrary	0°	0°			
Wrist		Arbitrary	0°	0°	0°	0°

Table 7.3.3 (c) Postures for greasing (R-2000iC/165R/210R/100P/100PH/270R)

Cumply position	Posture						
Supply position	J1	J2	J3	J4	J5	J6	
J1-axis reducer		Arbitrary	Al. :4	Arbitrary	Arbitrary		
J2-axis reducer	Al. :4	-90°	Arbitrary			Arbitrary	
J3-axis reducer	Arbitrary	-90°	90°				
Wrist		Arbitrary	90°	0°	0°	0°	

Grease replacement procedure of the J1/J2/J3-axis reducer

- Move the robot to the greasing posture described in Table 7.3.3 (b) and (c).
- 2 Turn off the controller power.
- 3 Remove the seal bolt from grease outlet (Fig. 7.3.3 (a) to (g)).
- Supply new grease through the grease inlet until new grease is output from grease outlet. 4
- Release remaining pressure using the procedure given in Subsection 7.3.4.




Fig. 7.3.3 (a) Replacing grease of the J1/J2-axis reducer (R-2000*i*C/165F/210F/240F/125L/220U)




Fig. 7.3.3 (b) Replacing grease of the J1/J2-axis reducer (R-2000*i*C/165R/210R)




Fig. 7.3.3 (c) Replacing grease of the J1/J2-axis reducer (R-2000*i*C/100P/100PH)




Fig. 7.3.3 (d) Replacing grease of the J1/J2-axis reducer (R-2000*i*C/270F/270R/210L/190U)




Fig. 7.3.3 (e) Replacing grease of the J1/J2-axis reducer (R-2000iC/190S)




Fig. 7.3.3 (f) Replacing grease of the J3-axis reducer (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R/100P/100PH)




Fig. 7.3.3 (g) Replacing grease of the J3-axis reducer (R-2000iC/270F/270R/190S/210L/190U)

Grease Replacement Procedure for the Wrist

! CAUTION

Grease replacing methods differ from R-2000iB, R-2000iA, please be careful.

- 1 Move the robot to the greasing posture described in Table 7.3.3 (b) and (c).
- 2 Turn off the controller power.
- Remove the taper plug of wrist grease outlet 1 (Fig. 7.3.3 (h), (i)).
- 4 Supply grease to the wrist grease inlet 1 until new grease outputs from wrist grease outlet 1.
- 5 Next, remove the seal bolt of wrist grease outlet 2.
- 6 Supply new grease through the wrist grease inlet 2 until new grease is output from wrist grease outlet 2
- 7 Release remaining pressure using the procedure given in Subsection 7.3.4.




Fig. 7.3.3 (h) Replacing grease of the wrist (R-2000*i*C/165F/210F/240F/125L/220U/165R/210R/100P/100PH)




Fig. 7.3.3 (i) Replacing grease of the wrist (R-2000*i*C/270F/270R/190S/210L/190U)

Table 7.3.3 (d) Spec. of the seal bolts, taper plugs and the grease nipple

rabio riolo (a) oposi si allo soal bollo, tapor piago alla allo giodeo imprio					
Parts name	Specifications				
Seal bolt (M5)	A97L-0218-0417#050505				
Seal bolt (M6)	A97L-0218-0417#060606				
Seal bolt (M12)	A97L-0218-0417#121515				
Taper plug (R1/8)	A97L-0001-0436#1-1D				
Grease nipple (J1 to J3-axis)	A97L-0218-0013#A610				
Grease nipple (Wrist)	A97L-0218-0013#A110				

⚠ CAUTION

Failure to follow proper greasing procedures may cause the suddenly increase of the grease bath internal pressure and the damage to the seal, which could lead to grease leakage and abnormal operation. When greasing, observe the following cautions.

- 1 Before starting to grease, remove the seal bolts or the taper plugs of the grease outlet to allow the grease to come out.
- 2 Supply grease slowly, using a manual pump.
- 3 Whenever possible, avoid using an air pump, which is powered by the factory air supply.
 - If the use of an air pump is unavoidable, supply grease with the pump at a pressure lower than or equal to the gun tip pressure (see Table 7.3.3 (a)).
- 4 Use specified grease. Use of non-approved grease may damage the reducer or lead to other problems.
- 5 After greasing, release remaining pressure from the grease bath using the procedure given in Subsection 7.3.4, and then close the grease outlet.
- 6 To prevent slipping accidents and catching fire, completely remove all any excess grease from the floor or robot.

7.3.4 Procedure for Releasing Remaining Pressure from the Grease Bath

Release remaining pressure as described below.

Under the grease inlets and outlets, attach bags for collecting grease so that grease does not spatter when it comes out of the inlets or outlets.

Grease replacement position	Motion angle	OVR	Operating time	Procedure
J1-axis reducer	80° or more	50%	20 minutes	On an the sures
J2-axis reducer	90° or more	50%	20 minutes	Open the grease inlets and outlets
J3-axis reducer	70° or more	50%	20 minutes	
Wrist	J4 : 60° or more J5 : 120° or more J6 : 60° or more	100%	10 minutes	and perform continuous operation.

If the above operation cannot be performed due to the environment, adjust the operating time according to the operating angle. (If only half of the predetermined motion angle can be set, perform an operation for a time twice as long as the specified time.) If you grease multiple axes, you can exercise multiple axes at the same time. After completion of the operation, attach the seal bolts, taper plugs and grease nipples to the grease inlets and outlets. When reusing the seal bolts, taper plugs and grease nipples, be sure to seal them with seal tape.

7.4 STORAGE

When storing the robot, place it on a level surface with the same posture that was used for transportation. (See Section 1.1.)

8. MASTERING B-83644EN/09

MASTERING

Mastering associates the angle of each robot axis with the pulse count value supplied from the absolute Pulsecoder connected to the corresponding axis motor. To be specific, mastering is an operation for obtaining the pulse count value; corresponding to the zero position.

CAUTION

- The motion limits are temporarily invalid during mastering. Cables may be damaged if the J1-axis exceeds +/-185°.
- 2 In case of performing mastering with gravity compensation (option) is enabled, if load setting (See Section 4.3) is not correct, it will influence the precision of the mastering.

8.1 **OVERVIEW**

The current position of the robot is determined according to the pulse count value supplied from the Pulsecoder on each axis.

Mastering is factory-performed. It is unnecessary to perform mastering in daily operations. However, mastering becomes necessary after:

- Motor replacement.
- Pulsecoder replacement
- Reducer replacement
- Cable replacement
- Batteries for pulse count backup in the mechanical unit have gone dead



⚠ CAUTION

Robot data (including mastering data) and Pulsecoder data are backed up by their respective backup batteries. Data will be lost if the batteries die. Replace the batteries in the controller and mechanical units periodically. An alarm will alert you when battery voltage is low.

Types of Mastering

Table 8.1 (a) describes the following mastering methods. If 7DC2 (V8.20P) or former software is installed, "Quick Mastering for Single Axis" has not been supported.

Table 8.1 (a) Type of mastering

Fixture position	This is performed using a mastering fixture before the machine is shipped from the				
mastering	factory.				
Zero-position mastering	This is performed with all axes set at the 0-degree position. A zero-position mark				
(witness mark	(witness mark) is attached to each robot axis. This mastering is performed with all axes				
mastering)	aligned to their respective witness marks.				
Quick mastering	This is performed at a user-specified position. The corresponding count value is obtained from the rotation count of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost. (All axes at the same time)				
Quick mastering for single axis	This is performed at a user-specified position for one axis. The corresponding count value is obtained from the rotation count of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost.				
Single-axis mastering	This is performed for one axis at a time. The mastering position for each axis can be specified by the user. This is useful in performing mastering on a specific axis.				
Mastering data entry	Mastering data is entered directly.				

8. MASTERING B-83644EN/09

Once mastering is performed, you must carry out positioning, or calibration. Positioning is an operation in which the controller reads the current pulse count value to sense the current position of the robot.

This section describes zero-position mastering, quick mastering, quick mastering for single axis, singleaxis mastering, and mastering data entry. For more accurate mastering (fixture position mastering), contact your local FANUC representative.

↑ CAUTION

- 1 If mastering is performed incorrectly, the positioner may behave unexpectedly. This is very dangerous. Therefore, the positioning screen is designed to appear only when the \$MASTER ENB system variable is 1 or 2. After performing positioning, press F5 [DONE] on the positioning screen. The \$MASTER ENB system variable is reset to 0 automatically, thus hiding the positioning screen.
- 2 It is recommended that you back up the current mastering data before performing mastering.

8.2 RESETTING ALARMS AND PREPARING FOR **MASTERING**

Before performing mastering because a motor has been replaced, it is necessary to release the relevant alarm and display the positioning menu.

Alarm displayed

"SRVO-062 BZAL" or "SRVO-075 Pulse not established"

Procedure

- Display the positioning menu by following the steps 1 to 6.
 - Press the [MENU] key.
 - 2 Press [0 NEXT] and select [6 SYSTEM].
 - 3 Press F1 ([TYPE]), and select [Variable] from the menu.
 - Place the cursor on \$MASTER ENB, then key in "1" and press the [ENTER] key.
 - 5 Press F1 ([TYPE]), and select [Master/Cal] from the menu.
 - Select the desired mastering type from the [Master/Cal] menu.
- To reset the "SRVO-062 BZAL" alarm, follow steps 1 to 5.
 - Press the [MENU] key.
 - Press [0 NEXT] and select [6 SYSTEM].
 - Press F1 ([TYPE]), and select [Master/Cal] from the menu. 3
 - Press F3 ([RES PCA]), then press F4 ([YES]).
 - Cycle power of the controller.
- To reset the "SRVO-075 Pulse not established" alarm, follow the steps 1 to 2. 3
 - After cycling controller power, the message "SRVO-075 Pulse not established" appears again.
 - Move the axis for which the message mentioned above has appeared in either direction till the alarm disappears when you press the [RESET] key.

If "SRVO-062 BZAL" alarm or "SRVO-068 DTERR" alarm occurred, and you cannot release the alarm, Please check there is no faulty wiring or disconnected part.

8. MASTERING B-83644EN/09

8.3 ZERO POSITION MASTERING

Zero position mastering (witness mark mastering) is performed with all axes set at the 0-degree position. A zero-position mark (witness mark) is attached to each robot axis. (Fig. 8.3 (a) to (c)) This mastering is performed with all axes set at the 0-degree position using their respective witness marks.

Zero position mastering involves a visual check, and might not be highly accurate. It should be used only as a quick-fix method.

Zero-position Mastering Procedure

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM GROUP.SV OFF ALL : FALSE

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE (for all axes)
After changing the system variables, cycle power of the controller.

- 5 Press the [MENU] key to display the screen menu.
- 6 Select [0 NEXT] and press [6 SYSTEM].
- 7 Press F1 [TYPE], display the screen change menu.
- 8 Select [Master/Cal]. The positioning screen will be displayed.


 B-83644EN/09 8. MASTERING

- 9 Jog the robot into a posture for mastering.
- 10 Select [2 ZERO POSITION MASTER]. Press F4 [YES].

11 Select [7 CALIBRATE] and press F4 [YES]. Mastering will be performed automatically. Alternatively, turn off the controller power and on again.

SYSTEM Master/Cal AUTO JOINT 10 % TORQUE = [ON] 1 FIXTURE POSITION MASTER 2 ZERO POSITION MASTER 3 QUICK MASTER 4 QUICK MASTER FOR SINGLE AXIS **5 SINGLE AXIS MASTER** 6 SET QUICK MASTER REF 7 CALIBRATE Robot Calibrated! Cur Jnt Ang(deg): 0.0000> < > <00000 0.0000> 0.0000> < 0.0000> < 0.0000>

12 After positioning is completed, press F5 [DONE].



- 13 Return the setting of the gravity compensation.
- 14 Return brake control to the original setting, and cycle power of the controller.

Table 8.3 (a) Posture with position marks (witness mark) aligned

rabio die (a) i detaid with position marke (without mark) anglieu					
Axis	Position				
J1-axis	0 deg				
J2-axis	0 deg				
J3-axis	0 deg (NOTE) When J2-axis is 0 deg.				
J4-axis	0 deg				
J5-axis	0 deg				
J6-axis	0 deg				

8. MASTERING B-83644EN/09




Fig. 8.3 (a) Zero-position mark (witness mark) for each axis (R-2000*i*C/165F/210F/240F/125L/220U)

B-83644EN/09 8. MASTERING




Fig. 8.3 (b) Zero-position mark (witness mark) for each axis (R-2000iC/165R/210R/100P/100PH)

8. MASTERING B-83644EN/09




Fig. 8.3 (c) Zero-position mark (witness mark) for each axis (R-2000iC/270F/270R/190S/210L/190U)

B-83644EN/09 8. MASTERING

8.4 QUICK MASTERING

Quick mastering is performed at a user-specified position for each axis. The pulse count value is obtained from the rotation times of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost.

Quick mastering is factory-performed at the position indicated in Table 8.3 (a). If possible, do not change the setting.

If setting the robot at the position mentioned above is impossible, you must re-set the quick mastering reference position using the following method. (It would be convenient to set up a marker that can work in place of the witness mark.)

⚠ CAUTION

- 1 Quick mastering can be used, if the pulse count value is lost, for example, because a low voltage has been detected on the backup battery for the pulse counter.
- 2 Quick mastering cannot be used, after the Pulsecoder is replaced or after the mastering data is lost from the robot controller.

Procedure Recording the Quick Mastering Reference Position

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:


\$PARAM GROUP.SV OFF ALL : FALSE

\$PARAM GROUP.SV OFF ENB[*] : FALSE (for all axes)


After changing the system variables, cycle power of the controller.

8. MASTERING B-83644EN/09

- Select [6 SYSTEM]. 5
- 6 Select [Master/Cal]. The positioning screen will be displayed.



- Jog the robot to the quick mastering reference position.
- Select [6 SET QUICK MASTER REF] and press F4 [YES]. Quick mastering reference position is saved.



- Return the setting of the gravity compensation.
- 10 Return brake control to the original setting, and cycle power of the controller.



↑ CAUTION

If the robot has lost mastering data due to mechanical disassembly or repair, you cannot perform this procedure. In this case, perform Fixture position mastering or Zero position mastering to restore mastering data.

B-83644EN/09 8. MASTERING

Procedure of Quick Mastering

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:


\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:


\$PARAM_GROUP.SV_OFF_ALL : FALSE

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE (for all axes)
After changing the system variables, cycle power of the controller.


5 Display the Master/Cal screen.



- 6 Jog the robot to the quick mastering reference position.
- Move the cursor to [3 QUICK MASTER] and press the [ENTER] key. Press F4 [YES]. Quick mastering data is saved.



- 8 Select [7 CALIBRATE] and press the [ENTER] key. Calibration is executed. Calibration is executed by cycling power.
- 9 After completing the calibration, press F5 [DONE].



- 10 Return the setting of the gravity compensation.
- 11 Return brake control to the original setting, and cycle power of the controller.

8. MASTERING B-83644EN/09

8.5 QUICK MASTERING FOR SINGLE AXIS

Quick mastering for a single axis is performed at a user-specified position for one axis. The pulse count value is obtained from the rotation times of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost.

Quick mastering is factory-performed at the position indicated in Table 8.3 (a). If possible, do not change the setting.

If setting the robot at the position mentioned above is impossible, you must re-set the quick mastering reference position using the following method. (It would be convenient to set up a marker that can work in place of the witness mark.)

⚠ CAUTION

- 1 Quick mastering can be used, if the pulse count value is lost, for example, because a low voltage has been detected on the backup battery for the pulse counter.
- 2 Quick mastering cannot be used, after the Pulsecoder is replaced or after the mastering data is lost from the robot controller.

Procedure Recording the Quick Mastering Reference Position

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM GROUP.SV OFF ALL : FALSE


\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE (for all axes)

After changing the system variables, cycle power of the controller.

- 5 Select [6 SYSTEM].
- 6 Select [Master/Cal]. The positioning screen will be displayed.

8. MASTERING B-83644EN/09

- Jog the robot to the quick mastering reference position.
- Select [6 SET QUICK MASTER REF] and press F4 [YES]. Quick mastering reference position is saved.



- Return the setting of the gravity compensation.
- 10 Return brake control to the original setting, and cycle power of the controller.



⚠ CAUTION

If the robot has lost mastering data due to mechanical disassembly or repair, you cannot perform this procedure. In this case, perform Fixture position mastering or Zero position mastering to restore mastering data.

Procedure of Quick Mastering for single axis

- Press the [MENU] key to display the screen menu.
- Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- If \$DMR GRP [group].\$GRAV MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM GROUP[group].\$SV DMY LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM GROUP.SV OFF ALL : FALSE

\$PARAM GROUP.SV OFF ENB[*] : FALSE (for all axes) After changing the system variables, cycle power of the controller.

Display the Master/Cal screen.

SYSTEM Master/Cal AUTO JOINT 10 % TORQUE = [ON] 1 FIXTURE POSITION MASTER 2 ZERO POSITION MASTER 3 QUICK MASTER 4 QUICK MASTER FOR SINGLE AXIS **5 SINGLE AXIS MASTER** 6 SET QUICK MASTER REF 7 CALIBRATE Press 'ENTER' or number key to select. [TYPE] LOAD RES_PCA DONE

Select [4 QUICK MASTER FOR SINGLE AXIS]. You will see the quick master for single axis screen.


8. MASTERING B-83644EN/09

	AUTO JOINT 1%								
QUICK MASTER FOR SINGLE AXIS									
					1/9				
	ACTUAL POS	(MS	STR POS)	(SEL)	[ST]				
J1	0.000	(0.000)	(0)	[2]				
J2	0.000	(0.000)	(0)	[2]				
J3	0.000	(0.000)	(0)	[2]				
J4	0.000	(0.000)	(0)	[2]				
J5	0.000	(0.000)	(0)	[2]				
J6	0.000	(0.000)	(0)	[0]				
E1	0.000	(0.000)	(0)	[0]				
E2		(0.000)	(0)	[0]				
E3	0.000	(0.000)	(0)	[0]				
					EXEC				

Move the cursor to the (SEL] column for the unmastered axis and press the numeric key [1]. Setting of (SEL] is available for one or more axes.

	AUTO JOIN 1%							
QUICK MASTER FOR SINGLE AXIS								
ACT J5 J6	UAL POS 0.000 0.000	(MS (TR POS) 0.000) 0.000)	(SEL) (1) (1)	1/9 [ST] [2] [2]			
					EXEC			

- 8 Jog the robot to the quick mastering reference position.
- 9 Press F5 [EXEC]. Mastering is performed. So, (SEL] is reset to 0, and [ST] is re-set to 2.
- 10 Select [7 CALIBRATE] and press F4 [YES]. Calibration is executed. Calibration is executed by cycling power.
- 11 After completing the calibration, press F5 [DONE].



- 12 Return the setting of the gravity compensation.
- 13 Return brake control to the original setting, and cycle power of the controller.

B-83644EN/09 8. MASTERING

8.6 SINGLE AXIS MASTERING

Single axis mastering is performed for one axis at a time. The mastering position for each axis can be specified by the user.

Single axis mastering can be used, if mastering data for a specific axis is lost, for example, because a low voltage has been detected on the pulse counter backup battery or because the Pulsecoder has been replaced.

SINGLE AX	(IS MAST	ER	ΑU	го јо	INT 10%
					1/9
ACTUA	L POS	(MST	R POS)	(SEL)	[ST]
J1	0.000	(0.000)	(0)	[2]
J2	0.000	(0.000)	(0)	[2]
J3	0.000	(0.000)	(0)	[2]
J4	0.000	(0.000)	(0)	[2]
J5	0.000	(0.000)	(0)	[2]
J6	0.000	(0.000)	(0)	[0]
E1	0.000	(0.000)	(0)	[0]
E2	0.000	(0.000)	(0)	[0]
E3	0.000	(0.000)	(0)	[0]
					FXFC
					EVEC

Table 8.6 (a) Items set in single axis mastering

Item	Description
Current position (ACTUAL AXIS)	The current position of the robot is displayed for each axis in degree units.
Mastering position (MSTR POS)	A mastering position is specified for an axis to be subjected to single axis mastering. It would be convenient to set to it to the 0_ position.
SEL	This item is set to 1 for an axis to be subjected to single axis mastering. Usually, it is 0.
ST	This item indicates whether single axis mastering has been completed for the corresponding axis. It cannot be changed directly by the user. The value of the item is reflected in \$EACHMST_DON (1 to 9). 0: Mastering data has been lost. Single axis mastering is necessary. 1: Mastering data has been lost. (Mastering has been performed only for the other interactive axes.) Single axis mastering is necessary. 2: Mastering has been completed.

Single axis mastering for interaction axis

When single axis mastering is done in interaction axis, the axis of the interaction pair is also influenced. Therefore, mastering of these interaction axes must be done at the same time. Interaction axis depends on the robot model. Following table shows the relation between robot model and interaction axis. For example, when robot model is R-2000*i*B/165F and J4 motor is changed, mastering of J5 and J6 should be done at the same time with J4. (Provided that if 7DC2(V8.20P)/14 or later software version is installed, axis numbers which should be selected to do single axis mastering at the same time are displayed if these are not selected. In this case, it is unnecessary to refer to a following table.)

Table 8.6 (b) Relation between robot model and interaction axis

Robot model		Interaction axis
R-2000 <i>i</i> C	/165F/210F	J2/J3J4/J5/J6

8. MASTERING B-83644EN/09

Procedure of Single axis mastering

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE (disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE (for all axes)
After changing the system variables, cycle power of the controller.

- 5 Select [6 SYSTEM].
- 6 Select [Master/Cal]. The positioning screen will be displayed.

	TO JOINT 10 % DRQUE = [ON]	
	RQUE - [UN]	
1 FIXTURE POSITION MAST	ER	
2 ZERO POSITION MASTER		
3 QUICK MASTER		
4 QUICK MASTER FOR SINGLE AXIS		
5 SINGLE AXIS MASTER		
6 SET QUICK MASTER REF		
7 CALIBRATE		
Press 'ENTER' or number	key to select.	
	-	
[TYPE] LOAD RES_PCA	DONE	

7 Select [5 SINGLE AXIS MASTER]. The following screen will be displayed.

SINGLE	E AXIS MAST	ER	AUT	O JOIN	NT 10%
					1/9
ACT	TUAL POS	(MST	R POS)	(SEL)	[ST]
J1	0.000	(0.000)	(0)	[2]
J2	0.000	(0.000)	(0)	[2]
J3	0.000	(0.000)	(0)	[2]
J4	0.000	(0.000)	(0)	[2]
J5	0.000	(0.000)	(0)	[2]
J6	0.000	(0.000)	(0)	[0]
E1	0.000	(0.000)	(0)	[0]
E2	0.000	(0.000)	(0)	[0]
E3	0.000	(0.000)	(0)	[0]
					EXEC


- 8 Move the cursor to the [SEL] column for the unmastered axis and press the numeric key [1]. Setting of [SEL] is available for one or more axes.
- 9 Turn off brake control, then jog the robot to the mastering position.
- 10 Enter axis data for the mastering position.

B-83644EN/09 8. MASTERING

11 Press F5 [EXEC]. Mastering is performed. So, [SEL] is reset to 0, and [ST] is re-set to 2 or 1.

SINGL	E AXIS MAST	ER	AUT	O JOI	NT 10%
					6/9
AC	TUAL POS	(MS	TR POS)	(SEL)	[ST]
J1	0.000	(0.000)	(0)	[2]
J2	0.000	(0.000)	(0)	[2]
J3	0.000	(0.000)	(0)	[2]
J4	0.000	(0.000)	(0)	[2]
J5	0.000	(0.000)	(0)	[2]
J6	90.000	(0.000)	(1)	[0]
E1	0.000	(0.000)	(0)	[0]
E2	0.000	(0.000)	(0)	[0]
E3	0.000	(0.000)	(0)	[0]
					EXEC

12 When single axis mastering is completed, press the [PREV] key to resume the previous screen.



- 13 Select [7 CALIBRATE], then press F4 [YES]. Positioning is performed. Alternatively, turn off the controller power and on again. Positioning is performed.
- 14 After positioning is completed, press F5 [DONE].



- 15 Return the setting of the gravity compensation.
- 16 Return brake control to the original setting, and cycle power of the controller.

8. MASTERING
B-83644EN/09

8.7 MASTERING DATA ENTRY

This function enables mastering data values to be assigned directly to a system variable. It can be used if mastering data has been lost but the pulse count is preserved.

Mastering data entry method

- Press the [MENU] key, then press [0 NEXT] and select [6 SYSTEM].
- 2 Press F1 [TYPE]. Select [Variables]. The system variable screen appears.

SYSTEM Variables	AUTO JOINT 1%
1 \$AO_MAXAX 2 \$AP_PLUGGED 3 \$AP_TOTALAX 4 \$AP_USENUM 5 \$AUTOINIT 6 \$BLT	TORQUE = [ON] 536870912 4 1677216 [12] of Byte 2 19920216
[TYPE]	13320210

3 Change the mastering data.

The mastering data is saved to the \$DMR_GRP.\$MASTER_COUN system variable.

	AUTO
SYSTEM Variables	JOINT 1%
135 \$DMR_GRP 136 \$ENC_STAT	TORQUE = [ON] DMR_GRP_T [2] of ENC STATT
[TYPE]	

4 Select \$DMR GRP.

		AUTO
SYSTEM Variables		JOINT 1%
\$DMR_GRP		1/1
1	[1]	DMR_GRP_T

	AUTO
SYSTEM Variables	JOINT 1%
\$DMR_GRP	1/29
1 \$MASTER_DONE 2 \$OT_MINUS 3 \$OT_PLUS 4 \$MASTER_COUNT 5 \$REF_DONE 6 \$REF_POS 7 \$REF_COUNT 8 \$BCKLSH SIGN	FALSE [9] of BOOLEAN [9] of BOOLEAN [9] of INTEGER FALSE [9] of REAL [9] of INTEGER [9] of BOOLEAN
[TYPE]	TRUE FALSE

B-83644EN/09 8. MASTERING

5 Select \$MASTER_COUN, and enter the mastering data you have recorded.

		A	OTUA
SYST	EM Varial	oles	JOINT 1%
\$DM	R GRP		1/1
1	[1]	95678329	
2	[2]	10223045	
1	[3]	3020442	
1	[4]	304055030	
1	[5]	20497709	
6	[6]	2039490	
7	[7]	0	
8	[8]	0	
9	[9]	Õ	
	[~]	ŭ	

- 6 Press the [PREV] key.
- 7 Set \$MASTER_DONE to TRUE.

	AUTO
SYSTEM Variables	JOINT 1%
4	
SDMR GRP	1/1
1 \$MASTER_DONE	TRUE
2 \$OT MINUS	[9] of BOOLEAN
[TYPE]	TRUE FALSE

- 8 Display the positioning screen, and select [7 CALIBRATE], then press F4 [YES].
- 9 After completing positioning, press F5 [DONE].



8. MASTERING B-83644EN/09

8.8 VERIFYING MASTERING

1 How to verify that the robot is mastered properly:

Usually, positioning is performed automatically when the power is turned on. To check whether mastering has been performed correctly, examine if the current displayed position meets the actual robot position by using the procedure described below:

- (1) Reproduce a particular point in a program. Check whether the point agrees with the specified position.
- (2) Set all axes of the robot to their 0-degree (0 rad) positions. Check that the zero-degree position marks indicated in Section 8.3 of OPERATOR'S MANUAL are aligned. There is no need to use a visual aid.

If the displayed and actual positions do not match, the counter value for a Pulsecoder may have been invalidated as a result of an alarm described in 2. Alternatively, the mastering data in system variable \$DMR_GRP.\$MASTER_COUN may have been overwritten as a result of an operation error or some other reason.

Compare the data with the values indicated on the supplied data sheet. This system variable is overwritten whenever mastering is performed. Whenever mastering is performed, record the value of the system variable on the data sheet.

- 2 Alarm type displayed during mastering and their solution method:
 - (1) BZAL alarm

This alarm is displayed if the Pulsecoder's backup battery voltage decreases to 0 V while the power to the controller is disconnected. Furthermore, if the Pulsecoder connector is removed for cable replacement, etc. this alarm is displayed as the voltage decreases to 0. Confirm if the alarm will disappear by performing a pulse reset (See Section 8.2.). Then, cycle power of the controller to check if the alarm disappears or not.

The battery may be drained if the alarm is still displayed. Perform a pulse reset, and turn off and on the controller power after replacing the battery. Note that, if this alarm is displayed, all the original data held by the Pulsecoder will be lost. Mastering is required.

- (2) BLAL alarm
 - This alarm is displayed if the voltage of the Pulsecoder's backup battery has fallen to a level where backup is no longer possible. If this alarm is displayed, replace the battery with a new one immediately while keeping the power turned on. Check whether the current position data is valid, using the procedure described in 1.
- (3) Alarm notification like CKAL, RCAL, PHAL, CSAL, DTERR, CRCERR, STBERR, and SPHAL may have trouble with Pulsecoder, contact your local FANUC representative.

TROUBLESHOOTING

The source of mechanical unit problems may be difficult to locate because of overlapping causes. Problems may become further complicated, if they are not corrected properly. Therefore, you must keep an accurate record of problems and take proper corrective actions.

9.1 TROUBLESHOOTING

Table 9.1 (a) shows the major troubleshooting symptoms that may occur in the mechanical unit and their probable causes. If you cannot pinpoint the cause of a failure or which measures to take, contact your local FANUC representative. For the troubleshooting except the mechanical unit, refer to "CONTROLLER MAINTENANCE MANUAL (B-83195EN etc.)" and Alarm Code List (B-83284EN-1).

	Table 9.1 (a) TROUBLESHOOTING					
Symptoms	Descriptions	Causes	Measures			
Vibration Noise	 As the robot operates, its base plate lifts off the floor plate. There is a gap between the base plate and the floor plate. There is a crack in the weld that fastens the base plate to the floor plate. 	[Base plate and floor plate fastening] - It is likely that the base plate is not securely fastened to the floor plate because of poor welding. - If the base plate is not securely fastened to the floor plate, it lifts as the robot operates, allowing the base and floor plates to strike each other which, in turn, leads to vibration.	 Re-weld the base plate to the floor plate. If the weld is not strong enough, increase its width and length. 			
	 The J1 base lifts off the base plate as the robot operates. There is a gap between the J1 base and base plate. A J1 base retaining bolt is loose. 	 [J1 base fastening] It is likely that the robot J1 base is not securely fastened to the base plate. Probable causes are a loose bolt, an insufficient degree of surface flatness, or foreign material caught between the base plate and floor plate. If the robot is not securely fastened to the floor plate, the J1 base lifts the floor plate as the robot operates, allowing the base and floor plates to strike each other. That, in turn, leads to vibration. 	 If a bolt is loose, apply LOCTITE and tighten it with the appropriate torque. Adjust the base plate surface flatness to within the specified tolerance. If there is any foreign material between the J1 base and base plate, remove it. Apply adhesive between the J1 base and base plate. 			
	The rack or floor plate vibrates during operation of the robot.	[Rack or floor] - It is likely that the rack or floor is not rigid enough. - If they are not rigid enough, counterforce can deform the rack or floor, and causes vibration.	 Reinforce the rack or floor to make it more rigid. If reinforcing the rack or floor is impossible, modify the robot control program; doing so will reduce the vibration. 			

Vibration - Vibration becomes more [Overload] -	
Vibration Poconico moro [Overload]	Check the maximum load
Noise serious when the robot - It is likely that the load on	that the robot can handle
(Continued) adopts a specific posture. the robot is greater than the	once more. If the robot is
- If the operating speed of maximum rating.	overloaded, reduce the
the robot is reduced, - It is likely that the robot	load, or modify the robot
vibration stops. control program is too	control program.
- Vibration is most noticeable demanding for the robot -	Vibration can be reduced
when the robot is hardware.	by re-modifying the robot
accelerating It is likely that the - Vibration occurs when two ACCELERATION value is	control program; reducing speed or acceleration with
or more axes operate at the excessive.	minimizing the influence on
same time.	the entire cycle time.
- Vibration or noise was first [Gear, bearing, or reducer] -	Operate one axis at a time
noticed after the robot - It is likely that the collision	to determine which axis is
collided with an object or or overload applied an	vibrating.
the robot was overloaded excessive force to the drive -	Remove the motor, and
for a long period. system, thus damaged the	replace the gear, the
- The grease of the vibrating geartooth surface or rolling	bearing, and the reducer.
or noise occurring axis has surface of a bearing, or	For the spec. of parts and
not been replaced for a reducer.	the method of replacement,
long period It is likely that prolonged	contact your local FANUC
- Periodic vibration and noise use of the robot while	representative.
occur. overloaded caused fretting -	Using the robot within its
of the gear tooth surface or	maximum rating prevents
rolling surface of a bearing, or reducer due to resulting	problems with the drive mechanism.
metal fatigue.	Supplying the specified
- It is likely that foreign	grease at the
material caught in a gear,	recommended interval will
bearing, or within a reducer	prevent problems.
caused damage on the	
gear tooth surface or rolling	
surface of the bearing, or	
reducer.	
- It is likely that foreign	
material caught in a gear,	
bearing, or within a reducer	
caused vibration.	
- It is likely that, because the	
grease has not been replaced for a long period,	
fretting occurred on the	
gear tooth surface or rolling	
surface of a bearing, or	
reducer due to metal	
fatigue.	

Symptoms	Descriptions	Causes	Measures
Vibration	- The cause of problem	[Controller, cable, and motor]	- Refer to the Controller
Noise	cannot be identified from	- If a failure occurs in a	Maintenance Manual for
(Continued)	examination of the floor,	controller circuit, preventing	troubleshooting related to
	rack, or mechanical unit.	control commands from	the controller and amplifier.
		being supplied to the motor	- Replace the motor of the
		normally, or preventing	axis that is vibrating, and
		motor information from	check whether vibration still
		being sent to the controller	occurs. For the method of
		normally, vibration might	replacement, contact your
		occur.	local FANUC
		- Pulsecoder defect may be	representative.
		the cause of the vibration	- If vibration occurs only
		as the motor cannot	when the robot assumes a
		propagate the accurate	specific posture, it is likely
		position to the controller.	that there is a mechanical
		- If the motor becomes	problem.
		defective, vibration might	- Shake the movable part
		occur because the motor	cable while the robot is at
		cannot deliver its rated	rest, and check whether an
		performance.	alarm occurs. If an alarm or
		- If a power line in a movable	any other abnormality
		cable of the mechanical	occurs, replace the
		unit has an intermittent	mechanical unit cable.
		break, vibration might occur	- Check whether the cable
		because the motor cannot	jacket of the robot
		accurately respond to	connection cable is
		commands.	damaged. If so, replace the
		- If a Pulsecoder wire in a	connection cable, and
		movable part of the mechanical unit has an	check whether vibration still
		intermittent break, vibration	occurs Check whether the power
		might occur because	cable jacket is damaged. If
		commands cannot be sent	so, replace the power
		to the motor accurately.	cable, and check whether
		- If a robot connection cable	vibration still occurs.
		has an intermittent break,	- Check that the robot is
		vibration might occur.	supplied with the rated
		- If the power supply cable is	voltage.
		about to be snapped,	Check that the robot control
		vibration might occur.	parameter is set to a valid
		- If the power source voltage	value. If it is set to an
		drops below the rating,	invalid value, correct it.
		vibration might occur.	Contact your local FANUC
		- It may vibrate when an	representative for further
		invalid value parameter	information if necessary.
		was set.	
		was set.	

Symptoms	Descriptions	Causes	Measures
Vibration Noise (Continued)	There is some relationship between the vibration of the robot and the operation of a machine near the robot.	 [Noise from a nearby machine] If the robot is not grounded properly, electrical noise can be induced on the grounding wire, preventing commands from being transferred accurately, thus leading to vibration. If the robot is grounded at an unsuitable point, its grounding potential becomes unstable, and noise is likely to be induced on the grounding line, thus will lead to vibrate. 	Connect the grounding wire firmly to ensure a reliable ground potential thereby preventing extraneous electrical noise.
	 There is an unusual sound after replacing grease. There is an unusual sound after a long time. There is an unusual sound during operation at low speed. 	 There may be an unusual sound when using other than the specified grease. Even for the specified grease, there may be an unusual sound during operation at low speed immediately after replacement or after a long period of time. 	 Use the specified grease. When there is an abnormal noise even when using the specified grease, operate for one or two days as an experiment. Generally, any abnormal noise will disappear.
	 Unusual noise occurred at the balancer inside. 	 Liquid might intruded into the balancer, and it caused corrosion of the spring and breakage. 	- Prevent liquid splashing to the balancer.
Rattling	 While the robot is not supplied with power, pushing it by hand wobbles part of the mechanical unit. There is a gap on the mounting face of the mechanical unit. 	[Mechanical unit mounting bolt] - It is likely that overloading or a collision has loosened a mounting bolt in the robot mechanical unit.	- Check the following retaining bolts tightness for each axis. If any of these bolts is loose, apply LOCTITE and bolt down with appropriate torque Motor retaining bolt - Reducer retaining bolt - Reducer shaft retaining bolt - Base retaining bolt - Arm retaining bolt - Casing retaining bolt - End effector retaining bolt

Symptoms	Descriptions	Causes	Measures
Motor	- The motor overheated due	[Ambient temperature]	- Reducing the ambient
overheat	to the temperature in the installation area rose. - After a cover was attached to the motor, the motor overheated. - After changing the Robot control program or the load, the motor overheat.	 It is likely that the motor overheated along with the ambient temperature rose, and could not release heat. [Operating condition] It is likely that the overcurrent is above the specified permissive 	temperature is the most effective means of preventing overheat. - Having the surroundings of the motor well ventilated enables the motor to release heat efficiently, thus preventing overheat.
		average current.	 If there is a source of heat near the motor, it is advisable to install shielding to protect the motor from heat radiation. Relaxing the robot control program and load condition is an effective way to reduce the average current. Thus, prevent overheat. The teach pendant can monitor the average current. Check the average current when the robot control program launched.
	After a robot control parameter (load setting etc.) was changed, the motor overheated.	 [Parameter] If data input for a workpiece is invalid, the robot cannot be accelerate or decelerate normally, so the average current increases, leading to the motor overheating. 	As for load setting, Input an appropriate parameter referring to Section 4.3 of the operator's manual.
	- Symptom other than stated above	 [Mechanical section problems] It is likely that problems occurred in the mechanical unit drive mechanism, thus placing an excessive load on the motor. [Motor problems] It is likely that a failure of the motor brake resulted in the motor running with the brake applied, thus placing an excessive load on the motor. It is likely that a failure of the motor prevented it from delivering its rated performance, thus causing an excessive current to flow through the motor. It is likely that cooling fan is broken. 	 Repair the mechanical unit referring to the above descriptions of vibration, noise, and rattling. Check that, when the servo system is energized, the brake is released. If the brake remains applied to the motor all the time, replace the motor. Judgment is possible if the average current decreased after replacing the motor, the former motor had been defected. If the cooling fan is broken, replace it with a new one.

Symptoms	Descriptions	Causes	Measures
Grease leakage	- Grease leaks from the mechanical unit.	[Poor sealing] - Probable causes are a crack in the casting, a damaged O-ring, a damaged oil seal, or a loose seal bolt The casting may crack with excessive force caused in collision An O-ring can be damaged if it is trapped or cut during disassembling or reassembling An oil seal may be damaged if dust scratches the lip A loose seal bolt may allow grease to leak along the threads Problems with the grease nipple.	- If the casting cracks, sealant can be used as a quick-fix to prevent further grease leakage. However, the component must be replaced as soon as possible, as the crack will widen O-rings are used in the locations listed below Motor coupling section - Reducer (case and shaft) coupling section - Wrist coupling section - J3 arm coupling section - J3 arm coupling section - Inside the wrist - Oil seals are used in the locations stated below Inside the reducer - Inside the wrist - Seal bolts are used in the locations stated below Grease outlet - Replace the grease nipple.
Dropping axis	 An axis falls because the brake went out. An axis falls while standing still. 	 [Brake drive relay and motor] It is likely that brake drive relay contacts are stuck to each other and keep the brake current flowing, thus preventing the brake from operating when the motor is reenergized. It is likely that the brake shoe has worn out or the brake main body is damaged, preventing the brake from operating efficiently. It is likely that oil or grease soak through the motor, causing the brake to slip. 	- Check whether the brake drive relays are stuck to each other or not. If they are found to be stuck, replace the relays Replace the motor after confirming whether the following symptoms have occurred Brake shoe is worn out - Brake main body is damaged - Oil soaked through the motor

Symptoms	Descriptions	Causes	Measures
Displace ment	 The robot moves to a point other than the taught position. The repeatability is not within the tolerance. 	 [Mechanical unit problems] If the repeatability is unstable, probable causes are a failure in the drive mechanism or a loose bolt, and so on. If the repeatability is stable, it is likely that collision by an excessive load caused slip on the fasting surface of each axis arm, and reducer. It is likely that the Pulsecoder is faulty. 	 If the repeatability is unstable, repair the mechanical unit by referring to the above descriptions of vibration, noise, and rattling. If the repeatability is stable, correct the taught program. The problem will not reoccur unless another collision occurs. If the Pulsecoder is faulty, replace the motor.
	Displacement occurs only in specific peripheral equipment.	[Peripheral equipment displacement] - It is likely that an external force was applied to the peripheral equipment, thus shifting its position relative to the robot.	 Correct the setting of the peripheral equipment position. Correct the taught program.
	 Displacement occurred after a parameter was changed. 	[Parameter] - It is likely that the mastering data was overwritten, and the origin had misaligned.	 Re-enter the previous optimal mastering data. If correct mastering data is unavailable, perform mastering again.

Symptoms		Descriptions	Causes		Measures
CLALM	-	Ambient temperature of the	[Peripheral temperature]	-	Perform a warm up
alarm		robot installation location is	- When the robot is used in a		operation or a low speed
occurred.		low, CLALM alarm is	low temperature		operation for several
Move error		displayed on the teach	environment that is near to		minutes.
excess alarm		pendant screen.	0°C, or the robot is not		
occurred.	-	Ambient temperature of the robot installation position is	operated for a long time in an environment that is less		
		low,	than 0°C, there will be a		
		"Move error excess" alarm	large viscous resistance of		
		is displayed on the teach	the drive train immediately		
		pendant screen.	after starting which will		
			cause the alarm.		
	-	After changing the motion	- It is likely that a robot		If a robot collision has
		program or the load	collision occurred.		occurred, press the
		condition, the CLALM			[RESET] key while
		alarm is displayed.			pressing the [SHIFT] key.
	-	After changing the motion program or the load			Then, jog the robot in the opposite direction while
		condition, the "Move error			pressing the [SHIFT] key.
		excess" alarm is displayed.			Check the motion program.
			[Overload]		Check the permissible
			- It is likely that load		value of the robot payload.
			exceeded the permissible		If the load exceeds the
			value.		permissible value, reduce
			- It is likely that the motion		the load or change the
			program is too severe for		motion program.
			the robot.		Consider minimizing the
			 Excessive motion due to a large "ACC 		influence on cycle time by
			(value)".		reducing the speed or acceleration, and changing
			· Tight motion such as		the motion program.
			reverse motion using		Check that the load setting
			"CNT".		is performed correctly.
			 Linear motion occurs near singularity point 		,
			where axes revolve in		
			high speed.		
	-	None of the symptoms	- It is likely the vibration	-	Refer to the Symptoms:
		stated above are the	occurred.		Vibration, Noise section of
		problem.			this troubleshooting for
					more information.
			- It is likely that rated voltage	-	Check that the robot is
			is not supplied due to the	:	supplied with the proper
			voltage drop.		rated voltage.
CLALM	-	CLALM alarm is displayed	[Peripheral temperature]	-	Perform a warm up
alarm		on the teach pendant	- When the robot is used in a		operation or a low speed
occurred. Move error		screen, because ambient	low temperature		operation for several
		temperature of the robot	environment that is near to		minutes.
excess alarm occurred.		installation location is low,	0°C, or the robot is not		
occurred.	-	"Move error excess" alarm	operated for a long time in		
		is displayed on the teach	an environment that is less		
		pendant screen, because	than 0°C, there will be a		
		ambient temperature of the	large viscous resistance of		
		robot installation position is	the drive train immediately		
		low	after starting which will		
			cause the alarm.		

Symptoms		Descriptions		Causes		Measures
Symptoms CLALM alarm occurred. Move error excess alarm occurred.		After changing the motion program or the load condition, the CLALM alarm is displayed. After changing the motion program or the load condition, the "Move error excess" alarm is displayed.	- [(C	It is likely that a robot collision occurred. Diverload] It is likely that load exceeded the permissible value. It is likely that the motion program is too severe for the robot. Excessive motion due to a large "ACC (value)". Tight motion such as reverse motion using "CNT". Linear motion occurs near singularity point where axes revolve in high speed.		If a robot collision has occurred, press the [RESET] key while pressing the [SHIFT] key. Then, jog the robot in the opposite direction while pressing the [SHIFT] key. Check the motion program. Check the permissible value of the robot payload. If the load exceeds the permissible value, reduce the load or change the motion program. Consider minimizing the cycle time by reducing the speed or acceleration, and changing the motion program. Check that the load setting is performed correctly.
	1	None of the symptoms stated above are the problem.	-	It is likely the vibration occurred. If the power source voltage drops below the rating, a vibration might occur.	-	Refer to the Symptoms: Vibration, Noise section of this troubleshooting for more information. Check that the robot is supplied with the proper
BZAL alarm displayed.	-	BZAL is displayed on the teach pendant screen.	-	It is likely that the voltage of the memory backup battery is low. It is likely that the Pulsecoder cable is defective.	-	rated voltage. Replace the battery. Replace the cable.
Encoder alarm displayed	-	Primary encoder alarm is displayed on the teach pendant screen. Secondary encoder alarm is displayed on the teach	-	The cause of the alarms occurring at the same time is Pulsecoder. The cause of the alarms occurring at the same time	-	Check the Pulsecoder. Contact your local FANUC representative.
		pendant screen.		is secondary encoder.		

10 SEVERE DUST/LIQUID PROTECTION PACKAGE

10.1 SEVERE DUST/LIQUID PROTECTION PACKAGE(OPTION)

The package is intended to improve the severe dust/liquid protection characteristics of the robot so that it can be used in a severe environment.

Refer to Section 3.1 about dustproof and waterproof characteristics of the R-2000iC.

NOTE

Contact your FANUC representative for confirmation that the Severe Dust/liquid protection package is suitable for your environment.

Model	Severe dust/liquid protection package specification
R-2000 <i>i</i> C/165F/210F/240F/125L	A05B-1333-J801
R-2000 <i>i</i> C/165R/210R	A05B-1334-J801
R-2000 <i>i</i> C/270F/210L	A05B-1337-J801
R-2000 <i>i</i> C/270R	A05B-1337-J802

10.2 CONFIGURATION OF THE SEVERE DUST/LIQUID PROTECTION PACKAGE

The following table lists the major differences between the R-2000*i*C standard specification and severe dust/liquid protection package.

	Standard specifications	Severe dust/liquid protection option		
	Entire mechanical unit	Main unit	J3 arm and wrist	
Bolts	Black oxide finish steel bolt Black oxide finish washer	FR coating bolt Black chromate washer Stainless steel bolt Black oxide finish steel bolt	FR coating bolt Stainless steel bolt Black chromate washer	
Covers		J1-axis motor cover J2-axis motor cover J3/J4/J5/J6-axis motor cover Battery box cover Cable cover in mechanical un	it (for all exposed cables)	
J3 connector panel EE(RI/RO) connector	Non-waterproof connector	Waterproof connector	, , ,	




Fig. 10.2 (a) Configuration of the severe dust/liquid protection package

11 PRESS HANDLING PACKAGE (OPTION)

The press handling package improves heat radiation performance by installing cooling fans to the J1/J2 - axis motors or J1/J2/J3-axis motors to prevent motor overheat under high temperature environment.

NOTE

- 1 Contact your FANUC representative for confirmation that the press handling package is suitable for your environment.
- When overheat occurs, see troubleshooting chapter and consider countermeasures.

Model	Axis	Press handling package spec.
R-2000 <i>i</i> C/165F/210F/240F/125L	For J1/J2	A05B-1333-J821
R-20001C/165F/210F/240F/125L	For J1/J2/J3	A05B-1333-J822
R-2000 <i>i</i> C/165R/210R	For J1/J2	A05B-1334-J821
R-20001C/103R/210R	For J1/J2/J3	A05B-1334-J822
R-2000 <i>i</i> C/270F/210L/190U	For J1/J2	A05B-1337-J821
R-20001C/210F/210L/1900	For J1/J2/J3	A05B-1337-J822
R-2000 <i>i</i> C/100P	For J1/J2	A05B-1334-H181
K-20001C/100P	For J1/J2/J3	A05B-1334-H182
R-2000 <i>i</i> C/100PH	For J1/J2	A05B-1334-H185
R-20001C/100PH	For J1/J2/J3	A05B-1334-H184
D 2000;C/270D	For J1/J2	A05B-1337-J871
R-2000 <i>i</i> C/270R	For J1/J2/J3	A05B-1337-J872

NOTE

In addition, the fan connection cable which length is same as the robot connection cable is required.




Fig. 11 (a) Configuration of the press handling package

12

ACCURACY AND STIFFNESS ENHANCEMENT OPTION

The accuracy and stiffness enhancement option eliminates the effects of the backlash and distortion of mechanical unit by additional encoders, and maintains high accuracy even if the robot receives external force such as milling.

NOTE

Contact your FANUC representative for confirmation that the accuracy and stiffness enhancement option is suitable for your environment and use.

Model	Accuracy and stiffness enhancement option spec.
R-2000 <i>i</i> C/190S	A05B-1337-J841

NOTE

- 1 Exclusive mechanical unit cable is required.
- 2 In addition, the accuracy and stiffness enhancement option connection cable which length is same as the robot connection cable is required.





Fig. 12 (a) Configuration of the accuracy and stiffness enhancement option





PERIODIC MAINTENANCE TABLE

FANUC Robot R-2000*i*C/165F/210F/240F/125L/220U/165R/210R/100P/100PH **Periodic Maintenance Table**

_	_	Accumulated operating	Check	Grease	First	3	6	9	1				2			
Ite	ms	time (H)	time	amount	check 320	months	months	months	year 3840	4800	5760	6720	years 7680	8640	9600	10560
		Check for external	0.411		320	0	0	0	0	0	0	0	0	0	0	0
	1	damage or peeling paint Check damages	0.1H			0	O	0	0	O	U	0	0	0	U	
	2	of the cable protective sleeves	0.1H	_		0	0	0	0	0	0	0	0	0	0	0
	3	Check wear debris of the balancer and the J1-axis swing stopper	0.1H	_		0	0	0	0	0	0	0	0	0	0	0
	4	Check for water	0.1H			0	0	0	0	0	0	0	0	0	0	0
	5	Check damages of the mechanical unit cable (movable part)							0							
	6	Check damage of the end effector (hand) cable	0.1H	_		0			0				0			
	7	Check tightness of each axis motor and other exposed connector	0.2H	_		0			0				0			
	8	Retightening the end effector mounting bolts	0.2H	_		0			0				0			
	9	Retightening the external main bolts	2.0H	_		0			0				0			
Mechanical unit	10	Check the fixed mechanical stopper and the adjustable mechanical stopper	0.1H	_		0			0				0			
hanic	11	Clean spatters, sawdust and dust	1.0H	_		0			0				0			
Mec	12	Check the operation of the cooling fan	0.1H	_		0			0				0			
	13	Greasing to the balancer bush *1	0.1H	Each 10ml					•				•			
	14	Replacing the mechanical unit batteries*1 *3	0.1H	_							•					
	15	Replacing the grease of J1-axis reducer*1	1.0H	4730ml 6900ml (100P /100PH)				1 55	—	· Bu	~ ■					
	16	Replacing grease of J2-axis reducer*1	0.5H	2500ml				Ø	17		-18	19	,		;	
	17	Replacing grease of J3-axis reducer*1	0.5H	2170ml				12	1							
	18	Replacing grease of wrist axis 1 (J4, J5-axis)*1	0.5H	2560ml] 13
	19	Replacing grease of wrist axis 2 (J6-axis)*1	0.2H	440ml 690ml (100P/ 100PH)					—— 16 Г	Positio	n of a	rooo	ninnl	15		
									F	บรเแด	ıı oı g	rease	nippl	C		
	20	Replacing the mechanical unit cable*1	4.0H	_												
	21	Cleaning the controller ventilation system	0.2H	_	0	0	0	0	0	0	0	0	0	0	0	0
Controller	22	Check damages of the teach pendant cable,						0								
		Replacing battery *1 *3	0.1H													

For descriptions about the items marked with an asterisk (*), refer to "REPLACING UNITS Chapter" of this manual or the following manuals.

R-30iB/R-30iB Plus CONTROLLER MAINTENANCE MANUAL (B-83195EN),

R-30iB Mate/R-30iB Mate Plus CONTROLLER MAINTENANCE MANUAL (B-83525EN)

- batteries at 4 years.
- *4 R-2000*i*C/220U has no balancer.

3 years 11520	12490	13440	14400	4 years	16320	17290	18240	5 years 19200	20160	21120	22000	6 years	24000	24960	25920	7 years 26880	27940	20000	20760	8 years 30720	Items
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	30720	1
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		2
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		3
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		4
0				0				0				0				0					5
0				0				0				0				0					6
0				0				0				0				0					7
0				0				0				0				0					8
0				0				0				0				0					9
0				0				0				0				0					10
0				0				0				0				0					11
0				0				0				0				0				anl	12
•				•				•				•				•				Overhaul	13
•						•						•						•			14
•												•									15
•												•									16
•												•									17
•												•									18
•												•									19
				•																	20
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		21
		•	,						,	,											-
0				0				0				0				0					22
				•																	23
																					20

FANUC Robot R-2000iC/270F/270R/190S/210L/190U

Periodic Maintenance Table

\	_	Accumulated operation	a		First	3	6	9	1				2			
lte	me	time (H)	Check time	Grease amount	check	months	months	months	year	4000	5700	6700	years	0040	0000	40500
116	1113	Check for external			320	960	1920	2880	3840	4800	5760	6720	7680	8640	9600	10560
	1	damage or peeling paint	0.1H	_		0	0	0	0	0	0	0	0	0	0	0
	2	Check damages of the cable protective sleeves	0.1H	_		0	0	0	0	0	0	0	0	0	0	0
	3	swing stopper		0	0	0	0	0	0	0	0	0	0			
	4	Check for water	0.1H — OOOOO				0	0	0	0	0	0	0			
	5	Check damages of the mechanical unit cable (movable part)	0.2H	_		0			0				0			
	6	Check damage of the end effector (hand) cable	0.1H	_		0			0				0			
	7	Check looseness of each axis motor and other exposed connector	0.2H	_		0			0				0			
	8	Retightening the end effector mounting bolts	0.2H	_		0			0				0			
ıit	9	Retightening the external main bolts	2.0H	_		0			0				0			
Mechanical unit	10	Check the fixed mechanical stopper and the adjustable mechanical stopper	0.1H	_		0			0				0			
echa	11	Clean spatters, sawdust and dust	1.0H	_		0			0				0			
Σ	12	Check the operation of the cooling fan	0.1H			0			0				0			
	13	Greasing to the balancer bush*1	0.1H	Each 10ml					•				•			
	14	Replacing the mechanical unit Batteries*1 *3	0.1H	_							•					
	15	Replacing the grease of J1- axis reducer*1	1.0H	6250ml (except 190S) 5720ml (190S)									> \	TO TO)	
	16	Replacing grease of J2-axis reducer*1	0.5H	3470ml				3	-17							
	17	Replacing grease of J3-axis reducer*1	0.5H	2640ml			1	-13	_		-				290	——13 }
	18	Replacing grease of wrist axis 1 (J4, J5-axis)*1	0.5H	5540ml						-18			1	5	7	,
	19	Replacing grease of wrist axis 2 (J6-axis)*1	0.2H	630ml					F	Positio	n of a	rease	nippl			3
									'	551110	5. 9	. 0000	,PPI			
	20	Replacing the mechanical unit cable*1	4.0H													
	21	Cleaning the controller ventilation system	0.2H	_	0	0	0	0	0	0	0	0	0	0	0	0
Controller	Check damages of the teach pendant cable, the operation box connection cable and the robot connection cable				0											
	23	Replacing battery *1 *3	0.1H	l —												

^{*1} For descriptions about the items marked with an asterisk (*), refer to "REPLACING UNITS Chapter" of this manual or the following manuals.

R-30iB/R-30iB Plus CONTROLLER MAINTENANCE MANUAL (B-83195EN),

- *2 •: Requires order of parts •: Does not require order of parts
- *3 Regardless of the operating time, replace the mechanical unit batteries at 1.5 year, replace controller batteries at 4 years.
- *4 R-2000*i*C/190S has no balancer.

3 years				4 years				5 years				6 years				7 years				8 years	Items
11520	12480	13440	14400 O	15360	16320	17280	18240	19200	20160	21120	22080	23040	24000	24960	25920	26880	27840	28800	29760	30720	1
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		2
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		3
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	-	4
0				0				0				0				0					5
0				0				0				0				0					6
0				0				0				0				0					7
0				0				0				0				0					8
0				0				0				0				0					9
0				0				0				0				0					10
0				0				0				0				0					11
0				0				0				0				0				Overhaul	12
•				•				•				•				•				Ove	13
•						•						•						•			14
•												•									15
•												•									16
•												•									17
•												•									18
•												•									19
				•																	20
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		21
		0)			0				0											۷۱
0				0				0				0				0					22
				•																	23

B

STRENGTH OF BOLT AND BOLT TORQUE LIST

NOTE

When applying LOCTITE to a part, spread the LOCTITE on the entire length of the engaging part of the female thread. If applied to the male threads, poor adhesion can occur, potentially loosening the bolt. Clean the bolts and the threaded holes and wipe off any oil on the engaging section. Make sure that there is no solvent left in the threaded holes. When finished, remove all the excess LOCTITE when you are finished screwing the bolts into the threaded holes.

Use the following strength bolts. Comply with any bolt specification instructions.

Hexagon socket head bolt made of steel:

Size M22 or less: Tensile strength 1200N/mm² or more Size M24 or more: Tensile strength 1000N/mm² or more All size plating bolt: Tensile strength 1000N/mm² or more

Hexagon bolt, stainless bolt, special shape bolt (button bolt, low-head bolt, flush bolt .etc.)

Tensile strength 400N/mm² or more

Refer to the following tables if the bolts tightening torque is not specified.

Recommended bolt tightening torques

Unit: Nm

Nominal diameter	(ste	olt eel)	bolt (stain	ocket head less steel)	,	n bolt ocket head bolt ad bolt eel)	Hexagon bolt (steel) Tightening torque			
	Tightenir	· • • • • • • • • • • • • • • • • • • •		ng torque	Tightenir	· · · · · · · · · · · · · · · · · · ·				
			Upper limit		Upper limit	Lower limit	Upper limit	Lower limit		
M3	1.8	1.3	0.76	0.53						
M4	4.0	2.8	1.8	1.3	1.8	1.3	1.7	1.2		
M5	7.9	5.6	3.4	2.5	4.0	2.8	3.2	2.3		
M6	14	9.6	5.8	4.1	7.9	5.6	5.5	3.8		
M8	32	23	14	9.8	14	9.6	13	9.3		
M10	66	46	27	19	32	23	26	19		
M12	110	78	48	33			45	31		
(M14)	180	130	76	53			73	51		
M16	270	190	120	82			98	69		
(M18)	380	260	160	110	·	-	140	96		
M20	530	370	230	160	·	-	190	130		
(M22)	730	510								
M24	930	650								
(M27)	1400	960								
M30	1800	1300								
M36	3200	2300								

INDEX

<a>	<m></m>	
ACCURACY AND STIFFNESS	MAINTENANCE	174
ENHANCEMENT OPTION216	MAINTENANCE AREA	29
Actual Installation Example19	MASTERING	184
ADJUSTABLE MECHANICAL STOPPER	MASTERING DATA ENTRY	
AND LIMIT SWITCH SETTING (OPTION)142	MECHANICAL UNIT EXTERNAL	
ADJUSTING LIMIT SWITCH (OPTION)164	DIMENSIONS AND OPERATING SPACE	44
AIR PIPING (OPTION)108	Method of Executing KAREL Program by Using	
AIR SUPPLY (OPTION)107	"Call program"	101
AXIS LIMITS SETUP138	Method of Executing KAREL Program Directly	
	<0>	
BASIC SPECIFICATIONS33	OVERVIEW	184
<c></c>	<p></p>	
CHANGE AXIS LIMIT BY DCS (OPTION)139	Periodic Checks and Maintenance	167
CHANGING THE MOTION RANGE BY THE	PERIODIC MAINTENANCE TABLE	
LIMIT SWITCH (OPTION)162	PIPING AND WIRING TO THE END	219
Changing the parameter setting157	EFFECTOR	106
Check of Fixed Mechanical Stopper and	PREFACE	
Adjustable Mechanical Stopper173	PRESS HANDLING PACKAGE (OPTION)	
CHECK POINTS	Procedure for Releasing Remaining Pressure	21 .
Check the Mechanical Unit Cables and	from the Grease Bath	183
Connectors	<q></q>	
CHECKS AND MAINTENANCE166		101
CONFIGURATION OF THE SEVERE	QUICK MASTERING	
DUST/LIQUID PROTECTION PACKAGE212	QUICK MASTERING FOR SINGLE AXIS	194
Confirmation of Oil Seepage	< <i>R</i> >	
Confirmation of the Air Control Set (option)170		
CONNECTION WITH THE CONTROLLER32	Replacing the Batteries (1.5 year Periodic Maintenance)	175
405	*	1 / 3
<d></d>	Replacing the Grease of the Drive Mechanism (3	176
Daily Checks	years (11520 hours) Periodic Maintenance) RESETTING ALARMS AND PREPARING	
<e></e>	FOR MASTERING	
END EFFECTOR INSTALLATION TO WRIST85	ROBOT CONFIGURATION	33
EQUIPMENT INSTALLATION TO THE	405	
ROBOT85	< \$>	
EQUIPMENT MOUNTING FACE90	SAFETY PRECAUTIONS	s-1
.0.	SEVERE DUST/LIQUID PROTECTION	
<g></g>	PACKAGE	212
Greasing the Balancer Bush (1 year (3840 hours)	SEVERE DUST/LIQUID PROTECTION	
Periodic Maintenance)174	PACKAGE(OPTION)	
db.	SINGLE AXIS MASTERING	
	STORAGE	183
INERTIA LOAD SETTING100	STRENGTH OF BOLT AND BOLT TORQUE	
INSTALLATION17	LIST	224
INSTALLATION CONDITIONS31	SWITCHING METHOD OF MAX PAYLOAD	
Installing adjustable mechanical stopper option145	SPECIFICATION	100
INTERFACE FOR OPTION CABLE (OPTION)110	<t></t>	
<l></l>	The maximum stopping distance (position) of	
LOAD CONDITIONS ON J2 BASE, J3 ARM	adjustable mechanical stopper	159
AND J3 CASING80	TRANSPORTATION	
LOAD SETTING98	TRANSPORTATION	
	I KAINSI OKTATION AND INSTALLATION	1

INDEX B-83644EN/09

Transportation with an End Effector Attached16	
TROUBLESHOOTING203	
< <i>V</i> >	
VERIFYING MASTERING202	
<w></w>	
WRIST LOAD CONDITIONS60	
< Z >	
ZERO POINT POSITION AND MOTION	
LIMIT54	
ZERO POSITION MASTERING186	

REVISION RECORD

REVISION RECORD

Edition	Date	Contents
		Addition of R-2000 <i>i</i> C/190S
09	Apr., 2022	Addition of R-2000 <i>i</i> C/270F 300kg option
		Correction of errors
08	Sep., 2021	• Addition of R-2000 <i>i</i> C/100PH
00	Зер., 2021	Correction of errors
07	Aug 2020	• Addition of R-2000 <i>i</i> C/240F
07	Aug., 2020	Correction of errors
00	Jan 2000	• Addition of R-2000 <i>i</i> C/270R
06	Jan., 2020	Correction of errors
05	A 2010	• Addition of R-2000 <i>i</i> C/190U
05	Aug., 2018	Correction of errors
		• Addition of R-2000 <i>i</i> C/100P/220U
04	Sep., 2017	Addition of R-30 <i>i</i> B Plus/R-30 <i>i</i> B Mate Plus Controller
		Correction of errors
		• Addition of R-2000 <i>i</i> C/270F/210L
03	Apr., 2016	Correction of errors
		- Addition of R-2000 <i>i</i> C/165R/210R
02	Dec., 2014	Addition of quick master for single axis
		Correction of errors
01	Apr., 2014	

B-83644EN/09

* B - 8 3 6 4 4 E N / 0 9 *