

FANUC Robot M-900iB /360/360E/280L/280/330L

MECHANICAL UNIT OPERATOR'S MANUAL

B-83684EN/07

- **Original Instructions**

Thank you very much for purchasing FANUC Robot.

Before using the Robot, be sure to read the "FANUC Robot series SAFETY HANDBOOK (B-80687EN)" and understand the content.

- No part of this manual may be reproduced in any form.
- The appearance and specifications of this product are subject to change without notice.

The products in this manual are controlled based on Japan's "Foreign Exchange and Foreign Trade Law". The export from Japan may be subject to an export license by the government of Japan. Further, re-export to another country may be subject to the license of the government of the country from where the product is re-exported. Furthermore, the product may also be controlled by re-export regulations of the United States government. Should you wish to export or re-export these products, please contact FANUC for advice.

In this manual, we endeavor to include all pertinent matters. There are, however, a very large number of operations that must not or cannot be performed, and if the manual contained them all, it would be enormous in volume. It is, therefore, requested to assume that any operations that are not explicitly described as being possible are "not possible".

SAFETY PRECAUTIONS

This chapter describes the precautions which must be followed to enable the safe use of the robot. Before using the robot, be sure to read this chapter thoroughly.

For detailed functions of the robot operation, read the relevant operator's manual to understand fully its specification.

For the safety of the operator and the system, follow all safety precautions when operating a robot and its peripheral equipment installed in a work cell.

For safe use of FANUC robots, you must read and follow the instructions in the “FANUC Robot series SAFETY HANDBOOK (B-80687EN)”.

1 PERSONNEL

Personnel can be classified as follows.

Operator:

- Turns the robot controller power ON/OFF
- Starts the robot program from operator panel

Programmer or Teaching operator:

- Operates the robot
- Teaches the robot inside the safeguarded space

Maintenance technician:

- Operates the robot
 - Teaches the robot inside the safeguarded space
 - Performs maintenance (repair, adjustment, replacement)
- The operator is not allowed to work in the safeguarded space.
 - The programmer or teaching operator and maintenance technician are allowed to work in the safeguarded space. Work carried out in the safeguarded space include transportation, installation, teaching, adjustment, and maintenance.
 - To work inside the safeguarded space, the person must be trained on proper robot operation.

Table 1 (a) lists the work outside the safeguarded space. In this table, the symbol “○” means the work allowed to be carried out by the specified personnel.

Table 1 (a) List of work outside the Safeguarded Space

	Operator	Programmer or Teaching operator	Maintenance technician
Turn power ON/OFF to Robot controller	○	○	○
Select operating mode (AUTO/T1/T2)		○	○
Select remote/local mode		○	○
Select robot program with teach pendant		○	○
Select robot program with external device		○	○
Start robot program with operator's panel	○	○	○
Start robot program with teach pendant		○	○
Reset alarm with operator's panel		○	○
Reset alarm with teach pendant		○	○
Set data on teach pendant		○	○



	Operator	Programmer or Teaching operator	Maintenance technician
Teaching with teach pendant		○	○
Emergency stop with operator's panel	○	○	○
Emergency stop with teach pendant	○	○	○
Operator's panel maintenance			○
Teach pendant maintenance			○

During robot operation, programming and maintenance, the operator, programmer, teaching operator and maintenance technician take care of their safety using at least the following safety protectors:

- Use clothes, uniform, overall adequate for the work
- Safety shoes
- Helmet

2 DEFINITION OF SAFETY NOTATIONS

To ensure the safety of users and prevent damage to the machine, this manual indicates each precaution on safety with "WARNING" or "CAUTION" according to its severity. Supplementary information is indicated by "NOTE". Read the contents of each "WARNING", "CAUTION" and "NOTE" before using the robot.

Symbol	Definitions
 WARNING	Used if hazard resulting in the death or serious injury of the user will be expected to occur if he or she fails to follow the approved procedure.
 CAUTION	Used if a hazard resulting in the minor or moderate injury of the user, or equipment damage may be expected to occur if he or she fails to follow the approved procedure.
NOTE	Used if a supplementary explanation not related to any of WARNING and CAUTION is to be indicated.

3

PROCEDURE TO MOVE ARM WITHOUT DRIVE POWER IN EMERGENCY OR ABNORMAL SITUATIONS

- (1) For emergency or abnormal situations (e.g. persons trapped in or pinched by the robot), brake release unit can be used to move the robot axes without drive power. Please order following unit and cable.

Name	Specification
Brake release unit	A05B-2450-J350 (Input voltage AC100-115V single phase) A05B-2450-J351 (Input voltage AC200-240V single phase)
Robot connection cable	A05B-2450-J360 (5m) A05B-2450-J361(10m)
Power cable	A05B-2525-J010 (5m) (AC100-115V Power plug) (*) A05B-2525-J011(10m) (AC100-115V Power plug) (*) A05B-2450-J364 (5m) (AC100-115V or AC200-240V No power plug) A05B-2450-J365(10m) (AC100-115V or AC200-240V No power plug)

(*) These do not support CE marking.

- (2) Please make sure that adequate numbers of brake release units are available and readily accessible for robot system before installation.
- (3) Regarding how to use brake release unit, please refer to Robot controller maintenance manual.



CAUTION

Robot systems installed without adequate number of brake release units or similar means are neither in compliance with EN ISO 10218-1 nor with the Machinery Directive and therefore cannot bear the CE marking.



WARNING

Robot arm would fall down by releasing its brake because of gravity. Therefore, it is strongly recommended to take adequate measures such as hanging Robot arm by a crane before releasing a brake.




Fig. 3 (a) Arm operation by the release of J2, J3-axis motor brake and measures

4 WARNING & CAUTION LABEL

(1) Greasing and degreasing label



Fig. 4 (a) Greasing and degreasing label

Description

When greasing and degreasing, observe the instructions indicated on this label.

- (a) When greasing, be sure to keep the grease outlet open.
- (b) Use a manual pump to grease.
- (c) Be sure to use specified grease.

NOTE

See Chapter 7 CHECKS AND MAINTENANCE for explanations about specified grease, the grease amount, and the locations of grease inlets and grease outlets for individual models.

(2) Step-on prohibitive label



Fig. 4 (b) Step-on prohibitive label

Description

Do not step on or climb the robot as it may adversely affect the robot and you may get hurt if you lose your footing as well.

(3) High-temperature warning label



Fig. 4 (c) High-temperature warning label

Description

Be cautious about a section where this label is affixed, as the section generates heat. If you have to inevitably touch such a section when it is hot, use a protective tool such as heat-resistant gloves.

(4) Transportation label




Fig. 4 (d) Transportation label

Description

When transporting the robot, observe the instructions indicated on this label. The above label indicates the following:

- (a) Using a forklift
 - Use a forklift having a load capacity of 3000 kg or greater.
 - Keep the total mass of the robot to be transported to within 2600 kg, because the allowable load of the forklift bracket (option) is 6370 N (650 kgf).
- (b) Using a crane
 - Use a crane having a load capacity of 3000 kg or greater.
 - Use at least four slings each having a load capacity of 1000 kg or greater.
 - Use at least four eyebolts each having a allowable load of 6174 N (630 kgf) or greater.



CAUTION

Transportation labels are model-specific. Before transporting the robot, see the transportation label affixed to the J2 base side.
See Subsection 1.1 TRANSPORTATION for explanations about the posture a specific model should take when it is transported.

(5) Operating space and payload label (When CE specification is specified)

The following label is added:




Fig. 4 (e) Operating space and payload label

(6) Transportation caution label



Fig. 4 (f) Transportation caution label (for eyebolt option)

Description

Do not pull eyebolts sideways when transporting the robot.




Fig. 4 (g) Transportation prohibitive label (for transport equipment option)

Description

Keep the following in mind when transporting the robot.

- (a) Do not pull eyebolts sideways.
- (b) Prevent the forks of the forklift from having impact on a transport equipment.
- (c) Do not thread a chain or the like through a transport equipment.

(7) Mastering caution label



Fig. 4 (h) Mastering caution label

Description

Keep the following in mind when performing the mastering.


The motion limits are temporarily invalid during mastering. Cables may be damaged if the J1-axis exceeds $\pm 185^\circ$.

PREFACE

This manual explains the operation procedures for the mechanical units of the following robots:

Model name	Mechanical unit specification No.	Maximum load
FANUC Robot M-900iB/360	A05B-1335-B201	360kg
FANUC Robot M-900iB/360E	A05B-1335-B202	360kg
FANUC Robot M-900iB/280L	A05B-1335-B203	280kg
FANUC Robot M-900iB/280	A05B-1335-B205	280kg
FANUC Robot M-900iB/330L	A05B-1335-B213	330kg

The label stating the mechanical unit specification number is affixed in the following position. Before reading this manual, verify the specification number of the mechanical unit.



Position of label indicating mechanical unit specification number

TABLE 1

	(1)	(2)	(3)	(4)	(5)
CONTENTS	MODEL NAME	TYPE	No.	DATE	WEIGHT kg (Without controller)
LETTERS	FANUC Robot M-900iB/360	A05B-1335-B201	SERIAL NO. IS PRINTED	PRODUCTION YEAR AND MONTH ARE PRINTED	1540
	FANUC Robot M-900iB/360E	A05B-1335-B202			1540
	FANUC Robot M-900iB/280L	A05B-1335-B203			1600
	FANUC Robot M-900iB/280	A05B-1335-B205			1700
	FANUC Robot M-900iB/330L	A05B-1335-B213			1780

RELATED MANUALS

For the FANUC Robot series, the following manuals are available:

SAFETY HANDBOOK B-80687EN All persons who use the FANUC Robot and system designer must read and understand thoroughly this handbook		Intended readers : Operator , system designer Topics : Safety items for robot system design, operation, maintenance
R-30iB, R-30iB Plus controller	OPERATOR'S MANUAL (Basic Operation) B-83284EN OPERATOR'S MANUAL (Alarm Code List) B-83284EN-1 Optional Function OPERATOR'S MANUAL B-83284EN-2 Spot Welding Function OPERATOR'S MANUAL B-83284EN-4 Dispense Function OPERATOR'S MANUAL B-83284EN-5 Servo Gun Function OPERATOR'S MANUAL B-83264EN	Intended readers : Operator, programmer, Teaching operator, Maintenance technician, System designer Topics : Robot functions, Operations, Programming, Setup, Interfaces, Alarms Use : Robot operation, Teaching, System design
	MAINTENANCE MANUAL B-83195EN	Intended readers : Maintenance technician, System designer Topics : Installation, Start-up, Connection, Maintenance Use : Installation, Start-up, Connection, Maintenance

This manual uses following terms.

Name	Terms in this manual
Connection cable between robot and controller	Robot connection cable
Robot mechanical unit	Mechanical unit

TABLE OF CONTENTS

SAFETY PRECAUTIONS	s-1
PREFACE	p-1
1 TRANSPORTATION AND INSTALLATION	1
1.1 TRANSPORTATION.....	1
1.1.1 Transportation with an End Effector Attached.....	9
1.2 INSTALLATION	10
1.2.1 Actual Installation Example	11
1.2.2 Angle of Mounting Surface Setting.....	16
1.2.3 J1-axis Fixed Mechanical Stopper (option) (fixed side swing stopper) in Case of Upside-Down Mount.....	18
1.3 MAINTENANCE AREA.....	19
1.4 INSTALLATION CONDITIONS.....	19
2 CONNECTION WITH THE CONTROLLER	20
3 BASIC SPECIFICATIONS	21
3.1 ROBOT CONFIGURATION	21
3.2 MECHANICAL UNIT EXTERNAL DIMENSIONS AND OPERATING SPACE	26
3.3 ZERO POINT POSITION AND MOTION LIMIT	30
3.4 WRIST LOAD CONDITIONS	35
3.5 LOAD CONDITION ON J2 BASE AND J3 ARM	45
3.6 OPERATING SPACE RESTRICTION AT WALL OR ANGLE MOUNTING ..	47
4 EQUIPMENT INSTALLATION TO THE ROBOT	60
4.1 END EFFECTOR INSTALLATION TO WRIST	60
4.2 EQUIPMENT MOUNTING FACE	61
4.3 LOAD SETTING	70
4.4 INERTIA LOAD SETTING	72
5 PIPING AND WIRING TO THE END EFFECTOR	73
5.1 AIR SUPPLY (OPTION)	74
5.2 AIR PIPING (OPTION)	75
5.3 INTERFACE FOR OPTION CABLE (OPTION)	77
6 AXIS LIMITS SETUP	92
6.1 CHANGE AXIS LIMIT BY DCS (OPTION).....	92
6.2 ADJUSTABLE MECHANICAL STOPPER AND LIMIT SWITCH SETTING (OPTION)	96
6.2.1 Installing adjustable mechanical stopper option.....	97
6.2.2 Changing the parameter setting	101
6.2.3 The maximum stopping distance (position) of adjustable mechanical stopper....	102
6.3 CHANGING THE MOTION RANGE BY THE LIMIT SWITCH (OPTION) ..	104

6.4	ADJUSTING LIMIT SWITCH (OPTION)	106
7	CHECKS AND MAINTENANCE	107
7.1	CHECKS AND MAINTENANCE	107
7.1.1	Daily Checks	107
7.1.2	Periodic Checks and Maintenance.....	108
7.2	CHECK POINTS.....	110
7.2.1	Confirmation of Oil Seepage.....	110
7.2.2	Confirmation of the Air Control Set (option).....	111
7.2.3	Check the Mechanical Unit Cables and Connectors	112
7.2.4	Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper	114
7.3	MAINTENANCE.....	115
7.3.1	Replacing the Batteries (1.5 year check Periodic Maintenance)	115
7.3.2	Greasing of J2/J3-axis Connection Part Bearing (3 years check (11520 hours) Periodic Maintenance)	116
7.3.3	Replacing the Grease of the Drive Mechanism (3 years check (11520 hours) Periodic Maintenance)	118
7.3.4	Procedure for Releasing Remaining Pressure from the Grease Bath	121
7.4	STORAGE	121
8	MASTERING	122
8.1	OVERVIEW	122
8.2	RESETTING ALARMS AND PREPARING FOR MASTERING	123
8.3	ZERO POSITION MASTERING	124
8.4	QUICK MASTERING	127
8.5	QUICK MASTERING FOR SINGLE AXIS	130
8.6	SINGLE AXIS MASTERING	133
8.7	MASTERING DATA ENTRY	136
8.8	VERIFYING MASTERING	138
9	TROUBLESHOOTING	139
9.1	TROUBLESHOOTING.....	139
10	SEVERE DUST/LIQUID PROTECTION PACKAGE.....	147
10.1	SEVERE DUST/LIQUID PROTECTION PACKAGE(OPTION).....	147
10.2	CONFIGURATION OF THE SEVERE DUST/LIQUID PROTECTION PACKAGE	147
11	PRESS HANDLING PACKAGE (OPTION)	149
APPENDIX		
A	PERIODIC MAINTENANCE TABLE	153
B	STRENGTH OF BOLT AND BOLT TORQUE LIST.....	156

1 TRANSPORTATION AND INSTALLATION

1.1 TRANSPORTATION

Use a crane or a forklift to transport the robot. When transporting the robot, be sure to change the posture of the robot to that shown below and lift by using the eyebolts and the transport equipment at their points.




Fig. 1.1 (a) Position of the eyebolts and transportation equipment

- (1) Transportation using a crane (Fig. 1.1 (b) to (e))
Fasten the M20 eyebolts at the four points and lift the robot by the four slings.



CAUTION

When lifting the robot, be careful not to damage motors, connectors, or cables of the robot by slings.

- (2) Transportation using a forklift (Fig. 1.1 (f) to (i))
The robot is transported with the specific transport equipment attached.



WARNING

- 1 When hoisting or lowering the robot with a crane or forklift, move it slowly with great care. When placing the robot on the floor, exercise care to prevent the installation surface of the robot from striking the floor.
- 2 Detach the end effectors and the floor plate before transporting the robot. If the robot must necessarily be transported with the floor plate or end effectors attached, take the following precautions:
 - The entire position of center of gravity is changed by installing the tool and the floor plate. Please note the balance enough.
 - The tool swings by the vibration etc. when transported, and there is a possibility that an excessive load acts on the robot. Secure the end effector firmly according to Subsection 1.1.1.
 - When you lift robot with the floor plate installed, please lift up not the robot but the floor plate.
- 3 Use the forklift transport equipment only to transport the robot with a forklift. Do not use the forklift transport equipment to secure the robot.
Before moving the robot by using forklift transport equipment, check and tighten any loose bolts on the forklift transport equipment.
- 4 When J2/J3-axis motor covers (option) are installed, be sure to remove them before transporting robot with a crane.




Fig. 1.1 (b) Transportation using a crane (M-900/B/360/360E)




Fig. 1.1 (c) Transportation using a crane (M-900iB/280L)




Fig. 1.1 (d) Transportation using a crane (M-900/B/280)




Fig. 1.1 (e) Transportation using a crane (M-900iB/330L)




Fig. 1.1 (f) Transportation using a forklift (M-900iB/360/360E)




Fig. 1.1 (g) Transportation using a forklift (M-900iB/280L)

**CAUTION**

Be careful not to strike the transport equipment with the forklift forks.




Fig. 1.1 (h) Transportation using a forklift (M-900iB/280)




Fig. 1.1 (i) Transportation using a forklift (M-900iB/330L)



CAUTION

Be careful not to strike the transport equipment with the forklift forks.

1.1.1 Transportation with an End Effector Attached

When transporting a robot with an end effector such as a welding gun or hand attached, secure the arm with wood. If the arm is not secured, the end effector may oscillate for a cause such as vibration during transportation, as a result, a large impact load, imposes on the reducer of the robot, cause premature failure of the reducer.




Fig. 1.1.1 (a) Example of securing the arm during transportation when an end effector is attached

1.2 INSTALLATION

Fig. 1.2 (a) shows the robot base dimensions. Avoid placing any object in front of the robot on the locating surface (Shaded portion).




Fig. 1.2 (a) Dimension of robot base

1.2.1 Actual Installation Example

- Installation example I Fig. 1.2.1 (a)
The floor plate is imbedded in concrete and fastened with twelve M20 (Tensile strength 400N/mm² or more) chemical anchors. Also fasten the base plate to the robot base using eight M20 x 65 bolts (Tensile strength 1200N/mm² or more). Next, position the robot, and weld the base plate to the floor plate. (Floor length is 10 to 15mm.) (The base plate is prepared as the option.)
- Installation example II Fig. 1.2.1 (b)
The floor plate is not imbedded in concrete. The floor plate is fastened at the twelve points with M20 chemical anchors (Tensile strength 400N/mm² or more) and the inclination of the floor plate is adjusted with the four fixing screws. The robot is positioned with the robot base pushed against the three $\phi 20$ parallel pins inserted into the floor plate and the robot base is fastened on the floor plate with eight M20 x 65 bolts (Tensile strength 1200N/mm² or more).
- Installation example III Fig. 1.2.1 (c)
The installation method is generally the same as described above except that the parallel pins for pushing the robot base are not used.

The following parts are required to install the robot.

(○ : Parts needs to be prepared.)

Required parts	Remarks	Example I	Example II	Example III
Robot mounting bolts	M20 x 65 (Tensile strength 1200N/mm ² or more) 8 pcs	○	○	○
Plain washers	For M20 (HRC 35 or more, thickness between 4 and 5 mm) 8 pcs	○	○	○
Chemical anchors	M20 (tensile strength 400N/mm ² or more) 12 pcs	○	○	○
Floor plate	Thickness 32t 1 pc	○	○	○
Base plates	Thickness 32t 4 pcs	○		
Fixing screws	M20 4 pcs		○	○
Nuts	M20 4 pcs		○	○
Parallel pins	$\phi 20$ 3 pcs		○	

NOTE

- Arrangements for installation work (such as welding and anchoring) need to be made by customers.
- Flatness of robot installation surface must be less than or equal to 0.5mm.
Inclination of robot installation surface must be less than or equal to 0.5°.
If robot base is placed on uneven ground, it may result in the base breakage or low performance of the robot.




Fig. 1.2.1 (a) Actual installation example I




Fig. 1.2.1 (b) Actual installation example II




Fig. 1.2.1 (c) Actual installation exampleⅢ

Table 1.2.1 (a) and Fig. 1.2.1 (d) indicate the force and moment applied to the base plate at the time of Power-off stop of the robot. Table 1.2.1 (b) to (d) indicate the stopping distance and time of the J1 to J3 axis until the robot stops by Power-Off stop or Smooth stop or by Controlled stop after input of the stop signal. Refer to the data when considering the strength of the installation face.

NOTE

Table 1.2.1 (b) to (d) are measured reference value complied with ISO10218-1. Values differs depending on each robot individual difference, payload and the program. So confirm the real value by measurement. Values in Table 1.2.1 (b) is affected by the robot operating status and number of times of the servo-off stop. Periodically measure the real values and confirm those.

Table 1.2.1 (a) Force and moment during Power-Off stop

Model	Vertical moment Mv [kNm(kgfm)]	Force in vertical direction Fv [kN(kgf)]	Horizontal moment Mh [kNm(kgfm)]	Force in horizontal direction Fh [kN(kgf)]
M-900iB/360/280	114.66 (11700)	59.78 (6100)	33.32 (3400)	45.08 (4600)
M-900iB/360E	116.62 (11900)	59.78 (6100)	34.30 (3500)	45.08 (4600)
M-900iB/280L	119.56 (12200)	57.82 (5900)	34.30 (3500)	44.10 (4500)
M-900iB/330L	119.56 (12200)	54.88 (5600)	37.24 (3800)	38.22 (3900)

**Table 1.2.1 (b) Stopping time and distance until the robot stopping
by Power-Off stop after input of stop signal**

Models		J1-axis	J2-axis	J3-axis
M-900iB/360	Stopping time [ms]	730	227	250
	Stopping distance [deg] (rad)	38.4 (0.67)	11.9 (0.21)	11.8 (0.21)
M-900iB/360E	Stopping time [ms]	752	240	250
	Stopping distance [deg] (rad)	38.4 (0.67)	11.9 (0.21)	11.8 (0.21)
M-900iB/280L	Stopping time [ms]	772	216	362
	Stopping distance [deg] (rad)	39.6 (0.69)	10.7 (0.19)	17.9 (0.31)
M-900iB/280	Stopping time [ms]	687	250	226
	Stopping distance [deg] (rad)	36.3 (0.63)	12.9 (0.23)	11.4 (0.20)
M-900iB/330L	Stopping time [ms]	778	220	342
	Stopping distance [deg] (rad)	36.5 (0.64)	9.2 (0.16)	15.9 (0.28)

**Table 1.2.1 (c) Stopping time and distance until the robot stopping
by Smooth stop after input of stop signal**

Models		J1-axis	J2-axis	J3-axis
M-900iB/360	Stopping time [ms]	844	574	540
	Stopping distance [deg] (rad)	45.5 (0.79)	28.5 (0.50)	25.6 (0.45)
M-900iB/360E	Stopping time [ms]	845	590	590
	Stopping distance [deg] (rad)	45.5 (0.79)	30.1 (0.53)	28.1 (0.49)
M-900iB/280L	Stopping time [ms]	1018	490	830
	Stopping distance [deg] (rad)	55.2 (0.96)	24.7 (0.43)	38.1 (0.66)
M-900iB/280	Stopping time [ms]	788	586	544
	Stopping distance [deg] (rad)	42.1 (0.73)	29.5 (0.51)	26.1 (0.66)
M-900iB/330L	Stopping time [ms]	1052	1034	730
	Stopping distance [deg] (rad)	52.0 (0.91)	41.6 (0.73)	29.8 (0.52)

Table 1.2.1 (d) Stopping time and distance until the robot stopping by Controlled stop after input of stop signal

Models		J1-axis	J2-axis	J3-axis
M-900iB/360	Stopping time [ms]	1028	1020	1020
	Stopping distance [deg] (rad)	60.1 (1.05)	55.6 (0.97)	53.9 (0.94)
M-900iB/360E	Stopping time [ms]	1032	1024	1024
	Stopping distance [deg] (rad)	60.1 (1.05)	55.6 (0.97)	53.9 (0.94)
M-900iB/280L	Stopping time [ms]	1020	1020	1020
	Stopping distance [deg] (rad)	60.1 (1.05)	56.5 (0.99)	53.1 (0.93)
M-900iB/280	Stopping time [ms]	1028	1020	1020
	Stopping distance [deg] (rad)	60.1 (1.05)	55.6 (0.97)	53.9 (0.94)
M-900iB/330L	Stopping time [ms]	1152	1152	1170
	Stopping distance [deg] (rad)	58.9 (1.03)	48.1 (0.84)	49.1 (0.86)




Fig. 1.2.1 (d) Force and moment during Power-Off stop

1.2.2 Angle of Mounting Surface Setting

For all robot mounts except floor mount, be sure to set the mounting angle referring to the procedure below. Refer to Section 3.1 for installation specifications.

*M-900iB/330L does not support angle mount setting.

- 1 Turn on the controller with [PREV] and [NEXT] key pressed. Then select [3 Controlled start].
- 2 Press the [MENU] key and select [9 MAINTENANCE].
- 3 Select the robot for which you want to set the mount angle, and press the [ENTER] key.

ROBOT MAINTENANCE		CTRL START MANU	
Setup Robot System Variables			
Group	Robot Library/Option	Ext	Axes
1	M-900iB/360		0
[TYPE]ORD NO AUTO MANUAL			

- 4 Press [F4] key.
- 5 Press the [ENTER] key until screen below is displayed.

```

*****Group 1 Initialization*****
*****M-900iB/360*****

--- MOUNT ANGLE SETTING ---

  0 [deg] : floor mount type
  90 [deg] : wall mount type
 180 [deg] : upside-down mount type

Set mount_angle (0-180[deg])->
Default value = 0

```

- 6 Input the mount angle referring to Fig. 1.2.2 (a).




Fig. 1.2.2 (a) Mounting angle

- 7 Press the [ENTER] key until screen below is displayed again.

```

ROBOT MAINTENANCE      CTRL START MANU
-----

Setup Robot System Variables

Group  Robot Library/Option Ext Axes
  1      M-900iB/360              0

[TYPE]ORD NO      AUTO      MANUAL

```

- 8 Press the [FCTN] key and select [1 START (COLD)].

1.2.3 J1-axis Fixed Mechanical Stopper (option) (fixed side swing stopper) in Case of Upside-Down Mount

In case of upside-down mount, install J1-axis fixed mechanical stopper (option) (fixed side swing stopper) upside-down as shown in Fig. 1.2.3(a).

Refer to Section 3.3 about fixed mechanical stopper.

*M-900iB/330L does not support upside-down mount setting.




Fig. 1.2.3 (a) J1-axis fixed mechanical stopper (option) (fixed side swing stopper)

1.3 MAINTENANCE AREA

Fig. 1.3 (a) shows the maintenance area of the mechanical unit. Be sure to leave enough room for the robot to be mastered. See Chapter 8 for fixture position mastering information.




Fig. 1.3 (a) Maintenance area

1.4 INSTALLATION CONDITIONS

Refer to specifications of Section 3.1 about installation conditions.



CAUTION

Damage of the cable jacket can cause water intrusion. Take care when installing the cable and exchange it if it is damaged.

2 CONNECTION WITH THE CONTROLLER

The robot is connected with the controller via the power and signal cable and earth cable. Connect these cables to the connectors on the back of the base. For details on air and option cables, see Chapter 5.

**WARNING**

Before turning on controller power, be sure to connect robot mechanical unit and controller with the earth line. Otherwise, there is the risk of electrical shock.

**CAUTION**

- 1 Before connecting the cables, be sure to turn off the controller power.
- 2 Do not use 10m or longer coiled cable without untying. The long coiled cable will heat and damage itself.




Fig. 2 (a) Cable connection

3 BASIC SPECIFICATIONS

3.1 ROBOT CONFIGURATION




Fig. 3.1 (a) Mechanical unit configuration (M-900iB/360/360E/280L)




Fig. 3.1 (b) Mechanical unit configuration (M-900iB/280)




Fig. 3.1 (c) Mechanical unit configuration (M-900iB/330L)




Fig. 3.1 (d) Each axis coordinates and mechanical interface coordinates

NOTE

The end effector mounting face center is 0, 0, 0 of the mechanical interface coordinates.

Specifications (1/2) (NOTE 1)

Model			M-900iB/360/280	M-900iB/360E	M-900iB/280L
Type			Articulated type		
Controlled axes			6 axes(J1, J2, J3, J4, J5, J6)		
Installation			Floor mount, Upside-down (Angle mount) (NOTE 2)		
Motion range	J1-axis	Upper limit	185° (3.23rad)		185° (3.23rad)
		Lower limit	-185° (-3.23rad)		-185° (-3.23rad)
	J2-axis	Upper limit	76° (1.33rad)		76° (1.33rad)
		Lower limit	-75° (-1.31rad)		-75° (-1.31rad)
	J3-axis	Upper limit	90° (1.57rad)		90° (1.57rad)
		Lower limit	-133.7° (-2.33rad)		-133.7° (-2.33rad)
	J4-axis	Upper limit	360° (6.28rad)		360° (6.28rad)
		Lower limit	-360° (-6.28rad)		-360° (-6.28rad)
	J5-axis	Upper limit	125° (2.18rad)		125° (2.18rad)
		Lower limit	-125° (-2.18rad)		-125° (-2.18rad)
	J6-axis	Upper limit	360° (6.28rad)		360° (6.28rad)
		Lower limit	-360° (-6.28rad)		-360° (-6.28rad)
Maximum speed (NOTE 3)	J1-axis		110°/s (1.92rad/s)		110°/s (1.92rad/s)
	J2-axis		105°/s (1.83rad/s)		105°/s (1.83rad/s)
	J3-axis		100°/s (1.75rad/s)		100°/s (1.75rad/s)
	J4-axis		110°/s (1.92rad/s)		125°/s (2.18rad/s)
	J5-axis		110°/s (1.92rad/s)		125°/s (2.18rad/s)
	J6-axis		180°/s (3.14rad/s)		205°/s (3.58rad/s)
Maximum load Capacity	At the wrist		360 kg (M-900iB/360/360E) 280 kg (M-900iB/280)		280 kg
	On the J3 arm (NOTE 4)		50 kg		50 kg
	On the J2 base (NOTE 4)		550 kg		550 kg
Allowable load moment at wrist	J4-axis		1960 N·m (200 kgf·m)	2330 N·m (238 kgf·m)	1700 N·m (174 kgf·m)
	J5-axis		1960 N·m(200 kgf·m)	2330 N·m (238 kgf·m)	1700 N·m (174 kgf·m)
	J6-axis		1050 N·m (107 kgf·m)	1280 N·m (131 kgf·m)	950 N·m (97 kgf·m)
Allowable load inertia at wrist (NOTE 5)	J4-axis	(NOTE 5) 260 kg·m ² (2653 kgf·cm·s ²)	500 kg·m ² (5102 kgf·cm·s ²)	(NOTE5) 215 kg·m ² (2194 kgf·cm·s ²)	
		(NOTE 5) 460 kg·m ² (4694 kgf·cm·s ²)		(NOTE 5) 340 kg·m ² (3470 kgf·cm·s ²)	
	J5-axis	(NOTE 5) 260 kg·m ² (2653 kgf·cm·s ²)	500 kg·m ² (5102 kgf·cm·s ²)	(NOTE 5) 215 kg·m ² (2194 kgf·cm·s ²)	
		(NOTE 5) 460 kg·m ² (4694 kgf·cm·s ²)		(NOTE 5) 340 kg·m ² (3470 kgf·cm·s ²)	
	J6-axis	(NOTE 5) 160 kg·m ² (1633 kgf·cm·s ²)	360 kg·m ² (3673 kgf·cm·s ²)	(NOTE 5) 140 kg·m ² (1429 kgf·cm·s ²)	
		(NOTE 5) 360 kg·m ² (3673 kgf·cm·s ²)		(NOTE 5) 260 kg·m ² (2654 kgf·cm·s ²)	
Drive method	Electric servo drive by AC servo motor				
Repeatability	±0.1mm (NOTE 6)				
Mass(NOTE 7)	1540 kg (M-900iB/360/360E) 1700 kg (M-900iB/280)				1600 kg
Acoustic noise level	73.9dB (NOTE 8)				
Installation environment	Ambient temperature: 0 to 45°C (NOTE 9) Ambient humidity: Normally 75%RH or less (No condensation allowed.) Short time (Within 1 month) 95%RH or less (No condensation allowed.) Permitted altitude: Up to 1000 m above sea level. Vibration acceleration: 4.9 m/s ² (0.5G) or less Free of corrosive gases (NOTE 10)				

(NOTE 1) Even if the robot is used according to the defined specifications, motion programs might shorten reducer life or cause the robot to overheat. Use ROBOGUIDE (system design support tool by FANUC) for further evaluation before running production.

(NOTE 2) The operation range of the J1-axis and J2-axis are limited to the installation condition. Please refer to Section 3.6 for details. For angle of mounting surface, refer to Subsection 1.2.2.

(NOTE 3) During short distance motions, the axis speed may not reach the maximum value stated.

(NOTE 4) Please refer to Section 3.5 for load condition of the J3 arm and the J2 base.

(NOTE 5) The allowable load in standard inertia mode is shown in upper half and the allowable load in high inertia mode in lower half. For details, see Section 4.4.

(NOTE 6) Compliant with ISO 9283.

(NOTE 7) Without controller

(NOTE 8) This value is equivalent continuous A-weighted sound pressure level that applied with ISO11201 (EN31201). This value is measured with the following conditions.

- Maximum load and speed
- Operating mode is AUTO

(NOTE 9) When robot is used in low temperature environment that is near to 0°C, or not operated for a long time in the environment that is less than 0°C in a holiday or the night, collision detection alarm (SRVO-050) etc. may occur since the resistance of the drive mechanism could be high immediately after starting the operation. In this case, we recommend performing the warm up operation for several minutes.

(NOTE 10) Contact the service representative, if the robot is to be used in an environment or a place subjected to hot/cold temperatures, severe vibrations, heavy dust, water, water vapor, cutting oil, cleaning fluid splash and or other contamination.

Specifications (2/2) (NOTE 1)

Model		M-900iB/330L
Type		Articulated type
Controlled axes		6 axes(J1, J2, J3, J4, J5, J6)
Installation		Floor mount
Motion range	J1-axis	Upper limit 185° (3.23rad)
		Lower limit -185° (-3.23rad)
	J2-axis	Upper limit 76° (1.33rad)
		Lower limit -75° (-1.31rad)
	J3-axis	Upper limit 30° (0.52rad)
		Lower limit -133.7° (-2.33rad)
	J4-axis	Upper limit 360° (6.28rad)
		Lower limit -360° (-6.28rad)
	J5-axis	Upper limit 125° (2.18rad)
		Lower limit -125° (-2.18rad)
	J6-axis	Upper limit 360° (6.28rad)
		Lower limit -360° (-6.28rad)
Maximum speed (NOTE 2)	J1-axis	100°/s (1.75rad/s)
	J2-axis	85°/s (1.48rad/s)
	J3-axis	85°/s (1.48rad/s)
	J4-axis	90°/s (1.57rad/s)
	J5-axis	85°/s (1.48rad/s)
	J6-axis	165°/s (2.88rad/s)
Maximum load Capacity	At the wrist	330 kg
	On the J3 arm (NOTE 3)	50 kg
	On the J2 base (NOTE 3)	550 kg
Allowable load moment at wrist	J4-axis	2205 N·m (225 kgf·m)
	J5-axis	2205 N·m (225 kgf·m)
	J6-axis	1200 N·m (122 kgf·m)
Allowable load inertia at wrist	J4-axis	340 kg·m ² (3470 kgf·cm·s ²)
	J5-axis	340 kg·m ² (3470 kgf·cm·s ²)
	J6-axis	220 kg·m ² (2245 kgf·cm·s ²)
Drive method		Electric servo drive by AC servo motor
Repeatability		±0.1mm (NOTE 4)
Mass (NOTE 5)		1780 kg
Acoustic noise level		73.9dB (NOTE 6)
Installation environment		Ambient temperature: 0 to 45°C (NOTE 7) Ambient humidity: Normally 75%RH or less(No condensation allowed.) Short time (Within 1 month) 95%RH or less (No condensation allowed.) Permitted altitude: Up to 1000 m above sea level. Vibration acceleration: 4.9 m/s ² (0.5G) or less Free of corrosive gases (NOTE 8)

(NOTE 1) Even if the robot is used according to the defined specifications, motion programs might shorten reducer life or cause the robot to overheat. Use ROBOGUIDE (system design support tool by FANUC) for further evaluation before running production.

(NOTE 2) During short distance motions, the axis speed may not reach the maximum value stated.

(NOTE 3) Please refer to Section 3.5 for load condition of the J3 arm and the J2 base.

(NOTE 4) Compliant with ISO 9283.

(NOTE 5) Without controller

(NOTE 6) This value is equivalent continuous A-weighted sound pressure level that applied with ISO11201 (EN31201). This value is measured with the following conditions.

- Maximum load and speed
- Operating mode is AUTO

(NOTE 7) When robot is used in low temperature environment that is near to 0°C, or not operated for a long time in the environment that is less than 0°C in a holiday or the night, collision detection alarm (SRVO-050) etc. may occur since the resistance of the drive mechanism could be high immediately after starting the operation. In this case, we recommend performing the warm up operation for several minutes.

(NOTE 8) Contact the service representative, if the robot is to be used in an environment or a place subjected to hot/cold temperatures, severe vibrations, heavy dust, water, water vapor, cutting oil, cleaning fluid splash and or other contaminations.

The following table lists the IEC60529-based dustproof and waterproof characteristics of the M-900iB. Refer to Chapter 10 about severe dust/liquid protection package (option).

	Standard	Severe dust/liquid protection package (option)
J3 arm and wrist section	IP67	IP67
Drive unit of the main body	IP66	IP66
Main body	IP54 (*)	IP56

(*) Except some connectors




Fig. 3.1 (e) Severe dust/liquid protection characteristics of M-900iB

NOTE

Definition of IP code

Definition of IP 67

6=Dust-tight

7=Protection from water immersion

Definition of IP 66

6=Dust-tight

6=Protection from powerful water jets

Definition of IP 54

5=Dust-protected

4=Protection from splashing water

Definition of IP 56

5=Dust-protected

6=Protection from powerful water jets

Performance of resistant chemicals and resistant solvents is as follows.

- (1) The robot (including severe dust/liquid protection model) cannot be used with the following liquids. Potentially these liquids will cause irreversible damage to the rubber parts (such as: gaskets, oil seals, O-rings etc.). (As exception to this only liquids tested and approved by FANUC can be used with the robot.)
 - (a) Organic solvents
 - (b) Cutting fluid or cleaning fluid including chlorine / gasoline
 - (c) Amine type cutting fluid or cleaning fluid
 - (d) Acid, alkali and liquid causing rust
 - (e) Other liquids or solutions, that will harm NBR or CR rubber
- (2) When the robots work in the environment, using water or liquid, complete draining of J1 base must be done. Incomplete draining of J1 base will make the robot break down.
- (3) Don not use unconfirmed cutting fluid and cleaning fluid.
- (4) Do not use the robot immersed in water, neither temporary nor permanent. Robot must not be wet permanently. *Example : in case motor surface is exposed to water for a long time, liquid may invade inside the motor and cause failure.

3.2 MECHANICAL UNIT EXTERNAL DIMENSIONS AND OPERATING SPACE

Fig. 3.2 (a) to (d) show the robot operating space. When installing peripheral devices, be careful not to interfere with the robot and its operating space.




Fig. 3.2 (a) Operating space (M-900iB/360/360E)




Fig. 3.2 (c) Operating space (M-900iB/280)




Fig. 3.2 (d) Operating space (M-900iB/330L)

3.3 ZERO POINT POSITION AND MOTION LIMIT

Zero point and motion range are provided for each controlled axis. Exceeding the software motion limit of a controlled axis is called overtravel (OT). Overtravel is detected at both ends of the motion limit for each axis. The robot cannot exceed the motion range unless there is a loss of zero point position due to abnormalities in servo system or system error. In addition, the motion range limit by a fixed mechanical stopper or limit switch is also prepared to improve safety.

Fig. 3.3 (a) shows the position of fixed mechanical stopper.

Only in case of J1, robot stops by transforming fixed mechanical stopper (option).

Be sure to replace transformed stopper to new one. Do not reconstruct the fixed mechanical stopper. There is a possibility that the robot doesn't stop normally. Tighten bolts with regulated torque referring to Appendix B [STRENGTH OF BOLT AND BOLT TORQUE LIST].

Replace mechanical stopper of J1-axis referring to Section 6.2.

In case of upside-down mount, install J1-axis mechanical stopper (option) (fixed side swing stopper) upside-down referring to Subsection 1.2.3.



WARNING

Do not reconstruct the fixed mechanical stopper. There is a possibility that the robot doesn't stop normally.




Fig. 3.3 (a) Position of mechanical stopper

Fig. 3.3 (b) to 3.3 (i) show the zero point and motion limit, limit switch detection position, and maximum stopping distance (stopping distance in condition of maximum speed and maximum load) of each axis.

- * The motion range can be changed. For information on how to change the motion range, see Chapter 6, "AXIS LIMIT SETUP".




Fig. 3.3 (b) J1-axis motion limit (When mechanical stopper is not specified)




Fig. 3.3 (c) J1-axis motion limit (When mechanical stopper is specified)




Fig. 3.3 (d) J2-axis motion limit




Fig. 3.3 (e) J3-axis motion limit (M-900iB/360/360E/280L/280)




Fig. 3.3 (f) J3-axis motion limit (M-900/B/330L)




Fig. 3.3 (g) J4-axis motion limit




Fig. 3.3 (h) J5-axis motion limit




Fig. 3.3 (i) J6-axis motion limit

3.4 WRIST LOAD CONDITIONS

- Fig. 3.4 (a) to (k) are diagrams showing the allowable load that can be applied to the wrist section.
- Apply a load within the region indicated in the graph.
- Apply the conditions of the allowable load moment and the allowable load inertia. See Section 3.1 about the allowable load moment and the allowable load inertia.
- See Section 4.1 about mounting of end effector.




Fig. 3.4 (a) Wrist load diagram (ISO flange)
(M-900iB/360)





Fig. 3.4 (b) Wrist load diagram (Insulated ISO flange)
(M-900iB/360)



**Fig. 3.4 (c) Wrist load diagram (ISO flange)
(M-900iB/360E)**




Fig. 3.4 (d) Wrist load diagram (Insulated ISO flange)
(M-900iB/360E)




Fig. 3.4 (e) Wrist load diagram (ISO flange)
(M-900iB/280L)





Fig. 3.4 (f) Wrist load diagram (Insulated ISO flange)
(M-900/B/280L)



**Fig. 3.4 (g) Wrist load diagram (ISO flange)
(M-900iB/280)**




Fig. 3.4 (h) Wrist load diagram (Insulated ISO flange)
(M-900iB/280)




Fig. 3.4 (i) Wrist load diagram (ISO flange)
(M-900iB/330L)




Fig. 3.4 (j) Wrist load diagram (Insulated ISO flange)
(M-900i/B/330L)

3.5 LOAD CONDITION ON J2 BASE AND J3 ARM

Fig. 3.5 (a), (b) and Table 3.5 (a) show J2 base and J3 arm load condition.




Fig. 3.5 (a) J2 base / J3 arm load condition (M-900iB/360/360E/280L/330L)




Fig. 3.5 (b) J2 base / J3 arm load condition (M-900iB/280)

Table 3.5 (a) J2 base / J3 arm load condition

Mounting position	Load capacity	Condition
J2 base	550kg	The center of gravity must lie within a radius of 500 mm from the rotation center of the J1-axis
J3 arm	50kg	The total weight of the load 1 and the load 2 is less than 50kg.

3.6 OPERATING SPACE RESTRICTION AT WALL OR ANGLE MOUNTING

When M-900iB/360/360E/280L/280 are mounted on wall or inclined surface, the operating space has restriction depending on its mounted angle.

Wall mount and inclination installation is enable against only the front direction and the back direction. Against side direction is impossible.




Fig.3.6 (a) Direction of robot wall mount and inclination installation

The following Fig. 3.6 (b) to (m) shows the operating space restriction on these conditions. Robot can't keep its posture in the hatching area on Fig. 3.6 (b) to (m).




Fig. 3.6 (b) Operating space of mount angle range (1)
 $(-180^\circ \leq \phi \leq -175^\circ, -5^\circ \leq \phi \leq 5^\circ, 175^\circ \leq \phi \leq 180^\circ)$
 (M-900iB/360/360E)




Fig. 3.6 (c) Operating space of mount angle range (2)
 $(-175^\circ < \phi \leq -155^\circ, -25^\circ \leq \phi < -5^\circ, 5^\circ < \phi \leq 25^\circ, 155^\circ \leq \phi < 175^\circ)$
 (M-900iB/360/360E)

NOTE

Robot can not stop in shaded area.




Fig. 3.6 (d) Operating space of mount angle range (3)
 $(-155^\circ < \phi \leq -135^\circ, -45^\circ \leq \phi < 25^\circ, 25^\circ < \phi \leq 45^\circ, 135^\circ \leq \phi < 155^\circ)$
 (M-900iB/360/360E)

NOTE

Robot can not stop in shaded area.




Fig. 3.6 (e) Operating space of mount angle range (4)
 $(-135^\circ < \phi < -45^\circ, 45^\circ < \phi < 135^\circ)$
 (M-900iB/360/360E)

NOTE

Robot can not stop in shaded area.




Fig. 3.6 (f) Operating space of mount angle range (1)
 $(-180^\circ \leq \phi \leq -175^\circ, -5^\circ \leq \phi \leq 5^\circ, 175^\circ \leq \phi \leq 180^\circ)$
 (M-900/B/280L)




Fig. 3.6 (g) Operating space of mount angle range (2)
 $(-175^\circ < \phi \leq -155^\circ, -25^\circ \leq \phi < -5^\circ, 5^\circ < \phi \leq 25^\circ, 135^\circ \leq \phi < 155^\circ)$
 (M-900iB/280L)

NOTE

Robot can not stop in shaded area.




Fig. 3.6 (h) Operating space of mount angle range (3)
 $(-155^\circ < \phi \leq -135^\circ, -45^\circ \leq \phi < 25^\circ, 25^\circ < \phi \leq 45^\circ, 135^\circ \leq \phi < 155^\circ)$
 (M-900iB/280L)

NOTE

Robot can not stop in shaded area.




Fig. 3.6 (i) Operating space of mount angle range (4)
 $(-135^\circ < \phi < -45^\circ, 45^\circ < \phi < 135^\circ)$
 (M-900/B/280L)

NOTE

Robot can not stop in shaded area.




Fig. 3.6 (j) Operating space of mount angle range (1)
 $(-180^\circ \leq \phi \leq -175^\circ, -5^\circ \leq \phi \leq 5^\circ, 175^\circ \leq \phi \leq 180^\circ)$
 (M-900iB/280)




Fig. 3.6 (k) Operating space of mount angle range (2)
 $(-175^\circ < \phi \leq -155^\circ, -25^\circ \leq \phi < -5^\circ, 5^\circ < \phi \leq 25^\circ, 155^\circ \leq \phi < 175^\circ)$
 (M-900iB/280)

NOTE

Robot can not stop in shaded area.




Fig. 3.6 (I) Operating space of mount angle range (3)
 $(-155^\circ < \phi \leq -135^\circ, -45^\circ \leq \phi < 25^\circ, 25^\circ < \phi \leq 45^\circ, 135^\circ \leq \phi < 155^\circ)$
 (M-900iB/280)

NOTE

Robot can not stop in shaded area.




Fig. 3.6 (m) Operating space of mount angle range (4)
 $(-135^\circ < \phi < -45^\circ, 45^\circ < \phi < 135^\circ)$
 (M-900iB/280)

NOTE

Robot can not stop in shaded area.

4 EQUIPMENT INSTALLATION TO THE ROBOT

4.1 END EFFECTOR INSTALLATION TO WRIST

Fig. 4.1 (a) and 4.1 (b) show the figures for installing end effectors on the wrist. To fasten the end effector, first position it by using fitting [A] or [B], two pin holes at [C], then lock it using screws at [D]. Select screws and positioning pins of a length that matches the depth of the tapped holes and pin holes. Fasten the bolt for fixing the end effector with following torque of bolts for fixing end effector.

$128.4 \pm 6.4 \text{ Nm}$ ($1310 \pm 65 \text{ kgfcm}$)



CAUTION

Notice the tooling coupling depth to wrist flange should be shorter than the flange coupling length.




Fig. 4.1 (a) End effector interface (ISO flange)




Fig. 4.1 (b) End effector interface (Insulated ISO flange)


4.2 EQUIPMENT MOUNTING FACE

As shown in Fig. 4.2 (a) to (h), tapped holes are provided to install equipment to the robot.




CAUTION


- 1 Never perform additional machining operations such as drilling or tapping on the robot body. This can seriously affect the safety and functions of the robot.
- 2 When using a user tap shown in Fig. 4.2 (a) to (h), please keep the center of gravity position of the equipment according to Section 3.5.
- 3 Equipment should be installed on robot in a way it does not interfere with the mechanical unit cables. If equipment interferes, the mechanical unit cable might be disconnected, and unexpected troubles might occur.
- 4 Note that the use of a tapped hole not shown in the following figure is not assured. Please do not tighten both with the tightening bolts used for mechanical unit.



**Fig. 4.2 (a) Equipment mounting faces
(M-900iB/360/360E (1/2))**



**Fig. 4.2 (b) Equipment mounting faces
(M-900iB/360/360E (2/2))**



**Fig. 4.2 (c) Equipment mounting faces
(M-900iB/280L (1/2))**




Fig. 4.2 (d) Equipment mounting faces (M-900iB/280L (2/2))






Fig. 4.2 (e) Equipment mounting faces
(M-900iB/280 (1/2))



**Fig. 4.2 (f) Equipment mounting faces
(M-900iB/280 (2/2))**



**Fig. 4.2 (g) Equipment mounting faces
(M-900iB/330L (1/2))**




Fig. 4.2 (h) Equipment mounting faces
(M-900iB/330L (2/2))

4.3 LOAD SETTING



CAUTION

- 1 Set load condition parameter before operating the robot. Do not operate the robot in over payload reduction. Do not exceed allowable payload including connection cables and its swing. Otherwise troubles such as degradation of reducer life may occur.
- 2 WHEN PERFORMING LOAD ESTIMATION AFTER PARTS REPLACEMENT
If wrist axis motors (J5/J6-axis) or reducers are replaced, payload estimation accuracy may decrease. Perform calibration of load estimation without the load such as hand before performing load estimation.
Refer to Chapter 9 "LOAD ESTIMATION" in the R-30iB/R-30iB Mate/R-30iB Plus/R-30iB Mate Plus Controller Optional Function OPERATOR'S MANUAL

The operation motion performance screens include the MOTION PERFORMANCE screen, MOTION PAYLOAD SET screen, and payload information and equipment information on the robot.

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [6 SYSTEM] on the next page,
- 3 Press the F1 ([TYPE]) key to display the screen switch menu.
- 4 Select "Motion" The MOTION PERFORMANCE screen will be displayed.

MOTION PERFORMANCE		JOINT 10%	
Group1			
No.	PAYLOAD[kg]	Comment	
1	360.00	[]
2	0.00	[]
3	0.00	[]
4	0.00	[]
5	0.00	[]
6	0.00	[]
7	0.00	[]
8	0.00	[]
9	0.00	[]
10	0.00	[]
Active PAYLOAD number =0			
[TYPE]	GROUP	DETAIL	ARMLOAD SETIND >

- 5 Ten different pieces of payload information can be set using condition No. 1 to 10 on this screen. Place the cursor on one of the numbers, and press F3 [DETAIL]. The MOTION PAYLOAD SET screen appears.

MOTION PAYLOAD SET			JOINT 10%
Group 1			
1	Schedule No[1]:[Comment]
2	PAYLOAD	[kg]	360.00
3	PAYLOAD CENTER X	[cm]	-3.00
4	PAYLOAD CENTER Y	[cm]	0.00
5	PAYLOAD CENTER Z	[cm]	27.78
6	PAYLOAD INERTIA X	[kgfcms^2]	560.84
7	PAYLOAD INERTIA Y	[kgfcms^2]	590.39
8	PAYLOAD INERTIA Z	[kgfcms^2]	150.10
[TYPE] GROUP NUMBER DEFAULT HELP			




Fig. 4.3 (a) Standard tool coordinate

- 6 Set the payload, gravity center position, and inertia around the gravity center on the MOTION PAYLOAD SET screen. The X, Y, and Z directions displayed on this screen correspond to the respective standard tool coordinates (with no tool coordinate system set up). When values are entered, the following message appears: “Path and Cycletime will change. Set it?” Respond to the message with F4 [YES] or F5 [NO].
- 7 Pressing F3 [NUMBER] will bring you to the MOTION PAYLOAD SET screen for another condition number. For a multigroup system, pressing F2 [GROUP] will bring you to the MOTION PAYLOAD SET screen for another group
- 8 Press the [PREV] key to return to the MOTION PERFORMANCE screen. Press F5 [SETIND], and enter the desired payload setting condition number.
- 9 On the MOTION PERFORMANCE screen, press F4 [ARMLOAD] to display the MOTION ARMLoad SET screen.

MOTION ARMLoad SET		JOINT	100%
Group 1			
1	J2 BASE LOAD [kg]	550.00	
2	J3 ARM 1 LOAD [kg]	25.00	
3	J3 ARM 2 LOAD [kg]	10.00	
[TYPE]	GROUP	DEFAULT	HELP

- 10 Specify the weight of the load on the J2 base and J3 arm as follows:
J2 BASE LOAD [kg] : Weight of the load on the J2 base
J3 ARM 1 LOAD [kg] : Weight of the load on the J3 arm (wrist side)
J3 ARM 2 LOAD [kg] : Weight of the load on the J3 arm (wrist-axis motors side)
The following message appears: “Path and Cycletime will change. Set it?” Respond to the message with F4 [YES] or F5 [NO]. Once the loads are set up, the settings are completed by cycling power of the controller.

4.4 INERTIA LOAD SETTING

High inertia mode is provided for the M-900iB/360/280L/280. The inertia mode is automatically set according to the load value set in Section 4.3. Table 4.4 (a) shows allowable load moment at wrist of standard inertia mode and high inertia mode.

Table 4.4 (a) Inertia load setting

			Standard inertia mode	High inertia mode
Wrist unit allowable load inertia	J4-axis	/360/280	260kg·m ² (2653kgf·cm·s ²)	460kg·m ² (4694kgf·cm·s ²)
		/280L	215kg·m ² (2194kgf·cm·s ²)	340kg·m ² (3470kgf·cm·s ²)
	J5-axis	/360/280	260kg·m ² (2653kgf·cm·s ²)	460kg·m ² (4694kgf·cm·s ²)
		/280L	215kg·m ² (2194kgf·cm·s ²)	340kg·m ² (3470kgf·cm·s ²)
	J6-axis	/360/280	160kg·m ² (1633kgf·cm·s ²)	360kg·m ² (3673kgf·cm·s ²)
		/280L	140kg·m ² (1429kgf·cm·s ²)	260kg·m ² (2654kgf·cm·s ²)

5 PIPING AND WIRING TO THE END EFFECTOR



WARNING

- Only use appropriately-specified mechanical unit cables.
- Do not add user cables or hoses inside of the mechanical unit.
- Please do not obstruct the movement of the mechanical unit when cables are added to outside of mechanical unit.
- Please do not perform remodeling (adding a protective cover, or secure an additional outside cable) that obstructs the behavior of the outcrop of the cable.
- When external equipment is installed in the robot, make sure that it does not interfere with other parts of the robot.
- Cut and discard any unnecessary length of wire strand of the end effector (hand) cable. Insulate the cable with seal tape. (See Fig. 5 (a))
- If you have end effector wiring and a process that develops static electricity, keep the end effector wiring as far away from the process as possible. If the end effector and process must remain close, be sure to insulate the cable.
- Be sure to seal the connectors of the user cable and terminal parts of all cables to prevent water from entering the mechanical unit. Also, attach the cover to the unused connector.
- Frequently check that connectors are tight and cable jackets are not damaged.
- When precautions are not followed, damage to cables might occur. Cable failure may result in incorrect function of end effector, robot faults, or damage to robot electrical hardware. In addition, electric shock could occur when touching the power cables.




Fig. 5 (a) Treatment method of end effector (hand) cable

5.1 AIR SUPPLY (OPTION)

Robot has air inlet and air outlet on the back of the J1 base and the J3 arm back or side used to supply air pressure to the end effector. The connector is an Rc1/2 female. Because coupling are not supplied, it will be necessary to prepare couplings which suit to the tube size.




Fig. 5.1 (a) Air supply (option)

5.2 AIR PIPING (OPTION)

Fig. 5.2 (a) shows how to connect air hose to the robot. If the air control set is specified as an option, the air hose between the mechanical unit and the air control set is provided. Mount the air control set using the information in Fig. 5.2 (b). This is outside FANUC delivery scope.




Fig. 5.2 (a) Air piping (option)

Air control set

For the lubricator of air control set, fill in turbine oil #90 to #140 to the specified level. The machine tool builder is required to prepare mounting bolts.




Fig. 5.2 (b) Air control set option (option)

NOTE

The capacity of the air control set is as follows.
These values must not be exceeded.

Air pressure	Supply air pressure	0.49 to 0.69MPa (5 to 7kgf/cm ²),	Setting: 0.49MPa (5kgf/cm ²)
	Amount of consumption	Maximum instantaneous amount	150Nl/min(0.15Nm ³ /min)

5.3 INTERFACE FOR OPTION CABLE (OPTION)

Fig. 5.3 (a) shows the position of the option cable interface. Fig. 5.3 (b) to (d) shows the option cable interface.

EE interface (RI/RO), user cable (signal lines, signal line usable to force sensor and 3D Laser Vision sensor, power lines), DeviceNet cable (signal), DeviceNet cable (power), additional axis motor cable (Pulsecoder), additional axis motor cable (power, brake), camera cable, Ethernet cable are prepared as options.

NOTE

Each option cable is written as shown below on the connector panel.

EE interface (RI/RO)	: EE
User cable (signal)	: AS
User cable (signal usable to force sensor and 3D Laser Vision sensor)	: ASi
User cable (power)	: AP
DeviceNet cable (signal)	: DS
DeviceNet cable (power)	: DP
Additional axis motor cable (Pulsecoder)	: ARP
Additional axis motor cable (power, brake)	: ARM
Camera cable	: CAM
Ethernet cable	: ES




Fig. 5.3 (a) Interface for option cable (option)

5. PIPING AND WIRING TO THE END EFFECTOR

B-83684EN/07




Fig. 5.3 (b) Interface for option cables (1/2)

5. PIPING AND WIRING TO THE END EFFECTOR




Fig. 5.3 (c) Interface for option cables (2/2)




Fig. 5.3 (d) Interface for option cables
(When severe dust/liquid protection package is specified)

1 EE interface (RI/RO) (option)

Fig. 5.3 (e), (f) show the pin layout for the EE interface (RI/RO). When severe dust/liquid protection package is specified, the connector has guide pins and bushes for preventing improper insertion. For cables prepared by the user, use these guide pins and bushes.




Fig. 5.3 (e) Pin layout for EE interface(RI/RO) (option)




Fig. 5.3 (f) Pin layout for EE interface(RI/RO)
(When severe dust/liquid protection package is specified) (option)

NOTE

For wiring of the peripheral device to the EE interface, refer to the PERIPHERAL DEVICE, ARC WELDING, AND END EE INTERFACES Chapter of CONTROLLER MAINTENANCE MANUAL, too.

5. PIPING AND WIRING TO THE END EFFECTOR

B-83684EN/07

2 User cable (signal line) (AS) interface (option)

Fig. 5.3 (g) shows the pin layout for the user cable (signal line) interface. The connector has code pins for preventing improper insertion. The code pin is required for the cable which is prepared by the user.




Fig. 5.3 (g) Pin layout for user cable (signal line) (AS) interface and code pin layout (option)

- 3 User cable (signal line usable to force sensor and 3D Laser Vision sensor) (ASi) interface (option)
Fig. 5.3 (h) shows the pin layout for the user cable (signal line usable to force sensor and 3D Laser Vision sensor) interface. The connector has code pins for preventing improper insertion. The code pin is required for the cable which is prepared by the user.




Fig. 5.3 (h) Pin layout for user cable (signal line usable to force sensor and 3D Laser Vision sensor) (ASi) interface and code pin layout (option)

5. PIPING AND WIRING TO THE END EFFECTOR

B-83684EN/07

4 User cable (power line) (AP) interface (option)

Fig. 5.3 (i) shows the pin layout for the user cable (power line) interface. The connector has code pins for preventing improper insertion. The code pin is required for the cable which is prepared by the user.




Fig. 5.3 (i) Pin layout for user cable (power line) (AP) interface and code pin layout (option)

5 DeviceNet cable (signal line) (DS) interface (option)

Fig. 5.3 (j) shows the pin layout for the DeviceNet cable (signal line) interface.




Fig. 5.3 (j) Pin layout for DeviceNet cable (signal) (DS) interface (option)

6 DeviceNet cable (power line) (DP) interface (option)

Fig. 5.3 (k) shows the pin layout for the DeviceNet cable (power line) interface.




Fig. 5.3 (k) Pin layout for DeviceNet cable (power line) (DP) interface (option)

5. PIPING AND WIRING TO THE END EFFECTOR

B-83684EN/07

7 Additional axis motor cable (Pulsecoder) (ARP) interface (option)

Fig. 5.3 (I) shows the pin layout of the additional axis motor cable (Pulsecoder) interface. The connector has code pins for preventing improper insertion.




Fig. 5.3 (I) Pin layout of the additional axis motor cable (Pulsecoder) (ARP) interface and layout position of the code pin (option)

Table 5.3 (a) Comparative table of signal name according to the motor

ARP	α motor, β motor	α_i , α_i -B motor, β_i , β_i -B motor
SPD	SD	-
XSPD	*SD	-
PRQ	REQ	RD
XPRQ	*REQ	*RD

8 Additional axis motor cable (power, brake) (ARM) interface (option)

Fig. 5.3 (m) shows the pin layout of the additional axis motor cable (power, brake) interface. The connector has code pins for preventing improper insertion.




Fig. 5.3 (m) Pin layout of the additional axis motor cable (power, brake) (ARM) interface and layout position of the code pin (option)

9 Ethernet cable (signal line) (ES) interface (option)

Fig. 5.3 (n) shows the pin layout of the Ethernet cable (signal line) (ES) interface.




Fig. 5.3 (y) Pin layout for Ethernet cable (signal line) (ES) interface (option)

5. PIPING AND WIRING TO THE END EFFECTOR

B-83684EN/07

Connector specifications

Table 5.3 (b) Connector specifications (Mechanical unit side)

Cable	Input side (J1 base)		Maker /dealer	Output side (J3 arm)		Maker /dealer	
EE (RI/RO)	————		—	JMWR2524F		Fujikura Ltd.	
EE (RI/RO) (When severe dust/liquid protection package is specified)	————		—	Housing Insert Contact Guide pin Bush	09 30 006 0301 09 16 024 3101 09 15 000 6204 09 33 000 9908 09 33 000 9909	HARTING K.K.	
AS ASi	Housing Insert Contact Code pin	09 30 006 0301 09 16 024 3001 09 15 000 6103 09 30 000 9901	HARTING K.K.	Housing Insert Contact Code pin	09 30 006 0301 09 16 024 3101 09 15 000 6203 09 30 000 9901		
AP	Housing Insert Contact Code pin	09 20 010 0301 09 21 015 3001 09 15 000 6101 09 30 000 9901		Housing Insert Contact Code pin	09 20 010 0301 09 21 015 3101 09 15 000 6201 09 30 000 9901		
ARP	Housing Insert Contact Contact Code pin	09 30 006 0301 09 16 024 3001 09 15 000 6103 09 15 000 6104 09 30 000 9901		Housing Insert Contact Contact Code pin	09 30 006 0301 09 16 024 3101 09 15 000 6203 09 15 000 6204 09 30 000 9901		
ARM	Housing Insert Contact Contact Code pin	09 20 010 0301 09 21 015 3001 09 15 000 6101 09 15 000 6106 09 30 000 9901		Housing Insert Contact Contact Code pin	09 20 010 0301 09 21 015 3101 09 15 000 6201 09 15 000 6206 09 30 000 9901		
ES	Connector Contact	21 03 882 2425 09 67 000 7476		Connector Contact	21 03 882 2425 09 67 000 7476		
DS	CM03A-R5P-S-2			Fujikura Ltd.	CM03A-PR5S-S-2		Fujikura Ltd.
DP	Housing Insert Contact	09 30 006 0301 09 32 010 3001 09 33 000 6105	HARTING K.K.	CM03A-PR4S-S-2			

5. PIPING AND WIRING TO THE END EFFECTOR

Table 5.3 (c) Connector specifications (User side) (1/3)

Cable	Input side (J1 base)	Output side (J3 arm)		Maker /dealer
EE (RI/RO)	_____	<u>JMSP2524M</u> (*1) Straight <u>JMLP2524M</u> Angle		Fujikura Ltd.
EE (RI/RO) (When severe dust/liquid protection package is specified)	_____	Hood (NOTE 2)	09 30 006 1540 Side entry 1541 0542 0543 1440(*2) Top entry 1441 0442 0443	HARTING K.K.
		Insert	<u>09 16 024 3001</u> (*3)	
		Contact (24 pcs)	<u>09 15 000 6104</u> (*4) AWG 26-22 6103 AWG 20 6105 AWG 18 6102 AWG 18 6101 AWG 16 6106 AWG 14	
		Clamp (NOTE 2)	<u>09 00 000 5085</u> (*5) 5086 5090 5094 Many other types are available	
		Guide pin (2 pcs)	<u>09 33 000 9908</u> (*6)	
		Bush (2 pcs)	<u>09 33 000 9909</u> (*7)	

NOTE 1

Underlined parts are attached. Below shows spec. to order in our company.

(*1)A63L-0001-0234#S2524M

(*2)A63L-0001-0453#06B1440

(*3)A63L-0001-0453#24DDM

(*4)A63L-0001-0453#CA6104

(*5)A63L-0001-0453#A-152D

(*6)A63L-0001-0453#A-9908

(*7)A63L-0001-0453#A-9909

5. PIPING AND WIRING TO THE END EFFECTOR

B-83684EN/07

Table 5.3 (d) Connector specifications (User side) (2/3)

Table 3.3 (a) Connector specifications (User side) (2/3)							
Cable	Input side (J1 base)			Output side (J3 arm)			Maker /dealer
AS ASi	Hood (NOTE 2)	09 30 006 1540 1541 0542 0543 1440 1441 0442 0443	Side entry ↓ Top entry ↓	Hood	← Same as left		HARTING K.K.
	Insert	09 16 024 3101		Insert	09 16 024 3001		
	Contact (NOTE 2)	09 15 000 6204 6203 6205 6202 6201 6206	AWG 26-22 AWG 20 AWG 18 AWG 18 AWG 16 AWG 14	Contact (NOTE 2)	09 15 000 6104 6103 6105 6102 6101 6106	AWG 26-22 AWG 20 AWG 18 AWG 18 AWG 16 AWG 14	
	Clamp (NOTE 2)	09 00 000 5083 5086 5090 5094 etc. Many other types are available		Clamp	← Same as left		
	Code pin	09 30 000 9901		Code pin	09 30 000 9901		
AP	Hood (NOTE 2)	09 20 010 1541 0540 0541 1440 0440 0441	Side entry ↓ Top entry ↓	Hood	← Same as left		
	Insert	09 21 015 3101		Insert	09 21 015 3001		
	Contact (NOTE 2)	09 15 000 6204 6203 6205 6202 6201 6206	AWG 26-22 AWG 20 AWG 18 AWG 18 AWG 16 AWG 14	Contact (NOTE 2)	09 15 000 6104 6103 6105 6102 6101 6106	AWG 26-22 AWG 20 AWG 18 AWG 18 AWG 16 AWG 14	
	Clamp (NOTE 2)	09 00 000 5083 5086 5090 5094 etc. Many other types are available		Clamp	← Same as left		
	Code pin	09 30 000 9901		Code pin	09 30 000 9901		
ES	Connector	21 03 882 1415		Connector	← Same as left		
	Contact (NOTE 2)	09 67 000 7576 5576 8576 3576	AWG 28-24 AWG 26-22 AWG 24-20 AWG 22-18	Contact	← Same as left		

5. PIPING AND WIRING TO THE END EFFECTOR

Table 5.3 (e) Connector specifications (User side) (3/3)

Table 3.3 (e) Connector specifications (User side) (3/3)						
Cable	Input side (J1 base)			Maker /dealer	Output side (J3 arm)	Maker /dealer
DS	MINI connector for use on the device net 5-pin, FEMALE CM03-P5S			Fujikura Ltd.	MINI connector for use on the device net 5-pin, MALE CM03-J5P	Fujikura Ltd.
DP	Hood (NOTE 2)	09 30 006 1540 1541 0542 0543 1440 1441 0442 0443	Side entry ↓ Top entry ↓	HARTING K.K.	MINI connector for use on the device net 4-pin, MALE CM03-J4P	
	Insert	09 32 010 3101				
	Contact (NOTE 2)	09 33 000 6220 6214 6205 6204 6202 6207	AWG20 AWG18 AWG18 AWG16 AWG14 AWG12			
	Clamp (NOTE 2)	09 00 000 5083 5086 5090 5094 Many other types are available.				

NOTE 2

For details, such as the dimensions, of the parts listed above, refer to the related catalogs offered by the respective manufactures, or contact your local FANUC representative.

6

AXIS LIMITS SETUP

By setting the motion range of each axis, you can change the robot's motion range from the standard values. Changing the motion range of the robot is effective under the following circumstances:

- Used motion range of the robot is limited.
- There is an area where tool and peripheral equipment interfere with the robot.
- The length of cables and hoses attached for application is limited.

There are three methods used to prevent the robot from going beyond the necessary motion range.

- Limit axis motion range by DCS (All axes (option))
- Limit axis motion range adjustable mechanical stopper (J1/J2/J3-axes (option))
- Limit axis motion range by adjustable mechanical stopper and switches (J1-axis (option))

WARNING

- 1 Changing the motion range of any axis affects the operating range of the robot. To avoid trouble, carefully consider any possible effect of the change to the movable range of each axis in advance. Otherwise, it is likely that an unexpected condition will occur; for example, an alarm may occur in a previously taught position.
- 2 For J1-axis, use adjustable mechanical stoppers, for J2/J3-axis, use the adjustable mechanical stoppers or DCS function so that damage to peripheral equipment and injuries to human bodies can be avoided.
- 3 Mechanical stoppers are physical obstacles. For J1 to J3-axis, it is possible to re-position the adjustable mechanical stoppers. But the robot cannot move beyond them. For J5-axis, the mechanical stoppers are fixed. For the J4 and J6-axes, only DCS-specified limits are available.
- 4 For changing J2 and J3-axes interference angles, only adjustable mechanical stoppers are available; DCS specified movable range cannot be changed.
- 5 Adjustable mechanical stoppers (J1, J2, and J3-axes) are deformed in a collision to stop the robot. Once a stopper is subject to a collision, it can no longer assure its original strength and, therefore, may not stop the robot. When this happens, replace it with a new one.

6.1 CHANGE AXIS LIMIT BY DCS (OPTION)

The robot motion can be restricted with DCS (Dual check safety) function by using the following software. For J2/J3-axis, the same effect as adjustable mechanical stopper described in Section 6.2 can be obtained. The robot motion can be restricted at any angle and position if it is in robot motion area. DCS functions are certified to meet the requirements of International Standard ISO13849-1 and IEC61508 approved by notified body. If only the operating space is set using Joint Position Check, the robot stops after it goes beyond the workspace. When the motor power is shut down, the robot's momentum causes it to move some distance before it completely stops. The actual "Robot Stop Position" will be beyond the workspace. To stop the robot within the robot workspace, use the DCS Stop Position Prediction function. The stop position prediction is disabled by default.

- DCS position/speed check function (J567)

As an example, we shows the procedure to set $\pm 30^\circ$ for J2-axis in here. Refer to Dual check safety function Operator's Manual (B-83184EN) for details of other setting, function and DCS stop position prediction.

Setting procedure

- 1 Press the [MENU] key to display the screen menu.
- 2 Press [0 NEXT] and press [6 SYSTEM].
- 3 Press the F1 ([TYPE]).
- 4 Select [DCS]. The following screen will be displayed.

DCS		AUTO	JOINT 1%
1	Joint position check		
2	Joint speed check:		
3	Cart. position check	OK	
4	Cart. speed check		
5	T1 mode speed check		
6	User model		
7	Tool frame		
8	User frame		
9	Stop position prediction		
[TYPE] APPLY DETAIL		UNDO	

- 5 Move the cursor to [1 Joint position check], then press the [DETAIL].

DCS		AUTO	JOINT 1%	
Join Position check				
No.	G	A	Status Comment	
1	DISABLE	1	----	[]
2	DISABLE	1	----	[]
3	DISABLE	1	----	[]
4	DISABLE	1	----	[]
5	DISABLE	1	----	[]
6	DISABLE	1	----	[]
7	DISABLE	1	----	[]
8	DISABLE	1	----	[]
9	DISABLE	1	----	[]
10	DISABLE	1	----	[]
[TYPE]		DETAIL		

- 6 Move the cursor to [1], then press the [DETAIL].

DCS		AUTO	JOINT 1%
No. 1	Status:		
1 Comment	[*****]		
2 Enable/Disable	DISABLE		
3 Group	1		
4 Axis	1		
5 Safe side:			
Position (deg):			
Current:	0.000		
6 Upper limit :	0.000		
7 Lower limit :	0.000		
8 Stop type:	Power-off stop		
[TYPE] PREV NEXT		UNDO	

- 7 Move the cursor to [DISABLE], then press [CHOICE], set the status to [ENABLE].
- 8 Move the cursor to [Group], then input the robot group number, then press the [ENTER] key.
- 9 Move the cursor to [Axis], then input "2", then press the [ENTER] key.
- 10 Move the cursor to [Upper limit] right side, then input "30", then press the [ENTER] key.
- 11 Move the cursor to [Lower limit] right side, then input "-30", then press the [ENTER] key.

**WARNING**

If only the operating space is set using Joint Position Check, the robot stops after it goes beyond the workspace. When the motor power is shut down, the robot's momentum causes it to move some distance before it completely stops. The actual "Robot Stop Position" will be beyond the workspace. To stop the robot within the robot workspace, use the DCS Stop Position Prediction function. The stop position prediction is disabled by default.

DCS		AUTO
		JOINT 1%
No. 1	Status:	
1 Comment	[*****]	
2 Enable/Disable	ENABLE	
3 Group	1	
4 Axis	2	
5 Safe side:		
Position (deg):		
Current:	0.000	
6 Upper limit :	+30.000	
7 Lower limit :	-30.000	
8 Stop type:	Power-off stop	
[TYPE] PREV NEXT		UNDO

12 Press the [PREV] key two times, back to the first screen.

DCS		AUTO
		JOINT 1%
1	Joint position check	UNSF CHGD
2	Joint speed check:	
3	Cart. position check	OK
4	Cart. speed check	
5	T1 mode speed check	
6	User model	
7	Tool frame	
8	User frame	
9	Stop position prediction	
[TYPE] APPLY DETAIL		UNDO

13 Press the [APPLY].

14 Input 4-digit password, then press the [ENTER] key. (Password default setting is "1111".)

15 The following screen will be displayed, then press the [OK].

DCS		AUTO
		JOINT 1%
Verify (diff)		
F Number :	F0000	
VERSION :	HandlingTool	
\$VERSION :	V7. 7097 9/1/2015	
DATE:	17-7-28 19:44	
DCS Version:	V2. 0. 11	
-----Joint Position Check-----		
No.	G A	Status Comment
1	EBABLE 1 2	CHGD [
2	ENABLE 1 2	----
3	DISABLE 1 2	----
		ALL OK QUIT

[CHGD] on the right side of [1 Joint position check] will change to [PEND].

DCS		AUTO	
		JOINT 1%	
1	Joint position check	UNSF	PEND
2	Joint speed check:		
3	Cart. position check	OK	
4	Cart. speed check		
5	T1 mode speed check		
6	User model		
7	Tool frame		
8	User frame		
9	Stop position prediction		
[TYPE] APPLY DETAIL		UNDO	

- 16 Cycle the power of the controller in the cold start mode so the new settings are enabled.

**WARNING**

You must cycle the power of the controller to enable the new setting. If you fail to do so, the robot does not work normally and it may injure personnel or damage the equipment.

6.2 ADJUSTABLE MECHANICAL STOPPER AND LIMIT SWITCH SETTING (OPTION)

For the J1, J2, and J3-axis, adjustable mechanical stopper (option) can be installed. It is possible to re-position adjustable mechanical stoppers. Change the position of the adjustable mechanical stoppers according to the desired movable range. For the J1-axis, the limit switch-based movable range can also be changed. Refer to Section 6.3 and 6.4 for details.

Table 6.2 (a) Adjustable mechanical stopper and limit switch

Item		M-900iB/360/360E/280L/280/330L
J1-axis adjustable mechanical stopper and limit switch	Upper limit	Settable in steps of 5° in a range of -110° to +180°.
	Lower limit	Settable in steps of 5° in a range of -180° to +110°.
	Space between the upper and lower limit	A space of 70° or more is required.
J2-axis adjustable mechanical stopper	Upper limit	Settable in steps of 15° in a range of -60° to +60°. A mechanical stopper is also provided at the upper limit +76° of the standard movable range.
	Lower limit	Settable in steps of 15° in a range of -60° to +60°. A mechanical stopper is also provided at the upper limit -75° of the standard movable range.
	Space between the upper and lower limit	A space of 15° or more is required.
J3-axis adjustable mechanical stopper	Upper limit	(M-900iB/360/360E/280L/280) Settable in steps of 15° in a range of -120° to +75°. A mechanical stopper is also provided at the upper limit +90° of the standard movable range. (M-900iB/330L) Settable in steps of 15° in a range of -120° to +15°. A mechanical stopper is also provided at the upper limit +30° of the standard movable range.
	Lower limit	(M-900iB/360/360E/280L/280) Settable in steps of 15° in a range of -120° to +75°. A mechanical stopper is also provided at the upper limit -133.7° of the standard movable range. (M-900iB/330L) Settable in steps of 15° in a range of -120° to +15°. A mechanical stopper is also provided at the upper limit -133.7° of the standard movable range.
	Space between the upper and lower limit	A space of 15° or more is required.

NOTE

If the newly set operation range does not include 0°, it is necessary to change it by zero position mastering so that 0° is included.

6.2.1 Installing adjustable mechanical stopper option

Attach adjustable mechanical stoppers referring to Fig. 6.2.1 (a) to (f).




Fig. 6.2.1 (a) J1-axis adjustable mechanical stopper (option)




Fig. 6.2.1 (b) Adjustable mechanical stopper locations of J1-axis (1/2)




Fig. 6.2.1 (c) Adjustable mechanical stopper locations of J1-axis (2/2)




Fig. 6.2.1 (d) J2/J3-axis adjustable mechanical stopper (option)




Fig. 6.2.1 (e) Adjustable mechanical stopper locations of J2-axis




Fig. 6.2.1 (f) Adjustable mechanical stopper locations of J3-axis

6.2.2 Changing the parameter setting

Setting procedure

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE].
- 4 Select [Axis Limits]. The following screen will be displayed.

System Axis Limits				JOINT 100%
Group1				1/16
AXIS	GROUP	LOWER	UPPER	
1	1	-185.00	185.00	deg
2	1	-75.00	76.00	deg
3	1	-133.70	90.00	deg
4	1	-360.00	360.00	deg
5	1	-125.00	125.00	deg
6	1	-360.00	360.00	deg
7	1	0.00	0.00	mm
8	1	0.00	0.00	mm
9	1	0.00	0.00	mm

[TYPE]

NOTE

0.00 indicates the robot does not have these axes.

- 5 Move the cursor to the axis limit to be set. Type the new value using the numeric keys on the teach pendant. In this time, set the axial upper limit and the lower limit at the position same as adjustable mechanical stoppers are attached.

System Axis Limits				2/16
AXIS	GROUP	LOWER	UPPER	
2	1	-75.00	76.00	deg

[TYPE]

- 6 Cycle power of the controller in the cold start mode so the new information can be used.



WARNING

- 1 You must cycle power of the controller to use the new information; otherwise, the old settings remain valid and could cause personnel injury or equipment damage.
- 2 After changing system variables, be sure to run the robot at a low speed and make sure that the robot stops at the ends of the stroke.
- 3 If a collision should occur, the adjustable mechanical stopper becomes deformed to absorb energy, so that the robot can stop safely. If the stopper is deformed by mistake, replace it.
- 4 Do not depend on parameter settings to control the motion range of your robot.

6.2.3 The maximum stopping distance (position) of adjustable mechanical stopper

The adjustable mechanical stopper is a mechanism that can be adjusted in its position. The robot can work safely inside the adjusted motion range, up to the maximum range as shown in Table 6.2.3 (a) and Fig. 6.2.3 (a) to 6.2.3 (c).

A robot attempting to travel beyond this set range of motion, will be stopped by these stoppers, by collision; and therefore the robot will remain contained within the setup range.

Stopping the robot will cause the mechanical stopper to be “transformed” (permanently damaged). Be sure to replace the deformed stopper before using the robot again.

Table 6.2.3 (a) The maximum stopping distance (position) of movable mechanical stopper

	Plus side	Minus side
J1-axis	+21°	-21°
J2-axis	+8°	-8°
J3-axis	+9°	-11°




Fig. 6.2.3 (a) The maximum stopping distance of movable mechanical stopper of J1-axis




Fig. 6.2.3 (b) The maximum stopping distance of movable mechanical stopper of J2-axis




Fig. 6.2.3 (c) The maximum stopping distance of movable mechanical stopper of J3-axis

6.3 CHANGING THE MOTION RANGE BY THE LIMIT SWITCH (OPTION)

The limit switch is an over travel switch, which interrupts power to the servo motor and stops the robot when turned on. The limit switch is optionally provided for the J1-axis.

To change the motion range by the limit switch, move the dog. The following figure shows the relationship between the dog position and the motion range.

The dog of the J1-axis is placed in the same position as with the mechanical stopper.




Fig. 6.3 (a) J1-axis dog position and motion range (option)

6.4 ADJUSTING LIMIT SWITCH (OPTION)

After the motion range is changed by the limit switch, be sure to make adjustment.

ADJUSTING PROCEDURE

- 1 Set the \$MOR_GRP.\$CAL_DONE system parameter to FALSE. This disables the motion limit specified by the software. As a result, the operator can rotate the robot by a jog feed which goes beyond the motion limit.
- 2 Loosen the following bolts that hold the limit switch.
J1-axis : M8 x 12 2 pcs M4 x 25 2 pcs
- 3 Move the limit switch so that the robot activates it at about 0.5° before the stroke end. Step on the dog, and position the limit switch in such a place that only one of the step-on allowance indication lines at the tip of the switch is hidden.
- 4 When the limit switch operates and detects overtravel (OT), the robot stops, and an error message, "OVERTRAVEL", is displayed. To restart the robot, hold on [SHIFT] key and press [RESET] key. Then, while holding on [SHIFT] key, move the adjusting axis off the OT limit switch by jogging in joint mode.
- 5 Check that the robot also activates the limit switch when the robot is approx. 0.5° from the opposite stroke end in the same way as above. If the limit switch does not operate at the position, adjust the position of the switch again.
- 6 Set the \$MOR_GRP.\$CAL_DONE system parameter to TRUE.
- 7 Turn off the controller power, then turn it on again to restart the controller.




Fig. 6.4 (a) Adjusting J1-axis limit switch (option)

7 CHECKS AND MAINTENANCE

Optimum performance of the robot can be maintained by performing the checks and maintenance procedures presented in this chapter. (See the APPENDIX A PERIODIC MAINTENANCE TABLE.)

NOTE

The periodic maintenance procedures described in this chapter assume that the FANUC robot is used for up to 3840 hours a year. In cases where robot use exceeds 3840 hours/year, adjust the given maintenance frequencies accordingly. The ratio of actual operating time/year vs. the 3840 hours/year should be used to calculate the new (higher) frequencies. For example, when using the robot 7680 hours a year with a recommended maintenance interval of 3 years or 11520 hours, use the following calculation to determine the maintenance frequency: $3 \text{ years} / 2 = \text{perform maintenance every 1.5 years}$.

7.1 CHECKS AND MAINTENANCE

7.1.1 Daily Checks

Check the following items when necessary before daily system operation.

Check items	Check points and management
Oil seepage	Check to see if there is oil on the sealed part of each joint. If there is an oil seepage, clean it. ⇒"7.2.1 Confirmation of Oil Seepage"
Air control set	(When air control set is used) ⇒"7.2.2 Confirmation of the Air Control Set"
Vibration, abnormal noises	Check whether vibration or abnormal noises occur. When vibration or abnormal noises occur, perform measures referring to the following section: ⇒"9.1 TROUBLESHOOTING"(symptom : Vibration, Noise)
Positioning accuracy	Check whether the taught positions of the robot have not deviated from the previous taught positions. When the displacement occurs, perform the measures as described in the following section: ⇒"9.1 TROUBLESHOOTING"(symptom : Displacement)
Peripheral equipment for proper operation	Check whether the peripheral equipment operate properly according to commands from the robot and the peripheral equipment.
Brakes for each axis	Check that the droppage of the end effector is within 0.2 mm when the servo power turned off. If the end effector (hand) drops, perform the measures as described in the following section: ⇒"9.1 TROUBLESHOOTING"(symptom : Dropping axis)
Warnings	Check whether unexpected warnings occur in the alarm screen on the teach pendant. If unexpected warnings occur, perform the measures as described in the following manual: ⇒"CONTROLLER OPERATOR'S MANUAL (Alarm Code List)(B-83284EN-1)"

7.1.2 Periodic Checks and Maintenance

Check the following items at the intervals recommended below based on the period or the accumulated operating time, whichever comes first.

Check and maintenance intervals (Period, Accumulated operating time)						Check and maintenance items	Check points, management and maintenance methods	Periodic maintenance table No.
1 month 320h	3 months 960h	1 year 3840h	1.5 years 5760h	3 years 11520h	4 years 15360h			
○ Only 1st check	○					Cleaning the controller ventilation system	Confirm the controller ventilation system is not dusty. If dust has accumulated, remove it.	23
	○					Check the external damage or peeling paint	Check whether the robot has external damage or peeling paint due to the interference with the peripheral devices. If an interference occurs, eliminate the cause. Also, if the external damage is serious, and causes a problem in which the robot will not operate, replace the damaged parts.	1
	○					Check the damages of the cable protective sleeves	Check whether the cable protective sleeves of the mechanical unit cable have holes or tears. If damage is found, replace the cable protective sleeve. If the cable protective sleeve is damaged due to interference with peripheral devices, eliminate the cause. ⇒"7.2.3 Check the Mechanical Unit Cables and Connectors"	2
	○					Check the wear debris of the J1-axis swing stopper	Check whether wear debris has accumulated on the J1-axis swing stopper rotation part. If serious wear is evident on the part that generated the wear debris, replace the part.	3
	○					Check for water	Check whether the robot is subjected to water or cutting oils. If liquid was found, remove the cause, and wipe the liquid off.	4
	○ Only 1st check	○				Check for damages to the teach pendant cable, the operation box connection cable or the robot connection cable	Check whether the cable connected to the teach pendant, operation box and robot are unevenly twisted or damaged. If damage is found, replace the damaged cables.	24
	○ Only 1st check	○				Check for damage to the mechanical unit cable (movable part)	Observe the movable part of the mechanical unit cable, and check for damage. Also, check whether the cables are excessively bent or unevenly twisted. ⇒"7.2.3 Check the Mechanical Unit Cables and Connectors"	5
	○ Only 1st Check	○				Check for damage to the end effector (hand) cable	Check whether the end effector cables are unevenly twisted or damaged. If damage is found, replace the damaged cables.	6
	○ Only 1st check	○				Check the connection of each axis motor and other exposed connectors	Check the connection of each axis motor and other exposed connectors. ⇒"7.2.3 Check the Mechanical Unit Cables and Connectors"	7

Check and maintenance intervals (Period, Accumulated operating time)						Check and maintenance items	Check points, management and maintenance methods	Periodic maintenance table No.
1 month 320h	3 months 960h	1 year 3840h	1.5 years 5760h	3 years 11520h	4 years 15360h			
	○ Only 1st check	○				Retightening the end effector mounting bolts	Retighten the end effector mounting bolts. Refer to the following section for tightening torque information: ⇒ "4.1 END EFFECTOR INSTALLATION TO WRIST"	8
	○ Only 1st check	○				Retightening the external main bolts	Retighten the bolts which are installed, removed in the inspection, and exposed. Refer to the recommended bolt tightening torque guidelines at the end of the manual. Some bolts are attached with adhesive. If the bolts are tightened with greater than the recommended torque, the adhesive might be removed. Therefore, follow the recommended bolt tightening torque guidelines when retightening the bolts.	9
	○ Only 1st check	○				Check the mechanical stopper and the adjustable mechanical stopper	Check that there is no evidence of a collision on the mechanical stopper, the adjustable mechanical stopper, and check the looseness of the stopper mounting bolts. Check that the J1-axis swing stopper rotates smoothly. ⇒ "7.2.4 Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper"	10
	○ Only 1st check	○				Clean spatters, sawdust and dust	Check that spatters, sawdust, or dust does not exist on the robot main body. If dust has accumulated, remove it. Especially, clean the robot movable parts well (each joint, and the cable protective sleeve).	11
	○ Only 1st check	○				Check the operation of the cooling fan	(When cooling fans are installed on the each axis motor) Check whether the cooling fans are operating correctly. If the cooling fans do not operate, replace them.	12
			○			Replacing the mechanical unit batteries	Replace the mechanical unit batteries. Regardless of operating time, replace batteries at 1.5 years. ⇒ "7.3.1 Replacing the Batteries"	13
				○		Supply grease to J2/J3-axis connection part bearing	Supply grease to J2/J3-axis connection part bearing ⇒ "7.3.2 Greasing of J2/J3-axis Connection Part Bearing"	14
				○		Replacing the grease of drive mechanism	Replace the grease of each axis reducer and gearbox ⇒ "7.3.3 Replacing the Grease of the Drive Mechanism"	15 to 21
					○	Replacing the mechanical unit cable	Replace the mechanical unit cable Contact your local FANUC representative for information regarding replacing the cable.	22
					○	Replacing the controller batteries	Replace the controller batteries. Regardless of operating time, replace batteries at 4 years. ⇒ Chapter 7 Replacing batteries of CONTROLLER MAINTENANCE MANUAL (B-83195EN)"	25

7.2 CHECK POINTS

7.2.1 Confirmation of Oil Seepage

Check items

Confirm whether there is oil seepage on the rotating parts of each joint axis.




Fig. 7.2.1 (a) Check parts of oil seepage

Management

- Oil might accumulate on the outside of the seal lip depending on the movement condition or environment of the axis. If the oil changes to a state of liquid, the oil might spill depending on the axis movement. To prevent oil spots, be sure to wipe away any accumulated oil under the axis components before you operate the robot.
- Also, drive mechanisms might become hot and the internal pressure of the grease bath might rise by frequent repetitive movement and in high temperature environments. In these cases, normal internal pressure can be restored by venting the grease outlet. (When opening the grease outlet, refer to Subsection 7.3.3 and ensure that grease is not expelled onto the machine or tooling.)



WARNING

Hot grease might eject suddenly when you open the grease outlet. Attach bags for collecting grease, and use appropriate protective equipment such as heat-resistant gloves, protective glasses, a face shield, or a body suit if necessary.

- If you must wipe oil frequently, and opening the grease outlet does not stop the seepage, perform the measures below.
⇒ "9.1 TROUBLESHOOTING" (symptom : Grease leakage)

7.2.2 Confirmation of the Air Control Set (option)

When an air control set is used, check the items below.

Item	Check items	Check points
1	Air pressure	Check the air pressure using the pressure gauge on the air control set as shown in Fig. 7.2.2 (a). If it does not meet the specified pressure of 0.49 to 0.69 MPa (5-7 kgf/cm ²), adjust it using the regulator pressure-setting handle.
2	Lubricator oil mist quantity	Check the number of oil drops during operation. If it does not meet the specified value (1 drop/10-20 sec), adjust it using the handle for lubricator adjustment. The lubricator becomes empty in about 10 to 20 days under normal operation.
3	Lubricator oil level	Check to see that the air control set oil level is within the specified level.
4	Leakage from hose	Check the joints, tubes, etc. for leaks. Retighten the joints or replace parts, as required.
5	Drain	Check the drain and release it. When quantity of the drain is remarkable, examine the setting of the air dryer to the air supply side.




Fig. 7.2.2 (a) Air control set (option)

7.2.3 Check the Mechanical Unit Cables and Connectors

Check points of the mechanical unit cables

J1, J2, and J3 movable parts and fixed part cables can interfere with the peripheral devices

- * For the J1-axis, inspect the cables from above the J2 base and from the side by removing the metal plate on the side of the J1 base.




Fig. 7.2.3 (a) Inspection points of the mechanical unit cables

Check items

< Cable protective sleeve >

- Check that no holes or tears exist on the cable protective sleeves.
- If there is damage as shown in Fig. 7.2.3 (b), replace the cable protective sleeves.



Fig. 7.2.3 (b) Damage on the cable protective sleeve

<Cables>

- Check that there is no wear or damage on the cable jacket.
- If the inside wire strands are exposed due to wear or damage, replace the cables.




Fig. 7.2.3 (c) Cable check method

Inspection points of the connectors

- Power/brake connectors of the motor exposed externally
- Robot connection cables, earth terminal and user cables

Check items

- Circular connector: Check the connector for tightness by turning it by hand.
- Square connector: Check the connector for engagement of its lever.
- Earth terminal: Check the terminal for tightness.




Fig. 7.2.3 (d) Connector Inspection points

7.2.4 Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper

- Check that there is no evidence of a collision on the mechanical stopper and the adjustable mechanical stopper. If there is evidence of a collision on the stopper, replace the parts.
- Check the tightness of the stopper mounting bolts. (Fig. 7.2.4 (a))
- Check that the J1-axis swing stopper rotates smoothly.
- Refer to Section 6.2 of the operator's manual for details regarding the adjustable mechanical stopper.




Fig. 7.2.4 (a) Check of fixed mechanical stopper and adjustable mechanical stopper

7.3 MAINTENANCE

7.3.1 Replacing the Batteries (1.5 year check Periodic Maintenance)

The position data of each axis is preserved by the backup batteries. The batteries need to be replaced every 1.5 year. Also use the following procedure to replace when the backup battery voltage drop alarm occurs.

Procedure of replacing the battery

- 1 Press the EMERGENCY STOP button to stop the robot motion.



CAUTION

Be sure to keep the power turning on. Replacing the batteries with the power turned off causes all current position data to be lost. Therefore, mastering will be required again.

- 2 Remove the battery case cap. (Fig. 7.3.1 (a))
- 3 Take out the old batteries from the battery case.
- 4 Insert new batteries into the battery case while observing their correct orientation.
- 5 Close the battery case cap.



CAUTION

When using a robot with the severe dust/liquid protection option, remove the cover from the battery case as shown in Fig. 7.3.1 (b) to replace the battery. After replacing the battery, reinstall the cover. At this time, please be sure to replace gasket with new one for severe dust/liquid protection.




Fig. 7.3.1 (a) Replacing the battery




Fig. 7.3.1 (b) Removing the battery cover plate (When severe dust/liquid protection is specified)

7.3.2 Greasing of J2/J3-axis Connection Part Bearing (3 years check (11520 hours) Periodic Maintenance)

Be sure to supply grease to J2/J3-axis connection part bearing specified in Table 7.3.2 (a) and 7.3.2 (b). Adjust the greasing timing if your robot is installed in an adverse environment. Supply grease immediately if water is splashed to the robot. Fig. 7.3.2 (a) shows greasing points of J2/J3-axis connection part bearing.

Table 7.3.2 (a) Greasing J2/J3-axis connection part bearing

Recommended grease	Amount of grease	Greasing interval
Shell Lubricants Alvania grease S2 Specification: A98L-0004-0602#CTG	20 ml for each (two points)	3 years or every 11520 hours of accumulated operation

Table 7.3.2 (b) Grease alternative to Alvania GREASE S2

Maker	Grease name
Exxon Mobil	Mobilux EP2
ENEOS	Multinoc 2
ENEOS	Epinoc grease AP(N)2
Idemitsu Kosan Co., Ltd.	Eponex grease No. 2
Cosmo Oil Co., Ltd.	Dynamax No. 2
Shell Lubricants	Shell Gadus S2 V100 2




Fig. 7.3.2 (a) J2/J3-axis connection part bearing greasing points

Table 7.3.2 (c) Spec. of the grease nipple

Parts name	Specifications
Grease nipple	A97L-0218-0013#A610

7.3.3 Replacing the Grease of the Drive Mechanism (3 years check (11520 hours) Periodic Maintenance)

According to below, replace the grease of each axis reducer and gearbox at the intervals based on every 3 years or 11520 hours, whichever comes first. See Table 7.3.3 (a) for the specified grease and the quantity.

Table 7.3.3 (a) Grease for 3-years (11520 hours) periodical replacement

Greasing	Quantity	Gun tip pressure	Specified grease
J1-axis reducer	5950g (6620ml)	0.15MPa or less (NOTE)	Spec : A98L-0040-0174
J2-axis reducer	2450g (2730ml)		
J3-axis reducer	2450g (2730ml)		
J4/J5/J6-axis gearbox	2400g (2670ml)		
wrist 1 (J4, J5-axis reducer)	4800g (5340ml)		
wrist 2 (J6-axis gearbox)	130g (140ml)		
wrist 3 (J6-axis reducer)	620g (690ml)		

NOTE

When a manual pump is used for greasing, the standard rate is two pumping cycles per three seconds.



WARNING

Hot grease might eject suddenly when you open the grease outlet. Attach bags for collecting grease, and use appropriate protective equipment such as heat-resistant gloves, protective glasses, a face shield, or a body suit if necessary.

For grease replacement or replenishment, use the posture indicated below.

Table 7.3.3 (b) Postures for greasing

Supply position	Posture					
	J1	J2	J3	J4	J5	J6
J1-axis reducer	Arbitrary	Arbitrary	Arbitrary	Arbitrary	Arbitrary	Arbitrary
J2-axis reducer		0°				
J3-axis reducer		0°	0°			
J4/J5/J6-axis gearbox		Arbitrary	0°			
Wrist			0°	0°	0°	0°

Grease replacement procedure of the J1, J2, J3-axis reducer and the J4/J5/J6-axis gearbox

- 1 Move the robot to the greasing posture described in Table 7.3.3 (b).
- 2 Turn off the controller power.
- 3 Remove the seal bolt from grease outlet and ventilator hole. (Fig. 7.3.3 (a))
- 4 Supply new grease through the grease inlet until new grease is output from grease outlet.
- 5 Release remaining pressure using the procedure given in Subsection 7.3.4.




Fig. 7.3.3 (a) Replacing grease of the J1, J2, J3-axis reducer and the J4/J5/J6-axis gearbox

Grease Replacement Procedure for the Wrist

- 1 Move the robot to the greasing posture described in Table 7.3.3 (b).
- 2 Turn off the controller power.
- 3 Remove the taper plug of wrist grease outlet 1 (Fig. 7.3.3 (b)).
- 4 Supply new grease to the wrist grease inlet 1 until new grease outputs from wrist grease outlet 1.
- 5 Next, remove the taper plugs of wrist grease inlet 2 and wrist grease outlet 2.
- 6 Attach a grease nipple to grease inlet 2.
- 7 Supply new grease to the wrist grease inlet 2 until new grease is output from wrist grease outlet 2.
- 8 Next, remove the taper plug of wrist grease outlet 3.
- 9 Supply new grease to the wrist grease inlet 3 until new grease is output from wrist grease outlet 3.
- 10 Release remaining pressure using the procedure given in Subsection 7.3.4.




Fig. 7.3.3 (b) Replacing grease of the wrist

Table 7.3.3 (c) Spec. of the seal bolt, the taper plug and the grease nipple

Parts name	Specifications
Seal bolt (M12)	A97L-0218-0417#121515
Taper plug (R1/8)	A97L-0001-0436#1-1D
Grease nipple (except the wrist grease inlet 1&2)	A97L-0218-0013#A610
Grease nipple (wrist grease inlet 1&2)	A97L-0218-0013#A110

**CAUTION**

Failure to follow proper greasing procedures may cause a sudden increase of the grease bath internal pressure and damage to the seal. This could lead to grease leakage and abnormal operation. When greasing, observe the following cautions.

- (1) Before starting to grease, remove the plug or bolt from the grease outlet and the ventilator hole to allow the grease to come out.
- (2) Supply grease slowly, using a manual pump.
- (3) Whenever possible, avoid using an air pump, which is powered by the factory air supply. If the use of an air pump is unavoidable, supply grease with the pump at a pressure lower than or equal to the gun tip pressure (Table 7.3.3 (a)).
- (4) Use specified grease. Use of non-approved grease may damage the reducer or lead to other problems.
- (5) After greasing, release remaining pressure from the grease bath using the procedure given in Subsection 7.3.4, and then close the grease inlet, the grease outlet and the ventilator hole.
- (6) To prevent an accident such as a fall or fire, remove all the excess grease from the floor and robot.

7.3.4 Procedure for Releasing Remaining Pressure from the Grease Bath

Release remaining pressure as described below.

Under the grease inlets and outlets, attach bags for collecting grease so that grease does not spatter when it comes out of the inlets or outlets.

Grease replacement position	Motion angle	OVR	Operating time	Open points
J1-axis reducer	80° or more	50%	20 minutes	Open the grease inlets, outlets and the ventilator hole and perform continuous operation.
J2-axis reducer	90° or more	50%	20 minutes	
J3-axis reducer	70° or more	50%	20 minutes	
J4/J5/J6-axis gearbox	J4 : 60° or more J5 : 120° or more J6 : 60° or more	100%	20 minutes	
Wrist	J4 : 60° or more J5 : 120° or more J6 : 60° or more	100%	10 minutes	

If the above operations cannot be performed because of workcell constraints, adjust the operating time according to the operating angle. (For example, when only half of the predetermined motion angle can be achieved, perform an operation for a period of time twice as long as the specified time.) If you grease multiple axes, you can exercise multiple axes at the same time. After completion of the operation, attach the seal bolts, taper plugs and grease nipples to the grease inlets, outlets and the ventilator hole immediately. When reusing the seal bolts and grease nipples, be sure to seal them with seal tape.

7.4 STORAGE

When storing the robot, place it on a level surface with the same posture that was used for transportation. (See Section 1.1.)

8 MASTERING

Mastering is a manipulation performed associating the angle of each robot axis with the pulse count value supplied from the absolute Pulsecoder connected to the corresponding axis motor. To be specific, mastering is an operation for obtaining the pulse count value; corresponding to the zero position.



CAUTION

- 1 The motion limits are temporarily invalid during mastering. Cables may be damaged if the J1-axis exceeds $\pm 185^\circ$.
- 2 In case of performing mastering with gravity compensation (option) is enabled, if load setting (See Section 4.3) is not correct, it will influence the precision of the mastering.

8.1 OVERVIEW

The current position of the robot is determined according to the pulse count value supplied from the Pulsecoder on each axis.

Mastering is factory-performed. It is unnecessary to perform mastering in daily operations. However, mastering is required under the following conditions:

- Motor replacement
- Pulsecoder replacement
- Reducer replacement
- Cable replacement
- Batteries for pulse count backup in the mechanical unit have gone dead



CAUTION

Robot data (including mastering data) and Pulsecoder data are backed up by their respective backup batteries. Data will be lost if the batteries are gone dead. Replace the batteries in the controller and mechanical units periodically. Alarm will alert decreasing the battery voltage.

Types of Mastering

There are following mastering methods. If 7DC2 (V8.20P) or former software is installed, "Quick Mastering for Single Axis" has not been supported.

Table 8.1 (a) Type of mastering

Fixture position mastering	Mastering performed with the mastering fixture before shipping.
Zero position mastering (witness mark mastering)	Mastering which performed with all axes set at the 0-degree position. A zero-position mark (witness mark) is attached to each robot axis. This mastering is performed with all axes aligned to their respective witness marks.
Quick mastering	This is performed at a user-specified position. The corresponding count value is obtained from the rotation count of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost. (All axes at the same time)
Quick mastering for single axis	This is performed at a user-specified position for one axis. The corresponding count value is obtained from the rotation count of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost.
Single axis mastering	Mastering which performed for one axis at a time. The mastering position for each axis can be specified by the user. Useful in performing mastering on a specific axis.
Mastering data entry	Enter the Mastering data directly.

Once mastering is performed, you must carry out positioning (calibration). Positioning is an operation in which the controller reads the pulse count value to sense the current position of the robot.

This section describes zero-position mastering, quick mastering, quick mastering for single axis, single-axis mastering, and mastering data entry. For more detailed mastering (fixture position mastering), contact your local FANUC representative.



CAUTION

- 1 If mastering is performed incorrectly, the robot may behave unexpectedly. This is very dangerous. For this reason, the Master/Cal screen is designed to appear only when the \$MASTER_ENB system variable is 1 or 2. After performing positioning, press F5, ([DONE]) on the Master/Cal screen. The \$MASTER_ENB system variable is then reset to 0 automatically, and the Master/Cal screen will disappear.
- 2 Before performing mastering, it is recommended that you back up the current mastering data.

8.2 RESETTING ALARMS AND PREPARING FOR MASTERING

Before performing mastering because a motor has been replaced, it is necessary to release the relevant alarm and display the positioning menu.

Alarm displayed

“SRVO-062 BZAL” or “SRVO-075 Pulse not established”

Procedure

- 1 Display the positioning menu by following the steps 1 to 6.
 - 1 Press the [MENU] key.
 - 2 Press [0 NEXT] and select [6 SYSTEM].
 - 3 Press F1 ([TYPE]), and select [Variable] from the menu.
 - 4 Place the cursor on \$MASTER_ENB, then key in “1” and press the [ENTER] key.
 - 5 Press F1 ([TYPE]), and select [Master/Cal] from the menu.
 - 6 Select the desired mastering type from the [Master/Cal] menu.
- 2 To reset the “SRVO-062 BZAL” alarm, follow steps 1 to 5.
 - 1 Press the [MENU] key.
 - 2 Press [0 NEXT] and select [6 SYSTEM].
 - 3 Press F1 ([TYPE]), and select [Master/Cal] from the menu.
 - 4 Press F3 ([RES_PCA]), then press F4 ([YES]).
 - 5 Cycle power of the controller.
- 3 To reset the “SRVO-075 Pulse not established” alarm, follow the steps 1 to 2.
 - 1 After cycling controller power, the message “SRVO-075 Pulse not established” appears again.
 - 2 Move the axis for which the message mentioned above has appeared in either direction till the alarm disappears when you press the [RESET] key.

8.3 ZERO POSITION MASTERING

Zero position mastering (witness mark mastering) is performed with all axes set at the 0-degree position. A zero-position mark (witness mark) is attached to each robot axis (Fig. 8.3 (a)). This mastering is performed with all axes set at the 0-degree position using their respective witness marks.

Zero position mastering involves a visual check, and might not be highly accurate. It should be used only as a quick-fix method.

Zero-position Mastering Procedure

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE(disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE (for all axes)

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE

After changing the system variables, cycle power of the controller.

(Mastering can be performed without setting of gravity compensation. However, it will affect precision.)

- 5 Press the [MENU] key to display the screen menu.
- 6 Select [0 NEXT] and press [6 SYSTEM].
- 7 Press F1 [TYPE], display the screen change menu.
- 8 Select [Master/Cal]. The positioning screen will be displayed.

```

SYSTEM Master/Cal    AUTO  JOINT 10 %
                    TORQUE = [ON ]

1 FIXTURE POSITION MASTER
2 ZERO POSITION MASTER
3 QUICK MASTER
4 QUICK MASTER FOR SINGLE AXIS
5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE
  Press 'ENTER' or number key to select.

[ TYPE ]  LOAD  RES_PCA          DONE
  
```

- 9 Jog the robot into a posture for mastering.
- 10 Select [2 ZERO POSITION MASTER]. Press F4 [YES].

```

SYSTEM Master/Cal    AUTO  JOINT 10 %
                    TORQUE = [ON ]
1 FIXTURE POSITION MASTER
2 ZERO POSITION MASTER
3 QUICK MASTER
4 QUICK MASTER FOR SINGLE AXIS
5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE
Robot Mastered! Mastering Data:
  <0> <11808249> <38767856>
  <9873638> <12200039> <2000319>
[ TYPE ] LOAD RES_PCA      DONE

```


- 11 Select [7 CALIBRATE] and press F4 [YES]. Mastering will be performed automatically. Alternatively, turn off the controller power and on again.

```

SYSTEM Master/Cal    AUTO  JOINT 10 %
                    TORQUE = [ON ]
1 FIXTURE POSITION MASTER
2 ZERO POSITION MASTER
3 QUICK MASTER
4 QUICK MASTER FOR SINGLE AXIS
5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE
Robot Calibrated! Cur Jnt Ang(deg):
  < 0.0000> < 0.0000> < 0.0000>
  < 0.0000> < 0.0000> < 0.0000>

```

- 12 After positioning is completed, press F5 [DONE].



- 13 Return the setting of the gravity compensation.
- 14 Return brake control to the original setting, and cycle power of the controller.

Table 8.3 (a) Posture with position marks (witness mark) aligned

Axis	Position
J1-axis	0 deg
J2-axis	0 deg
J3-axis	0 deg
J4-axis	0 deg
J5-axis	0 deg
J6-axis	0 deg




Fig. 8.3 (a) Zero-position mark (witness mark) for each axis

8.4 QUICK MASTERING

Quick mastering is performed at a user-specified position for one axis. The pulse count value is obtained from the rotation times of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the character that the absolute value of a rotation angle within one rotation will not be lost.

Quick mastering is factory-performed at the position indicated in Table 8.3 (a). If possible, do not change the setting.

If setting the robot at the position mentioned above is impossible, you must re-set the quick mastering reference position using the following method. (It would be convenient to set up a marker that can work in place of the witness mark.)



CAUTION

- 1 Quick mastering can be used, if the pulse count value is lost, for example, because a low voltage has been detected on the backup battery for the pulse counter.
- 2 Quick mastering cannot be used, after the Pulsecoder is replaced or after the mastering data is lost from the robot controller.

Procedure Recording the Quick Mastering Reference Position

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE(disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE (for all axes)

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE

After changing the system variables, cycle power of the controller.

(Mastering can be performed without setting of gravity compensation. However, it will affect precision.)

- 5 Select [6 SYSTEM].
- 6 Select [Master/Cal]. The positioning screen will be displayed.

SYSTEM Master/Cal	AUTO	JOINT 10 %
TORQUE = [ON]		
1 FIXTURE POSITION MASTER		
2 ZERO POSITION MASTER		
3 QUICK MASTER		
4 QUICK MASTER FOR SINGLE AXIS		
5 SINGLE AXIS MASTER		
6 SET QUICK MASTER REF		
7 CALIBRATE		
Press 'ENTER' or number key to select.		
[TYPE]	LOAD	RES_PCA
		DONE

- 7 Jog the robot to the quick mastering reference position.
- 8 Select [6 SET QUICK MASTER REF] and press F4 [YES]. Quick mastering reference position is saved.

5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE

[TYPE]	YES	NO
----------	-----	----

F4

- 9 Return the setting of the gravity compensation.
- 10 Return brake control to the original setting, and cycle power of the controller.

**CAUTION**

If the robot has lost mastering data due to mechanical disassembly or repair, you cannot perform this procedure. In this case, perform Fixture position mastering or Zero position mastering to restore mastering data.

Procedure of Quick Mastering

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE(disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE (for all axes)

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE

After changing the system variables, cycle power of the controller.

(Mastering can be performed without setting of gravity compensation. However, it will affect precision.)

- 5 Display the Master/Cal screen.

SYSTEM Master/Cal	AUTO	JOINT 10 %
TORQUE = [ON]		
1 FIXTURE POSITION MASTER		
2 ZERO POSITION MASTER		
3 QUICK MASTER		
4 QUICK MASTER FOR SINGLE AXIS		
5 SINGLE AXIS MASTER		
6 SET QUICK MASTER REF		
7 CALIBRATE		
Robot Not Mastered!		
Quick master? [NO]		

- 6 Jog the robot to the quick mastering reference position.
 7 Move the cursor to [3 QUICK MASTER] and press [ENTER]. Press F4 [YES]. Quick mastering data is saved.

2 ZERO POSITION MASTER
3 QUICK MASTER
4 QUICK MASTER FOR SINGLE AXIS

F4

- 8 Select [7 CALIBRATE] and press [ENTER] key. Calibration is executed. Calibration is executed by cycling power.
 9 After completing the calibration, press F5 Done.

DONE

F5

- 10 Return the setting of the gravity compensation.
 11 Return brake control to the original setting, and cycle power of the controller.

8.5 QUICK MASTERING FOR SINGLE AXIS

Quick mastering is performed at a user-specified position for one axis. The pulse count value is obtained from the rotation times of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the character that the absolute value of a rotation angle within one rotation will not be lost.

Quick mastering is factory-performed at the position indicated in Table 8.3 (a). Do not change the setting unless there is any problem.

If setting the robot at the position mentioned above is impossible, you must re-set the quick mastering reference position using the following method. (It would be convenient to set up a marker that can work in place of the witness mark.)



CAUTION

- 1 Quick mastering can be used, if the pulse count value is lost, for example, because a low voltage has been detected on the backup battery for the pulse counter.
- 2 Quick mastering cannot be used, after the Pulsecoder is replaced or after the mastering data is lost from the robot controller.

Procedure Recording the Quick Mastering Reference Position

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE(disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE (for all axes)

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE

After changing the system variables, cycle power of the controller.

(Mastering can be performed without setting of gravity compensation. However, it will affect precision.)

- 5 Select [6 SYSTEM].
- 6 Select [Master/Cal]. The positioning screen will be displayed.

SYSTEM Master/Cal	AUTO	JOINT 10 %
TORQUE = [ON]		
1 FIXTURE POSITION MASTER		
2 ZERO POSITION MASTER		
3 QUICK MASTER		
4 QUICK MASTER FOR SINGLE AXIS		
5 SINGLE AXIS MASTER		
6 SET QUICK MASTER REF		
7 CALIBRATE		
Press 'ENTER' or number key to select.		
[TYPE]	LOAD	RES_PCA
		DONE

- 7 Jog the robot to the quick mastering reference position.
- 8 Select [6 SET QUICK MASTER REF] and press F4 [YES]. Quick mastering reference position is saved.

5 SINGLE AXIS MASTER
6 SET QUICK MASTER REF
7 CALIBRATE

[TYPE]	YES	NO
----------	-----	----

F4

- 9 Return the setting of the gravity compensation.
- 10 Return brake control to the original setting, and cycle power of the controller.

**CAUTION**

If the robot has lost mastering data due to mechanical disassembly or repair, you cannot perform this procedure. In this case, perform Fixture position mastering or Zero position mastering to restore mastering data.

Procedure of Quick Mastering for single axis

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE(disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE (for all axes)

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE

After changing the system variables, cycle power of the controller.

(Mastering can be performed without setting of gravity compensation. However, it will affect precision.)

- 5 Display the Master/Cal screen.

SYSTEM Master/Cal		AUTO	JOINT 10 %
TORQUE = [ON]			
1 FIXTURE POSITION MASTER			
2 ZERO POSITION MASTER			
3 QUICK MASTER			
4 QUICK MASTER FOR SINGLE AXIS			
5 SINGLE AXIS MASTER			
6 SET QUICK MASTER REF			
7 CALIBRATE			
Press 'ENTER' or number key to select.			
[TYPE]	LOAD	RES_PCA	DONE

- 6 Select [4 QUICK MASTER FOR SINGLE AXIS]. You will see the quick master for single axis screen.

AUTO JOINT 1%					
QUICK MASTER FOR SINGLE AXIS					
	ACTUAL	POS	(MSTR POS)	(SEL)	1/9 [ST]
J1	0.000	(0.000)	(0)	[2]
J2	0.000	(0.000)	(0)	[2]
J3	0.000	(0.000)	(0)	[2]
J4	0.000	(0.000)	(0)	[2]
J5	0.000	(0.000)	(0)	[2]
J6	0.000	(0.000)	(0)	[0]
E1	0.000	(0.000)	(0)	[0]
E2	0.000	(0.000)	(0)	[0]
E3	0.000	(0.000)	(0)	[0]
EXEC					

- 7 Move the cursor to the (SEL) column for the unmastered axis and press the numeric key [1]. Setting of (SEL) is available for one or more axes.

AUTO JOINT 1%					
QUICK MASTER FOR SINGLE AXIS					
	ACTUAL	POS	(MSTR POS)	(SEL)	1/9 [ST]
J5	0.000	(0.000)	(1)	[2]
J6	0.000	(0.000)	(1)	[2]
EXEC					

- 8 Jog the robot to the quick mastering reference position.
 9 Press F5 [EXEC]. Mastering is performed. So, (SEL) is reset to 0, and [ST] is re-set to 2.
 10 Select [7 CALIBRATE] and press F4 [YES]. Calibration is executed. Calibration is executed by cycling power.
 11 After completing the calibration, press F5 [DONE].

DONE
F5

- 12 Return the setting of the gravity compensation.
 13 Return brake control to the original setting, and cycle power of the controller.

8.6 SINGLE AXIS MASTERING

Single axis mastering is performed for one axis at a time. The mastering position for each axis can be specified by the user.

Single axis mastering can be used, if mastering data for a specific axis is lost, for example, because a low voltage has been detected on the pulse counter backup battery or because the Pulsecoder has been replaced.

SINGLE AXIS MASTER		AUTO		JOINT 10%	
	ACTUAL POS	(MSTR POS)	(SEL)	[ST]	1/9
J1	0.000	(0.000)	(0)	[2]	
J2	0.000	(0.000)	(0)	[2]	
J3	0.000	(0.000)	(0)	[2]	
J4	0.000	(0.000)	(0)	[2]	
J5	0.000	(0.000)	(0)	[2]	
J6	0.000	(0.000)	(0)	[0]	
E1	0.000	(0.000)	(0)	[0]	
E2	0.000	(0.000)	(0)	[0]	
E3	0.000	(0.000)	(0)	[0]	
EXEC					

Table 8.6 (a) Items set in single axis mastering

Item	Description
Current position (ACTUAL AXIS)	The current position of the robot is displayed for each axis in degree units.
Mastering position (MSTR POS)	A mastering position is specified for an axis to be subjected to single axis mastering. It would be convenient if it is set to 0 degree position.
SEL	This item is set to 1 for an axis to be subjected to single axis mastering. Usually, it is 0.
ST	This item indicates whether single axis mastering has been completed for the corresponding axis. It cannot be changed directly by the user. The value of the item is reflected in \$EACHMST_DON (1 to 9). 0 : Mastering data has been lost. Single axis mastering is necessary. 1 : Mastering data has been lost. (Mastering has been performed only for the other interactive axes.) Single axis mastering is necessary. 2 : Mastering has been completed.

Single axis mastering for interaction axis

When single axis mastering is done in interaction axis, the axis of the interaction pair is also influenced. Therefore, mastering of these interaction axes must be done at the same time. Interaction axis depends on the robot model. Following table shows the relation between robot model and interaction axis. For example, the J4 motor is replaced, mastering of J5 and J6 should be done at the same time with J4. (Provided that if 7DC2 (V8.20P)/14 or later software version is installed, axis numbers which should be selected to do single axis mastering at the same time are displayed if these are not selected. In this case, it is unnecessary to refer to a following table.)

Table 8.6 (b) Relation between robot model and interaction axis

Robot model		Interaction axis
M-900iB	/360	• J4/J5/J6

Procedure of Single axis mastering

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE]. Then select [Variables] from the menu.
- 4 If \$DMR_GRP [group].\$GRAV_MAST=1, set the gravity compensation to enabled, if it is 0, set the gravity compensation to disabled. In addition release the brake control.

NOTE

Gravity compensation can be set to enabled/disabled by setting the system variables as follows:

\$PARAM_GROUP[group].\$SV_DMY_LNK[8] : FALSE(disabled) or TRUE (enabled)

Brake control can be released by setting the system variables as follows:

\$PARAM_GROUP.SV_OFF_ALL : FALSE (for all axes)

\$PARAM_GROUP.SV_OFF_ENB[*] : FALSE

After changing the system variables, cycle power of the controller.

(Mastering can be performed without setting of gravity compensation. However, it will affect precision.)

- 5 Select [6 SYSTEM].
- 6 Select [Master/Cal]. The positioning screen will be displayed.

SYSTEM Master/Cal		AUTO	JOINT 10 %
TORQUE = [ON]			
1 FIXTURE POSITION MASTER			
2 ZERO POSITION MASTER			
3 QUICK MASTER			
4 QUICK MASTER FOR SINGLE AXIS			
5 SINGLE AXIS MASTER			
6 SET QUICK MASTER REF			
7 CALIBRATE			
Press 'ENTER' or number key to select.			
[TYPE]	LOAD	RES_PCA	DONE

- 7 Select [5 SINGLE AXIS MASTER]. The following screen will be displayed.

SINGLE AXIS MASTER		AUTO	JOINT 10%
			1/9
ACTUAL	POS	(MSTR POS)	(SEL) [ST]
J1	0.000	(0.000)	(0) [2]
J2	0.000	(0.000)	(0) [2]
J3	0.000	(0.000)	(0) [2]
J4	0.000	(0.000)	(0) [2]
J5	0.000	(0.000)	(0) [2]
J6	0.000	(0.000)	(0) [0]
E1	0.000	(0.000)	(0) [0]
E2	0.000	(0.000)	(0) [0]
E3	0.000	(0.000)	(0) [0]
EXEC			

- 8 Move the cursor to the [SEL] column for the unmastered axis and press the numeric key [1]. Setting of [SEL] is available for one or more axes.
- 9 Turn off brake control, then jog the robot to the mastering position.
- 10 Enter axis data for the mastering position.


- 11 Press F5 [EXEC]. Mastering is performed. So, [SEL] is reset to 0, and [ST] is re-set to 2 or 1.

SINGLE AXIS MASTER			AUTO	JOINT 10%
	ACTUAL POS	(MSTR POS)	(SEL)	[ST]
J1	0.000	(0.000)	(0)	[2]
J2	0.000	(0.000)	(0)	[2]
J3	0.000	(0.000)	(0)	[2]
J4	0.000	(0.000)	(0)	[2]
J5	0.000	(0.000)	(0)	[2]
J6	90.000	(0.000)	(1)	[0]
E1	0.000	(0.000)	(0)	[0]
E2	0.000	(0.000)	(0)	[0]
E3	0.000	(0.000)	(0)	[0]
EXEC				

- 12 When single axis mastering is completed, press the [PREV] key to resume the previous screen.

SYSTEM Master/Cal	AUTO	JOINT 10 %
TORQUE = [ON]		
1 FIXTURE POSITION MASTER		
2 ZERO POSITION MASTER		
3 QUICK MASTER		
4 QUICK MASTER FOR SINGLE AXIS		
5 SINGLE AXIS MASTER		
6 SET QUICK MASTER REF		
7 CALIBRATE		
Press 'ENTER' or number key to select.		
[TYPE]	LOAD	RES_PCA
DONE		

- 13 Select [7 CALIBRATE], then press F4 [YES]. Positioning is performed. Alternatively, turn off the controller power and on again. Positioning is performed.
- 14 After positioning is completed, press F5 [DONE].



- 15 Return the setting of the gravity compensation.
- 16 Return brake control to the original setting, and cycle power of the controller.

8.7 MASTERING DATA ENTRY

This function enables mastering data values to be assigned directly to a system variable. It can be used if mastering data has been lost but the pulse count is preserved.

Mastering data entry method

- 1 Press the [MENU] key, then press [0 NEXT] and select [6 SYSTEM].
- 2 Press F1 [TYPE]. Select [Variables]. The system variable screen appears.

SYSTEM Variables		AUTO	JOINT 10%
			1/669
1	\$AAVM_GRP	AAVM_GRP_T	
2	\$AAVM_WRK	AAVM_WRK_T	
3	\$ABSPOS_GRP	ABSPOS_GRP_T	
4	\$ACC_MAXLMT	0	
5	\$ACC_MINLMT	0	
6	\$ACC_PRE_EXE	0	
[TYPE]		DETAIL	

- 3 Change the mastering data. The mastering data is saved to the \$DMR_GRP.\$MASTER_COUN system variable.

SYSTEM Variables		AUTO	JOINT 10%
			1/669
135	\$DMR_GRP	DMR_GRP_T	
136	\$DMSW_CFG	DMSW_CFG_T	
[TYPE]			

- 4 Select \$DMR_GRP.

SYSTEM Variables		AUTO	JOINT 10%
\$DMR_GRP			1/1
1	[1]	DMR_GRP_T	
[TYPE]		DETAIL	

SYSTEM Variables		AUTO	JOINT 10%
\$DMR_GRP			1/29
1	\$MASTER_DONE	FALSE	
2	\$OT_MINUS	[9] of BOOLEAN	
3	\$OT_PLUS	[9] of BOOLEAN	
4	\$MASTER_COUN	[9] of INTEGER	
5	\$REF_DONE	FALSE	
6	\$REF_POS	[9] of REAL	
[TYPE]		TRUE	FALSE


- 5 Select \$MASTER_COUN, and enter the mastering data you have recorded.

SYSTEM Variables		AUTO	JOINT 10%
\$DMR_GRP[1].\$MASTER_COUN			1/9
1	[1]	95678329	
2	[2]	10223045	
3	[3]	3020442	
4	[4]	30405503	
5	[5]	20497709	
6	[6]	2039490	
7	[7]	0	
8	[8]	0	
9	[9]	0	
[TYPE]			

- 6 Press the [PREV] key.
 7 Set \$MASTER_DONE to TRUE.

SYSTEM Variables		AUTO	JOINT 10%
\$DMR_GRP			1/29
1	\$MASTER_DONE	TRUE	
2	\$OT_MINUS	[9] of BOOLEAN	
[TYPE]		TRUE	FALSE

- 8 Display the positioning screen, and select [7 CALIBRATE], then press F4 [YES].
 9 After completing positioning, press F5 [DONE].



8.8 VERIFYING MASTERING

- 1 How to verify that the robot is mastered properly:
Usually, positioning is performed automatically when the power is turned on. To check whether mastering has been performed correctly, examine if the current displayed position matches the actual robot position by using one or more of the procedures described below:
 - (1) Reproduce a particular point in a program. Check whether the point agrees with the specified position.
 - (2) Set all axes of the robot to their 0-degree (0 rad) positions. Check that the zero-degree position marks indicated in Section 8.3 of the OPERATOR'S MANUAL are aligned. There is no need to use a visual aid.
If the displayed and actual positions do not match, the counter value for a Pulsecoder may have been invalidated as a result of an alarm described in 2 in this Section. Alternatively, the mastering data in system variable \$DMR_GRP.\$MASTER_COUN may have been overwritten as a result of an operation error or some other reason.
Compare the data with the values indicated on the supplied data sheet. This system variable is overwritten whenever mastering is performed. Whenever mastering is performed, record the value of the system variable on the data sheet.
- 2 Alarm types displayed during mastering and their solution method:
 - (1) BZAL alarm
This alarm is displayed if the Pulsecoder's backup battery voltage decreases to 0 V while the power to the controller is disconnected. Furthermore, if the Pulsecoder connector is removed for cable replacement, etc. this alarm is displayed as the voltage decreases to 0. Check to see if the alarm will disappear by performing a pulse reset (See Section 8.2.). Then, cycle controller power and check if the alarm disappears or not.
The battery may be drained if the alarm is still displayed. Perform a pulse reset, and turn off and on the controller power after replacing the battery. Note that, if this alarm is displayed, all the original data held by the Pulsecoder will be lost. Mastering is required.
 - (2) BLAL alarm
This alarm is displayed if the voltage of the Pulsecoder's backup battery has fallen to a level where backup is no longer possible. If this alarm is displayed, replace the battery with a new one immediately while keeping the power turned on. Check whether the current position data is valid, using the procedure described in 1 in this Section.
 - (3) Alarm notification like CKAL, RCAL, PHAL, CSAL, DTERR, CRCERR, STBERR, and SPHAL may have trouble with Pulsecoder, contact your local FANUC representative.

9 TROUBLESHOOTING

The cause of a failure in the mechanical unit may be difficult to localize, because failures can arise from many interrelated factors. If you fail to take the correct measures, the failure may be aggravated. So, it is necessary to analyze the symptoms of the failure precisely so that the true cause can be found.

9.1 TROUBLESHOOTING

Table 9.1 (a) shows the major troubleshooting symptoms that may occur in the mechanical unit and their probable causes. If you cannot pinpoint a failure cause or which measures to take, contact your local FANUC representative. For troubleshooting except the mechanical unit, refer to “CONTROLLER MAINTENANCE MANUAL (B-83195EN etc.)” and Alarm Code List (B-83284EN-1).

Table 9.1 (a) Troubleshooting

Symptoms	Descriptions	Causes	Measures
Vibration Noise	<ul style="list-style-type: none"> - As the robot operates, its base plate lifts off the floor plate. - There is a gap between the base plate and the floor plate. - There is a crack in the weld that fastens the base plate to the floor plate. 	<p>[Base plate and floor plate fastening]</p> <ul style="list-style-type: none"> - It is likely that the base plate is not securely fastened to the floor plate because of poor welding. - If the base plate is not securely fastened to the floor plate, it lifts as the robot operates, allowing the base and floor plates to strike each other which, in turn, leads to vibration. 	<ul style="list-style-type: none"> - Re-weld the base plate to the floor plate. - If the weld is not strong enough, increase its width and length.
	<ul style="list-style-type: none"> - The J1 base lifts off the floor plate as the robot operates. - There is a gap between the J1 base and floor plate. - The J1 base retaining bolt is loose. 	<p>[J1 base fastening]</p> <ul style="list-style-type: none"> - It is likely that the robot J1 base is not securely fastened to the floor plate. - Probable causes are a loose bolt, an insufficient degree of surface flatness, or contamination caught between the J1 base plate and floor plate. - If the robot is not securely fastened to the floor plate, the J1 base lifts the floor plate as the robot operates, allowing the base and floor plates to strike each other. That, in turn, leads to vibration. 	<ul style="list-style-type: none"> - If a bolt is loose, apply LOCTITE and tighten it to the appropriate torque. - Adjust the base plate surface flatness to within the specified tolerance. - If there is any contamination between the J1 base and base plate, eliminate them. - Apply adhesive between the J1 base and base plate.

Symptoms	Descriptions	Causes	Measures
Vibration Noise (Continued)	- The rack or floor plate vibrates during operation of the robot.	[Rack or floor] - It is likely that the rack or floor is not rigid enough. - If they are not rigid enough, counterforce can deform the rack or floor, and cause vibration.	- Reinforce the rack or floor to make it more rigid. - If reinforcing the rack or floor is impossible, modify the robot control program; doing so might reduce the vibration.
	- Vibration becomes more serious when the robot is in a specific posture. - If the operating speed of the robot is reduced, vibration stops. - Vibration is most noticeable when the robot is accelerating. - Vibration occurs when two or more axes operate at the same time.	[Overload] - It is likely that the load on the robot is heavier than the maximum rating. - It is likely that the robot control program is too demanding for the robot hardware. - It is likely that the ACCELERATION value is excessive.	- Check the maximum load that the robot can handle or not. If the robot is overloaded, reduce the load, or modify the robot control program. - Vibration can be reduced by re-modifying the robot control program; reducing speed or acceleration with minimizing the influence on the entire cycle time.
	- Vibration or noise was first noticed after the robot collided with an object or the robot was overloaded for a long period. - The grease of the vibrating or noise occurring axis has not been exchanged for a long period. - Cyclical vibration and noise occur.	[Gear, bearing, or reducer] - It is likely that collision or overload applied an excessive force on the drive mechanism, thus damaging the gear tooth surface or rolling surface of a bearing, or reducer. - Prolonged use with overloaded may cause the fretting fatigue on gear tooth surface or rolling surface of bearing and reducer. - It is likely that contamination caught in a gear, bearing, or within a reducer has caused damage on the gear tooth surface or rolling surface of the bearing, or reducer. - It is likely that contamination caught in a gear, bearing, or within a reducer is causing vibration. - It is likely that, because the grease has not been changed for a long period, fretting occurred on the gear tooth surface or rolling surface of a bearing, or reducer due to metal fatigue by neglect greasing.	- Operate each axis at individually to judge which axis has been vibrating. - Remove the motor, and replace the gear, the bearing, and the reducer. For the specification of parts and the procedure of replacement, contact your local FANUC representative. - Using the robot within its maximum rating prevents problems with the drive mechanism. - Regularly greasing with the specified grease can help prevent problems.

Symptoms	Descriptions	Causes	Measures
Vibration Noise (Continued)	<ul style="list-style-type: none"> - The cause of problem cannot be identified from examination of the floor, rack, or mechanical unit. 	<p>[Controller, cable, and motor]</p> <ul style="list-style-type: none"> - If a failure occurs in a controller circuit, preventing control commands from being supplied to the motor normally, or preventing motor information from being sent to the controller normally, vibration might occur. - Pulsecoder defect may be the cause of the vibration as the motor cannot propagate the accurate position to the controller. - If the motor becomes defective, vibration might occur because the motor cannot deliver its rated performance. - If a power line in a movable cable of the mechanical unit has an intermittent break, vibration might occur because the motor cannot accurately respond to commands. - If a Pulsecoder wire in a movable part of the mechanical unit has an intermittent break, vibration might occur because commands cannot be sent to the motor accurately. - If a robot connection cable has an intermittent break, vibration might occur. - If the power supply cable is about to be snapped, vibration might occur. - If the power source voltage drops below the rating, vibration might occur. - It may vibrate when an invalid value parameter was set. 	<ul style="list-style-type: none"> - Refer to the Controller Maintenance Manual for troubleshooting related to the controller and amplifier. - Replace the motor of the axis that is vibrating, and check whether vibration still occurs. For the method of replacement, contact your local FANUC representative. - If vibration occurs only when the robot assumes a specific posture, it is likely that a cable in the mechanical unit is broken. - Shake the movable part cable while the robot is at rest, and check whether an alarm occurs. If an alarm or any other abnormal condition occurs, replace the mechanical unit cable. - Check whether the cable jacket of the robot connection cable is damaged. If so, replace the connection cable, and check whether vibration still occurs. - Check whether the power cable jacket is damaged. If so, replace the power cable, and check whether vibration still occurs. - Check that the robot is supplied with the rated voltage. - Check that the robot control parameter is set to a valid value. If it is set to an invalid value, correct it. Contact your local FANUC representative for further information if necessary.

Symptoms	Descriptions	Causes	Measures
Vibration Noise (Continued)	- There is some relationship between the vibration of the robot and the operation of a machine near the robot.	[Noise from Peripheral] - If the robot is not grounded properly, electrical noise can be induced on the grounding wire, preventing commands from being transferred accurately, thus leading to vibration. - If the robot is grounded at an unsuitable point, its grounding potential becomes unstable, and noise is likely to be induced on the grounding line, thus will lead to vibrate.	- Connect the grounding wire firmly to ensure a reliable ground potential thereby preventing extraneous electrical noise.
	- There is an unusual sound after replacement of grease. - There is an unusual sound after a long period of time. - There is an unusual sound during operation at low speed.	- There may be an abnormal noise when using other than the specified grease. - Even for the specified grease, there may be an abnormal noise during operation at low speed immediately after replacement or after a long time.	- Use the specified grease. - When there is an abnormal noise even when using the specified grease, operate for one or two days as an experiment. Generally, the abnormal noise will disappear.
Rattling	- While the robot is not supplied with power, pushing it with the hand causes tottering part of the mechanical unit. - There is a gap on the mounting face of the mechanical unit.	[Mechanical unit coupling bolt] - It is likely that overloading or a collision has loosened a mounting bolt in the robot mechanical unit.	- Check the following retaining bolts tightness for each axis. If any of these bolts is loose, apply LOCTITE and bolt down with appropriate torque. - Motor - Reducer - Reducer shaft - Base - Arm - End effector

Symptoms	Descriptions	Causes	Measures
Motor overheating	<ul style="list-style-type: none"> - The motor overheated due to the temperature in the installation area rose. - After a cover was attached to the motor, the motor overheated. - After changing the Robot control program or the load, the motor overheat. 	<p>[Ambient temperature]</p> <ul style="list-style-type: none"> - It is likely that the motor overheated along with the ambient temperature rose, and could not dissipate the heat. <p>[Operating condition]</p> <ul style="list-style-type: none"> - It is likely that the overcurrent above the specified permissive average current. 	<ul style="list-style-type: none"> - Reducing the ambient temperature is the most effective means of preventing overheat. - Having the surroundings of the motor well ventilated enables the motor to release heat efficiently, thus preventing overheating. - If there is a source of heat near the motor, it is advisable to install shielding to protect the motor from heat radiation. - Relaxing the robot control program and load condition is effective to reduce the average current. Thus, prevent overheating. - The teach pendant can monitor the average current. Check the average current when the robot control program launched.
	<ul style="list-style-type: none"> - After a control parameter (load setting etc.) was changed, the motor overheated. 	<p>[Parameter]</p> <ul style="list-style-type: none"> - If data input for a workpiece is invalid, the robot cannot be accelerated or decelerated normally, so the average current increases, leading to overheating. 	<ul style="list-style-type: none"> - As for load setting, Input an appropriate parameter referring to Section 4.3.
	<ul style="list-style-type: none"> - Symptom other than stated above 	<p>[Mechanical unit problems]</p> <ul style="list-style-type: none"> - It is likely that problems occurred in the mechanical unit drive mechanism, thus placing an excessive load on the motor. <p>[Motor problems]</p> <ul style="list-style-type: none"> - It is likely that a failure of the motor brake resulted in the motor operating with the brake applied, thus placing an excessive load on the motor. - It is likely that a failure of the motor prevented it from delivering its rated performance, thus causing an excessive current to flow through the motor. - It is likely that cooling fan is broken. 	<ul style="list-style-type: none"> - Repair the mechanical unit while referring to the above descriptions of vibration, noise, and rattling. - Check that, when the servo system is energized, the brake is released. If the brake remains applied to the motor all the time, replace the motor. - If the average current falls after the motor is replaced, it indicates that the first motor was faulty. - If the fan is broken, replace it by new one.

Symptoms	Descriptions	Causes	Measures
Grease leakage	<ul style="list-style-type: none"> - Grease leaks from the mechanical unit. 	<p>[Poor sealing]</p> <ul style="list-style-type: none"> - Probable causes are a crack in the casting, a broken O-ring, a damaged oil seal, or a loose seal bolt. - The casting may crack with excessive force caused in collision. - An O-ring can be damaged if it is trapped or cut during disassembling or re-assembling. - An oil seal may be damaged if extraneous dust scratches the lip of the oil seal. - A loose seal bolt may allow grease to leak along the threads. - Problems with the grease nipple or threads. 	<ul style="list-style-type: none"> - If the casting cracks, sealant can be used as a quick-fix to prevent further grease leakage. However, the component must be replaced as soon as possible, as the crack will widen. - O-rings are used in the locations listed below. <ul style="list-style-type: none"> - Motor coupling section - Reducer (case and shaft) coupling section - Wrist coupling section - J3 arm coupling section - Inside the wrist - Oil seals are used in the locations stated below. <ul style="list-style-type: none"> - Inside the reducer - Inside the wrist - Seal bolts are used in the locations stated below. <ul style="list-style-type: none"> - Grease drain outlet - Replace the grease nipple.
Dropping axis	<ul style="list-style-type: none"> - An axis falls because the brake went out. - An axis falls in standstill. 	<p>[Brake drive relay and motor]</p> <ul style="list-style-type: none"> - It is likely that brake drive relay contacts are stuck to each other and keep the brake current flowing, thus preventing the brake from operating when the motor is reenergized. - It is likely that the brake shoe has worn out or the brake main body is damaged, preventing the brake from operating efficiently. - It is likely that oil or grease soak through the motor, causing the brake to slip. 	<ul style="list-style-type: none"> - Check whether the brake drive relay contacts stuck each other or not. If they are found to be stuck, replace the relay. - Replace the motor confirmed following symptoms. <ul style="list-style-type: none"> - Brake shoe is worn out - Brake main body is damaged - Oil soak through the motor

Symptoms	Descriptions	Causes	Measures
Displacement	<ul style="list-style-type: none"> - The robot operates at a point other than the taught position. - The repeatability is not within the tolerance. 	<p>[Mechanical unit problems]</p> <ul style="list-style-type: none"> - If the repeatability is unstable, probable causes are a failure in the drive mechanism or a loose bolt, and so on. - If the repeatability is stable, it is likely that collision by an excessive load caused slip on the fastening surface of each axis arm, and reducer. - It is likely that the Pulsecoder is abnormal. 	<ul style="list-style-type: none"> - If the repeatability is unstable, repair the mechanical unit by referring to the above descriptions of vibration, noise, and rattling. - If the repeatability is stable, correct the taught program. Variation will not occur unless another collision occurs. - If the Pulsecoder is abnormal, replace the motor or the Pulsecoder.
	<ul style="list-style-type: none"> - Displacement occurs only in a specific peripheral unit. 	<p>[Peripheral unit displacement]</p> <ul style="list-style-type: none"> - It is likely that an external force was applied to the peripheral unit, thus shifting its position relative to the robot. 	<ul style="list-style-type: none"> - Correct the setting of the peripheral unit position. - Correct the taught program.
	<ul style="list-style-type: none"> - Displacement occurred after a parameter was changed. 	<p>[Parameter]</p> <ul style="list-style-type: none"> - It is likely that the mastering data was overwritten, and the origin had misaligned. 	<ul style="list-style-type: none"> - Re-enter the previous optimal mastering data. - If optimal mastering data is unavailable, perform mastering again.
CLALM alarm occurred. Move error excess alarm occurred.	<ul style="list-style-type: none"> - Ambient temperature of the robot installation location is low, CLALM alarm is displayed on the teach pendant screen. - Ambient temperature of the robot installation position is low, "Move error excess" alarm is displayed on the teach pendant screen. 	<p>[Peripheral temperature]</p> <ul style="list-style-type: none"> - When the robot is used in a low temperature environment that is near to 0°C, or the robot is not operated for a long time in an environment that is less than 0°C, there will be a large viscous resistance of the drive train immediately after starting which will cause the alarm. 	<ul style="list-style-type: none"> - Perform a warm up operation or a low speed operation for several minutes.
	<ul style="list-style-type: none"> - After changing the motion program or the load condition, the CLALM alarm is displayed. - After changing the motion program or the load condition, the "Move error excess" alarm is displayed. 	<ul style="list-style-type: none"> - It is likely that a robot collision occurred. 	<ul style="list-style-type: none"> - If a robot collision has occurred, press the [RESET] key while pressing the [SHIFT] key. Then, jog the robot in the opposite direction while pressing the [SHIFT] key. - Check the motion program.
		<p>[Overload]</p> <ul style="list-style-type: none"> - It is likely that load exceeded the permissible value. - It is likely that the motion program is too severe for the robot. <ul style="list-style-type: none"> · Excessive motion due to a large "ACC (value)". · Tight motion such as reverse motion using "CNT". · Linear motion occurs near singularity point where axes revolve in high speed. 	<ul style="list-style-type: none"> - Check the permissible value of the robot payload. If the load exceeds the permissible value, reduce the load or change the motion program. - Consider minimizing the influence on cycle time by reducing the speed or acceleration, and changing the motion program. - Check that the load setting is performed correctly.

Symptoms	Descriptions	Causes	Measures
CLALM alarm occurred. Move error excess alarm occurred.	- None of the symptoms stated above are the problem.	- It is likely the vibration occurred.	- Refer to the Symptoms: Vibration, Noise section of this troubleshooting for more information.
		- It is likely that rated voltage is not supplied due to the voltage drop.	- Check that the robot is supplied with the proper rated voltage.
		- Angle of robot mounting surface is not set correctly.	- According to "Angle of Mounting Surface Setting", set the angle of robot mounting surface correctly.
BZAL alarm displayed	- BZAL is displayed on the teach pendant screen.	<ul style="list-style-type: none"> - The voltage of the memory backup battery may be low. - The Pulsecoder cable may be broken. 	<ul style="list-style-type: none"> - Replace the battery. - Replace the cable.

10 SEVERE DUST/LIQUID PROTECTION PACKAGE

10.1 SEVERE DUST/LIQUID PROTECTION PACKAGE(OPTION)

The package is intended to improve the severe dust/liquid protection characteristics of the robot so that it can be used in a harsh environment.

Refer to Section 3.1 about dustproof and waterproof characteristics of the M-900iB.

NOTE

Contact your FANUC representative for confirmation that the Severe Dust/liquid protection package is suitable for your environment.

Model	Severe dust/liquid protection package specification
M-900iB/360/360E	A05B-1335-J801
M-900iB/280L	A05B-1335-J802
M-900iB/280	A05B-1335-J803
M-900iB/330L	A05B-1335-J804

10.2 CONFIGURATION OF THE SEVERE DUST/LIQUID PROTECTION PACKAGE

The following table lists shows the major differences between the M-900iB standard specification and severe dust/liquid protection package.

	Standard specifications	Severe dust/liquid protection option	
	Entire mechanical unit	Main unit	J3 arm and wrist
Bolts	Black oxide finish steel bolt Black oxide finish washer	FR coating bolt Black chromate washer Stainless steel bolt Black oxide finish steel bolt	FR coating bolt Stainless steel bolt Black chromate washer
Covers		J1-axis motor cover J2-axis motor cover J3-axis motor cover J4/J5/J6-axis motor cover (upper side/Lower side) Battery box cover Cable cover in mechanical unit (for all exposed cables)	
J3 connector panel EE(RI/RO) connector	Non-waterproof connector	Waterproof connector	




Fig. 10.2 (a) Configuration of the severe dust/liquid protection package

11 PRESS HANDLING PACKAGE (OPTION)

The press handling package improves heat radiation performance by installing cooling fans to the J1/J2/J3-axis motors or J2/J3-axis motors to prevent motor overheat under high temperature environment.

NOTE

- 1 Contact your FANUC representative for confirmation that the press handling package is suitable for your environment.
- 2 When overheat occurs, see troubleshooting chapter and consider countermeasures.

Model	Axis	Press handling package spec.
M-900iB/360/360E/280L/280	For J1/J2/J3-axis	A05B-1335-J821
	For J2/J3-axis	A05B-1335-J822

NOTE

In addition, the fan connection cable which length is same as the robot connection cable is required.




Fig. 11 (a) Configuration of the press handling package

APPENDIX


A

PERIODIC MAINTENANCE TABLE

FANUC Robot M-900iB/360/360E/280L/280/330L

Periodic Maintenance Table

Items		Accumulated operating time (H)	Check time	Grease amount	First check 320	3 months 960	6 months 1920	9 months 2880	1 year 3840	4800	5760	6720	2 years 7680	8640	9600	10560
Mechanical unit	1	Check for external damage or peeling paint	0.1H	—		○	○	○	○	○	○	○	○	○	○	○
	2	Check damages of the cable protective sleeves	0.1H	—		○	○	○	○	○	○	○	○	○	○	○
	3	Check wear debris of J1-axis swing stopper	0.1H	—		○	○	○	○	○	○	○	○	○	○	○
	4	Check for water	0.1H	—		○	○	○	○	○	○	○	○	○	○	○
	5	Check damages of the mechanical unit cable (movable part)	0.2H	—		○			○				○			
	6	Check damage of the end effector (hand) cable	0.1H	—		○			○				○			
	7	Check tightness of each axis motor and other exposed connector	0.2H	—		○			○				○			
	8	Retightening the end effector mounting bolts	0.2H	—		○			○				○			
	9	Retightening the External main bolts	2.0H	—		○			○				○			
	10	Check the fixed mechanical stopper and the adjustable mechanical stopper	0.1H	—		○			○				○			
	11	Clean spatters, sawdust and dust	1.0H	—		○			○				○			
	12	Check the operation of the cooling fan	0.1H	—		○			○				○			
	13	Replacing the mechanical unit Batteries *1 *3	0.1H	—							●					
	14	Greasing of J2/J3-axis connection part bearing *1	0.1H	Each 20ml												
	15	Replacing grease of J1-axis reducer *1	1.0H	6620ml												
	16	Replacing grease of J2-axis reducer *1	0.5H	2730ml												
	17	Replacing grease of J3-axis reducer *1	0.5H	2730ml												
	18	Replacing grease of J4/J5/J6-axis gearbox *1	0.5H	2670ml												
	19	Replacing grease of wrist axis 1 (J4, J5-axis reducer) *1	1.0H	5340ml												
	20	Replacing grease of wrist axis 2 (J6-axis gearbox) *1	0.1H	140ml												
	21	Replacing grease of wrist axis 3 (J6-axis reducer) *1	0.2H	690ml												
	22	Replacing the mechanical unit cable	4.0H	—												
Controller	23	Cleaning the controller ventilation system	0.2H	—	○	○	○	○	○	○	○	○	○	○	○	○
	24	Check damages of the teach pendant cable, the operation box connection cable and the robot connection cable	0.2H	—		○			○				○			
	25	Replacing batteries *1 *3	0.1H	—												



Position of grease inlet

*1 Refer to this manual or “REPLACING UNITS Chapter of MAINTENANCE ” of the following manuals.
CONTROLLER MAINTENANCE MANUAL (B-83195EN)

*2 ●: requires order of parts
○: does not require order of parts

*3 Regardless of the operating time, replace the mechanical unit batteries at 1 year or 1.5 year, replace controller batteries at 4 years.

3 years 11520	12480	13440	14400	4 years 15360	16320	17280	18240	5 years 19200	20160	21120	22080	6 years 23040	24000	24960	25920	7 years 26880	27840	28800	29760	8 years 30720	Item
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		1
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		2
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		3
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		4
○				○				○				○				○					5
○				○				○				○				○					6
○				○				○				○				○					7
○				○				○				○				○					8
○				○				○				○				○					9
○				○				○				○				○					10
○				○				○				○				○					11
○				○				○				○				○					12
●						●						●						●			13
●												●									14
●												●									15
●												●									16
●												●									17
●												●									18
●												●									19
●												●									20
●												●									21
				●																	22
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○		23
○				○				○				○				○					24
				●																	25

Overhaul

B STRENGTH OF BOLT AND BOLT TORQUE LIST

NOTE

When applying LOCTITE to a part, spread the LOCTITE on the entire length of the engaging part of the female thread. If applied to the male threads, poor adhesion can occur, potentially loosening the bolt. Clean the bolts and the threaded holes and wipe off any oil on the engaging section. Make sure that there is no solvent left in the threaded holes. When finished, remove all the excess LOCTITE when you are finished screwing the bolts into the threaded holes.

Use the following strength bolts. Comply with any bolt specification instructions.

Hexagon socket head bolt made of steel:

Size M20 or less: Tensile strength 1200N/mm² or more

Size M22 or more: Tensile strength 1000N/mm² or more

All size plated bolt: Tensile strength 1000N/mm² or more




Hexagon bolt, stainless bolt, special shape bolt (button bolt, low-head bolt, flush bolt .etc.)

Tensile strength 400N/mm² or more

Refer to the following tables if the bolts tightening torque are not specified.

Recommended bolt tightening torques

Unit: Nm

Nominal diameter	Hexagon socket head bolt (steel)		Hexagon socket head bolt (stainless steel)		Hexagon socket head button bolt Hexagon socket head flush bolt Low-head bolt (steel)		Hexagon bolt (steel)	
	Tightening torque		Tightening torque		Tightening torque		Tightening torque	
	Upper limit	Lower limit	Upper limit	Lower limit	Upper limit	Lower limit	Upper limit	Lower limit
M3	1.8	1.3	0.76	0.53	—	—	—	—
M4	4.0	2.8	1.8	1.3	1.8	1.3	1.7	1.2
M5	7.9	5.6	3.4	2.5	4.0	2.8	3.2	2.3
M6	14	9.6	5.8	4.1	7.9	5.6	5.5	3.8
M8	32	23	14	9.8	14	9.6	13	9.3
M10	66	46	27	19	32	23	26	19
M12	110	78	48	33	—	—	45	31
(M14)	180	130	76	53	—	—	73	51
M16	270	190	120	82	—	—	98	69
(M18)	380	260	160	110	—	—	140	96
M20	530	370	230	160	—	—	190	130
(M22)	730	510	—	—	—	—	—	—
M24	930	650	—	—	—	—	—	—
(M27)	1400	960	—	—	—	—	—	—
M30	1800	1300	—	—	—	—	—	—
M36	3200	2300	—	—	—	—	—	—
								

INDEX

<A>

Actual Installation Example	11
ADJUSTABLE MECHANICAL STOPPER AND LIMIT SWITCH SETTING (OPTION)	96
ADJUSTING LIMIT SWITCH (OPTION)	106
AIR PIPING (OPTION)	75
AIR SUPPLY (OPTION)	74
Angle of Mounting Surface Setting	16
AXIS LIMITS SETUP	92

BASIC SPECIFICATIONS	21
----------------------------	----

<C>

CHANGE AXIS LIMIT BY DCS (OPTION)	92
CHANGING THE MOTION RANGE BY THE LIMIT SWITCH (OPTION)	104
Changing the parameter setting	101
Check of Fixed Mechanical Stopper and Adjustable Mechanical Stopper	114
CHECK POINTS	110
Check the Mechanical Unit Cables and Connectors	112
CHECKS AND MAINTENANCE	107
CONFIGURATION OF THE SEVERE DUST/LIQUID PROTECTION PACKAGE	147
Confirmation of Oil Seepage	110
Confirmation of the Air Control Set (option)	111
CONNECTION WITH THE CONTROLLER	20

<D>

Daily Checks	107
--------------------	-----

<E>

END EFFECTOR INSTALLATION TO WRIST	60
EQUIPMENT INSTALLATION TO THE ROBOT	60
EQUIPMENT MOUNTING FACE	61

<G>

Greasing of J2/J3-axis Connection Part Bearing (3 years check (11520 hours) Periodic Maintenance)	116
---	-----

<I>

INERTIA LOAD SETTING	72
INSTALLATION	10
INSTALLATION CONDITIONS	19
Installing adjustable mechanical stopper option	97
INTERFACE FOR OPTION CABLE (OPTION)	77

<J>

J1-axis Fixed Mechanical Stopper (option) (fixed side swing stopper) in Case of Upside-Down Mount	18
--	----

<L>

LOAD CONDITION ON J2 BASE AND J3 ARM	45
LOAD SETTING	70

<M>

MAINTENANCE	115
MAINTENANCE AREA	19
MASTERING	122
MASTERING DATA ENTRY	136
MECHANICAL UNIT EXTERNAL DIMENSIONS AND OPERATING SPACE	26

<O>

OPERATING SPACE RESTRICTION AT WALL OR ANGLE MOUNTING	47
OVERVIEW	122

<P>

Periodic Checks and Maintenance	108
PERIODIC MAINTENANCE TABLE	153
PIPING AND WIRING TO THE END EFFECTOR	73
PREFACE	p-1
PRESS HANDLING PACKAGE (OPTION)	149
Procedure for Releasing Remaining Pressure from the Grease Bath	121

<Q>

QUICK MASTERING	127
QUICK MASTERING FOR SINGLE AXIS	130

<R>

Replacing the Batteries (1.5 year check Periodic Maintenance)	115
Replacing the Grease of the Drive Mechanism (3 years check (11520 hours) Periodic Maintenance)	118
RESETTING ALARMS AND PREPARING FOR MASTERING	123
ROBOT CONFIGURATION	21

<S>

SAFETY PRECAUTIONS	s-1
SEVERE DUST/LIQUID PROTECTION PACKAGE	147
SEVERE DUST/LIQUID PROTECTION PACKAGE(OPTION)	147
SINGLE AXIS MASTERING	133
STORAGE	121
STRENGTH OF BOLT AND BOLT TORQUE LIST	156

<T>

The maximum stopping distance (position) of adjustable mechanical stopper	102
TRANSPORTATION	1
TRANSPORTATION AND INSTALLATION	1
Transportation with an End Effector Attached	9
TROUBLESHOOTING	139

<V>

VERIFYING MASTERING	138
---------------------------	-----

<W>

WRIST LOAD CONDITIONS 35

<Z>

ZERO POINT POSITION AND MOTION LIMIT 30
ZERO POSITION MASTERING 124

REVISION RECORD

Edition	Date	Contents
07	Nov., 2022	<ul style="list-style-type: none">• Addition of M-900iB/360E• Correction of errors
06	Sep., 2021	<ul style="list-style-type: none">• Addition of the mechanical unit cables• Addition items to the troubleshooting• Correction of errors
05	Jan, 2020	<ul style="list-style-type: none">• Addition of M-900iB/330L• Correction of errors
04	Jun, 2017	<ul style="list-style-type: none">• Addition of R-30iB Plus Controller• Correction of errors
03	Jul., 2015	<ul style="list-style-type: none">• Addition of M-900iB/280• Addition of quick master for single axis• Correction of errors
02	Aug., 2014	<ul style="list-style-type: none">• Addition of M-900iB/280L• Addition of severe dust/liquid protection option• Correction of errors
01	June, 2014	

B-83684EN/07

